OWNER'S MANUAL

Operation Maintenance Specifications

All information in this Owner's Manual is current at the time of publication. However, GENESIS reserves the right to make changes at any time so that our policy of continual product improvement may be carried out.

This manual applies to all models of this vehicle and includes descriptions and explanations of optional as well as standard equipment.

As a result, you may find material in this manual that does not apply to your specific vehicle.

CAUTION: MODIFICATIONS TO YOUR GENESIS VEHICLE

Your GENESIS vehicle should not be modified in any way. Such modifications may adversely affect the performance, safety or durability of your GENESIS vehicle and may, in addition, violate conditions of the limited warranties covering the vehicle. Certain modifications may also be in violation of regulations established by the Department of Transportation and other government agencies in your country.

TWO-WAY RADIO OR CELLULAR TELEPHONE INSTALLATION

Your vehicle is equipped with electronic fuel injection and other electronic components. It is possible for an improperly installed/adjusted two-way radio or cellular telephone to adversely affect electronic systems. For this reason, we recommend that you carefully follow the radio manufacturer's instructions or consult your authorised GENESIS repairer for precautionary measures or special instructions if you choose to install one of these devices.

SAFETY AND VEHICLE DAMAGE WARNING

This manual includes information titled as DANGER, WARNING, CAUTION and NOTICE. These titles indicate the following:

A DANGER

DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

A WARNING

WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

A CAUTION

CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE indicates a situation which, if not avoided, could result in vehicle damage.



Table of contents

Foreword: Electric vehicle system overview	1
Vehicle information	2
Safety system	3
Instrument cluster	4
Convenience features	5
Driving your vehicle	6
Driver assistance system	7
Emergency situations	8
Maintenance	9
Index	1



1. Foreword: Electric vehicle system overview

Introduction	1-3
Hyundai Motor Company	1-3
Australian Design Rules	1-3
Safety messages	1-4
Vehicle modifications	1-5
About "Getting started with your electric vehicle"	1-6
Understanding your electric vehicle	
Characteristics of your electric vehicle	
Precautions when using the high voltage battery	
Other precautions for electric vehicle management	1-9
Charging your electric vehicle	1-10
Safety precautions for charging your electric vehicle	1-10
Checking basic information on charging your electric vehicle	
Using an AC charger	
Using a DC charger	
Using a portable charger (ICCB)Stopping charging immediately	
Using Electric Vehicle functions	
Checking energy information	
Setting the next departure time	
Setting the options for the AC charger	
Setting the target battery charge level	
Setting a battery discharging limit when using Vehicle to Load (V2L)	1-37
Setting electric vehicle specialised functions	1-38
Using V2L function	
Safety precautions when using the V2L function	
Using electricity outside the vehicle	
Solving V2L problems	
Aux. Battery Saver+	
Driving your electric vehicle	
Starting and stopping the vehicle	
Checking electric vehicle driving information	
Countermeasures for accidents or fire	
If the electric vehicle catches fire	1-57

If the electric vehicle is submerged	1-57
If the electric vehicle needs towing	
Other precautions for electric vehicle accidents	

INTRODUCTION

Congratulations, and thank you for choosing a Genesis vehicle. We are pleased to welcome you to the growing number of discerning people who drive a Genesis vehicle. We are very proud of the advanced engineering and high-quality construction of each Genesis vehicle we build.

Your Owner's Manual will introduce you to the features and operation of your new Genesis vehicle. To become familiar with your new Genesis vehicle, so that you can fully enjoy it, read this Owner's Manual carefully before driving your new vehicle.

This manual contains important safety information and instructions intended to familiarize you with your vehicle's controls and safety features so you can safely operate your vehicle.

This manual also contains information on maintenance designed to enhance safe operation of the vehicle. It is recommended that all service and maintenance on your car be performed by an authorised Genesis repairer. An authorised Genesis repairer are prepared to provide high-quality service, maintenance, and any other assistance that may be required.

HYUNDAI MOTOR COMPANY

Copyright 2024 Hyundai Motor Company. All rights reserved. No part of this publication may be reproduced, stored in any retrieval system or transmitted in any form or by any means without the prior written permission of Hyundai Motor Company.

AUSTRALIAN DESIGN RULES

The compliance plate shows that your vehicle has been tested and found to comply with all relevant Australian Design Rules (ADR's) applicable at its date of manufacture.

Any part, that is subject to these ADR's, must not be removed or altered and is to be maintained in good order at all times for the vehicle to be roadworthy and re-registerable by all registerable authorities.

We recommend that you consult an authorised Genesis repairer before conducting any repairs that may affect these areas or if requiring further classification on design rules or safety features. Failure to observe the above warning may render the vehicle compliance invalid and result in personal injury which may have otherwise been avoided.

SAFETY MESSAGES

Your safety, and the safety of others, are very important. This Owner's Manual provides you with many safety precautions and operating procedures. This information alerts you to potential hazards that may hurt you or others, and may damage your vehicle.

Safety messages found on vehicle labels and in this manual describe these hazards and what to do to avoid or reduce the risks.

Warnings and instructions contained in this manual are for your safety. Failure to follow safety warnings and instructions can lead to serious injury or death.

Throughout this manual DANGER, WARNING, CAUTION, NOTICE, and the SAFETY ALERT SYMBOL will be used.



This is the safety alert symbol. It is used to alert you to potential physical injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death. The safety alert symbol precedes the signal words DANGER, WARNING, and CAUTION.

A DANGER

DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.

A WARNING

WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.

CAUTION

CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.

NOTICE

NOTICE indicates a situation that, if not avoided, could result in vehicle damage.

Vehicle modifications

- This vehicle should not be modified. Modification of your vehicle could affect its performance, safety or durability and may even violate governmental safety and emissions regulations.
 - In addition, damage or performance problems resulting from any modification may not be covered under warranty.
- If you use unauthorised electronic devices, it may cause the vehicle to operate abnormally, wire damage, battery discharge, and fire.

NOTICE

Some vehicle interior sounds (including welcome sound, navigation alerts, or warning sounds) may be generated from the interior speakers and amplifier. We recommend that you do not replace these components with anything other than the original Genesis/Hyundai factory parts. Any unauthorised product may cause a malfunction of the vehicle interior sounds that may affect the intended operation of the vehicle.

About "Getting started with your electric vehicle"

"Getting started with your electric vehicle" provides information about new technologies applied to the vehicle and explains how to use the main features. "Getting started with your electric vehicle" allows you to quickly and easily understand new vehicle features and how to operate them conveniently.

- Before driving, carefully read the manual provided with the vehicle and follow all safety information and precautions for every vehicle feature.
- "Getting started with your electric vehicle" covers all optional specifications. It may include descriptions for features that are not equipped in your vehicle.
- Images of the exterior and interior of the vehicle in "Getting started with your electric vehicle" may differ from the actual vehicle.

Understanding your electric vehicle

Electric vehicles are driven using a battery and an electric motor. You should understand the characteristics and features of your electric vehicle before you drive it.

Characteristics of your electric vehicle

The characteristics that differentiate electric vehicles from petrol and diesel vehicles are as follows:

- Electric vehicles are eco-friendly because they do not use fossil fuels for driving. Additionally, unlike petrol and diesel vehicles, noise and vibration are minimal, and the vehicle's lifespan is relatively long.
- When slowing down or driving downhill, recuperative braking is used. Recuperative braking charges the high voltage battery and minimises energy loss.
- If the high voltage battery is running low, you can charge the vehicle using the AC charger, DC charger, or portable charging cables. For more information, see "Charging your electric vehicle".

i Information

Recuperative braking uses an electric motor when decelerating and braking, and it transforms kinetic energy to electrical energy in order to charge the high voltage battery.

Battery information

The batteries used in the electric vehicle are as follows:

- **High voltage battery (high-capacity)**: Drives the motor and operates the air conditioning. It can be charged via an AC charger, DC charger, or portable charger.
- 12 V battery: Operates all lamps, wipers, and the audio system. It is automatically charged when the vehicle is in the POWER ON or DRIVE READY or the high voltage battery is being charged.

Main components of your electric vehicle

The main components of your electric vehicle and their functions are as follows:

- On-Board Charger (OBC): Charges the high voltage battery by converting the power grid's AC power to DC power.
- Inverter: Converts power from direct current (DC) to alternating current (AC) and supplies power to the motor, and converts power from AC to DC to charge the high voltage battery during deceleration and braking.
- Low Voltage DC-DC Converter (LDC): Converts the high voltage battery's power source to a low voltage (12 V) power source and supply power to the electrical devices in the vehicle.
- Vehicle Control Unit (VCU): Controls the various controllers and sensors on the vehicle.
- **Motor**: Uses electricity accumulated in the high voltage battery to drive the vehicle (the role of an engine in petrol and diesel vehicles).
- **Reduction gear**: Delivers the rotational force of the motor to the tyres at appropriate speeds and torque.
- **High voltage battery (Lithium-ion battery)**: Stores and supplies power necessary for the electric vehicle to operate. (The separately installed 12 V battery provides power to the vehicle when the vehicle is in POWER ON or OFF.)

WARNING

- Do not remove or disassemble any of the high voltage battery connectors and wires.
 Doing so may lead to accidents, such as electric shock, and result in serious injury and significantly degrade the vehicle's performance and durability.
- When the high voltage battery or its related components require inspection and maintenance, we recommend that you contact an authorised Genesis repairer.

Precautions when using the high voltage battery

Precautions for high voltage battery when driving and storing the vehicle are as follows:

A CAUTION

- Keep the gauge of the high voltage battery from going below 20 %. Storing the vehicle
 whilst the battery level is low for a long time may damage the battery or reduce the
 battery's capacity, potentially causing the need for a battery replacement.
- If a collision occurs and the vehicle is impacted, we recommend that your vehicle be inspected by an authorised Genesis repairer to check the battery connection status.
- Using the V2L function may reduce the driving distance due to the use of the high voltage battery energy, and repeated use of the V2L function may cause a decrease in the life of the high voltage battery.
- Repeated use of a DC charger may cause a decrease in the life of the high voltage battery.
- The high voltage battery level may reduce naturally even if the vehicle is not driven.
- Storing the vehicle in temperatures that are too hot or cold may degrade the battery performance.
- The distance to empty or power output may vary depending on the driving conditions, such as the outside temperature. Driving at high speeds or uphill may increase battery consumption, resulting in a shorter distance to empty.
- If you use the air conditioning or heating, which is powered by the high voltage battery, the distance to empty may decrease. Maintain the recommended temperature when using the air conditioning or heating.
- Depending on the vehicle's period of use, natural degradation of the battery may occur, and as such the distance to empty may decrease. When the charge capacity and distance to empty keep failing, we recommend that your vehicle be inspected by an authorised Genesis repairer.
- If you do not use the vehicle for a long time, charge the vehicle at least once every 3
 months to prevent the battery from fully discharging. When the battery level has lower
 power, immediately charge the vehicle.
- To keep the battery in optimal condition, use AC charging. Fully charging the battery
 when it is 20 % or lower helps to keep the battery in optimal condition. (Charging once
 a month or more is recommended.)
- The charging level value displayed on the instrument cluster may decrease according
 to the charging conditions (charger status, outside temperature, battery temperature,
 etc.). For longer battery life and safety, once a certain charging level is reached, the
 charging current is gradually lowered to fully charge the battery.

Other precautions for electric vehicle management

A CAUTION

- If post repair heat treatment after repairs or painting is required after an accident, the high voltage battery's performance may be degraded. If heat treatment is required, we recommend that you contact an authorised Genesis repairer.
- When cleaning the motor compartment, do not use a high-pressure washer. Doing so
 may result in electric shock, due to a discharge in high voltage electricity, or damage
 to the vehicle's electric system.
- Do not install third-party parts or modified parts on the vehicle. Doing so may damage the electric power system. Only use or install genuine parts.

High voltage cut-off switch

High voltage cut-off switch is a device located inside the motor compartment to block the battery's high voltage when your vehicle is inspected at an authorised Genesis repairer.



A WARNING

- Never touch the high voltage cut-off switch. This could result in serious injury or death in a collision or electric shock.
- If the high voltage cut-off switch requires an inspection or repair, we recommend that you contact an authorised Genesis repairer.
- Never disconnect or cut the high voltage cut-off switch except in an emergency situation. Serious problems may occur, such as the vehicle may not start.

Charging your electric vehicle

Check the detailed information about charging an electric vehicle and charge your vehicle.

Electric vehicles can be charged via an AC charger or DC charger installed at public charging stations. If the vehicle cannot be moved to a public charging station in the event of an emergency, you can charge the vehicle via the In-Cable Control Box (ICCB) with a power source (AC 230 V).

To find a nearby charging station, refer to the "Using Electric Vehicle functions" section in this chapter.

Safety precautions for charging your electric vehicle

Before charging your electric vehicle, carefully read and follow all the safety information below. Failure to do so may cause electric shock or fire and result in a serious injury, death, malfunctions, or property damage.

Precautions for electric medical devices

A WARNING

The electromagnetic waves generated from the charger can seriously affect electrical medical devices/implants, such as a cardiac pacemaker. When using such devices, make sure to consult with your doctor and the manufacturer to find out whether charging your electric vehicle will impact the operation of your device.

Basic safety precautions for charging

A WARNING

- Before charging, apply the Electronic Parking Brake (EPB) with the brake pedal pressed, shift to P (Park) and turn off the vehicle. Movement of the vehicle whilst charging may result in property damage, serious injury, or death.
- Use only specified electric vehicle chargers. Failure to do so may damage the charger, charging cable, or vehicle. Also, it may lead to safety hazards, such as fire, explosion, etc.
- To avoid property damage, serious injury, or death from electric shock and fire, follow the instructions below:
 - Do not touch the charging connector, charging plug, or the charging inlet when connecting the cable to the charger and the charging inlet on the vehicle.
 - Do not touch the charging connector and charging plug with wet hands, or when standing in water or snow, when connecting the charging cable.
 - When connecting or removing the charging cable, you must hold the charging connector handle and charging plug.
 - Use a waterproof charger. Do not charge the vehicle in a place where rainwater may come into contact with the joints of the charging cable connector and the charging plug.

- Ensure there is no water, dust, or other contaminants on the charging cable connector and the charging plug.
- Immediately stop charging if you notice abnormal conditions, such as odour or smoke.
- Do not charge the vehicle if there is a risk of lightning.

i Information

- Whilst charging, the vehicle cannot be shifted from P (Park) to any other gear.
- Ensure the vehicle doors are unlocked before disconnecting the charging connector.
 The unlock button on the charging connector does not work when the vehicle doors are locked.
- To control the temperature of the high voltage battery whilst charging or when the
 battery temperature is high, the air conditioning is used to cool down the battery. This
 may generate noise or vibration due to operation of the air conditioning compressor
 and cooling fan, but this is a normal condition when charging the high voltage battery.
- The cooling system may be operated when using the air conditioning during charging. This may degrade the air conditioning performance temporarily.
- Depending on the condition and durability of the high voltage battery, charger specifications, condition and ambient temperature, the time required for charging the battery and distance to empty may vary.
- In rare cases, you might hear high-frequency noise (a small beeping sound) outside the
 car when charging with a 400 V DC charger that has deteriorated or has long
 communication delay. The high-frequency noise can be generated only when the
 vehicle tries to reduce its own electromagnetic waves to keep DC charging as stable as
 possible. Do not worry about this beeping noise, because it is intentional and does not
 affect the charging performance or the vehicle itself.

Precautions for operating the cooling fan

▲ WARNING



Do not put your hand near the cooling fan in the motor compartment whilst charging. It may operate automatically to control the battery temperature, even if the vehicle is turned off.

Precautions for operating the charging door

Before operating the charging door, carefully read and follow all the safety information below.

A CAUTION

- Before opening the charging door, check the direction in which the door opens and ensure that there are no objects that will interfere with the opening or closing of the charging door.
- When opening and closing the charging door, be careful not to bump your face, head, etc., or get your hands or other body parts caught in the door.
- If you cannot open the charging door due to freezing weather, lightly tap or remove any ice near the charging door.
 - For more information, refer to the "Electric charging door" section in chapter 5.
- Do not try to forcibly open the charging door. It may cause damage to the charging door or cause a malfunction.
- Do not hold the parts that support the charging door. Damage to parts or deformation of parts may cause vehicle damage and accidents.

Precautions for using, handling, and storing the charging cable

Precautions when using the charging cable

A CAUTION

- To prevent electric shock, replace the charging cable if the sheath or the connector are damaged.
- Do not modify or disassemble the charging cable. Doing so may result in fire, electric shock, or injury.
- Do not pull or twist the charging cable excessively, and ensure that the cable is not twisted. Power cuts or damage to the cable's insulation sheath may result in electric shock or fire.
- Do not drag the charging cable on the floor or place objects on it. Damage to the insulation of the cable may result in electric shock or fire.
- Do not use the charging cable near a heat source or heating appliance.
- Do not drop or subject the charging cable to a strong impact. Also, ensure no water or liquid comes into contact with the cable.
- Use the charging cable only when there are no children around.
- If there is any sign of damage, corrosion, or rust on the charging connector and plug, or if the connection of the charging connector and plug feels loose, do not use the cable. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Precautions when handling and storing the charging cable

A CAUTION

- Always keep the charging connector and plug dry and clean.
- Ensure that the connectors, plugs, and control box (portable charger) of the charging cable are not submerged or in contact with water.
- Keep the charging cable free from water or moisture, and keep it in the luggage compartment.
- Do not keep the charging cable near a heat source or heating appliances.
- · Keep the charging cable away from children.
- If there is dust or contaminants inside the charging connector or plug, remove them using compressed air.
- If the charging cable is contaminated, completely disconnect the cable from the charger or power, and remove the contaminants.
 - Wipe the charging cable lightly with the soft cloth soaked with a 3 % neutral detergent aqueous solution, then use a clean cloth to completely remove moisture and dry the cable in a well-ventilated shaded location.
 - When removing contaminants, ensure the charging connector and charging plug do not come in contact with water.
 - Do not use organic solvents, such as benzene, paint thinner, or detergent. Doing so may cause deformation, discolouration, or malfunction of charging cable.
 - When using a vehicle decontamination agent, ensure that the product does not contain organic solvents, such as benzene, paint thinner, or detergent.

Checking basic information on charging your electric vehicle

Before charging your vehicle, check and understand the information such as the expected charging time according to the charge type, checking the State of Charge (SOC), and setting the charger lock mode.

Checking charge types and times

The charge types for electric vehicle are as follows:

- AC charge: The electric vehicle is charged via an AC charger at public charging stations. An AC charger may require an AC charging cable (sold separately).
- **DC charge**: You can charge at high speeds at public charging stations. Refer to the respective company's manual that is provided for each DC charger type.
- **Portable charge**: If the vehicle cannot be moved to a public charging station due to a lack of battery power, the vehicle can be charged with household electricity, using the 230 V portable charger (sold separately).

A CAUTION

- Battery performance and life may deteriorate if a DC charger is used constantly. Use of DC charging should be minimised in order to help prolong high voltage battery life. Use AC charging unless DC charging is necessary.
- The electrical outlet at home must comply with regulations and safely accommodate
 the Voltage, Current (Amps), and Power (Watts) ratings specified on the portable
 charger. If not, the vehicle may not be charged or safety hazards, such as fire, may
 occur.
- If the power distributor exceeds its capacity whilst charging the vehicle with a portable charger at home, the power to home may be cut off or a fire may occur.
- If you use a portable charger to charge your electric vehicle with household electricity, you are charged on your household electricity bill.

The estimated charging time for each charging type is as follows:

Charging type		Charging time (at room temperature)	Charge level (Minimum-Maximum)	Charging condition (Temperature)
AC charge		About 8 hours and 30 minutes	10-100 %	
DC	350 kW	About 25 minutes	10-80 % (Can be charged to 100 %)	Battery temperature
charge 50 kW		About 84 minutes	10-80 % (Can be charged to 100 %)	(25 °C)
Portable charge		About 38 hours and 30 minutes	10-100 %	

i Information

- Depending on the condition and duration of use of the high voltage battery, charger specifications and ambient temperature, the time required for charging the high voltage battery may vary.
- If the charger is worn out, exposed, or damaged in some way, charging may stop for your safety. Use another charger that works normally.
- When charging the battery, an additional 3 minutes may be required to check battery condition.

Checking the charging status

Inside the charging door

Check the State of Charge (SOC) of the high voltage battery using the charge indicator lamp inside the charging door.

- 1. With the vehicle door unlocked, press the open indicator on the charging door to open the charging door.
- 2. Check the SOC referring to the charge indicator lamp inside the charging door.
 - · SOC is indicated in 4 levels.



Charge indicator lamp	SOC [%]
	0-24 %
*	25-49 %
	50-74 %
*	75-100 %

On the instrument cluster



Check the charging state on the instrument cluster to monitor the battery capacity of the high voltage and estimated charging time.

When charging starts, the charging state will be displayed on instrument cluster.

i Information

- With the vehicle on, the charging state will be displayed continuously.
- When the vehicle is off, the charging state will be displayed for up to 1 minute. The charging state will be displayed continuously when a door is opened.
- When scheduled charging is set, scheduled charging message is displayed.
- When scheduled air conditioning or heating operates whilst waiting for the scheduled charging, the estimated charging time is displayed as "-".

Checking information on the charging label

Open the charging door and check the information on the charging label. The charging label shows safety symbols and the rated input specifications for charging.





Name		Description
(1)	Warning for high voltage	Indicates a device with a risk of electric shock.
(2)	Warning/Caution symbol	Indicates a device that may cause property damage, serious injury or death if not operated carefully.
(3)	Rated voltage and maximum charging current	Indicates the type of input current (AC) and the rated voltage range (V) and charging current (A) when AC charging.

Setting charging connector locking mode

You can lock the charging connector during AC charging to prevent unintended detachment of the charging connector from the vehicle.

i Information

The connector is automatically locked during DC charging or whilst using the V2L function, regardless of the settings of charging connector locking mode applied to the vehicle.

- When DC charging is complete, the charging connector unlocks automatically.
- After using electricity, you can unlock the charging connector by pressing the switch on the V2L connector to turn off the power and unlock the vehicle door.
- On the Home screen of the infotainment system, select Electric vehicle > (EV Settings) > Lock charging cable to set the locking mode of the charging connector.
 The available locking mode options are as follows:
 - **Always**: Locks the connector automatically whenever the charging connector is plugged into the charging inlet.
 - While charging: Locks the connector automatically only whilst charging is in progress after the charging connector is properly connected to the vehicle.
 - **Do not lock**: The connector unlocks regardless of the state of charging.

Disconnecting the charging connector in an emergency

When the unlock button is not functioning properly due to a discharged battery or abnormal electrical wiring, the charging connector cannot be disconnected from the vehicle.

A CAUTION

Do not disconnect the charging connector forcibly. Doing so may damage the charging connector or the charging inlet on the vehicle.

If the charging connector is not disconnected due to a fully discharged battery or a wiring failure, open the bonnet and pull the emergency cable.



 If the charging connector does not disconnect after pulling the emergency cable, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Using an AC charger

AC charging is the most common charging method for electric vehicles. Charge your electric vehicle using an AC charging cable installed in public charging stations or separately purchased AC charging cable.

• To find a nearby charging station, refer to the "Searching for nearby charging stations" section in this chapter.

WARNING

Before charging the vehicle, carefully read and follow the instructions in "Safety precautions for charging your electric vehicle" to prevent property damage or injury due to electric shock, fire, explosion, etc.

CAUTION

To prevent property damage or injury due to fire or explosion, follow the instructions below.

- Only use the genuine AC charging cable provided by the manufacturer (if equipped).
- Do not use an extension cable.
- Check the rated voltage and maximum charging current required for charging, and ensure that the charger power you are using meets the requirements.
- · Immediately stop charging if you discover abnormal conditions, such as odour or smoke.

Understanding the AC charging cable

The exterior and configuration of the AC charging cable are as follows:



- [A] Charging connector (Vehicle side)[B] Charging plug (Charger side)

Charging with an AC charger

Follow the instructions below to charge the vehicle with an AC charger.

- 1. With the vehicle started, apply the Electronic Parking Brake (EPB) whilst pressing the brake pedal.
- 2. Turn all switches off, shift to P (Park), and turn off the vehicle.
- 3. With the vehicle door unlocked, press the open indicator on the charging door to open the charging door.
- 4. Open the charging inlet cover and check the charging connector and charging inlet for dust or other contaminants.
 - If there is any dirt or contaminants, remove them using compressed air.

M WARNING

Do not touch the charging connector of the charging cable or the charging inlet on the vehicle.

- 5. Remove the charging connector protection cap of the AC charging cable, hold the charging connector handle, and connect it to the AC charging inlet on the vehicle. Push it until you hear a click.
- 6. [If using separately purchased charging cable] Remove the charging plug protection cap of the AC charging cable, hold the charging plug handle, and connect it to the electric outlet (230 V) of the AC charger.
 - This process is required only when using a separately purchased AC charging cable.
 If you use a charging cable installed in an AC charger, a separate charging plug connection is not required.
 - When charging starts, the estimated charging time is displayed on the instrument cluster.
- 7. [If using a separately purchased charging cable] When charging is complete, hold the charging plug handle, disconnect the charging plug from the electric outlet (230 V) of the AC charger, and close the protection cap of the charging plug.
 - This process is required only when using an AC charging cable purchased separately.
 If you use a charging cable installed in an AC charger, a separate charging plug disconnection is not required.
- 8. Hold the charging connector handle, and pull the charging connector to disconnect it from the charging inlet.

A CAUTION

Do not forcibly disconnect the charging connector without pressing the unlock button on the charging connector. It may damage the charging connector or the charging inlet on the vehicle.

9. Close the charging inlet cover and press the charging door to completely close it.

i Information

- If the charging connector locking mode is set to Always or While charging, unlock
 the door by pressing the button on the smart key or the button on the driver's door,
 and disconnect the charging connector from the charging inlet.
 - For more information, refer to the "Setting charging connector locking mode" section in this chapter.
- During AC charging, the quality of radio reception may reduce in some areas.

Using a DC charger

If you need to charge the vehicle in a short time, you can charge at high speeds using a DC charger installed in public charging stations.

 To find a nearby charging station, refer to the "Searching for nearby charging stations" section in this chapter.

A WARNING

Before charging the vehicle, carefully read and follow the instructions in "Setting charging connector locking mode" to prevent property damage or injury due to electric shock, fire, explosion, etc.

A CAUTION

Battery performance and life may deteriorate if a DC charger is used constantly. Use of DC charging should be minimised in order to help prolong high voltage battery life. Use AC charging unless DC charging is necessary.

Understanding the DC charging connector

The exterior of the DC charging cable is as follows:



Charging with a DC charger

Follow the instructions below to charge the vehicle with a DC charger.

- 1. With the vehicle started, apply the Electronic Parking Brake (EPB) whilst pressing the brake pedal.
- 2. Turn all switches off, shift to P (Park), and turn off the vehicle.
- 3. With the vehicle door unlocked, press the open indicator on the charging door to open the charging door.
- 4. Open the charging inlet cover and check the charging connector and charging inlet for dust or other contaminants.
 - If there is any dirt or contaminants, remove them using compressed air.

WARNING

Do not touch the charging connector of the charging cable or the charging inlet on the vehicle.

- 5. Remove the charging connector protection cap of the DC charging cable, hold the charging connector handle, and connect it to the DC charging inlet on the vehicle. Push it until you hear a click.
 - When charging starts, the estimated charging time is displayed on the instrument cluster.

i Information

If you open the driver's door whilst charging, the estimated charging time is also displayed on the instrument cluster.

- 6. When charging is complete, hold the charging connector handle and pull out the charging connector to disconnect it from the charging inlet.
 - Depending on the DC charger types, some DC chargers may not have a charger connector unlock button.

A CAUTION

Before disconnecting the charging connector, check if there is an unlock button on the connector handle. If the connector handle is equipped with an unlock button, forcibly disconnecting the connector without pressing the button may damage the charging connector or charging inlet on the vehicle.

NOTICE

For more information, refer to the "Setting charging connector locking mode" section in this chapter.

- 7. Close the charging inlet cover.
- 8. Press the charging door to completely close it.

i Information

During DC charging, the quality of radio reception may degrade in some areas.

Using a portable charger (ICCB)

If the vehicle cannot be moved to a public charging station, you can charge the vehicle using a separately purchased In-Cable Control Box (ICCB) in places where general power (AC 230 V) is supplied.

A WARNING

Before charging the vehicle, carefully read and follow the instructions in "Setting charging connector locking mode" to prevent property damage or injury due to electric shock, fire, explosion, etc.

A CAUTION

To prevent property damage or injury due to fire or explosion, follow the instructions below.

- Only use a genuine Genesis portable charger (if equipped).
- Do not let children operate or touch the portable charger. Doing so may lead to unexpected accidents.
- · Do not use an extension cable.
- The charger power you are using must comply with regulations and safely accommodate the voltage, current (amps), and power (watts) ratings. If not, the vehicle may not be charged or safety hazards, such as fire, may occur.
- If the power distributor exceeds its capacity whilst charging the vehicle with a portable charger at home, the power to the home may be cut off or a fire may occur.
- Immediately stop charging if you discover abnormal conditions, such as odour or smoke.
- Use a portable charger only in emergencies, and do not use it to fully charge the battery.
- If you charge the vehicle with household electricity, you are charged on the electricity bill according to the home rate system, not the electric vehicle rate system.

Understanding portable chargers

The configuration of a portable charger and the display of the operation indicator are as follows:



- [A] Control box[B] Power plug[C] Charging connector

Indicator	Name	Colour	Description
=CL POWER	POWER	Green	Turns on when the power is on.
[4] CHARGE	CHARGE	Blue	Turns on whilst charging and blinks when current is limited (Forcibly switched to 6 A).
INUELT	FAULT	Red	Blinks when a leakage current, communication error, or overcurrent error occurs, or when the high-temperature protection inside the plug and charger is activated.
88 .	CHARGE LEVEL	-	Displays the present charging current setting (6 A, 8 A, 10 A, or 12 A).

Indicator	Name		Colour	Description
	E1	Control pilot communication	-	Vehicle communication error
	E2	- Leakage	-	Current leakage
	E3		-	Charger error
	E4		-	Plug overheating warning
	E5	Plug temperature	-	Plug temperature failure
	E6		-	Charger error
	E7	Overcurrent	-	Charging overcurrent warning
	E8	Internal temperature	-	Charger overheating
	E9		-	Charger error
BB_{\star}	F1	Relay fusion	-	Charger error
	Ground F2 Monitoring/ Interrupt	-	Poor grounding of outlet	
	F3	Switched mode power supply	-	Switched mode power supply error (voltage failure)
	F4 power failure	-	Switched mode power supply error (abnormal voltage)	
	F5	Control Pilot voltage error	-	Control Pilot (-) voltage error
	F6		-	Control Pilot (+) voltage error
	F7	Temperature	-	Plug temperature sensor error
	F8 sensor error	-	PCB internal temperature sensor error	

- If an error occurs, you can reset the portable charger by disconnecting and reconnecting the power plug, and then pressing the button on the control box for more than 2 seconds.
- If the same symptom repeats after resetting the portable charger, we recommend that your vehicle be inspected by an authorised Genesis repairer.
- If there is no status change for more than 1 minute, the portable charger is switched to power saving mode, and the display light is turned off.

Charging with a portable charger

Follow the instructions below to charge the vehicle with a portable charger.

- 1. Connect the power plug of the portable charger to the electrical outlet at your home.
 - The power indicator light on the control box turns green.
- 2. Set the charging current by pressing the button on the control box for more than 2 seconds until the number on the charging current indicator blinks.

NOTICE

An example of a portable charger charging current setting suitable for the rated current of the power supplied is as follows. However, the appropriate charging current may vary depending on the environment, such as the power usage inside the building.

Outlet current	ICCB charge level
14-16 A	12 A
12-13 A	10 A
10-11 A	8 A
8-9 A	6 A

- The charging current is changed each time the button is pressed, in the order of '6 A
 8 A 10 A 12 A'.
- If 10 seconds have passed without pressing any button, the blinking stops and the charging current setting is finished.
- 3. With the vehicle on, apply the Electronic Parking Brake (EPB) whilst pressing the brake pedal.
- 4. Turn all switches off, shift to P (Park), and turn off the vehicle.
- 5. With the vehicle door unlocked, press the open indicator on the charging door to open the charging door.
- Open the charging inlet cover and check the charging connector and charging inlet for dust or other contaminants.
 - If there is any dirt or contaminants, remove them using compressed air.

A WARNING

Do not touch the charging connector of the charging cable or the charging inlet of the vehicle.

- 7. Remove the charging connector protection cap of the portable charging cable, hold the charging connector handle, and connect it to the AC charging inlet of the vehicle. Push it until you hear a click.
 - When charging starts, the estimated charging time is displayed on the instrument cluster.

8. When charging is complete, hold the charging connector handle with the unlock button pressed and pull on the charging connector to disconnect it from the charging inlet.

i Information

If you have set the charging connector locking mode as **Always** or **While charging**, unlock the door by pressing the button on the smart key or the button on the driver's door, and disconnect the charging connector from the charging inlet.

- For more information, refer to the "Setting charging connector locking mode" section in this chapter.
- 9. Close the charging inlet cover.
- 10. Press the charging door to completely close it.

i Information

During portable charging, the quality of radio reception may degrade in some areas.

Using the scheduled charging function

The scheduled charging function allows you to charge your vehicle using low-cost, late-night power until the next departure time.

i Information

You can use the scheduled charging function only when using an AC charger or the portable charger (ICCB: In-Cable Control Box). For more information about connecting an AC charger and portable charger, refer to the "Using an AC charger" and "Using a portable charger (ICCB)" sections in this chapter.

On the Home screen from the infotainment system, select **Electric vehicle** > **Scheduled charging**.

- For more information, refer to the "Setting the options for the AC charger" section in this chapter.
- When scheduled charging is set and the AC charger or the portable charger (ICCB) is connected for charging, the indicator lamp gradually illuminates for 3 minutes to indicate that scheduled charging is set.
- When scheduled charging is set, charging is not started immediately when the AC charger or portable charger (ICCB) is connected. To charge the vehicle immediately, open the charging door and press the immediate charging button for more than 2 seconds or select Electric vehicle > Scheduled charging on the screen and deactivate the scheduled charge setting.

i Information

- You can set up or cancel scheduled charging using the Genesis Connected Service app on your smartphone. For more information, refer to the infotainment system manual.
- Charging may start immediately after a charger is connected to the vehicle, depending on the charging time calculated when setting up the scheduled charging.

Stopping charging immediately

If you cannot stop charging the electric vehicle through the charger whilst charging with an AC charger, DC charger, or portable charger, follow the instructions below:

- 1. Press the door lock or unlock button of the vehicle.
- 2. Within 15 seconds press the immediate charging button [A] for more than 2 seconds.



Checklist when charging does not start

Check the following if charging does not start after connecting the charger to the vehicle.

- Check the scheduled charging setting. If the scheduled charging is set, charging is not started after connecting an AC charger or portable charger to the vehicle until the setting conditions are met.
- Check the operation status of the AC charger, DC charger, and portable charger. Actual
 method for indicating the operation status may vary in accordance with the charger
 manufacturer.
- If a warning sign related to charging appears on the instrument cluster, check its message.
- If the charging connector and charging inlet are not connected properly, the connector may droop or vibrate. In this case, hold the charging connector handle and push it all the way in.
- Check the charging status by connecting another charger that has been approved for proper operation.
 - If the vehicle is charged normally using another charger, contact the charger manufacturer for a solution.
 - If the vehicle is not charged even when using another charger, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Using Electric Vehicle functions

The **Electric vehicle** mode provides driving information and high voltage battery information. You can set various electric vehicle functions in **Electric vehicle** mode.

Checking the Electric Vehicle screen configuration

Follow the instructions below to enter Electric vehicle mode and check the screen configuration.

- 1. On the infotainment screen, move to Home screen.
- 2. On the Home screen, select Electric vehicle.
 - The Electric vehicle mode screen appears.

The details of the **Electric vehicle** mode screen are as follows:



Name		Description
(1)	Energy information	You can check the energy consumption and energy economy history.
(2)	Next departure time	You can set a scheduled departure time by which charging is complete and the cabin temperature is preconditioned.
(3)	Scheduled charging	You can set the date and time of when to charge the battery and the climate control temperature.
(4)	EV charge transfer	You can set the battery discharging limit (%) for the high voltage battery for driving. For more information, refer to the "Setting a battery discharging limit when using Vehicle to Load (V2L)" section in this chapter.
(5)	Utility mode	You can use devices inside the system with the use of a high voltage battery.

Name		Description	
		You can check the energy information, charging station and online manual.	
(7)	© (EV settings)	You can set various electric vehicle specialized functions. • Maximum % Charge • AC charging current • Battery conditioning mode • Utility mode etc. For more information, refer to the "Setting electric vehicle specialised functions" section in this chapter.	

Checking energy information


You can check the energy consumption and energy economy history.

- 1. On the infotainment screen, move to Home screen.
- 2. On the Home screen, select Electric vehicle.
 - · Check the energy information.

Checking the energy consumption

On the infotainment screen, select **Energy information**.

• You can check the current energy consumption for each vehicle system.




Name		Description	
(1)	Driving	Shows the percentage of instantaneous and regenerative energy consumed by the motor to drive the vehicle and also what percentage of the total power was used by the driving systems since starting the vehicle.	
(2)	Electronics	Shows the power and energy consumption used by the vehicle system, including the instrument cluster, infotainment system (speaker and navigation), headlamps, vehicle control unit, etc., and also what percentage of the total power was used by the vehicle systems since starting the vehicle.	
(3)	Climate	Shows the power and energy consumption used by the air conditioning or heating and also what percentage of the total power was used by the climate systems since starting the vehicle	
(4)	Battery care	Shows the momentary power and energy consumption used when increasing and cooling down the battery temperature to maintain optimal battery performance and also what percentage of the total power was used by the battery care mode systems since starting the vehicle.	

Checking the energy economy history

On the infotainment screen select EV Economy History.

 You can check the history of electric energy economy with the date and distance of previous driving.




Setting the next departure time

You can set an anticipated departure time for scheduled charging and target temperature.

i Information

- Scheduled climate is activated based on the departure time.
- The scheduled climate function directly uses the power of the connected charger or the 12 V battery that is being recharged. It can maintain a pleasant environment and enhance vehicle performance by controlling the temperature of the vehicle.
- 1. On the infotainment screen, move to Home screen.
- 2. On the Home screen, select **Electric vehicle** > **Next departure time**.
- 3. Set the anticipated departure schedule.



4. Set anticipated departure time (1) and temperature (2) of the vehicle departure after charging.

5. On the repeat option (3), select the day of the week to activate target temperature for the departure time.



6. Scheduled charging and climate is activated based on the departure time.

The scheduled climate operates 20 minutes before and 10 minutes after the departure.


- (1) Departure: Enter the time of departure.
- (2) Target temperature settings: Enter the desired temperature.
- (3) Repeat: Designate the date you want to repeat.

In cold weather, pre-scheduled heating helps enhance electric vehicle performance by heating the vehicle in advance.

Setting the options for the AC charger

You can set the options for the AC charger including scheduled charging and charging current.


- 1. On the infotainment screen, move to Home screen.
- 2. On the Home screen, select Electric vehicle > Scheduled charging.



3. Set the required functions.

Setting scheduled charging

Select Scheduled charging to turn on the function.



- Start time (1): If selected, starts charging only on the designated off-peak time.
- End time (2): If selected, sets the most inexpensive time to complete charging.
- Scheduled charging option (3):
 - **Off-peak tariffs only**: Charging is activated only during the off-peak time. It may not be able to reach the target battery charge level.
 - **Off-peak tariffs prioritised**: Charging is activated during the off-peak time. It may keep on charging past the off-peak time to reach the target battery charge level.
 - For more information about setting the target battery charge level, refer to the "Setting the charging current" section in this chapter.

Setting the charging current

Set the charging current when using an AC charger. Select:

Electric Vehicle > (EV settings) > Charging current




Setting the target battery charge level

You can set the target battery charge level when charged with an AC charger or a DC charger.

 You can check the status of high voltage battery, estimated distance to empty, and the time required for charging the target battery level.

i Information

- The distance to empty is estimated based on the energy economy and temperatures. It may vary according to your driving style.
- The distance to empty may vary even with the same target level depending on changes in your driving style.
- 1. On the infotainment screen, move to Home screen.
- 2. On the Home screen, select Electric vehicle > @ (EV settings) > Charging limit.



- 3. Set each of the target battery charge levels for AC and DC charging.
 - The charging level can be changed by 10 %.
 - If the target battery charge level is lower than the current high voltage battery charge level, the battery is not charged.

Setting a battery discharging limit when using Vehicle to Load (V2L)

Setting battery discharging limit (%) can prevent the battery from discharging when operating home appliances or electronic devices using the high voltage battery.

• For more information about V2L function, refer to the "Using V2L function" section in this chapter.

i Information

V2L is the system that provides AC power using the high voltage battery for driving to operate several electronic devices. You can operate home appliances and electronic devices, or charge another electric vehicle in an emergency using the stored electricity from the vehicle's battery whilst camping or doing other outdoor activities.

- 1. On the infotainment screen, move to Home screen.
- 2. On the Home screen, select **Electric vehicle** > **EV charge transfer**.



- 3. Set the desired battery discharging limit (%).
 - The battery discharging limit can only be set below the current battery charge.
 - When the battery charge reaches the set battery discharging limit, V2L function cuts
 off automatically.

Setting electric vehicle specialised functions

You can set various EV specialised functions such as battery conditioning mode and utility mode.

Using Battery Conditioning

The Battery Conditioning mode is a function to improve DC charging performance during the winter and summer when the high voltage battery temperature is low and high. You can manually operate the Battery Conditioning function or automatically operate the function by setting a DC charging station as a destination or a waypoint.

Manual operation

- 1. On the infotainment screen, move to Home screen.
- 2. On the Home screen, select **Electric vehicle** > ③ (EV settings) > **Battery conditioning mode** and select **Activate** to use manually.



Linked to navigation route

If you set a DC charging station as a destination or waypoint on your navigation, the Battery Conditioning function maintains the battery temperature ideal for DC charging whilst considering the arrival time.

i Information

- Battery Conditioning function operates only in a vehicle equipped with a battery heater.
- Battery Conditioning function does not operate to ensure driving distance when the battery charge level is low. The function also does not operate if the temperature of the battery is ideal for driving and charging.
- The charged power used to raise the temperature of a battery may shorten the driving distance. Reaching the optimal temperature of a battery requires time.
- When you are a member of Genesis Connected Service, you can control the battery Conditioning function remotely whilst parking from the Genesis Connected Service app. For more information on Genesis Connected Service, refer to the separately supplied manual.

Setting Utility mode

Utility mode allows the high voltage battery to be used instead of the 12 V battery for purposes other than driving. You can use the audio and lights of the vehicle without worrying about discharging the battery and even use the indoor V2L feature.

i Information

- You cannot drive the vehicle whilst the utility mode is activated, and the vehicle can only be shifted to P (Park).
- You can use every electric device in the vehicle whilst the utility mode is activated.
- When the utility mode is activated, the Electronic Parking Brake (EPB) is applied automatically and you can release EPB by pressing the EPB switch if necessary.

Follow the instructions below to set the utility mode.

- 1. Check the operation conditions of the utility mode.
 - Check if the Start/Stop button is in POWER ON position.
 - Check if the READY indicator is displayed on the instrument cluster.
 - Check if the gear is shifted to P (Park).
- 2. On the infotainment screen, move to Home screen.

3. Select **Electric vehicle** > ③ (EV settings) > **Utility mode** in the infotainment system, and then select **Activate utility mode** to activate the function (Utility mode: ON).



- The UTIL indicator illuminates on the instrument cluster and the EPB is applied.
- Press the Start/Stop button whilst not pressing the brake pedal to turn off the vehicle.
- Press the Start/Stop button whilst pressing the brake pedal to turn on DRIVE READY.
- Select **Electric Vehicle** > (**EV settings**) > **Utility Mode** in the infotainment system. Then, press '**Activate utility mode**' to turn off the function. Utility Mode will be dismissed once you press '**Yes**' after a message indicating the Utility Mode has been cancelled is displayed. It will then be set to OFF.
- If you want to utilise the V2L feature in the vehicle whilst the utility mode is activated, refer to the "Using V2L function" in this chapter.

i Information

If the utility mode is not activated when the gear is shifted to P (Park), check the operation status of EPB.

Searching for nearby charging stations


When looking for a charging station, this function searches for stations along the route, around the current location, around the selected destination and charging stations of interest (favourites). When you choose a charging station, its detailed information is provided.

i Information

When you sign up for Genesis Connected Service, the available chargers at each charging station are displayed.

Follow the instructions below to search for nearby charging stations:

- 1. On the infotainment screen, move to Home screen.
- 2. On the Home screen, select **Electric vehicle** $> \Xi > EV$ charging stations.



- You can choose between "Route", "Current position", Destination, and "Favourite station".
- The direction and distance, charger type, address, and location on the map of the charging stations corresponding to the selected option are displayed on the right side of the screen.



3. Select the charging station on the list and check the detailed information.

Using V2L function

equipped

With the Vehicle to Load (V2L) feature, you can turn on electronic devices by connecting them to the high voltage battery.

Safety precautions when using the V2L function

Before using V2L function, read and follow precisely the safety information below. Failure to do so may cause electric shock or fire and result in a serious injury, death, malfunction in your vehicle or property damage.

Precautions when using the V2L function

WARNING

- Do not use the V2L function if the V2L connector, charging inlet, power plug, or cable is damaged, corroded, or rusted.
- Do not touch the V2L connector, charging inlet, or power plug with wet hands.
- Do not use the V2L function if the connection part of the V2L connector and the charging inlet are loose.
- Check that there is no water, dust, or other contaminants before connecting the connector and the plug. They may cause electric shock or fire.
- Do not put metal objects or bare hands into the V2L connector or charging inlet.
- For electric devices used outdoors with the vehicle, use a product with a waterproof function or use it in a waterproof environment. If rain or humidity intrude into electric devices, multi-outlets, extension cords, etc., they may cause electric shock or damage to the vehicle or the devices.
- If there is a risk of lightning, do not use the V2L function outside the vehicle.
- Do not use any electric heating appliances like electric kettle, toaster, or iron in the vehicle. Doing so may result in a fire and injury.

Precautions for operating the cooling fan

MARNING



When using the V2L, the cooling fan in the vehicle motor compartment can operate automatically even if the vehicle is turned off. Do not put your hand near the cooling fan in the V2L operating state.

Precautions for handling and using the V2L connector

A CAUTION

- Do not remodel or disassemble the V2L connector. It may cause fire, electric shock, or injury. Damage to your vehicle caused by remodeling and disassembling is not covered by warranty.
- When the power plug is being connected or disconnected to the V2L connector or when opening or closing the connector cover of the V2L, be careful to not be scratched or injured.
- Be sure to disconnect the V2L connector from the vehicle when you are finished using V2L.
- Do not charge the vehicle using the V2L connector. If you charge the vehicle arbitrarily by remodeling the power cable of the connector, etc., it may damage the vehicle.
- Do not place objects on top of the V2L connector. This may damage the cable and cause electric shock or fire.
- Do not drop the V2L connector or impact it strongly in anyway. Keep it clean in a dry place away from water or humidity.

Precautions when using electric/electronic products

A CAUTION

- Before using the product, check the product manual for instructions and precautions during use.
- Only use products that meet AUS/NZ safety standards.
- Only use an electric device that does not exceed the maximum power capacity that the
 vehicle can supply. Also be aware, some electric devices may not operate normally
 even if the product has power consumption less than the maximum power capacity
 provided by the vehicle.
 - Electric devices that require high power during initial operation.
 - Measuring devices that need to process accurate data.
 - Electric devices that are sensitive to inverter type AC charger.
- Do not use products that require a continuous power supply, such as medical equipment. The power supply may be interrupted depending on the vehicle's condition.
- The V2L discharging mode is blocked automatically in the event of overheating. When
 the discharging mode is blocked, check whether the V2L connector or power plug is
 contaminated, worn, corroded or broken.
 - If the temperature falls to a proper level after it is left unsupervised, you can use it again.
 - If overheating repeats when using a certain electric device, do not use that electric device.
- Do not connect more than two extension cords or multi-outlet. Also, when using the
 extension cable, make sure it is not twisted or tangled. Heat from the overlapped cable
 may cause fire.

- Do not hang the home appliances onto the wire.
- Do not use if the sheath of home appliance cable is damaged or broken.
- · Insert the power plug fully before connecting to the power.
- Only use a qualified plug with ground connection that meets the standard. Do not use worn, corroded, or broken plug or improper plug that does not meet the standard.

Using electricity outside the vehicle

Before using V2L function, read carefully and follow all the safety information and precautions in the "Safety precautions when using the V2L function".

To connect the V2L connector to the charging inlet on the vehicle and supply power to an electronic product:

- 1. Open the cover of the V2L connector.
- 2. Close the cover after connecting the plug of an electronic product to the power outlet of the connector.

A WARNING

Some types of plugs may not fit into the outlet cover of the V2L connector, causing incomplete closing of the cover. Do not use the V2L connector on a rainy or snowy day if the outlet cover is not completely closed. There is a risk of fire and/or injury.

- 3. Open the connection terminal protection cap of the connector whilst pressing on the open switch.
- 4. Open the charging door and connect the V2L connector to the charging inlet on the vehicle.
 - Connect the V2L connector to the charging inlet within 60 seconds after opening the charging door.
 - Time remaining until the battery level reaches the set value, and the distance to empty at the set value appears on the instrument cluster or the infotainment system.
- 5. Press the power switch of the V2L connector.
 - The power is supplied and the indicator on the V2L connector is turned on.

i Information

- When the V2L connector is connected to the charging inlet of the vehicle, all doors and connectors will be automatically locked to prevent theft and separation. To disconnect the V2L connector, unlock the door and pull the connector whilst pressing on the open switch.
- Before using the V2L function, deactivate the scheduled climate setting referring to the "Setting the next departure time" section in this chapter. The V2L function may be cut off depending on the scheduled climate setting.
- To check and change the V2L setting, refer to the "Setting a battery discharging limit when using Vehicle to Load (V2L)" section in this chapter.
- If an electric device that exceeds the maximum power capacity is connected, a warning
 message appears on the instrument cluster and the power supply shuts off immediately.

Solving V2L problems

If a problem occurs whilst using the V2L function, the V2L stops and a related message appears on the cluster display.

Check the cause of the message and take the appropriate measure referring to the table below.

Message	Cause	Measure	
V2L finished. Defined charge level reached	The high voltage battery level reaches the discharging limit set level.	To use the V2L continuously, make the discharging limit set level lower than the present battery level. (Refer to the "Setting a battery discharging limit when using Vehicle to Load (V2L)" section in this chapter.) Check the total power consumption of the electrical appliance and replace it with a product within the V2L maximum power output range. Make sure there are no problems with the V2L connector and the vehicle indoor outlet.	
Energy consumption too high. V2L cancelled	An electrical appliance that exceeds the maximum power output the vehicle can supply is connected.		
V2L conditions not met	V2L is stopped for the following reasons: V2L connector switch off V2L connector overheating Opening the charging door whilst using the V2L indoor outlet		

Aux. Battery Saver+

+if equipped

A WARNING

When the function is active, high voltage electricity flows into the vehicle. Follow the instructions below to prevent electrical shock or injuries.

- Do not touch the high voltage electric wires (orange), connectors, or any electric components and devices.
- Do not modify or disconnect any electronic devices in your vehicle.

The Aux. Battery Saver+ is a function that specialises in battery protection, which prevents battery failure from a full discharge of the 12 V battery.

If the user drives or charges the vehicle, the Aux. Battery Saver+ is automatically activated to check the 12 V battery charging state. If necessary, the high voltage battery charges the 12 V battery.

A CAUTION

The Aux. Battery Saver+ function cannot prevent the 12 V battery discharging in the following situations:

- The 12 V battery is damaged or worn out.
- The 12 V battery is used as a power supply or unauthorised electronic devices are used.

i Information

- If the Aux. Battery Saver+ function was activated, the high voltage battery level may have decreased.
- Depending on the condition of the vehicle or high voltage battery, the Aux. Battery Saver+ function may not operate normally or stop working completely.

Driving your electric vehicle

Before driving, be sure to familiarise yourself with the starting, braking and gear shifting functions of your electric vehicle.

Starting and stopping the vehicle

Follow the instructions below to start or stop the vehicle.

A CAUTION

- Always fasten the seat belt before starting the vehicle for safety.
- Check if the EPB is applied before starting the vehicle.

Starting the vehicle

- 1. With the smart key in your possession, sit in the driver's seat.
- 2. Press the Start/Stop button whilst pressing the brake pedal.
 - On the instrument cluster, READY indicator is displayed.

i Information

Whilst the READY indicator is displayed, press the brake pedal, shift to D (Drive) or R (Reverse), and release the EPB and the brake pedal to start moving the vehicle forward or rearward. You can start driving by pressing the accelerator pedal slowly and decelerate or stop by pressing the brake pedal.

Stopping the vehicle

- 1. Stop the vehicle completely by pressing the brake pedal.
- 2. Apply the EPB whilst pressing the brake pedal, and press the reduction gear's **P** button to shift to P (Park).
- 3. Press the Start/Stop button.
 - The READY indicator on the instrument cluster turns off.

i Information

There are other Start/Stop button positions besides the DRIVE READY/OFF. Use these appropriately.

• **POWER ON**: The vehicle power is turned on, allowing to check the instrument cluster and use all the electric devices inside the vehicle. Press the Start/Stop button when it is in the OFF position to turn on POWER ON.

Understanding virtual engine sound system

Electric vehicles do not use an internal combustion engine, so there is no engine noise whilst driving. The Virtual Engine Sound System (VESS) generates engine sound to make pedestrians aware of the approaching vehicle when driving.

- If the vehicle is in the ready mode (READY indicator ON) and the vehicle is not in P (Park), the VESS is operated.
- When the vehicle is shifted to R (Reverse), an additional warning sound is heard.

A CAUTION

- Be aware that the vehicle does not make engine noise whilst driving.
- Pay attention to the surrounding environment and drive carefully.
- After parking or waiting for a traffic light, please check around for children, or other obstacles before departure.
- When reversing, check directly behind you before driving. Pedestrians may not be able to hear or recognise the vehicle sounds.

Checking electric vehicle driving information

During vehicle operation, the instrument cluster displays the main information, such as distance to empty, real-time energy status, battery charge level, and warning messages, via the user interface and indicators.

Factors affecting the distance to empty

The distance to empty refers to the distance that can be driven by the current charged battery level and is displayed on the bottom of the instrument cluster whilst driving the electric vehicle.



The distance to empty varies depending on many factors such as driving habits, power usage, driving conditions, and conditions of the high voltage battery. The distance to empty may actually be greater or less than the stated figures as it reflects all the factors comprehensively. Check the distance to empty considering the following:

The driving habits: The driving speed and tendency of accelerating and decelerating.
High-speed driving or frequent accelerating and decelerating reduces the distance to
empty.

- The power usage: Additional power use, such as the air conditioning, heating, lamps, etc. As the power usage increases, the distance to empty reduces.
- The driving conditions: The weather, temperature, and terrain. If you drive in snow/rain/strong wind or low temperature, the distance to empty will be reduced. The distance to empty will also be reduced when driving uphill or on slippery or rough roads.
- The electric energy: Proportional to the State of Charge (SOC), but may vary depending on the battery temperature and the State of Health (SOH) of a battery.

Change in the distance to empty when 100 % charged

When the distance to empty has been reduced due to learning of the driving style or the driving conditions, you can increase the distance to empty again by continuously driving following these "Tips for enhancing the distance to empty".

- Resetting the previously learned driving patterns at the service centre may increase
 the distance to empty displayed on the bottom of the instrument cluster, but it does
 not increase the actual distance to empty. The distance to empty may not be accurate
 until new learning occurs.
- If the high voltage battery temperature is low in winter, the distance to empty reduces but it is not a permanent change. The distance to empty may increase again once the temperature rises.
- If you reduce the power usage, the distance to empty may increase.
- Natural degradation may occur with the high voltage battery depending on the number of years the vehicle is used. This may reduce the distance to empty.

When setting a destination

When a destination is set, the distance to empty may change because the distance to empty is recalculated using the information of the destination instead of the learned electric energy economy history.

i Information

The distance to empty may vary significantly based on traffic conditions or driving speed.

Tips for enhancing the distance to empty

The distance to empty varies depending on the charge level of the high voltage battery, weather, temperature, duration of the battery use, terrain, driving habits, etc.

You can increase the distance to empty by driving the vehicle following the instructions below.

- The air resistance increases rapidly as the electric vehicle drives faster, so avoid speeding to increase the distance to empty and the electric energy economy.
- Rapid acceleration consumes a lot of driving energy and rapid deceleration limits the recuperative braking. Gradually press and release the accelerator pedal when accelerating or decelerating to maintain speed.

- If you operate the air conditioning or heating too much, the high voltage battery uses
 excessive electricity. This may reduce the distance to empty. Therefore, set the cabin
 temperature to 22 °C AUTO level 2. Especially in winter, reducing heating and using
 heated seats instead can significantly increase the distance to empty. Turn off the air
 conditioning or heating if you do not need them.
- When using the air conditioning or heating, the energy consumption is reduced if recirculation mode is selected instead of fresh mode. Fresh mode requires a large amount of energy consumption as the outside air has to be reheated or cooled.
- Close the windows whilst driving. Driving with the windows open increases air resistance and the usage of the air conditioning or heating.
- When using the air conditioning or heating whilst driving alone, switch to the DRIVER ONLY function.
- Always maintain specified tyre pressures and use tyres for electric vehicles.
- Do not use unnecessary electrical systems or devices whilst driving.
- · Do not load unnecessary items in the vehicle.
- · Do not mount parts that may increase air resistance.

When the distance to empty is insufficient

- When the battery warning indicator is displayed, immediately charge the vehicle at a nearby charging station.
- Drive energy efficiently following the "Tips for enhancing the distance to empty".
- When the battery level is 0 %, do not try to drive. Move to a safe place and call for assistance.

Checking the real-time energy status (Charge/Power gauge)

The Charge/Power gauge displays the charging and discharging status of the electric energy produced by the recuperative braking and the energy consumption of the electric motor.

Type A/Type B

ROOM REPEDAL 1000 km 82% 24

CHARGE: Shows the charging status of the battery, which is charged by the
recuperative brakes, when pressing the brake pedal or decreasing the vehicle speed
due to coasting. The more electric energy is charged, the more the gauge level turns
anti-clockwise.

• **POWER**: Shows the discharging status of the motor when the vehicle is accelerating. The more electric energy is discharged (used), the more the gauge level turns clockwise.

Checking the State of Charge (SOC)

The SOC indicator shows the charge level of the high voltage battery as a percentage. The lower the number, the more the vehicle needs to be charged, and 100 % indicates a full charge.



- When the remaining charge of the high voltage battery is lower than 20 %, the warning light is displayed.
- When the warning light is displayed, charge the vehicle.

i Information

- To find a nearby charging station, refer to the "Using Electric Vehicle functions" section in this chapter.
- Check if the SOC is sufficient before driving on highways or motorways.
- After the warning light is displayed, immediately charge the vehicle at a nearby charging station. The vehicle may not operate properly depending on the driving speed, weather, and other driving conditions.

Checking the warning and indicator lights

The warning and indicator lights are displayed in the middle of the instrument cluster before or whilst driving, depending on the status of the electric vehicle. Understand the meaning of the warning and indicator lights, referring to the instructions below and drive safely.

A CAUTION

If the warning light illuminates whilst driving or does not go off, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Checking the warning lights

Check the cause of the warning lights referring to the table below and take appropriate measures.

Warning light	Cause	Measure	
Service warning light	 This warning light illuminates: When there is a problem with related parts of the electric vehicle control system, such as sensors, etc. When an actuator, electric compressor for air conditioning, etc. malfunctions. 	In normal conditions, it illuminates for about 3 seconds when the Start/Stop button is in the POWER ON position and then goes off. • When the warning light illuminates whilst driving, or does not go off after starting the vehicle, we recommend that your vehicle be inspected by an authorised Genesis repairer.	
Power down indicator light	This indicator light illuminates: When the high voltage battery level is too low or voltage is decreasing. (Output limit occurs when the charge level is insufficient.) When the temperature of the high voltage battery is too high or too low. When the driving system temperature is overheated and requires protection.	If it illuminates alone, it is not a failure. If both power down indicator light and service warning light illuminate at the same time, we recommend that your vehicle be inspected by an authorised Genesis repairer. When the indicator is illuminating, immediately charge the vehicle. The driving speed may be limited and the vehicle may not properly drive uphill.	
High voltage battery level warning light	This warning light illuminates when the high voltage battery level is low.	Immediately charge the vehicle. The vehicle can drive an additional 25-50 km. • The actual distance to empty depends on the driving conditions.	
Recuperative brake warning light	This warning light illuminates when the recuperative brake does not operate and the brake does not perform well due to a malfunction of the brake system.	We recommend that your vehicle be inspected and repaired by an authorised Genesis repairer. The operation of the brake pedal may feel deeper than normal or the braking distance may increase.	

Checking the indicator lights

Check the meaning of the indicator lights referring to the table below and take appropriate measures if necessary.

Indicator light	Meaning
Charging indicator light	Indicates the charging connector is connected to the high voltage battery. • When the charging connector is connected, it turns green.
Ready indicator	Illuminates when the electric vehicle is ready to be driven, and indicates that the vehicle is operable.
DEADY	When the vehicle malfunctions, the indicator goes off or blinks.
READY	If the indicator is turned off or blinks, we recommend that your vehicle be inspected and repaired by an authorised Genesis repairer.

Checking warning messages

Check the meaning of the warning messages referring to the table below and take appropriate measures.

A WARNING

- Do not drive with a warning message displayed.
- If a warning message does not go off after taking measures, we recommend that you
 have the vehicle immediately inspected and repaired by an authorised Genesis
 repairer.

Warning message	Cause	Measure
Low EV battery	The high voltage battery level reaches below 20 %. The (➡) warning light on the instrument cluster turns on simultaneously.	Charge the vehicle immediately.
Charge immediately. Power limited	The high voltage battery level reaches below 10 %. • The (□) warning light on the instrument cluster turns on simultaneously. • The vehicle's power may be reduced to minimise the energy consumption of the high voltage battery.	Charge the battery immediately.

Warning message	Cause	Measure
Check electric vehicle system	There is a problem with the electric vehicle control system.	 Do not drive when the warning message is displayed. We recommend that you immediately have the vehicle towed to an authorised Genesis repairer and have it inspected and repaired.
Power limited	This warning message is displayed when the power of the vehicle is limited to ensure the safety of high-powered components for the reasons below: The high voltage battery level is too low or voltage is decreasing. The temperature of the high voltage battery is too high or too low. When the driving system is overheated and requires protection.	If it illuminates alone, this is not a failure. Charge the vehicle is the charge level is low. If both power down indicator light and service warning light illuminate at the same time, we recommend that your vehicle be inspected by an authorised Genesis repairer. Do not accelerate or start the vehicle suddenly when the warning message is displayed. Be careful when the power down indicator is displayed. The vehicle may not properly drive uphill and roll back on a slope.
Power limited. Low battery temperature	If you start or turn off the vehicle when the outside temperature is low, warning message is displayed to protect electric vehicle system. If the high voltage battery charge level is low and parked outside for a long time, vehicle power could be limited due to the low battery temperature.	 Charging the battery before driving helps increase power. If this warning message is still displayed even after the ambient temperature has increased, we recommend that your vehicle be inspected and repaired by an authorised Genesis repairer.

Warning message	Cause	Measure	
Battery overheated! Stop safely	The high voltage battery temperature is too high.	Stop the vehicle in a safe place and turn off the Start/Stop button and wait until the battery temperature decreases. If these warning messages are still displayed even after turning off the vehicle and waiting for a sufficient time, we recommend that you immediately have the vehicle towed to an authorised Genesis repairer for inspection and repair.	
Stop safely and check power supply	Immediately stop the vehicle a safe place. We recommend that you have the vehicle tow to an authorised Genesis repairer for inspection and maintenance.		
Unplug vehicle to start	You started the vehicle with the charging connector plugged in.	Unplug the charging cable and start the vehicle.	
Charging door open	You started the vehicle with the charging door open. Check if the charging door is completely closed after charging the vehicle.		
Charging stopped. Please check the AC (DC) charger	This warning message is displayed when charging is stopped for the reasons below: There is a problem with the external AC charger or DC charger. The external AC charger stopped the charging. The charging cable is damaged.	 Check whether there is any problem with the external AC or DC charger and charging cable. Charge the vehicle with an AC charger that has been approved for proper operation or a genuine Genesis portable charger. If the same problem occurs, we recommend that your vehicle be inspected by an authorised Genesis repairer. 	

Warning message	Cause	Measure
Charging interrupted. Please check the cable connection	 This warning message is displayed when charging is stopped for the reasons below: The charging connector is not correctly connected to the charging inlet. The unlock button on the charging connector is pressed. 	 Separate the charging connector from the vehicle and reconnect it. Check whether there is any problem, such as external damage, foreign substances, etc., with the charging connector and charging inlet. Charge the vehicle with a charger that has been approved for proper operation or a genuine Genesis portable charger. If the same problem occurs, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Countermeasures for accidents or fire

When an accident occurs whilst driving the electric vehicle, turn on the hazard warning flasher, move the vehicle to a safe place, and do not let other people approach the site.

A WARNING

When an accident occurs, and the high voltage battery is damaged, harmful gas and electrolytes may leak.

- · Be careful not to touch the leaked liquid.
- When you suspect leakage of inflammable gas and other harmful gases, open the windows and immediately evacuate to a safe location.
- If any leaked fluid comes in contact with your eyes or skin, immediately clean the
 affected area thoroughly with tap water or saline solution and have doctors inspect it
 as soon as possible.

If the electric vehicle catches fire

If a fire occurs, evacuate to a safe place and do not let other people approach the site.

 Contact the fire authority, report an electric vehicle fire, and then follow their instructions.

A CAUTION

- If a fire occurs, evacuate to a safe place and wait until the firefighters arrive.
- If the lower part of the vehicle where the high voltage battery is located catches fire, large amount of water must be supplied continuously for a long time to completely extinguish the fire. It is hard to extinguish the fire without sufficient water and appropriate fire extinguishers. If you approach the vehicle carelessly, it may cause an accident, such as electric shock, and result in serious injury.

If the electric vehicle is submerged

If the electric vehicle is submerged whilst driving, follow the instructions below:

- Immediately turn off the vehicle and evacuate to a safe place with your key.
- Contact the emergency rescue service such as a fire authority, or an authorised Genesis repairer.

WARNING


Never touch a submerged electric vehicle. This may lead to an incident such as an electric shock or fire.

If the electric vehicle needs towing

If towing is required, lift all wheels to tow. Towing with the wheels on the ground may damage the vehicle's motor components.

A CAUTION

Contact the fire authority when towing the vehicle after a fire. When a vehicle fire occurs due to the battery, there is a risk of a second fire.



Other precautions for electric vehicle accidents


A CAUTION

- Be extremely cautious for electricity safety. An electric shock accident may occur due to a short circuit in high voltage power.
- When you paint or apply heat treatment to the vehicle as a result of an accident, the performance of the high voltage battery can be reduced. If heat treatment is required, we recommend that you contact an authorised Genesis repairer.
- Use or install only genuine parts. Third-party parts or modified parts may damage the electric power system.

2. Vehicle information

Exterior overview (Front view)	2-2
Exterior overview (Rear view)	2-3
Interior overview	2-4
Centre console overview	2-5
Steering wheel controls overview	2-7
Motor compartment overview	2-8
Dimensions	2-9
Electric vehicle specifications	2-9
Bulb wattage	2-10
Tyres and wheels	2-11
Air conditioning system	2-12
Vehicle weight and luggage volume	2-12
Recommended lubricants and capacities	2-12
Vehicle Identification Number (VIN)	2-13
Vehicle certification label	2-13
Tyre specification and pressure label	2-13
Motor number	2-14
Air conditioner compressor label	2-14
Refrigerant label	2-14
Open Source Software Notice	2-15

Exterior overview (Front view)



The actual shape may differ from the illustration.

(1)	Bonnet	5-41
(2)	Front windscreen wiper blades	5-71, 9-18
(3)	Windows	5-38
(4)	Front radar	7-5
(S)	Electric charging door	5-51
(6)	HeadlampTyres and wheels	5-56, 9-51
(7)	Tyres and wheels	9-23
(8)	Outside rear-view mirror	5-34

Exterior overview (Rear view)



The actual shape may differ from the illustration.

(1)	Door	5-15
(2)	Rear combination lamp	9-52
	Antenna	
	High mounted stop lamp	
	Boot	
	Wide-rear view camera	


Interior overview



The actual shape may differ from the illustration.

(1) ESC (Electronic Stability Control) OFF button	6-31
(2) Electric charging door open button	5-51
(3) Instrument panel illumination control switch	4-3
(4) EPB (Electronic Parking Brake) switch	6-24
(5) Power boot open/close button	5-45
(6) Seat	
(7) Steering wheel tilt/telescopic switch	5-31
(8) Steering wheel	
(9) Fuse box	9-30
(10)Bonnet release lever	5-41
(11) Inside door handle	
(12)Outside rear-view mirrors control switch	5-35
(13)Outside rear-view mirrors folding button	
(14)Central door lock switch	
(15)Power window switches	5-38
(16)Rear window sunshade button	
(17) Power window lock button, Electronic child safety lock button	5-39, 5-21
· ·	•

Centre console overview




The actual shape may differ from the illustration.

(1) Passenger's front airbag	3-50
(2) Glove box	5-94
(3) Automatic climate control system	5-73
(4) Hazard warning flasher button	
(5) Infotainment system	5-107
(6) Start/Stop button	
(7) Driver's front airbag	
(8) Instrument cluster	4-2
(9) Horn	5-32
(10)Easy Door close button	5-19
(11) Parking Safety button	7-122
(12)Drive mode button	6-42
(13)Parking/View button	7-105, 7-108
(14)UV-C sterilizer system	5-96
(15)Wireless charging system	
(16)P release cap cover	
(17) Rotary shifter (Rotary gear shift dial)	6-9
(18)Fingerprint authentication system	
(19)Auto Hold button	6-27
(19)Auto Hold button(20)USB port	5-106
(==,000 po:	

Vehicle information

21)USB charger	5-99
22)Power outlet	5-uu


Steering wheel controls overview



The actual shape may differ from the illustration.

(1)	Wiper and washer control lever	5-71
	Lighting control lever	
	Forward Attention Warning camera	
	Paddle shifter	
	Driving Assist button	
	Instrument cluster display control	
	Vehicle Distance button	
	Lane Driving Assist button	
	Voice recognition button	
	Optical mouse	
	Audio remote control buttons	
	Bluetooth® hands-free phone button	
	Mode button	

Motor compartment overview



The actual motor compartment in the vehicle may differ from the illustration.

(1)	Windscreen washer fluid reservoir	9-16
(2)	Brake fluid reservoir	9-14
(3)	Cabin air filter	9-16
	Jump-start negative (chassis) terminal	
	Fuse box	
(6)	Low conductivity coolant reservoir	.9-12
	Coolant reservoir	
	Emergency cable	

Dimensions

Ite	ms	mm		
Overall length		5,135		
Overall width		1,925		
Overall height		1,480		
Track	Tyre size	Front	Rear	
19 in.		1,629	1,636	
Wheelbase		3,1	40	

Electric vehicle specifications

Items			AWD	
Motor	Max. power (kW)		Front 136 / Rear 136	
(Front/Rear)	Max. torque (Nm)		Front 350 / Rear 350	
Battery (Lithium-ion)	Capacity (kWh)		94.5	
	Power output (kW)		307	
	Voltage (V)		522.7	
		5P	10.9	
Charger (OBC)	Max. output (kW)	7P	7 (single-phase) / 10.5 (three-phase)	

OBC: On-Board Battery Chargers

Bulb wattage

Light bulb			Bulb type	Wattage
	Headlamp	Low	LED	LED
		High	LED	LED
	Turn signal lamp)	LED	LED
Front	Parking lamp		LED	LED
	Daytime Runnin	g lamp (DRL)	LED	LED
	Charge indicato	r lamp	LED	LED
	Puddle light		LED	LED
	Stop lamp		LED	LED
Rear	Tail lamp		LED	LED
	Turn signal lamp)	LED	LED
	Reverse guide la	ımp	LED	LED
	Licence plate la	mp	LED	LED
High mounted stop lamp		LED	LED	
	Front lamp (map	lamp, interior lamp)	LED	LED
	Interior lamp		LED	LED
	Vanity mirror lar	np	LED	LED
	Glove box lamp		LED	LED
Interior	Inner door hand lamp	le lamp/Foot lamp/Mood	LED	LED
	Door courtesy la	mp	Bulb	5W
	Boot lamp		LED	LED
	Boot emergency	lamp	LED	LED

Tyres and wheels

Items		Wheel size	Inflation pressure kPa (psi)				Wheel bolt
	Tyre size		Normal load		Maximum load		torque kgf·m
			Front	Rear	Front	Rear	(lbf·ft, N·m)
Full size tyre	245/45 ZR19	8.5J X 19	250 (36)	-	250 (36)	-	14-16 (101-116, 137-157)
	275/40 ZR19	9.5J X 19	-	260 (38)	-	260 (38)	

NOTICE

- It is permissible to add 20 kPa (3 psi) to the standard tyre pressure specification if colder temperatures are expected soon. Tyres typically lose 7 kPa (1 psi) for every 7 °C temperature drop. If extreme temperature variations are expected, recheck your tyre pressure as necessary to keep them properly inflated.
- Tyre inflation pressures may vary depending on changes in elevation. If driving in areas of higher or lower elevation, be sure to check and adjust for proper tyre inflation.
- Do not exceed the maximum inflation pressure, as found on the sidewall of the tyre(s).
- No spare tyre is provided as this vehicle provides a Tyre Mobility Kit (TMK).

A CAUTION

When replacing tyres, ALWAYS use the same size, type, brand, construction, and tread pattern supplied with the vehicle. If not, it can damage the related parts or make it work irregularly.

Air conditioning system

Items	Weight of volume	Classification
Refrigerant	980 ± 25 g	R-134a
Compressor lubricant	180 ± 10 g	POE RB100EV

We recommend that you contact an authorised Genesis repairer for more details.

Vehicle weight and luggage volume

Items	Value
Gross vehicle weight	2,900 kg
Luggage volume (VDA)	334 ℓ

i Information

Elevator type automated parking is not possible due to the weight of the vehicle.

Recommended lubricants and capacities

To help achieve proper vehicle performance and durability, use only lubricants of the proper quality.

These lubricants and fluids are recommended for use in your vehicle.

Lubricant			Volume	Classification	
Reductiongear	AWD	Front	2.9-3.0 ℓ	HK ATF 65 SP4M-1	
fluid	luid		2.8-2.9 ℓ	TIKATI 03 SI HWI I	
Coolant			6.42 ℓ	Designated coolant water for electric vehicles	
Low conductivity coolant			12.631 {		
Brake fluid		As required	SAE J1704 DOT-4 LV, FMVSS 116 DOT-4, ISO 4925 CLASS-6		

Vehicle Identification Number (VIN)

Frame number



The vehicle identification number (VIN) is the number used in registering your vehicle and in all legal matters pertaining to its ownership, etc.

The number is punched on the floor under the right front seat. To check the number, open the cover.

Vin label (if equipped)



The VIN is also on a plate attached to the top of the left side instrument panel. The number on the plate can easily be seen through the windscreen from outside.

Vehicle certification label



The vehicle certification label attached on the driver's (or front passenger's) side centre pillar gives the vehicle identification number (VIN).

Tyre specification and pressure label



The tyres supplied on your new vehicle are chosen to provide the best performance for normal driving.

The tyre label located on the driver's side centre pillar gives the tyre pressures recommended for your vehicle.

Motor number

Front



Rear



The motor numbers are stamped as shown in the image.

Air conditioner compressor label



A compressor label informs you of the type of compressor your vehicle is equipped with such as model (1), serial number (2), supplier part number (3), lot number (4), refrigerant oil (5) and refrigerant (6).

Refrigerant label

+if equipped



You can find out which air conditioning refrigerant is applied to your vehicle on the label located inside of the bonnet.

Open Source Software Notice

This vehicle contains software with open source licences.

Open source software information including the source code, copyright notices and referred licence terms may be obtained on the website https://www.genesis.com/worldwide/en/opensource.html.

Hyundai Motor Company will provide the open source code to you in storage medium such as CD-ROM for minimum charge covering the cost of performing source distribution upon email request to opensource@genesis.com within a period of 3 years from the date of product purchase.



3. Safety system

important safety precautions	
Always wear your seat belt	3-3
Restrain all children	
Airbag hazards	3-3
Driver distraction	
Never drink or take drugs and drive	3-3
Control your speed	
Keep your vehicle in safe condition	
Seats	
Safety precautions	
Front seats	
Rear seats	
Headrest	
Seat warmers	
Air ventilation seats	
Seat belts	
Seat belt safety precautions	
Seat belt warning light	
Seat belt restraint system	
Pre-Active Seat Belt (PSB)	
Additional seat belt safety precautions	
Care of seat belts	
Child Restraint System (CRS)	
Our recommendation: Children always in the rear	
Selecting a Child Restraint System	
Installing a Child Restraint System	3-42
Supplemental restraint system - airbags	3-47
SRS components	
Where are the airbags?	
How does the airbags system operate?	
What to expect after an airbag inflates	
SRS warning light	
Do not install a Child Restraint System on the front passenger seat	
Why didn't my airbag go off in a collision?	
SRS care	
Additional safety precautions	
Airbag warning labels	

Active Bonnet lift system	3-61
System activation	
System limitation	
System malfunction	3-63

Important safety precautions

You will find many safety precautions and recommendations throughout this section, and throughout this manual. The safety precautions in this section are among the most important.

Always wear your seat belt

A seat belt is your best protection in all types of accidents. Airbags are designed to supplement seat belts, not replace them. So even though your vehicle is equipped with airbags, always make sure you and your passengers wear your seat belts, and wear them properly.

Restrain all children

All children under age 13 should travel in your vehicle properly restrained in a rear seat, not the front seat. Infants and small children should be restrained in an appropriate Child Restraint System. Larger children should use a booster seat with the lap/shoulder belt until they can use the seat belt properly without a booster seat.

Airbag hazards

Whilst airbags can save lives, they can also cause serious or fatal injuries to occupants who sit too close to them, or who are not properly restrained. Infants, young children, and short adults are at the greatest risk of being injured by an inflating airbag. Follow all instructions and warnings in this manual.

Driver distraction

Driver distraction presents a serious and potentially deadly danger, especially for inexperienced drivers. Safety should be the first concern when behind the wheel and drivers need to be aware of the wide array of potential distractions, such as drowsiness, reaching for objects, eating, personal grooming, other passengers, and using mobile phones.

Drivers can become distracted when they take their eyes and attention off the road or their hands off the wheel to focus on activities other than driving. To reduce your risk of distraction and an accident:

- Set up your mobile devices (for example, MP3 players, phones, navigation units, etc.) when your vehicle is parked or safely stopped.
- ONLY use your mobile device when allowed by laws and conditions permit safe use. NEVER text or email whilst driving. Most countries have laws prohibiting drivers from texting. Some countries and cities also prohibit drivers from using handheld phones.
- NEVER let the use of a mobile device distract you from driving. You have a responsibility to your passengers and others on the road to always drive safely, with your hands on the wheel as well as your eyes and attention on the road.

Never drink or take drugs and drive

Drinking alcohol or taking drugs can reduce your ability to respond to changing conditions and emergencies. Do not drink or take drugs and drive, and do not let your friends drink or take drugs and drive.

Control your speed

Excessive speed is a major factor in crash injuries and deaths. Generally, the higher the speed, the greater the risk, but serious injuries can also occur at lower speeds. Never drive faster than is safe for current conditions, regardless of the maximum speed posted.

Keep your vehicle in safe condition

Having a tyre blowout or a mechanical failure can be extremely hazardous. To reduce the possibility of a tyre hazard whilst driving, check your tyre pressures regularly and also inspect the condition of your tyres (tread depth, uneven wear, etc.). Be sure to perform all regularly scheduled maintenance as indicated in your Owner's Manual.

Seats



The position of the switches may vary depending on the feature available to your vehicle.

Front seat

- (1) Comfortable stretch
- (2) Seatback angle
- (3) Lumbar support
- (4) Seat cushion extension/Seat cushion support
- (5) Seat sliding forward or rearward/Seat cushion tilt/Seat height
- (6) Seatback bolster
- (7) Walk-in seat switch (Seatback angle)(8) Walk-in seat switch (Sliding forward or rearward)
- (9) Seat warmer
- (10)Air ventilation seat
- (11) Headrest



Rear seat

- (1) Comfortable stretch
- (2) LOCK button
- (3) Seat warmer
- (4) Air ventilation seat
- (5) Rear window sunshade control
- (6) Armrest
- (7) Ski through
- (8) Headrest
- (9) Rest mode switch
- (10)Return mode switch
- (11) Headrest adjustment
- (12) Lumbar support
- (13) Seat sliding forward or rearward/Seat cushion tilt
- (14)Seatback angle
- (15) Seatback bolster
- (16)Walk-in switch
- (17) Leg support

Infotainment system



Select **Setup** > **Vehicle** > **Seats** from the Settings menu in the infotainment system, you may use various convenience functions.

- Seat switch notifications: Detailed information of the seat switch and image is displayed when the switch is touched or the switch is moved.
 - **Smart support**: The driver's seat bolster is increased when SPORT mode is selected or when driving at high speed.

· Ergo-Motion seat

- **Comfortable stretch**: The operation intensity and operation time for Comfortable Stretch may be selected.
- **Smart posture assist**: The seat is adjusted to assist the driver's posture after driving for an hour.

Heating/Ventilation

- Automatic controls linked to climate control settings(for driver's seat): The seat temperature is automatically controlled.
- Seat heater balance: When the seat heater is on, you may lower the seat heater (warmer) setting, or may turn the seat heater off for either the seatback or seat cushion.

· Seat easy access

- Driver seat easy access: The distance (Normal/Extended/Off) the seat automatically
 moves when the driver enters or leaves the vehicle may be selected.
- Passenger seat: Moves the passenger seat when the passenger enters or leaves the vehicle.
- Left rear seat: Moves the rear left seat when the passenger exits the vehicle.
- Right rear seat: Moves the rear right seat when the passenger exits the vehicle.
- **Steering easy access**: Moves the steering wheel when the driver enters or leaves the vehicle.

i Information

- The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.
- The information provided may differ depending on which functions are applicable to your vehicle.

Safety precautions

Adjusting the seats to sit in a safe and comfortable position plays an important role for the safety of the driver and passengers. Proper seating positions, secured seat belts, and protection from airbags work together to provide a measure of safety in the event of a collision.

A WARNING

Do not use a cushion that reduces friction between the seat and the passenger. The passenger's hips may slide under the lap portion of the seat belt during an accident or a sudden stop.

Serious or fatal internal injuries could result because the seat belt cannot operate properly.

Airbags

You can take steps to reduce the risk of being injured by an inflating airbag. Sitting too close to an airbag greatly increases the risk of injury in the event the airbag inflates. Move your seat as far back as possible from front airbags, whilst still maintaining control of the vehicle.

A WARNING

To reduce the risk of serious injury or death from an inflating airbag:

- Adjust the driver's seat as far to the rear as possible whilst maintaining your ability to control the vehicle.
- Adjust the front passenger seat as far to the rear as possible.
- Hold the steering wheel with hands at the 9 o'clock and 3 o'clock positions to minimise the risk of injuries to your hands and arms.
- Never place anything or anyone between you and the airbag.
- Do not allow the front passenger to place feet or legs on the instrument panel to minimise the risk of leg injuries.

Seat belts

Always fasten your seat belt before starting any trip. At all times, passengers should sit upright and be properly restrained with a seat belt. Infants and small children must be restrained in appropriate Child Restraint Systems.

A WARNING

To prevent serious injury or death:

- Never use one seat belt for more than one occupant.
- Always position the seatback upright with the lap portion of the seat belt snug and low across the hips.
- Never allow children or small infants to travel on a passenger's lap.
- Do not route the seat belt across your neck, across sharp edges, or reroute the shoulder strap away from your body.
- Do not allow the seat belt to become caught or iammed.

Front seats

A WARNING

Take the following precautions when adjusting your seat:

- Never attempt to adjust the seat whilst the vehicle is moving. The seat could respond with unexpected movement and may cause loss of vehicle control resulting in a collision
- Do not place anything under the front seats. Loose objects, including unsecured floor mats, in the driver's foot area could interfere with the operation of the foot pedals.
- Do not allow anything to interfere with the normal position and proper locking of the seatback.
- Do not place a cigarette lighter on the floor or seat.
- Use extreme caution when picking up small objects trapped under the seats or between the seat and the centre console. Your hands might be cut or injured by the sharp edges of the seat mechanism.
- If there are occupants in the rear seats, be careful whilst adjusting the front seat.
- Make sure that the seat is locked in place after the adjustment. If not, the seat might move unexpectedly resulting in an accident.

Reclining seatback

Sitting in a reclined position when the vehicle is moving can be dangerous. Even when buckled up, the protections of your restraint system (seat belts and/or airbags) is greatly reduced by reclining your seatback.

▲ WARNING

Never travel with a reclined seatback when the vehicle is moving.

Travelling with a reclined seatback increases your chance of serious or fatal injuries in the event of a collision or sudden stop.

The driver and any passengers should always sit well back in their seats, properly restrained, and with the seatbacks upright.

Seat belts must be snug against your hips and chest to work properly. When the seatback is reclined, the shoulder belt cannot do its job because it will not be snug against your chest. Instead, it will be in front of you. During a collision, you could be thrown into the seat belt, causing neck or other injuries.

The more the seatback is reclined, the greater chance the passenger's hips will slide under the lap belt or the passenger's neck will strike the shoulder belt.

Power seats

The front seat can be adjusted by using the control switches located on the outside of the seat cushion.

▲ WARNING

NEVER allow children to remain in the vehicle unsupervised. The power seats are operable when the vehicle is turned off.

NOTICE

To prevent damage to the seats:

- Always stop adjusting the seats when the seat has been adjusted as far forward or rearward as possible.
- Do not adjust the seats longer than necessary when the vehicle is turned off. This may result in unnecessary battery drain.
- Do not operate two or more seats at the same time. This may result in an electrical malfunction.

Forward and rearward



To move the seat forward or rearward:

- Push the control switch forward or rearward.
- 2. Release the switch once the seat reaches the desired position.

Seatback angle



To recline the seatback:

- Push the control switch forward or rearward.
- 2. Release the switch once the seatback reaches the desired position.

Seat cushion tilt/Seat height



• Seat cushion tilt (1)

To change the angle of the front part of the seat cushion:

- Push the front portion of the control switch up to raise or down to lower the front part of the seat cushion.
- 2. Release the switch once the seat reaches the desired position.
- Seat height (2)

To change the height of the seat:

- Push the rear portion of the control switch up to raise or down to lower the height of the seat.
- 2. Release the switch once the seat reaches the desired position.

Seat cushion extension

tif equipped



To move the front part of the cushion forward or rearward:

- 1. Push the control switch forward or rearward.
- 2. Release the switch once the seat cushion reaches the desired length.

Seat cushion support

tif equipped



To adjust cushion support:

- Push the control switch up to increase cushion support or down to decrease cushion support.
- 2. Release the switch once the seat cushion support reaches the desired position.

Lumbar support

tif equipped



To adjust the lumbar support:

- 1. Press the front portion of the switch (1) to increase support or the rear portion of the switch (2) to decrease support.
- 2. Press switch (3) or (4) to move the support position up or down.
- 3. Release the switch once the lumbar support reaches the desired position.

Seat bolster

tif equipped



To adjust seat bolster:

- Push the adjustment lever clockwise, the seatback bolster is adjusted inward.
 Push the lever anti-clockwise, the seatback bolster is adjusted outward.
- 2. Release the lever once the bolster reaches the desired position.

Ergo-motion seat

tif equipped

Select **Setup** > **Vehicle** > **Seat** > **Ergo-motion seat** from the infotainment system's Settings menu to select and set up supplemental functions.

A WARNING

Before actually using each function, try the functions with the vehicle parked.

Comfortable stretch

Comfortable stretch is a function that helps relieve fatigue of the pelvis and lower back due to driving.



Every time you press the button, you may select a mode or turn off the function in the following order.

- Pelvic stretching: The cushion portion moves, helping the left and right movement of the pelvis.
- Lumbar stretching: The seatback portion moves, helping back and forth movement of the lower back.
- Whole Body stretching: The cushion and seatback moves in sequence, helping the whole body reduce fatigue.
- · Off: Turns off Comfortable Stretch.

Also, you can change the operation intensity and operation time from the Settings menu in the infotainment system.

- Intensity: Setup > Vehicle > Seat > Ergo-motion seat > Comfortable stretch > Intensity > High/Moderate
- Time: Setup > Vehicle > Seat >
 Ergo-motion seat > Comfortable
 stretch > Session length > Long (20
 min)/Medium (15 min)/Short (10 min)

Smart posture assist

After driving for an hour, Smart Posture Assist automatically adjusts the pelvis and back portion of the seat to assist the posture.

You can activate or deactivate Smart Posture Assist function from the Settings menu in the infotainment system. Select:

 Setup > Vehicle > Seat > Ergo-motion seat > Smart posture assist

Smart support

The seat bolster support increases when SPORT mode is selected for Drive Mode and when driving at high speed.

You can activate or deactivate Smart Support function from the Settings menu in the infotainment system. Select:

 Setup > Vehicle > Seat > Ergo-motion seat > Smart support

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Walk-in switch



The rear seat passenger may use the switches to control the front passenger seat.

- Sliding forward or rearward:
 Press the switch (1) or (2) to move the front passenger seat forward or rearward.
- Seatback angle:
 Press the switch (3) or (4) to recline the front passenger seatback forward or rearward.

A WARNING

The rear passenger should not adjust the front seat when a passenger is seated.

Seatback pocket



The seatback pocket is provided on the back of the front seats.

A CAUTION

Do not put heavy or sharp objects in the seatback pockets. In a collision, they can come loose from the pocket and injure occupants.

Pre-active Safety Seat (PSS)

Pre-active Safety Seat enhances crashworthiness and driving stability by pulling up the backrest before collision and hazardous situations when the passenger seat is reclined.

▲ WARNING

Pre-active Safety Seat is a supplementary device. The drivers should keep their eyes on the road and verify that there are no obstructions ahead. If there is not a passenger or the seatbelt is not fastened, the system does not work. In addition, the seat belt interval is increased whilst a passenger's seat is reclined so that its performance might be degraded.

System Operation

Crashworthiness

Pre-active Safety Seat limits passenger's movement and decreases the chance of injury from the early stage of collision by reducing the seat belt interval with putting the seat in the upright position. The operation conditions are as follows.

- It is considered as a risky situation due to emergency braking.
- It is considered as a dangerous situation due to the difficulties of vehicle operation.
- It is considered as a hazardous situation due to vehicle distance detection sensor.

Driving stability

Pre-active Safety Seat pulls up the backrest whilst sudden braking or rapid turning to boost the tightness of seat belt in order to prevent leaning forward or laterally and increase driving stability. The operation conditions are as follows

- There is a leaning forward of the upper body due to sudden braking.
- There is a lateral leaning of the upper body because of rapid turning.
- Driving on the slippery frozen road
- Driving on the unpaved road
- High risk of rollover

WARNING

Whilst the system operates automatically, please do not be surprised or misunderstand it as a system failure.

- Inoperative status If the passenger adjusts the seat manually, the system stops immediately. However, it resumes operation after 5 seconds when the hazardous signal continues.
- Malfunction If the Pre-active Safety Seat system

does not operate properly, we recommend that you have the vehicle inspected by an authorised Genesis repairer.

Rear seats

WARNING

NEVER adjust the rear power seats when a Child Restraint System is installed in that seat.

WARNING

To prevent serious injury or death:

- Do not adjust your seat whilst wearing your seat belt. Moving the seat cushion forward may cause strong pressure on vour abdomen.
- Do not allow your hands or fingers to get caught in the seat mechanisms whilst the seat is moving.

NOTICE

To prevent damage to the seats:

- Always stop adjusting the seats when the seat has been adjusted as far forward or rearward as possible.
- · Do not adjust the seats longer than necessary when the vehicle is turned off. This may result in unnecessary drain of the battery.
- Do not operate two or more seats at the same time. This may result in an electrical malfunction.

Seat sliding adjustment

tif equipped



Push the control switch to slide the seat to the desired position.

Seatback angle

tif equipped



Push the control switch to adjust seatback angle.

Rear switches operating limitation

tif equipped



You can activate or deactivate the rear seat control by using the LOCK button on the rear armrest.

A CAUTION

Deactivate the switch operation by pressing the LOCK button, when a child occupies a rear seat.

Lumbar support

tif equipped



To adjust the lumbar support:

- Press the front portion of the switch (1) to increase support or the rear portion of the switch (2) to decrease support.
- 2. Press switch (3) or (4) to move the support position up or down.
- 3. Release the switch once the lumbar support reaches the desired position.

Seat bolster

tif equipped



To adjust seat bolster:

- Push the adjustment lever clockwise, the seatback bolster is adjusted inward.
 Push the lever anti-clockwise, the seatback bolster is adjusted outward.
- 2. Release the lever once the bolster reaches the desired position.

Seat easy access

tif equipped

The seats can automatically move rearward by opening the rear door with the rear seats moved forward.

To use these features, it can be enable the Settings menu in the infotainment system. Select:

 Setup > Vehicle > Seat > Seating easy access > Left rear Seat/Right rear seat

VIP seat

+if equipped

The rear seat occupant can adjust the VIP seat and front passenger seats for VIP convenience.

VIP seat mode switches

tif equipped



You can automatically adjust the seat for comfort or various in-vehicle activities.

Relax mode (1)

The front and rear passenger seats are automatically adjusted for comfort.

Press the REST button (1) on the rear armrest. Each seat is adjusted automatically as below.

- · Rear left seat
 - Seatback tilts rearward → Headrest moves downward → Headrest moves rearward
 - Seat position moves forward → Front part of the cushion rises → Lumbar support protrudes
- · Rear right seat
 - Seatback tilts rearward → Headrest moves downward → Headrest moves rearward
 - Seat position moves forward → Front part of the cushion rises → Lumbar support protrudes
 - Leg support moves to set position
- · Front passenger seat
 - Front part of the cushion moves lower → Seat height moves to set position
 - Seat position moves forward → Seatback moves to set position
 - The entire seat moves downward

 Once adjusted to Relax mode, a chime sounds to indicate adjustment is completed.

NOTICE

Any items, which occupy the front passenger's seat, may get damaged whilst automatically adjusting the seat positions for the relax mode.

Do not put any items on the front passenger's seat.

i Information

- Relax mode for adjusting the front passenger's seat does not operate in the following situations:
 - The Start/Stop button is in the OFF position.
 - A passenger occupies the front passenger's seat.
 - An item occupies the front passenger's seat.
 - The front passenger's door is open.
 - The front passenger's seatbelt is fastened
- Relax mode for rear left seat is unavailable under the following circumstances:
 - The driver's seat is positioned back too far.
 - The driver's seatback is reclined back too much.
- Operating range of the relax mode of the rear left seat may vary depending on the position of the driver's seat.

i Information

- Whilst being adjusted for the relax mode, pressing the REST button will stop the seats from moving.
- The forward and rearward position for the rear seats are adjusted based on its current position. The starting position may differ.
- Operating the seat control switch whilst the seat is being adjusted for relax mode stops the seats from moving. To adjust the seats again, use the control switch and adjust manually.

Return mode (2)

Return all passenger seats to the regular position suited for driving after using the relax mode. Press the return mode button (2) on the rear armrest.

- · Rear left seat
 - Seat position moves rearward → Front part of the cushion moves downward
 → Lumbar support moves rearward
 - Seatback tilts forward → Headrest moves downward → Headrest moves rearward
- · Rear right seat
 - Leg support moves downward
 - Seat position moves rearward → Front part of the cushion lowers → Lumbar support moves rearward
 - Seatback tilts forward > Headrest moves downward → Headrest moves rearward
- Passenger seat
 - Seat position moves to set position → Seatback moves to set position
 - Seat height moves to set position
- Once adjusted to return mode, a chime sounds to indicate adjustment is completed.

i Information

Return mode for adjusting the front passenger's seat does not operate in the following situations:

- The Start/Stop button is in the OFF position.
- A passenger occupies the front passenger's seat.
- An item occupies the front passenger's seat.
- The front passenger's door is open.
- The front passenger's seatbelt is fastened.

i Information

- Whilst being adjusted for the return mode, pressing the return mode button (2) will stop the seats from moving.
- Operating the seat control switch whilst the seat is being adjusted for return mode stops the seats from moving.

To adjust the seats again, use the control switch and adjust manually.

Leg support (calf support) adjustment

tif equipped



Place your leg on the leg support and adjust its angle to relax.

i Information

Opening the door will return the leg support to its original position.

A CAUTION

Do not sit or place heavy objects on the leg support. It may damage the system.

M WARNING

- When lowering or raising the leg support, be careful not to have your hands or legs caught under the front seats or other surrounding parts of the leg support. Unexpected injuries may occur.
- Do not allow children to adjust the switch. Unexpected injuries may occur.

Walk-in switch

tif equipped



Seating position, seatback angle and cushion angle of the front passenger seat can be adjusted by operating the rear seat control switches

- 1. Press the walk-in device switch on the rear armrest.
 - Indicator light on the walk-in device switch illuminates.
- 2. Operate the rear seat control switch to adjust the front passenger seat.
 - Press the switch again to turn off the walk-in device.
 - If you do not adjust the front passenger seat within 15 seconds after pressing the walk-in switch, the front passenger seat adjustment function automatically turns off.

A WARNING

Do not adjust the passenger seat when a passenger is seated.

i Information

For more information refer to the "Front seats" section in this chapter.

Rear seat massage function

tif equipped

Use massage seat to relax after a long drive, or when resting inside the vehicle.



- Whilst the Start/Stop button is in DRIVE READY position or whilst the vehicle is being charged, press the massage button on the rear armrest to start the function.
 - The light indicating massage intensity level illuminates, and the massage function will start.
 - The massage lasts 20 minutes and operates based on a full body stretching logic.
- 2. Press the button again to set the intensity level.
 - Each time you press the button, the intensity setting of the Massage is changed as follows:

High → Low → Off

 To stop the function, press the button multiple times until the indicator light does not illuminate.

Armrest



The armrest is located in the centre of the rear seat.

Grab the handle on the upper end of the armrest. Then, pull down the handle to use the armrest.

NOTICE

Do not put any items on the rear centre seat. Those items may get damaged, when the armrest is pulled down.

Do not attempt to fold back the armrest, when the cup holder is extended out.

Ski through



Additional cargo space is provided to accommodate long/narrow cargo (skis, poles, etc.) not able to fit properly in the boot when closed.

- 1. Pull the armrest down.
- Pull the cover down whilst pushing the release lever down.

NOTICE

Be careful when loading cargo through the rear passenger seats to prevent damage to the vehicle interior.

When both the armrest and the panel, which is located between the rear seatback and the boot for long-item storage, are folded down, put back the panel first, before folding back the armrest. If not, the panel knobs and the armrest knobs may interfere with each other and get damaged.

A CAUTION

Make sure the vehicle is off, the vehicle is shifted to P (Park) and the parking brake is applied whenever loading or unloading cargo. The vehicle may move if the shift lever is inadvertently moved to another position.

When cargo is loaded through the rear passenger seats, ensure the cargo is properly secured to prevent it from moving whilst driving.

A WARNING

Cargo should always be secured to prevent it from being thrown about the vehicle in a collision and causing injury to the vehicle occupants. Do not place objects in the rear seats, since they cannot be properly secured and may hit the front seat occupants in a collision.

Headrest

The vehicle's front and rear seats have adjustable headrests. The headrests are designed to help protect passengers from whiplash and other neck and spinal injuries during a collision, especially a rear impact collision. When there are no occupants in the rear seats, adjust the rear headrests to the lowest height to improve the driver's visibility.

A WARNING

To help reduce the risk of serious injury or death in an accident, take the following precautions when adjusting your headrests:

- Always adjust the headrests properly for all passengers BEFORE starting the vehicle.
- Never let anyone travel in a seat with the headrest removed or reversed.
- Adjust the headrests so that the middle of the headrest is at the same height as the top of the eyes.



- Never adjust the driver's headrest when the vehicle is moving.
- Adjust the headrest as close to the passenger's head as possible.
- Make sure the headrest is locked in place after adjustment.

▲ WARNING


When passengers are sitting on the rear seats, always raise the headrests above the lowest stored position.

Front seat headrests



The driver's and front passenger's seats are equipped with adjustable headrests for passenger safety and comfort.

Height adjustment



To raise the headrest:

1. Pull it up to the desired position (1).

To lower the headrest:

- 1. Push and hold the release button (2) on the headrest support.
- 2. Lower the headrest to the desired position (3).

Forward and rearward adjustment



The headrest may be adjusted forward to 3 different positions by pulling the headrest forward to the desired detent. To adjust the headrest to it's furthest rearwards position, pull it fully forward to the farthest position and release it.



If you adjust the seatback towards the front with the headrest and seat cushion raised, the headrest may come in contact with the sunvisor or other parts of the vehicle.

Removal/Reinstall



To remove the headrest:

- 1. Recline the seatback (2) with the seatback angle switch (1).
- 2. Raise the headrest as far as it can go.
- 3. Press the headrest release button (3) whilst pulling the headrest up (4).



To reinstall the headrest:

- 1. Recline the seatback.
- 2. Put the headrest poles (2) into the holes whilst pressing the release button (1).
- 3. Adjust the headrest to the appropriate height.
- 4. Return the seatback (4) with the seatback angle switch (3).

⚠ WARNING

Always make sure the headrest is locked in place and properly adjusted for the passenger.

Rear seat headrests



The Rear seats are equipped with headrests in all the seating positions for the passenger's safety and comfort.

Manual adjustment



To raise the headrest:

- 1. Pull it up to the desired position (2).
- To lower the headrest:
- 1. Push and hold the release button (1) on the headrest support.
- 2. Lower the headrest to the desired position (3).

Power adjustment



To adjust the headrest up and down: Push the control switch up (2) or down (1) to adjust the headrest up and down.

▲ WARNING

Do not remove the headrest. Removing the headrest on your own might damage the adjustment motor connector. We recommend that you have your vehicle inspected by an authorised Genesis repairer.

Wing-out headrest adjustment **t**if equipped



Whilst driving, the wing-out headrest supports the passenger's head from shaking. Hold both ends of the wing-out headrest with your hands and pull out or push in to adjust its position.

i Information

When the wing-out headrest is not in use, hold both ends of the headrest and pull out to return it to its original position.

Seat warmers

Seat warmers are provided to warm the seats during cold weather.

During mild weather or under conditions where the operation of the seat warmer is not needed, keep the seat warmers off.

▲ WARNING

The seat warmers may cause serious burns, even at low temperatures and especially if used for long periods of time.

Passengers must be able to feel if the seat is becoming too warm so they can turn it off, if needed.

People who cannot detect temperature change or pain to the skin should use extreme caution, especially the following types of passengers:

- Infants, children, elderly or disabled persons, or hospital outpatients.
- People with sensitive skin or who burn easily.
- · Fatiqued individuals.
- · Intoxicated individuals.
- People taking medication that may cause drowsiness or sleepiness.

A WARNING

Never place anything on the seat that insulates against heat when the seat warmer is operating, such as a blanket or seat cushion.

NOTICE

To prevent damage to the seat warmers and seats:

- Never use a solvent such as paint thinner, benzene, alcohol, or petrol to clean the seats.
- Do not place heavy or sharp objects on seats equipped with seat warmers.
- · Do not change the seat cover.

Front seat warmers



- Whilst the vehicle is running, press
 Front on the upper part of the climate
 control information screen
 - The climate control information screen for the front seats is displayed.
- 2. Press the button to warm the driver's seat or front passenger's seat.
 - The seat warmer temperature changes from high, medium, low, and to off each time the button is pressed.
 - Touching the icon for more than 1.5 seconds with the seat warmer operating, will turn the seat warmer off.

i Information

- The seat warmer is automatically turned off if the seat temperature goes above a certain level. The seat warmer turns on again if the temperature is low.
- The armrest warmer automatically turns on when the function is enabled from the infotainment system and the seat warmer turns on.(if equipped)
- Automatic Controls Linked to Climate Control Settings (for driver's seat)

The seat warmer automatically controls the seat temperature depending on the ambient temperature when the vehicle is running.

To use this function, enable it from the Settings menu in the infotainment system. Select:

- Setup > Vehicle > Seat >
 Heated/Ventilated features >
 Automatic controls linked to
 climate control settings > Seat
 heating/ventilation
- · Seat Heater Balance

The seat warmer temperature can be adjusted or turned off for the seatback or seat cushion, when the seat warmer is on.

To use this function, enable it from the Settings menu in the infotainment system. Select:

- Setup > Vehicle > Seat >
 Heated/Ventilated features > Seat heater balance
- The seat warmer defaults to the OFF position whenever the Start/Stop button is pressed to the POWER ON or DRIVE READY position. However, if the Automatic Controls Linked to Climate Control Settings function is on, the driver's seat warmer turns on and off depending on the ambient temperature.

Rear seat warmers

tif equipped

Type A



Type B



Whilst the vehicle is running, press the button to warm the rear seats.

- The seat warmer temperature changes from high, medium, low, and to off each time the button is pressed.
- When pressing the button for more than 1.5 seconds with the seat warmer operating, the seat warmer will turn off.

i Information

- The seat warmer temperature is lowered automatically after a certain time to prevent low temperature burn.
- The seat warmer defaults to the OFF position whenever the Start/Stop button is in the POWER ON or DRIVE READY position.

Operating the rear seat warmer from the front seat

tif equipped



Rear seat heaters can be turned on or off from the front seats.

- Press Rear on the upper part of the climate control information screen whilst the vehicle is running.
 - The climate control information screen for the rear seats is displayed.
- Press the button next to the seat which requires heating from the climate control information screen.
 - The temperature changes from high, medium, low, and to off each time the button is pressed.
 - Touching the icon for more than 1.5 seconds with the seat warmer operating, will turn the seat warmer off.

Air ventilation seats

The air ventilation seats cool the front seats by blowing air through small vent holes on the surface of the seat cushions and seatbacks.

When air ventilation is not desired, keep the air ventilation seats off.

NOTICE

To prevent damage to the air ventilation seats:

- Never use a solvent such as paint thinner, benzene, alcohol or petrol to clean the seats.
- Avoid spilling liquids on the surface of the front seats and seatbacks. This may cause the air vent holes to become blocked and not work properly.
- Do not place materials such as plastic bags or newspapers under the seats.
 They may block the air intake causing the air vents not to work properly.
- · Do not change the seat covers.
- If the air vents do not operate, restart the vehicle. If there is no change, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Front air ventilation seats

tif equipped



- Whilst the vehicle is running, press Front on the upper part of the climate control information screen.
 - The climate control information screen for the front seats is displayed.
- 2. Press the button to cool the driver's seat or front passenger's seat.
 - The blower speed changes from high, medium, low, and to off each time the button is pressed.
 - Touching the icon for more than 1.5 seconds with the air ventilation seat operating, with turn the air ventilation off.

i Information

- If the air ventilation seat is positioned to high, blower speed increases depending on the vehicle speed and driving time.
- Use the air ventilation seat with the air conditioning on for more effective ventilation.
- After the air ventilation seat is turned on, it takes 3-5 minutes for the passengers to notice the temperature change.
- Automatic Controls Linked to Climate Control Settings (for driver's seat)
 The air ventilation seat automatically controls the seat temperature depending on the ambient temperature when the vehicle is running.

To use this function, enable it from the Settings menu in the infotainment system. Select:

- Setup > Vehicle > Seat >
 Heated/Ventilated Features >
 Automatic Controls Linked to
 Climate Control Settings > Seat
 Warmer/Ventilation
- The air ventilation seats default to the OFF position whenever the Start/Stop button is pressed to the POWER ON or DRIVE READY position. However, if the Automatic Controls Linked to Climate Control Settings function is on, the driver's air ventilation seat turns on and off depending on the ambient temperature.

Rear seat air ventilation seats



Whilst the vehicle is running, press the button to cool the seat.

- The blower speed changes from high, medium, low, and to off each time the button is pressed.
- Touching the button for more than 1.5 seconds with the air ventilation seat operating, will turn the air ventilation off.

i Information

- If the air ventilation seat is positioned to high, blower speed increases depending on the vehicle speed and driving time.
- Use the air ventilation seat with the air conditioning on for more effective ventilation.
- After the air ventilation seat is turned on, it takes 3-5 minutes for the passengers to notice the temperature change.
- The air ventilation seat defaults to the OFF position whenever the Start/Stop button is in the POWER ON or DRIVE READY position.

Operating the rear ventilation seat from the front seat

tif equipped



Rear seat air ventilation can be turned on or off from the front seats.

- Press Rear on the upper part of the climate control information screen whilst the vehicle is running.
 - The climate control information screen for the rear seats is displayed.
- Press button next to the seat which requires ventilating from the climate control information screen.
 - The blower speed changes from high, medium, low, and to off each time the button is pressed.
 - Touching the icon for more than 1.5 seconds with the air ventilation seat operating, will turn the air ventilation off.

Seat belts

Seat belt safety precautions

Always fasten your seat belt and make sure all passengers have fastened their seat belts before starting any trip. Airbags are designed to supplement the seat belt as an additional safety device, they are not a substitute. Most countries require ALL occupants of a vehicle to wear seat belts.

A WARNING

Seat belts must be used by ALL passengers whenever the vehicle is moving. To prevent serious injury or death:

- Children under the age of 13 should be properly restrained in the rear seats.
- Never allow children to travel in the front passenger seat. If a child age 13 or older must be seated in the front passenger seat, move the seat as far back as possible, ensuring the child is restrained in the seat properly.
- Never allow an infant or child to be carried on an occupant's lap.
- Never travel with the seatback reclined when the vehicle is moving.
- Do not allow children to share a seat or seat belt.
- Do not wear the shoulder belt under your arm or behind your back.
- Do not use the seat belt if it is twisted. A twisted seat belt may not protect you properly in an accident.
- Do not latch the seat belt into the buckles intended for other seating positions.
- Never unfasten the seat belt whilst driving. This may cause loss of vehicle control resulting in a collision.

- Make sure there is nothing in the buckle that could interfere with the seat belt latch mechanism from fastening securely.
- Never modify seat belt or install devices that may prevent seat belt assembly from removing slack.
- Do not use a seat belt if the webbing or hardware is damaged. We recommend that the seat belt be replaced by an authorised Genesis repairer.
- No modifications or additions should be made by the user which will either prevent the seat belt adjusting devices from operating to remove slack, or prevent the seat belt assembly from being adjusted to remove slack.

A WARNING

Damaged seat belts and seat belt assemblies do not operate properly. Always replace:

- Frayed, contaminated, or damaged webbing.
- Damaged hardware.
- The entire seat belt assembly after it has been worn in an accident, even if damage to webbing or assembly is not apparent.

A WARNING

Seat belts are designed to bear upon the bony structure of the body, and should be worn low across the front of the pelvis or the pelvis, chest and shoulders, as applicable; wearing the lap section of the belt across the abdominal area must be avoided.

Seat belts should be adjusted as firmly as possible, consistent with comfort, to provide the protection for which they have been designed.

A slack belt will greatly reduce the protection afforded to the wearer. Care should be taken to avoid contamination of the webbing with polishes, oils and chemicals, and particularly battery acid. Cleaning may safely be carried out using mild soap and water.

The belt should be replaced if webbing becomes frayed, contaminated or damaged. It is essential to replace the entire assembly after it has been worn in a severe impact even if damage to the assembly is not obvious. Belts should not be worn with straps twisted. Each seat belt assembly must only be used by one occupant; it is dangerous to put a belt around a child being carried on the occupant's lap.

Seat belt warning light

Instrument cluster



Driver's seat belt warning

As a reminder to the driver, the seat belt warning light illuminates for about 6 seconds each time the Start/Stop button is in the POWER ON position regardless of seat belt fastening.

If you continue not to fasten the seat belt or unfasten the seat belt and you drive below 20 km/h, the warning light illuminates.

If you continue not to fasten the seat belt or unfasten the seat belt and you drive above 20 km/h, the seat belt warning chime sounds for a certain period of time and the warning light blinks.

Front passenger's seat belt warning

As a reminder to the front passenger, the front passenger's seat belt warning light illuminates for about 6 seconds each time the Start/Stop button is in the POWER ON position regardless of seat belt fastening.

If the passenger continues to not fasten their seat belt or unfasten their seat belt and you drive below 20 km/h, the seat belt warning light illuminates.

If the passenger continues to not fasten their seat belt or unfasten their seat belt and you drive above 20 km/h, the seat belt warning chime sounds for a certain period of time and the warning light blinks.

A WARNING

Travelling in an improper position may adversely affect the front passenger's seat belt warning system. Instruct the passenger to properly be seated when the vehicle is moving.

i Information

- If the front passenger seat is not occupied, the seat belt warning light blinks or illuminates for 6 seconds.
- The front passenger's seat belt warning may operate when luggage is placed on the front passenger seat.

Rear passenger's seat belt warning • if equipped



Rear outboard seat seatbelt (1, 3)

As a reminder to the rear outboard seat passengers, the corresponding seat belt warning lights illuminate for about 6 seconds each time the Start/Stop button is in the POWER ON position regardless of seat belt fastening.

If the seat belt is still not fastened whilst driving, or unfastened whilst driving, it will operate as follows depending on vehicle speed.

Below 20 km/h:

The corresponding seat belt warning light illuminates until the seat belt is fastened.

Above 20 km/h:

The corresponding seat belt warning light blinks and the warning chime sounds for about 35 seconds, and then the warning light continues to illuminate until the seat belt is fastened.

Rear centre seat belt (2)

tif equipped

With the Start/Stop button in the POWER ON position, if the second row centre seat passenger's seat belt is not fastened, the seat belt warning light illuminates for 70 seconds. But, if the seat belt is fastened after 6 seconds, the seat belt warning light immediately turns off.

If the seat belt is fastened, and then unfastened when you are driving below 20 km/h, the seat belt warning light illuminates for 70 seconds.

If the seat belt is fastened, and then unfastened when you are driving above 20 km/h, the seat belt warning light blinks and the warning chime sounds for about 35 seconds.

Seat belt restraint system

WARNING

Improperly positioned seat belts may increase the risk of serious injury in an accident. Take the following precautions when adjusting the seat belt:


- Position the lap portion of the seat belt as low as possible across your hips, not on your waist, so that it fits snugly. This allows your strong pelvic bones to absorb the force of a collision, reducing the chance of internal injuries.
- Position one arm under the shoulder belt and the other over the belt, as shown in the image.
- Always position the shoulder belt anchor into the locked position at an appropriate height.
- Never position the shoulder belt across your neck or face.

Lap/shoulder belt

To fasten your seat belt:



Pull the seat belt out of the retractor and insert the metal tab (1) into the buckle (2). An audible "click" sounds when the tab locks into the buckle. Make sure the seat belt is not twisted.



Place the lap belt (1) portion across your hips and the shoulder belt (2) portion across your chest.

The seat belt automatically adjusts to the proper length after the lap belt portion is adjusted manually so that it fits snugly across your hips. If you lean forward in a slow, easy motion, the belt extends and moves with you.

If there is a sudden stop or collision, the belt is locked in place. It also locks if you try to lean forward too quickly.

NOTICE

If you cannot smoothly pull the seat belt out from the retractor, firmly pull the seat belt out and release it. After release, the belt may be pulled out smoothly.

Height adjustment


Adjust the height of the shoulder belt so that it lies across your chest and midway over your shoulder nearest the door, not over your neck.

To adjust the height of the seat belt anchor:

Pull it up (1) to raise the height. To lower it, push it down (2) whilst pressing the height adjuster button [A].

Release the button to lock the anchor in place. Try pushing the height adjuster down to make sure that it is locked in place.

Front seat



To release your seat belt:

Press the release button [A] in the locking buckle.



The belt should automatically draw back into the retractor. If this does not happen, check the belt to be sure it is not twisted, then try again.

Rear webbing guide

tif equipped

Webbing guides are provided to prevent the shoulder belt from passing over the neck or face.

Install the separately provided webbing guide on the side of the rear seat backrest.



Locate the webbing guide button to face downward. Otherwise, the seatbelt may not protect you properly.





▲ WARNING

Avoid wearing seatbelt too loose. If seatbelt does not fit tightly, it may not protect you from an accident.

Rear centre seat belt



Insert the tongue plate (1) into the buckle (2) until an audible "click" is heard, indicating the latch is locked. Pull the shoulder portion of the belt until it is snug across your hips and then remove slack. Make sure the seat belt is not twisted.

When using the rear centre seat belt, use the buckle with the "CENTER" mark.

i Information

If you cannot pull out the safety belt from the retractor, firmly pull the belt out and release it. After release, pull out the belt smoothly.

WARNING

Make sure the seatback is locked in place when using the rear centre seat belt.

If not secure, the seatback may move if there is a sudden stop or collision and result in serious injury or death.

Pretensioner seat belt



Your vehicle is equipped with driver's, front passenger's and rear passengers' (except for the rear centre seat) pretensioner seat belts (retractor pretensioner). The pretensioner makes sure the seat belts fit tightly against your body in certain frontal or side collision(s). The pretensioner seat belts may be activated in some crashes where the frontal or side collision(s) is severe enough, together with the airbags.

When the vehicle stops suddenly, or if you try to lean forward too quickly, the seat belt retractor locks in place. In some frontal collisions, the pretensioner activates and pulls the seat belt against your body.

If the system senses excessive tension on the driver or passenger's seat belt when the pretensioner system activates, the load limiter inside the retractor pretensioner releases some of the pressure on the driver's or passenger's seat belt. (for vehicles equipped with load limiter)

A WARNING

To prevent serious injury or death:

- Always wear your seat belt and sit properly in your seat.
- Do not use the seat belt if it is loose or twisted.
- · Do not place anything near the buckle.
- Always replace your pretensioner after activation or an accident.
- We recommend that the pretensioner be inspected, serviced, repaired, or replaced by an authorised Genesis repairer.
- · Do not hit the seat belt assemblies.

A WARNING

Do not touch the pretensioner seat belt assemblies for several minutes after they have been activated. When the pretensioner seat belt mechanism deploys during a collision, the pretensioner can become hot and can burn you.

A WARNING

We recommend that the system be serviced by an authorised Genesis repairer. Body work on the front of the vehicle may damage the pretensioner seat belt system.



The Pretensioner Seat Belt System consists mainly of the following components. Their locations are shown in the illustration above:

- (1) SRS airbag warning light
- (2) Front retractor pretensioner
- (3) SRS control module
- (4) Rear retractor pretensioner

NOTICE

The sensor that activates the SRS control module is connected with the pretensioner seat belts. The SRS airbag warning light on the instrument cluster illuminates for about 3-6 seconds after the Start/Stop button is in the POWER ON position, and then it turns off.

If the pretensioner is not working properly, the warning light illuminates even if the SRS airbag is not malfunctioning. If the warning light does not illuminate when starting the vehicle or stays illuminated or illuminates whilst driving, we recommend the pretensioner seat belts and/or SRS control module be inspected by an authorised Genesis repairer as soon as possible.

i Information

- The pretensioner seat belts may be activated in certain frontal or side collisions or rollover situations (if equipped with rollover sensor).
- When the pretensioner seat belts are activated, a loud noise may be heard and fine dust, which may appear to be smoke, may be visible in the passenger compartment.
- Although it is non-toxic, the fine dust may cause skin irritation and should not be inhaled for prolonged periods. Wash all exposed skin areas thoroughly after an accident in which the pretensioner seat helts were activated.

Pre-Active Seat Belt (PSB)

The purpose of the Pre-Active Seat Belt is to tighten the seat belt when a collision is sensed, during emergency braking, or when a loss of control is sensed.

NOTICE

Pre-Active Seat Belt is a supplementary system. Pre-Active Seat Belt activates only when the passenger is wearing their seat belt.

Pre-Active Seat Belt operation

In order to maximise the safety of the passenger, Pre-Active Seat Belt system operates as follows:

Full retraction

The seat belt is tightened when:

- Emergency braking situation occurs
- Losing control of the vehicle
- The vehicle detects a collision
- Unstable rolling of the vehicle occurs
- · Dynamic support

The seat belt is tightened where:

- High longitudinal deceleration occurs
- Slack removal

Tightens a loose seat belt when the seat belt is fastened.

Warning message

The "Check PSB (Pre-active Seat Belt)" warning message appears if there is a problem with your Pre-Active Seat Belt.

We recommend that the system be inspected by an authorised Genesis repairer if the warning message comes on whilst the vehicle is moving. When the Pre-Active Seat Belt warning message disappears, the master (A) warning light illuminates.

Additional seat belt safety precautions

Seat belt use during pregnancy

The seat belt should always be used during pregnancy. The best way to protect your unborn child is to protect yourself by always wearing the seat belt.

Pregnant women should always wear a lap-shoulder seat belt. Place the shoulder belt across your chest and away from your neck. Place the lap belt below your belly and pull the shoulder portion so that it fits SNUGLY across your hips and pelvic bone, under the rounded part of your belly.

A WARNING

- Pregnant women and patients are more vulnerable to any impacts on the abdomen during an abrupt stop or collision. If you are in an accident whilst pregnant, consult your doctor.
- To reduce the risk of serious injury or death to an unborn child during an accident, pregnant women should NEVER place the lap portion of the seat belt above or over the area of the abdomen where the unborn child is located.

Seat belt use and children

Infant and small children

Most countries have Child Restraint System laws that require children to travel in approved Child Restraint System devices, including booster seats. The age at which seat belts can be used instead of Child Restraint System may be different, so you should be aware of the specific requirements in your country and where you are travelling. Infant and Child Restraint System must be properly placed and installed in a rear seat.

For more information, refer to the "Child Restraint System (CRS)" section in this chapter.

A WARNING

Always properly restrain infants and small children in a Child Restraint System appropriate for the child's height and weight.

To reduce the risk of serious injury or death to a child and other passengers. Never hold a child in your lap or arms when the vehicle is moving. Violent forces created during a collision will tear the child from your arms and throw the child against the interior or to be ejected from the vehicle.

Small children are best protected from injury in an accident when properly restrained in the rear seat by a Child Restraint System that meets the requirements of the Australian/New Zealand standards. Before buying any Child Restraint System, make sure that it has a label certifying that it meets the requirements of the Australian/New Zealand standards.

The Child Restraint System must be appropriate for your child's height and weight. Check the label on the Child Restraint System for this information. Refer to "Child Restraint System (CRS)" in this chapter.

Larger children

Children under age 13 and who are too large for a booster seat should always occupy the rear seat and use the available lap/shoulder belts. A seat belt should be snug against the hips and be snug across the shoulder and chest to restrain the child safely. A child's squirming could move the belt out of position. Adults should frequently check belt fit. In a collision, the safest place for children is in the rear seats, using a Child Restraint System appropriate for the child.

If a larger child over age 13 must be seated in the front seat, the child must be securely restrained by the available seat belt and the seat should be placed in the rearmost position.

If the shoulder belt portion slightly touches the child's neck or face, try placing the child closer to the centre of the vehicle. If the shoulder belt still touches their face or neck, the child needs to return to an appropriate booster seat in the rear seat.

A WARNING

- Always make sure larger children's seat belts are buckled and properly adjusted.
- Never allow the shoulder belt to contact the child's neck or face.
- Do not allow more than one child to use a single seat belt.

Seat belt use and injured people

A seat belt should still be used when an injured person is being transported. Consult a physician for specific recommendations.

One person per belt

When two people (children or adults) are sitting together, never attempt to use a single seat belt. This could increase the severity of injuries in a collision.

Do not lie down

Sitting in a reclined position when the vehicle is moving, can be dangerous. Even when buckled up, the protections of your restraint systems (seat belts and/or airbags) are greatly reduced by reclining your seatback.

Seat belts must be snug against your hips and chest to work properly.

During a collision, you could be thrown into the seat belt, causing neck or other injuries.

The more the seatback is reclined, the greater the chance for the passenger's hips to slide under the lap belt or the passenger's neck to strike the shoulder belt.

A WARNING

- Never travel with a reclined seatback when the vehicle is moving.
- Travelling with a reclined seatback increases your chance of serious or fatal injuries in the event of a collision or sudden stop.
- The driver and all passengers should always sit well back in their seats, properly restrained, and with the seatbacks upright.

Care of seat belts

Seat belt systems should never be disassembled or modified. In addition, care should be taken to assure that seat belts and belt hardware are not damaged by seat hinges, doors or other abuse.

Periodic inspection

All seat belts should be inspected periodically for wear or damage of any kind. Any damaged parts should be replaced as soon as possible.

Keep belts clean and dry

Seat belts should be kept clean and dry. If belts become dirty, they can be cleaned by using a mild soap solution and warm water. Bleach, dye, strong detergents, or abrasives should not be used because they may damage and weaken the fabric.

When to replace seat belts

The entire seat belt assembly or assemblies should be replaced if the vehicle has been involved in an accident. This should be done even if no damage is visible. We recommend that you consult an authorised Genesis repairer for assistance.

Child Restraint System (CRS)

Our recommendation: Children always in the rear

A WARNING

Always properly restrain children in the rear seats of the vehicle. Children of all ages are safer when restrained in the rear seat. A child travelling in the front passenger seat can be forcefully struck by an inflating airbag resulting in serious injury or death.

Children under age 13 should always travel in the rear seats and must always be properly restrained to minimise the risk of injury in a collision, sudden stop, or sudden manoeuvre.

According to accident statistics, children are safer when properly restrained in the rear seat than in the front seat. Children too large for a Child Restraint System must use the seat belts provided.

Most countries have child restraint regulations that require children to travel in approved Child Restraint Systems.

The laws governing the age or height/weight restrictions at which seat belts can be used instead of Child Restraint System differs among countries, so you should be aware of the specific requirements where you are travelling.

Child Restraint Systems must be properly installed in the vehicle seat. Always use a commercially available Child Restraint System that meets the requirements of the Australian/New Zealand standards.

Child Restraint Systems are generally designed to be secured in a vehicle seat by a lap/shoulder seat belt, or by a top tether and/or ISOFIX anchorage in the rear seats of the vehicle.

Child Restraint System

Infants and younger children must be restrained in an appropriate rearward-facing or forward-facing CRS that has first been properly secured to the seats of the vehicle. Read and comply with the instructions for installation and use provided by the manufacturer of the Child Restraint System.

▲ WARNING

Do not use an improperly secured Child Restraint System. It may increase the risk of serious injury or death in a collision. When using a Child Restraint System:

- Always follow the Child Restraint System manufacturer's instructions for installation and use.
- Always properly restrain your child in the Child Restraint System.
- Do not use an infant carrier or a child safety seat that "hooks" over a seatback. It may not provide adequate protection in an accident.
- After an accident, we recommend that an authorised Genesis repairer check the Child Restraint System, seat belts, ISOFIX anchorages, and top tether anchorages.

Selecting a Child Restraint System

When selecting a Child Restraint System for your child, always:

- Make sure the Child Restraint System
 has a label certifying that it meets
 applicable Safety Standards of your
 country. A Child Restraint System may
 only be installed if it was approved in
 accordance with the requirements of
 Australian/New Zealand standards.
- Select a Child Restraint System based on your child's height and weight. The required label or the instructions for use typically provide this information.
- Select a Child Restraint System that fits the vehicle seating position where it is to be used.
- Read and comply with the warnings and instructions for installation and use provided with the Child Restraint System.

Child Restraint System types

There are three main types of Child Restraint Systems: rearward-facing, forward-facing, and booster seat Child Restraint Systems. They are classified according to the child's age, height, and weight.

Rearward-facing Child Restraint System



A WARNING

- Extreme hazard! Do not use a rearward facing child restraint on a seat protected by an airbag in front of it!
- Never install a child or infant restraint in the front passenger's seat. Placing a rear-facing child restraint in the front seat can result in SERIOUS INJURY or DEATH if the child restraint is struck by an inflating airbag.

With a rearward-facing Child Restraint System, the collision forces are absorbed by its shell instead of the child's body. The shell also supports the system's cradles and protects the head, neck and spine of the child. All children under the age of one year must always travel in a rearward-facing Child Restraint System. Convertible and 3-in-1 Child Restraint Systems typically have higher height and weight limits for the rearward-facing position, allowing you to keep your child rearward-facing for a longer period of time.

Continue using the Child Restraint Systems in the rearward-facing position as long as the child is within the height and weight limits allowed by the Child Restraint System's manufacturer. It's the best way to keep them safe. Once your child has outgrown the rearward-facing Child Restraint System, your child is ready for a forward-facing Child Restraint System with a harness.

Forward-facing Child Restraint System



A forward-facing Child Restraint System provides restraint for the child's body with a harness. Keep children in a forward-facing Child Restraint System with a harness until they reach the height or weight limit allowed by your Child Restraint System's manufacturer.

Once your child outgrows the forward-facing Child Restraint System, your child is ready for a booster seat.

Booster seats

A booster seat is a Child Restraint System designed to improve the fit of the vehicle's seat belt system. A booster seat positions the seat belt so that it fits properly over the stronger parts of your child's body. Keep your children in booster seats until they are big enough to fit in a seat belt properly.

For a seat belt to fit properly, the lap belt must lie snugly across the pelvis, not the abdomen. The shoulder belt should lie snug across the shoulder and chest and not across the neck or face. Children under age 13 must always be properly restrained to minimise the risk of injury in an accident, sudden stop, or sudden manoeuvre.

Installing a Child Restraint System

WARNING

Before installing your Child Restraint System, always read and follow the instructions provided by the manufacturer of the Child Restraint System and in this manual to prevent serious injury or death if a collision occurs.

▲ WARNING

If the vehicle headrest prevents proper installation of a Child Restraint System (as described in the Child Restraint System manual), readjust or remove the headrest for that seating position.

After selecting a proper Child Restraint System for your child and checking that the Child Restraint System fits properly in a seating position, there are three general steps for a proper installation:

- Properly secure the Child Restraint
 System to the vehicle. All Child
 Restraint Systems must be secured to
 the vehicle with the lap belt or lap part
 of a lap/shoulder belt or with the ISOFIX
 top tether and/or ISOFIX anchorage
 and/or with a support leg.
- Make sure the Child Restraint System is firmly secured. After installing a Child Restraint System to the vehicle, push and pull the seat forwards and rearwards and from side to side to verify that it is securely attached to the seat. Install a Child Restraint System secured with a seat belt as tightly as possible. Some side-to-side movement can be expected.

 Secure the child in the Child Restraint System. Make sure the child is properly strapped in the Child Restraint System according to the Child Restraint System manufacturer's instructions.

A CAUTION

Check the seating surface and buckles before placing your child in the Child Restraint System to prevent burns. A Child Restraint System in a closed vehicle can become very hot.

ISOFIX anchorage and top tether anchorage (ISOFIX anchorage system) for children

The ISOFIX system connects a Child Restraint System to the vehicle during driving and in a collision. This system is designed to make installation of the Child Restraint System easier and reduce the possibility of improperly installing your Child Restraint System. The ISOFIX system uses anchors in the vehicle and attachments on the Child Restraint System. The ISOFIX system eliminates the need to use seat belts to secure the Child Restraint System to the rear seats.

ISOFIX anchorages are metal bars built into the vehicle. There are two lower anchors for each ISOFIX seating position that accommodates a Child Restraint System with lower attachments.

To use the ISOFIX system in your vehicle, install a Child Restraint System with ISOFIX attachments. (An ISOFIX-seat may only be installed if it has vehicle-specific or universal approval in accordance with the requirements of relevant regulation.)

The Child Restraint System manufacturer will provide you with instructions on how to use the Child Restraint System with its attachments for the ISOFIX anchorages. (CRS with universal approval to relevant regulation need to be fixed additionally with a top-tether strap connected to the corresponding top-tether anchorage point on the back side of the rear seats.)



ISOFIX anchorages have been provided in the left and right outboard rear seating positions. Their locations are shown in the image. There are no ISOFIX anchorages provided for the centre rear seating position.

A WARNING

Do not attempt to install a Child Restraint System using ISOFIX anchorages in the rear centre seating position. There are no ISOFIX anchorages provided for this seat. Do not use the outboard seat anchors for the centre seat. It may damage the anchorages that may break or fail in a collision resulting in serious injury or death.



[A] ISOFIX Anchorage Position Indicator [B] ISOFIX Anchorage

The ISOFIX anchorage position indicator symbols are located on the left and right rear seatbacks to identify the positions of the lower anchors in your vehicle.

Both rear outboard seats are equipped with a pair of ISOFIX anchorages as well as corresponding top tether anchorage on the package tray.

The ISOFIX anchorages are located between the seatback and the seat cushion of the rear seat left and right outboard seating positions, indicated by the symbols.

A WARNING

Before installing the Child Restraint System, make sure that there are no objects (e.g. toys, pens, wires) near the ISOFIX anchorage area. Those objects may damage either the seat belt system or the Child Restraint System during installation. If necessary, we recommend that the vehicle be inspected by an authorised Genesis repairer.

Securing a Child Restraint System with the "ISOFIX Anchorage System"

To install an ISOFIX-compatible Child Restraint System in either of the rear outboard seating positions:

- Move the seat belt buckle away from the ISOFIX anchorages.
- Move any other objects away from the anchorages that could prevent a secure connection between the Child Restraint System and the ISOFIX anchorages.
- Place the Child Restraint System on the vehicle seat, then attach the seat to the ISOFIX anchorages according to the instructions provided by the Child Restraint System manufacturer.
- 4. Follow the instructions of the Child Restraint System's manufacturer for proper installation and connection of the ISOFIX attachments on the Child Restraint System to the ISOFIX anchorages.

A WARNING

Take the following precautions when using the ISOFIX system:

- Read and follow all installation instructions provided with your Child Restraint System.
- To prevent the child from reaching and taking hold of unretracted seat belts, buckle all unused rear seat belts and retract the seat belt webbing behind the child. The child can be strangled if a shoulder belt becomes wrapped around their neck and the seat belt tightens.
- Never attach more than one Child Restraint System to a single anchorage. This may cause the anchor or attachment to come loose or break.
- Always have the ISOFIX system inspected by your dealer after a collision. A collision can damage the ISOFIX system and may not properly secure the Child Restraint System.

Securing a Child Restraint System seat with "Top Tether Anchorage" system



First secure the child restraint with the ISOFIX anchorages or the seat belt. If the child restraint manufacturer recommends that the top tether strap be attached, attach and tighten the top tether strap to the top tether strap anchorage.

Top tether anchorages are located on the parcel tray.



- Route the Child Restraint System top tether strap over the seatback, then place the top tether strap by following the instructions of the Child Restraint System manufacturer.
- Connect the top tether strap to the top tether anchorage, then tighten the top tether strap according to the instructions of your Child Restraint System's manufacturer to firmly secure the Child Restraint System.
- Check the Child Restraint System is secure by pushing and pulling the seat forward and back and side-to-side.

A WARNING

Take the following precautions when installing the top tether anchorage:

- Read and follow all installation instructions provided with your Child Restraint System.
- Never attach more than one Child Restraint System to a single ISOFIX top tether anchorage. This could cause the anchorage or attachment to come loose or break.
- Do not attach the top-tether to anything other than the System correct top-tether anchorage. It may not work properly if attached to something else.
- Child Restraint anchorages are designed to withstand only those loads imposed by correctly fitted Child Restraints.

Under no circumstances are they to be used for adult seat belts, harnesses, or for attaching other items or equipment to the vehicle.

Securing a Child Restraint System with a lap/shoulder belt

When not using the ISOFIX system, all Child Restraint Systems must be secured to a rear seat using the lap part of a lap/shoulder belt.



⚠ WARNING

Always place a rear-facing child restraint in the rear seat of the vehicle.

Placing a rear-facing child restraint in the front seat can result in serious injury or death if the child restraint is struck by an inflating airbag.

Extreme hazard! Do not use a rearward facing child restraint on a seat protected by an airbag in front of it!

Installing a Child Restraint System with a lap/shoulder belt

To install a Child Restraint System on the rear seats:

- Place the Child Restraint System on a rear seat and route the lap/shoulder belt around or through the Child Restraint System, following the Child Restraint System manufacturer's instructions. Make sure the seat belt webbing is not twisted.
- Fasten the lap/shoulder belt latch into the buckle. Listen for the distinct "click" sound.



i Information

Position the release button so it is easy to access in an emergency.

Remove as much slack from the belt as possible by pushing down on the Child Restraint System whilst feeding the shoulder belt back into the retractor. 4. Push and pull on the Child Restraint System to confirm that the seat belt is holding it firmly in place.



If your Child Restraint System manufacturer recommends the use of a top tether anchorage with the lap/shoulder belt, refer to the "Securing a Child Restraint System seat with "Top Tether Anchorage" system" section for more information.


To remove the Child Restraint System, press the release button on the buckle and then pull the seat belt out of the Child Restraint System and allow the seat belt to retract fully.

If the child seat moves, readjust the length of the seat belt. In Australia/New Zealand the child restraint manufacturer's instructions must be followed when fitting the unit to the vehicle.

A WARNING

If a child restraint is installed in the second row centre seat, move the second row seat far back as possible, to minimise contact with the front centre side airbag (if equipped with front centre side airbag).

Supplemental restraint system - airbags



The actual airbags in the vehicle may differ from the illustration.

- (1) Driver's front airbag
- (2) Passenger's front airbag
- (3) Side airbag
- (4) Curtain airbag
- (5) Driver's knee airbag
- (6) Front centre side airbag

Your vehicle is equipped with a Supplemental Airbag System for the driver's seat and front passenger's seats.

The front airbags are designed to supplement the three-point seat belts. For these airbags to provide protection, the seat belts must be properly worn at ALL times when driving.

You can be severely injured or killed in an accident if you are not wearing a seat belt. Airbags are built into the vehicle as a supplementary system. They are not intended as a replacement for wearing 3-point seat belts. Also, airbags are not designed to deploy in every collision. In some accidents, the seat belts are the only restraint protecting you.

A WARNING

AIRBAG SAFETY PRECAUTIONS

Always use seat belts and Child Restraint Systems - every trip, every time, everyone! Even with airbags, you can be seriously injured or killed in a collision if you are improperly restrained or not wearing your seat belt when the airbag inflates.

NEVER place a child in any Child Restraint System or booster seat in the front passenger seat. An inflating airbag could forcefully strike the infant or child causing serious or fatal injuries.


ABC - Always Buckle Children under age 13 in the back seat. It is the safest place for children of any age to travel. If a child age 13 or older must be seated in the front seat, they must be properly restrained and the seat should be moved as far back as possible.

Make sure that all occupants sit upright with the seatback in an upright position, centred on the seat cushion with their seat belt on, legs comfortably extended, and their feet on the floor until the vehicle is parked and the vehicle is turned off. If an occupant is out of position during an accident, the rapidly deploying airbag may forcefully contact the occupant causing serious or fatal injuries.

Never sit or lean unnecessarily close to the airbags or lean against the door or centre console.

Move your seat as far back as possible from front airbags, whilst still maintaining control of the vehicle.

SRS components



The SRS consists of the following components:

- (1) Front impact sensors
- (2) Airbag warning light
- (3) Driver's knee airbag module
- (4) Driver's front airbag module
- (5) Side impact sensors (pressure)
- (6) Retractor pretensioner
- (7) Side impact sensors (acceleration)
- (8) Side air bag modules
- (9) Curtain air bag modules
- (10)Front centre side airbag modules
- (11) Driver's and front passenger's seat belt buckle sensors
- (12) Passenger's front air bag module
- (13) SRS control module (SRSCM)/Rollover sensor

Where are the airbags?

Driver's and passenger's front airbags

Driver's front airbag



Driver's knee airbag



Passenger's front airbag



The SRS consists of airbags located in the centre of the steering wheel, in the driver's side lower crash pad below the steering wheel, and the passenger's side front panel pad above the glove box.

The airbag locations are embossed with the letters "AIRBAG".

The purpose of the SRS is to provide the vehicle's driver and front passengers with additional supplemental protection than that the seat belt system does not provide in case of a frontal impact of sufficient severity.


A WARNING

To reduce the risk of serious injury or death from inflating front airbags:

- Seat belts must be worn at all times to help keep occupants positioned properly.
- Move your seat as far back as possible from front airbags, whilst still maintaining control of the vehicle.
- Never lean against the door or centre console.
- Hold the steering wheel at the 9 o'clock and 3 o'clock positions, to minimise the risk of injuries to your hands and arms.
- Do not allow the front passenger to place their feet or legs on the instrument panel.
- Never place any objects (such as instrument panel cover, mobile phone holder, cup holder, perfume or stickers) over or near the airbag modules on the steering wheel, instrument panel, windscreen glass, and the front passenger's panel above the glove box. Such objects may cause harm if the vehicle is in a crash severe enough to cause the airbags to deploy.
- Do not attach any objects on the front windscreen and inside mirror.

Side airbags and front centre side airbag

Side airbag (Front row, Rear row)



Front centre side airbag





Side airbags are located in each front and outboard second row seats. Additionally, a front centre side airbag is located in the inboard side of the driver seatback.

The side airbags and front centre side airbag are designed to deploy during certain side impact collisions, depending on the crash severity.

For vehicles equipped with a rollover sensor the front centre side airbag, side and/or curtain airbags and pretensioners on both sides of the vehicle may deploy if a rollover or possible rollover is detected.

The side airbags and front centre side airbag are not designed to deploy in all side impact or rollover situations.

WARNING

To reduce the risk of serious injury or death from an inflating side airbag:

- Seat belts must be worn at all times to help keep occupants positioned properly.
- Do not allow passengers to lean their heads or bodies onto doors, put their arms on the doors, stretch their arms out of the window, or place objects between the doors and seats.
- Do not use any accessory seat covers. It may reduce or prevent the effectiveness of the system.
- Do not hang other objects except clothes. In an accident it may cause vehicle damage or personal injury especially when airbag is inflated.
- Do not place any objects over the airbag or between the airbag and yourself. Also, do not attach any objects around the area the airbag inflates such as the door, side door glass, front and rear pillar.
- Do not place any objects between the door and the seat. They may become dangerous projectiles if the side airbag inflates.
- Do not install any accessories on the side or near the side airbags.
- Do not cause impact to the doors when the Start/Stop button is in the POWER ON or DRIVE READY position as this may cause the side airbags to inflate.
- If the seat or seat cover is damaged, we recommend that the system be serviced by an authorised Genesis repairer.

Curtain airbags





Curtain airbags are located along both sides of the roof rails above the front and rear doors.

They are designed to help protect the heads of the front seat occupants and the rear outboard seat occupants in certain side impact collisions.

The curtain airbags are designed to deploy during certain side impact collisions, depending on the crash severity.

For vehicles equipped with a rollover sensor the side and/or curtain airbags and pretensioners on both sides of the vehicle may deploy if a rollover or possible rollover is detected.

The curtain airbags are not designed to deploy in all side impact or rollover situations.

WARNING

To reduce the risk of serious injury or death from an inflating curtain airbag:

- Seat belts must be worn at all times to help keep occupants positioned properly.
- Properly secure Child Restraint System as far away from the door as possible.
- Do not place any objects over the airbag. Also, do not attach any objects around the area the airbag inflates such as the door, side door glass, front and rear pillar, and roof side rail.
- Do not hang other objects except clothes, especially hard or breakable objects near airbag locations. In an accident, these may cause vehicle damage or personal injury.
- Do not allow passengers to lean their heads or bodies onto doors, put their arms on the doors, stretch their arms out of the window, or place objects between the doors and seats.
- Do not open or repair the side curtain airbags yourself. If necessary, we recommend that the airbag be inspected and/or repaired by an authorised Genesis repairer.

How does the airbags system operate?

The SRSCM (Supplemental Restraint System Control Module) continually monitors all SRS components whilst the Start/Stop button is DRIVE READY to determine if a crash impact is severe enough to require airbag deployment or pretensioner seat belt deployment.

During a moderate to severe frontal collision, sensors detect the vehicle's rapid deceleration. If the rate of deceleration is high enough, the SRSCM inflates the front airbags with the force needed.

The front airbags help protect the driver and front passenger by responding to frontal impacts in which seat belts alone cannot provide adequate restraint. When needed, the side airbags help provide protection in the event of a side impact or rollover by supporting the side upper body area.

- Airbags are activated (able to inflate if necessary) only when the Start/Stop button is in the POWER ON or DRIVE READY position, and it can be activated within about 3 minutes after the vehicle is turned off.
- Airbags inflate in the event of certain frontal or side collisions to help protect the occupants from serious physical injury.
- The front airbags completely inflate and deflate in an instant. It is virtually impossible for you to see the airbags inflate during an accident. It is much more likely that you simply see the deflated airbags hanging out of their storage compartments after the collision.
- In addition to inflating in serious side collisions, vehicles equipped with a rollover sensor, side and/or curtain airbags and front centre side airbag inflate if the sensing system detects a rollover.

When a rollover is detected, curtain airbags remain inflated longer to help provide protection from ejection, especially when used in conjunction with the seat belts.

- To help provide protection, the airbags must inflate rapidly. The speed of airbag inflation is a consequence of the extremely short time in which the airbag has to inflate between the occupant and the vehicle structures before the occupant impacts those structures. This speed of inflation reduces the risk of serious or life-threatening injuries and is thus a necessary part of airbag design.
 - However, the rapid airbag inflation can also cause injuries which can include facial abrasions, bruises, and broken bones because the inflation speed also causes the airbags to expand with great force.
- There are even circumstances under which contact with the airbag may cause fatal injuries, especially if the occupant is positioned excessively close to the airbag.

You can take steps to reduce the risk of being injured by an inflating airbag. The greatest risk is sitting too close to the airbag. An airbag needs space to inflate. It is recommended that drivers sit as far as possible maximising the distance of the steering wheel and the chest whilst still maintaining control of the vehicle.

Driver's front airbag (1)



When the SRSCM detects a sufficiently severe impact to the front of the vehicle, it automatically deploys the front airbags.

Driver's front airbag (2)



Upon deployment, tear seam in the pad cover separates from the expansion of the airbags.

A fully inflated airbag, in combination with a properly worn seat belt, slows the driver's or the front passenger's forward motion, reducing the risk of head and chest injury.

Driver's front airbag (3)



Passenger's front airbag



After complete inflation, the airbag immediately starts deflating, enabling the driver to maintain forward visibility and the ability to steer or operate other controls.

WARNING

To prevent objects from becoming dangerous projectiles when the passenger's airbag inflates:

- Do not install or place any objects (drink holder, CD holder, stickers, etc.) on the front passenger's panel above the glove box where the passenger's airbag is located.
- Do not install a container of liquid air freshener near the instrument cluster or on the instrument panel surface.

What to expect after an airbag inflates

After a frontal or side airbag inflates, it will deflate very quickly. airbag inflation will not prevent the driver from seeing out of the windscreen or being able to steer. Curtain airbags may remain partially inflated for some time after they deploy.

▲ WARNING

After an airbag inflates, take the following precautions:

- Open your windows and doors as soon as it is safe to do so after impact to reduce prolonged exposure to the smoke and powder released by the inflating airbag.
- Do not touch the airbag storage area's internal components immediately after an airbag has inflated. The parts that come into contact with an inflating airbag may be very hot.
- Always wash exposed skin areas thoroughly with cold water and mild soap.

 We recommend that an authorised Genesis repairer replace the airbag immediately after deployment. airbags are designed to be single use only.

Noise and smoke from inflating airbag

When the airbags inflate, they make a loud noise and may produce smoke and powder in the air inside of the vehicle. This is normal and is a result of the ignition of the airbag inflator. After the airbag inflates, you may feel substantial discomfort in breathing because of the contact of your chest with both the seat belt and the airbag, as well as from breathing the smoke and powder. The powder may aggravate asthma for some people. If you experience breathing problems after an airbag deployment, seek medical attention immediately.

Though the smoke and powder are nontoxic, they may cause irritation to the skin, eyes, nose, throat, etc. If this is the case, wash and rinse with cold water immediately and seek medical attention if the symptoms persist.

SRS warning light



The SRS (Supplemental Restraint System) airbag warning light on the instrument panel displays the airbag symbol in the illustration. The light indicates if there is a potential problem with your airbag system, which could include your side and/or curtain airbags used for rollover protection.

▲ WARNING

If your SRS malfunctions, the airbags may not inflate properly during a collision increasing the risk of serious injury or death.

Your SRS malfunctions in the following conditions:

- The light does not turn on for about three to six seconds when the Start/Stop button is in the POWER ON position.
- The light stays on after illuminating for about three to six seconds.
- The light comes on whilst the vehicle is moving.
- The light blinks when the vehicle is running.

We recommend that an authorised Genesis repairer inspect the SRS as soon as possible.

Do not install a Child Restraint System on the front passenger seat



Never install a Child Restraint System in the front passenger seat.

A WARNING

- Extreme hazard! Do not use a rearward facing child restraint on a seat protected by an air bag in front of it!
- NEVER use a rearward facing Child Restraint on a seat protected by an ACTIVE AIRBAG in front of it, DEATH or SERIOUS INJURY to the CHILD can occur.
- Never put a child restraint in the front passenger's seat. If the front passenger air bag inflates, it would cause serious or fatal injuries.

Why didn't my airbag go off in a collision?


There are certain types of accidents in which the airbag would not deploy including rear impacts and second or third collisions in multiple impact accidents, as well as low speed impacts. Damage to the vehicle indicates a collision energy absorption, and is not an indicator of whether or not an airbag should have inflated.

Airbag collision sensors

▲ WARNING

To reduce the risk of an airbag deploying unexpectedly and causing serious injury or death:

- Do not hit or allow any objects to impact the locations where airbags or sensors are installed.
- Do not perform maintenance on or around the airbag sensors. If the location or angle of the sensors is altered, the airbags may deploy when they should not or may not deploy.
- Do not install bumper guards with non-genuine Genesis or non-equivalent parts. These may adversely affect the collision and airbag deployment performance.
 - To ensure correct function of the airbag system, we recommend that you replace the bumper with genuine Genesis part or the equivalent (of the genuine part) specified for your vehicle.
- Press the Start/Stop button to the OFF or POWER ON position and wait for 3 minutes when the vehicle is being towed to prevent unintended airbag deployment.
- We recommend that all airbag repairs be performed by an authorised Genesis repairer.



- (1) Front impact sensor
- (2) Side impact sensor (Pressure)
- (3) SRS control module/Rollover sensor
- (4) Side impact sensor (Acceleration)
- (5) Side impact sensor (Acceleration)

Airbag inflation conditions

Front airbags



Front airbags are designed to inflate in a frontal collision depending on the severity of impact.

Side and curtain airbags and front centre side airbag





Side and curtain airbags and the front centre side airbag are designed to inflate when an impact is detected by side collision sensors depending on the severity of impact resulting from a side impact collision.

Although the driver's and front passenger's airbags are designed to inflate in frontal collisions and side and curtain airbags and front centre side airbag are designed to inflate in side impact collisions, airbags may inflate in other types of collisions if the sensors detect a sufficient impact.

Also, the side and curtain airbags and the front centre side airbag are designed to inflate when a rollover is detected by a rollover sensor.

If the vehicle chassis is impacted by bumps or objects on unimproved roads, the airbags may deploy. Drive carefully on unimproved roads or on surfaces not designed for vehicle traffic to prevent unintended airbag deployment.

Airbag non-inflation conditions



In certain low-speed collisions, the airbags may not deploy. The airbags are designed not to deploy in such cases because they may not provide benefits beyond the protection of the seat belts.



Front airbags are not designed to inflate in rear collisions, because occupants are moved rearward by the force of the impact. In this case, inflated airbags would not provide any additional benefit.



Front airbags may not inflate in side impact collisions, because occupants move in the direction of the collision, and thus in side impacts, front airbag deployment would not provide additional occupant protection.

Side and curtain airbags and the front centre side airbag may inflate depending on the severity of impact.



In an angled collision, the force of impact may direct the occupants in a direction where the airbags would not be able to provide any additional benefit, and thus the sensors may not deploy any airbags.



Just before impact, drivers often brake heavily. Such heavy braking lowers the front portion of the vehicle causing it to "ride" under a vehicle with a higher ground clearance. Airbags may not inflate in this "underride" situation because deceleration forces that are detected by sensors may be significantly reduced by such "underride" collisions.



Front airbags may not inflate in rollover accidents because front airbag deployment would not provide additional occupant protection.

The side and curtain airbags and the front centre side airbag may inflate in a rollover situation, when it is detected by the rollover sensor.



Airbags may not inflate if the vehicle collides with objects such as utility poles or trees, where the point of impact is concentrated and the collision energy is absorbed by the vehicle structure.

SRS care

The SRS is virtually maintenance-free and there are no parts you can safely service by yourself. If the SRS airbag warning light does not illuminate when the Start/Stop button is in the POWER ON position, or continuously remains on, we recommend that the system be immediately inspected by an authorised Genesis repairer.

We recommend any work on the SRS system, such as removing, installing, repairing, or any work on the steering wheel, the front passenger's panel, front seats, and roof rails should be performed by an authorised Genesis repairer. Improper handling of the SRS system may result in serious personal injury or death.

A WARNING

To reduce the risk of serious injury or death:

 Do not attempt to modify or disconnect the SRS components or wiring, including the addition of any kind of badges to the pad covers or modifications to the body structure.

- Do not place objects over or near the airbag modules on the steering wheel, instrument panel, and the front passenger's panel above the glove box.
- Clean the airbag pad covers with a soft cloth moistened with plain water.
 Solvents or cleaners could adversely affect the airbag covers and proper deployment of the system.
- We recommend that inflated airbags be replaced by an authorised Genesis repairer.
- If components of the airbag system must be discarded, or if the vehicle must be scrapped, observe safety precautions. We recommend that you consult an authorised Genesis repairer for the necessary information. Failure to follow these precautions could increase the risk of personal injury.

Additional safety precautions

Passengers should not move out of or change seats whilst the vehicle is moving. A passenger who is not wearing a seat belt during a collision or emergency stop can be thrown against the inside of the vehicle, against other occupants, or be ejected from the vehicle.

Do not use any accessories on seat belts. Devices claiming to improve occupant comfort or reposition the seat belt can reduce the protection provided by the seat belt and increase the chance of serious injury in a collision.

Do not modify the front seats. Modification of the front seats may interfere with the operation of the Supplemental Restraint System sensing components or side airbags.

Do not place items under the front seats.Placing items under the front seats may interfere with the operation of the

interfere with the operation of the Supplemental Restraint System sensing components and wiring harnesses.

Do not cause impact to the doors. Impact to the doors when the Start/Stop button is in the POWER ON or DRIVE READY position may cause the airbags to inflate

Adding equipment to or modifying your airbag equipped vehicle

If you modify your vehicle by changing your vehicle's frame, bumper system, front end or side sheet metal, or ride height, this may affect the operation of your vehicle's Supplemental Restraint System.

Airbag warning labels



Airbag warning labels are attached to alert the driver and passengers of potential risks of the airbag system. Be sure to read all of the information about the airbags that are installed on your vehicle in this Owner's Manual.

Active Bonnet lift system

The active boonet lift system can reduce a risk of injury to pedestrians by raising the bonnet in certain accident situations. The active bonnet lift system has the additional deformation space under the bonnet, which is made available for subsequent head impact.

System activation

Prerequisite for activation

The Start/Stop button is in the DRIVE READY position and the vehicle speed is between about 25 km/h and 50 km/h.

i Information

Active bonnet lift system repair

- If the active bonnet lift system has been activated, do not place the bonnet back by yourself. We recommend that the system be repaired by an authorised Genesis repairer.
- If you change or repair the front bumper, we recommend that the system be checked by an authorised Genesis repairer.

System activation

The active bonnet lift system is designed to work in a frontal collision depending on the intensity, speed or angles of impact of the front collision.





The system may activate when:

- The vehicle falls in the gutter or from a high place.
- An impact is detected by a frontal collision without pedestrians in front.
- Certain high-speed frontal or angled collision with a vehicle or barrier.


System limitation












The system will not activate when:

- In side collisions, rear collision, and rollover accident. The vehicle can detect only frontal collision.
- The front bumper is damaged or modified.
- The vehicle is in an angled frontal collision with pedestrians.
- A pedestrian is lying on the road.
- A pedestrian has an object to absorb the shock such as a suit case, buggy or cart.

System malfunction



If there is a problem with the system a message will appear on the instrument cluster.

This warning message means that the protection of pedestrians by the active bonnet lift system is not working properly.

If the warning message is displayed, we recommend that the system be checked as soon as possible by an authorised Genesis repairer.

i Information

- Do not remove or change the components and the wiring of the active bonnet system.
- Do not change the front bumper or the body structure.
- Do not install or assemble any aftermarket accessory on the front bumper or cover.
- When replacing tyres, make sure they are the same size as your original tyres.
 If you drive with different tyre or wheel sizes, the active bonnet lift system may not work normally.

The above situations may cause a malfunction of the active bonnet lift system.



4. Instrument cluster


Instrument cluster	4-2
Instrument cluster control	4-3
Gauges and meters	4-3
Warning and indicator lights	
Instrument cluster display messages	4-20
Instrument cluster display	4-24
Instrument cluster display control	4-24
View modes	4-25
Vehicle settings (infotainment system)	4-28
Setting your vehicle	4-28

Instrument cluster

Type A



Type B



The actual instrument cluster in the vehicle may differ from the illustration. For more information, refer to the "Gauges and meters" section in this chapter.

- (1) Speedometer
- (2) Warning indicator light
- (3) Charge/Power gauge
- (4) Battery SOC (State of Charge) gauge
- (5) Distance to empty
- (6) Outside temperature gauge(7) Reduction gear shift indicator
- (8) Instrument cluster display
- (9) Recuperative braking level indicator
- (10)Odometer
- (11) Widget

i Information

Press the mode (\Longrightarrow) button on the steering wheel to select between instrument cluster Type A or Type B.

Instrument cluster control

Instrument panel illumination



Press the illumination control switch to adjust the brightness of the instrument panel illumination.

When pressing the illumination control switch, the interior switch illumination intensity is also adjusted.

A WARNING

Never adjust the instrument panel illumination whilst driving to prevent death, serious injury, or vehicle damage.



- The brightness of the instrument panel illumination is displayed.
- When the brightness setting reaches either the minimum or maximum level, a chime sounds.

Gauges and meters

Speedometer


Type A/Type B



The speedometer indicates the speed of the vehicle and is calibrated in kilometres per hour (km/h).

Charge/Power gauge

Type A/Type B





The Charge/Power gauge gauge shows the energy consumption and recovery status of the electric motor.

- CHARGE: It shows the charging status of the battery, which is charged by the recuperative brakes, when pressing the brake pedal or decreasing the vehicle speed due to coasting. The more electric energy is charged, the more the gauge level turns anti-clockwise.
- POWER: It shows the discharging status of the motor when the vehicle is accelerating. The more electric energy is discharged (used), the more the gauge level turns clockwise.

State of charge (SOC) gauge for high voltage battery



- The SOC gauge shows the charging status of the high voltage battery.
- The low percentage number on the indicator indicates that there is not enough energy in the high voltage battery. 100% indicates that the driving battery is fully charged.
- When driving on highways or motorways, make sure to check in advance if the driving battery is charged enough. When the remaining battery is lower than 20 % on the SOC gauge, the warning light turns ON to alert you of the battery level.

When the warning light turns ON, the vehicle can drive an additional 25-50 km depending on the driving speed, heating/air conditioning, weather, driving style, and other factors. Charging is required.

NOTICE

When the high voltage battery level is low, the power down (ⓐ) indicator light illuminates and the vehicle power is limited. Charge the battery immediately since your vehicle may not be driven, or may roll back on a slope with the indicator light ON.

Outside temperature gauge



The outside ambient temperature appears in the lower portion of the instrument cluster display. The temperature reads in Celsius or Fahrenheit depending on the units selected from the Settings menu in the infotainment system.

The temperature indicated on the instrument cluster may not change as quickly as the outside temperature.

Select:

 Setup > General > Units > Temperature unit > °C/°F

Both the temperature unit on the instrument cluster and climate control information screen is changed.

NOTICE

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Odometer



The odometer indicates the total distance that the vehicle has been driven and is used to determine when periodic maintenance should be performed.

Distance to empty



 The distance to empty is the estimated distance the vehicle can be driven with the remaining electric energy.

The distance to empty differs depending on which drive mode (ECO/COMFORT/SPORT/SNOW) is selected.

For more detail information, refer to the "Checking electric vehicle driving information" section in chapter 1.

i Information

- The distance to empty may differ from the actual driving distance because it is only an estimate of the available driving distance.
- The distance to empty may differ significantly based on driving conditions, driving habits, and condition of the vehicle.
- If the battery power has been interrupted, the distance to empty function may not operate correctly.

Reduction gear shift indicator



The reduction gear shift indicator in the upper corner of the instrument cluster display indicates the current gear or P (Park).

Recuperative braking level indicator



The recuperative brake indicates the level of the recuperative braking that you set. And it also indicates Smart recuperative system's operation status.

For more details, refer to the "Recuperative braking system" and "Smart recuperation system" section in chapter 6.

Warning and indicator lights

i Information

Make sure that all warning lights are OFF after starting the vehicle. If any light is still ON, this indicates a situation that needs attention.

Ready indicator light

READY

This indicator illuminates:

When the vehicle is ready to be driven.

- · ON: Normal driving is possible.
- OFF: Normal driving is not possible, or a problem has occurred.
- · Blinking: Emergency driving.

When the ready indicator goes OFF or blinks, there is a problem with the system. In this case, we recommend that you have your vehicle inspected by an authorised Genesis repairer.

Service warning light



This warning light illuminates:

- When the Start/Stop button is in the POWER ON position.
 - It illuminates for about 3 seconds and then goes off.
- When there is a problem with related parts of the electric vehicle control system, such as sensors, etc.

When the warning light illuminates whilst driving, or does not go OFF after starting the vehicle, we recommend that you have your vehicle inspected by an authorised Genesis repairer.

Power down Indicator light



This indicator light illuminates:

- For the safety of high-powered components of electric vehicles, the power is limited due to the following reasons. (Unless both Service warning light and Power down indicator light illuminate at the same time, it is not a failure.)
 - The high voltage battery level is too low or voltage is decreasing
 - The temperature of the high voltage battery is too high or too low
 - The temperature of the motor is high

NOTICE

- Do not accelerate or start the vehicle suddenly when the power down indicator light is ON.
- When the power is limited for the safety
 of the high-powered parts of an electric
 vehicle, the power down indicator light
 illuminates. Your vehicle may not be
 driven, or may roll back on a slope with
 the indicator light ON due to the
 limitation of vehicle power.

Charging indicator light



This indicator light illuminates:
When charging the high voltage battery.

High voltage battery level warning light



This warning light illuminates:

- When the high voltage battery level is low.
- When the warning light turns ON, charge the battery immediately.

Seat belt warning light



This warning light informs the driver that the seat belt is not fastened.

For more information, refer to the "Seat belt warning light" section in chapter 3.

Airbag warning light



This warning light illuminates:

- When the Start/Stop button is in the POWER ON position. It illuminates for 3-6 seconds and then goes off.
- When there is a malfunction with the SRS.

If the Airbag warning light remains illuminated whilst driving, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Recuperative brake warning light



This warning light illuminates:

When the recuperative brake does not operate and the brake does not perform well. This causes the Brake Warning light (red) and Recuperative brake warning light (yellow) to illuminate simultaneously. In this case, drive safely and we recommend that you have your vehicle inspected by an authorised Genesis repairer.

The operation of the brake pedal may be more difficult than normal and the braking distance can increase.

Parking brake & Brake fluid warning light



This warning light illuminates:

- When the Start/Stop button is in the POWER ON position. It illuminates for 3 seconds and then goes off once the parking brake is released.
- Whenever the parking brake is applied.
- Whenever the brake fluid level in the reservoir is low
 - If the warning light illuminates with the parking brake released, it indicates the brake fluid level in the reservoir is low.

If the brake fluid level in the reservoir is low:

- 1. Drive carefully to the nearest safe location and stop your vehicle.
- 2. With the vehicle stopped, check the brake fluid level immediately and add fluid as required. For more information, refer to the "Brake fluid" section in chapter 9. After adding brake fluid, check all brake components for fluid leaks. If a brake fluid leak is found, or if the warning light remains on, or if the brakes do not operate properly, do not drive the vehicle. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Dual-diagonal braking system

Your vehicle is equipped with the dual-diagonal braking system. This means you still have braking on two wheels even if one of the dual systems should fail.

With only one of the dual systems working, more than normal pedal travel and greater pedal force are required to stop the vehicle.

Also, the vehicle does not stop in as short a distance if only a portion of the brake system is working.

If the brakes fail whilst you are driving, shift to a lower gear for additional vehicle braking and stop the vehicle as soon as it is safe to do so.

A WARNING

If the Parking brake & Brake fluid warning light illuminates with the parking brake released, it indicates that the brake fluid level is low. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Anti-lock Brake System (ABS) warning light



This warning light illuminates:

- When the Start/Stop button is in the POWER ON position. It illuminates for about 3 seconds and then goes off.
- Whenever there is a malfunction with the ARS

The hydraulic braking system still operates even if there is a malfunction with the ARS.

If the ABS warning light remains illuminated whilst driving, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Electronic Brake Force Distribution (EBD) system warning light





These two warning lights illuminate at same time whilst driving:

When the ABS warning and Parking brake warning lights are on simultaneously, it may indicate a problem with the Electronic Brake Force Distribution system.

If both the ABS warning light and the Parking Brake warning light remain illuminated whilst driving, we recommend that your vehicle be inspected by an authorised Genesis repairer.

WARNING

When both ABS and Parking brake & Brake fluid warning lights are on, the braking system will does not work normally and you may experience an unexpected and dangerous situation during sudden braking.

Avoid high speed driving and abrupt braking.

We recommend that your vehicle be inspected by an authorised Genesis repairer as soon as possible.

NOTICE

When the ABS warning light is on or both ABS and Parking brake & Brake fluid warning lights are on, the speedometer, odometer, or tripmeter may not work. Also, the MDPS warning light may illuminate and the steering effort may increase or decrease.

Motor Driven Power Steering (MDPS) warning light



This warning light illuminates:

- When the Start/Stop button is in the POWER ON position. It illuminates for about 3 seconds and then goes off.
- Whenever there is a malfunction with the Motor Driven Power Steering.
 If the MDPS warning light remains illuminated whilst driving, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Master warning light



This warning light illuminates:

If a malfunction is detected in any of the following:

- Forward Collision-Avoidance Assist malfunction
- Forward Collision-Avoidance Assist radar blocked
- Blind-Spot Collision-Avoidance Assist malfunction
- Blind-Spot Collision-Avoidance Assist radar blocked
- LED headlamp malfunction
- High Beam Assist malfunction (if equipped)
- · Smart Cruise Control malfunction
- · Smart Cruise Control radar blocked
- Tyre Pressure Monitoring System (TPMS) malfunction
- Rear Wheel Steering (RWS) system malfunction (if equipped)

If the issue is resolved, the Master warning light turns off.

Electronic Parking Brake (EPB) warning light

EPB

This warning light illuminates:

- When the Start/Stop button is in the POWER ON position. It illuminates for about 3 seconds and then goes off.
- Whenever there is a malfunction with FPB

If the EPB warning light remains illuminated whilst driving, we recommend that your vehicle be inspected by an authorised Genesis repairer.

i Information

The Electronic Parking Brake (EPB) warning light may illuminate when the Electronic Stability Control (ESC) indicator light comes on to indicate that ESC is not working properly. This does not indicate malfunction of EPB.

12 V Battery charging system warning light



This warning light illuminates: When there is a malfunction with electrical charging system.

If there is a malfunction with electrical charging system:

- 1. Drive carefully to the nearest safe location and stop your vehicle.
- 2. Turn the vehicle off and check the electrical charging system.

If the Charging system warning light remains illuminated whilst driving, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Low tyre pressure warning light



This warning light illuminates:

- When the Start/Stop button is in the POWER ON position. It illuminates for about 3 seconds and then goes off.
- When one or more tyres are significantly underinflated. (The location of the under-inflated tyre appears on the instrument cluster display.)

For more information, refer to the "Tyre Pressure Monitoring System (TPMS)" section in chapter 8.

This warning light remains ON after blinking for about 60 seconds, or repeatedly blinks ON and OFF at 3 second intervals:

When there is a malfunction with the TPMS.

If this occurs, we recommend that your vehicle be inspected by an authorised Genesis repairer as soon as possible.

For more information, refer to the "Tyre Pressure Monitoring System (TPMS)" section in chapter 8.

A WARNING

- The TPMS cannot alert you to severe and sudden tyre damage caused by external factors.
- If you notice any vehicle instability, immediately take your foot off the accelerator pedal, apply the brakes gradually with light force, and slowly move to a safe position off the road.

Forward Safety warning light



This warning light illuminates:

- When the Start/Stop button is in the POWER ON position. It illuminates for about 3 seconds and then goes off.
- Yellow: When Forward Safety of Forward Collision-Avoidance Assist is deselected, disabled, or a malfunction is detected.

If the yellow warning light remains on after the sensor has been uncovered or unblocked when the Forward Safety is set, we recommend that your vehicle be inspected by an authorised Genesis repairer.

This warning light blinks:

• Red: When Forward Safety function is operating.

For more information, refer to the "Forward Collision-Avoidance Assist (FCA)" section in chapter 7.

Emergency steering warning light

+if equipped



This warning light illuminates:

- When the Start/Stop button is in the POWER ON position. the yellow warning light illuminates for about 3 seconds and then goes off.
- Continuously Yellow: When Forward/Side Safety is deselected or Forward Collision-Avoidance Assist is disabled or a malfunction is detected.
- Blinking Red: When Forward/Side Safety of Forward Collision-Avoidance Assist is operating.

If the yellow warning light is still on even after removing foreign material from the front of the sensors after Forward Safety is set, we recommend that your vehicle be inspected by an authorised Genesis repairer.

For more information, refer to the "Forward Collision-Avoidance Assist (FCA)" section in chapter 7.

Lane Safety indicator light



This indicator light illuminates:

- Green: When Lane Keeping Assist operating conditions are satisfied.
- Grey: When Lane Keeping Assist operating conditions are not satisfied.
- Yellow: When Lane Safety is deselected, disabled, or a malfunction is detected.

If the yellow warning light remains on after the sensor has been uncovered or unblocked when Lane Safety is set, we recommend that your vehicle be inspected by an authorised Genesis repairer.

For more information, refer to the "Lane Keeping Assist (LKA)" section in chapter 7.

Inattentive Driving warning light



This warning light illuminates:

- When the Start/Stop button is in the POWER ON position. It illuminates for about 3 seconds and then goes off.
- Yellow: When Driver Attention Warning is disabled or a malfunction is detected.
 If the yellow indicator light remains on after the front view camera has been uncovered or unblocked, we recommend that your vehicle be inspected by an authorised Genesis repairer.

This warning light blinks:

 Yellow: When Driver Attention Warning recommends to take a break.

For more information, refer to the "Driver Attention Warning (DAW)" section in chapter 7.

Forward Attention Warning light





This warning light illuminates:

- When the Start/Stop button is in the ON position. It illuminates for about 3 seconds and then goes off.
- Red: When Forward Attention Warning is disabled or a malfunction is detected.
 If the red warning light remains on after the in-cabin camera has been uncovered or unblocked, we recommend that your vehicle be inspected by an authorised Genesis repairer.

This warning light blinks:

 Red: When Forward Attention Warning warns the driver to keep eyes on the road.

For more information, refer to the "Forward Attention Warning (FAW)" section in chapter 7.

Intelligent Speed Limit Assist indicator light



This indicator light illuminates:

- When the Start/Stop button is in the ON position. It illuminates for about 3 seconds and then goes off.
- Yellow: When Intelligent Speed Limit Assist is off, disabled, or a malfunction is detected.

If the yellow indicator light remains on after the front view camera has been uncovered or unblocked, we recommend that your vehicle be inspected by an authorised Genesis repairer.

For more information, refer to the "Intelligent Speed Limit Assist (ISLA)" section in chapter 7.

Lane Following Assist indicator light







This indicator light illuminates:

- Green: When Lane Following Assist is operating.
- Grey: When Lane Following Assist operating conditions are not satisfied.

This indicator light blinks:

 White: When the steering wheel assist is cancelled.

For more information, refer to the "Lane Following Assist (LFA)" section in chapter 7

All Wheel Drive (AWD) warning light



This warning light illuminates:

Whenever a malfunction with the AWD system is detected.

If this occurs, we recommend that your vehicle be inspected by an authorised Genesis repairer.

For more information, refer to the "All Wheel Drive (AWD)" section in chapter 6.

Intelligent Front-Lighting System warning light



AFS

This warning light illuminates:

- When the Start/Stop button is in the ON position. It illuminates for about 3 seconds and then goes off.
- Whenever a malfunction with the Intelligent Front-Lighting System is detected.

If this occurs, drive your vehicle to the nearest safe location, and turn the vehicle off and restart the vehicle. If the warning light remains on, we recommend that your vehicle be inspected by an authorised Genesis repairer.

LED headlamp warning light



This warning light illuminates:

- When the Start/Stop button is in the ON position. It illuminates for about 3 seconds and then goes off.
- Whenever there is a malfunction with a LED headlamp.

If the LED headlamp warning light remains illuminated whilst driving, we recommend that your vehicle be inspected by an authorised Genesis repairer.

NOTICE

Driving with the LED headlamp warning light on may reduce LED headlamp life.

Icy road warning light



This warning light illuminates:

To warn the driver the road may be icy.

When the outside temperature on the outside temperature gauge is below 4 °C (40 °F), a single chime sounds, both the outside temperature gauge and Icy Road Warning indicator blink several times and then illuminates

You can activate or deactivate the lcy Road Warning function from the Settings menu in the infotainment system. Select:

 Setup > Vehicle > Cluster > Content selection > Icy road warning

i Information

- If the Icy Road warning light appears whilst driving, avoid speeding, rapid acceleration, sudden braking, or sharp turning.
- The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the guick reference guide.

Electronic Stability Control (ESC) indicator light



This indicator light illuminates:

- When the Start/Stop button is in the ON position. It illuminates for about 3 seconds and then goes off.
- Whenever there is a malfunction with ESC system.

If this occurs, we recommend that your vehicle be inspected by an authorised Genesis repairer.

This indicator light blinks:

Whilst ESC is operating.

For more information, refer to the "Electronic Stability Control (ESC)" section in chapter 6.

Electronic Stability Control (ESC) OFF indicator light



This indicator light illuminates:

- When the Start/Stop button is in the ON position. It illuminates for about 3 seconds and then goes off.
- When you deactivate ESC system by pressing the ESC OFF button.

For more information, refer to the "Electronic Stability Control (ESC)" section in chapter 6.

Immobiliser indicator light



This indicator light illuminates for up to 30 seconds:

When the vehicle detects the smart key in the vehicle with the Start/Stop button is in the POWER ON or DRIVE READY position.

- · At this time, you can start the vehicle.
- The indicator light goes off after starting the vehicle.

This indicator light blinks for a few seconds:

When the smart key is not in the vehicle, you cannot start the vehicle.

This indicator light illuminates for 2 seconds and goes off:

If the smart key is in the vehicle and the Start/Stop button is ON, but the vehicle cannot detect the smart key.

If this occurs, we recommend that your vehicle be inspected by an authorised Genesis repairer.

This indicator light blinks:

Whenever there is a malfunction with the immobiliser system.

If this occurs, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Door open indicator light



This indicator light illuminates:
When any door or the boot is left open.

A WARNING

Before driving the vehicle, confirm the door and boot are fully closed.

NOTICE

The 12 V battery may discharge if you leave the vehicle with the Door open indicator light illuminated.

Turn signal indicator light



This indicator light blinks:

When you operate the turn signal lever.

If any of the following occur, there may be
a malfunction with the turn signal system.

- The turn signal indicator light illuminates but does not blink.
- The turn signal indicator light blinks rapidly.
- The turn signal indicator light does not illuminate at all.

If any of these conditions occur, we recommend that your vehicle be inspected by an authorised Genesis repairer.

High beam indicator light



This indicator light illuminates:

- When the headlamps are on and the turn signal lever is moved to the high beam position.
- When the turn signal lever is pulled into the Flash-to-Pass position.

Low beam indicator light



This indicator light illuminates: When the headlamps are on.

Light ON indicator light



This indicator light illuminates: When the parking lamps or headlamps are on.

High Beam Assist indicator light





This indicator light illuminates:

When the high beam is on with the light switch in the AUTO position.

- White: When High Beam Assist is ready to operate.
- Green: When High Beam Assist is operating.

If your vehicle detects oncoming or preceding vehicles, High Beam Assist switches the high beam to low beam automatically.

For more information, refer to the "High Beam Assist (HBA)" section in chapter 5.

Intelligent Front-Lighting System indicator light





This indicator light illuminates:

When the high beam is on with the light switch in the AUTO position.

- White: When Intelligent Front-Lighting system is ready to operate.
- Green: When Intelligent Front-Lighting system is operating.

If your vehicle detects oncoming or preceding vehicles, the Intelligent Front-Lighting system partially turns off the high beam LED lamps.

For more information, refer to the "Intelligent Front-lighting System (IFS)" section in chapter 5.

AUTO HOLD indicator light



This indicator light illuminates:

- White: When you activate Auto Hold by pressing the AUTO HOLD switch.
- Green: When you stop the vehicle completely by pressing the brake pedal with Auto Hold activated.
- Yellow: Whenever a malfunction with the Auto Hold is detected.

If the Will indicator light remains yellow whilst driving, we recommend that your vehicle be inspected by an authorised Genesis repairer.

For more information, refer to the "Auto Hold" section in chapter 6.

Speed Limiter indicator light



This indicator light illuminates:

When the speed limiter is enabled.

For more information, refer to the "Manual Speed Limit Assist (MSLA)" section in chapter 7.

Instrument cluster display messages

Low key battery

When the Start/Stop button is pressed to the OFF position, a message may appear, indicating the internal battery of the smart key is low. Replace the smart key battery.

Press START button while turning wheel

tif equipped

This message appears if the steering wheel does not unlock normally when the Start/Stop button is pressed.

Press the Start/Stop button whilst turning the steering wheel right and left.

Check steering wheel lock system

tif equipped

This message appears if the steering wheel does not lock normally whilst the Start/Stop button is pressed to the OFF position.

Press brake pedal to start vehicle

This message appears if the Start/Stop button is pressed repeatedly without pressing the brake pedal.

Start the vehicle by pressing the brake pedal and then pressing the Start/Stop button.

Key not in vehicle

This message appears if the smart key is not in the vehicle when you left the vehicle with the Start/Stop button in the ON or Start position.

Always turn off the vehicle before leaving your vehicle.

Key not detected

This message appears if the smart key is not detected when you press the Start/Stop button.

Press START button again

If you cannot start the vehicle after the Start/Stop button is pressed, attempt to start the vehicle by pressing the Start/Stop button again.

If the warning message appears each time you press the Start/Stop button, we recommend that the vehicle be inspected by an authorised Genesis repairer.

Press START button with key

#if equipped

This message appears and the immobiliser indicator blinks if you press the Start/Stop button whilst the warning message, "Key not detected" appears.

Check BRAKE SWITCH fuse

This message appears if the brake switch fuse is disconnected.

Replace the fuse before starting the vehicle.

If that is not possible, you can start the vehicle by pressing the Start/Stop button for 10 seconds in the OFF position.

Shift to P to start vehicle

This message appears if you try to start the vehicle in any other position except P (Park).

$m{i}$ Information

You can start the vehicle with the gear in N (Neutral). But, for your safety, we recommend that you start the vehicle with the gear shifted to P (Park).

Check virtual engine sound system

This message appears when there is a problem with the Virtual Engine Sound System (VESS).

If this occurs, we recommend that you have the vehicle inspected by an authorised Genesis repairer.

Authentication successful. The vehicle can now be started

This message appears for 4 seconds when you place your finger on the fingerprint sensor, and it is verified whilst the vehicle is off.

You can start the vehicle by pressing the brake pedal and then pressing the Start/Stop button. However, the vehicle starts when the Start/ Stop button is pressed within 30 seconds after your fingerprint is verified and the immobiliser (a) indicator light is illuminated. If the immobiliser indicator light is off, your fingerprint must be verified again.

Fingerprint authentication is locked out. Try again in XX min.

This message appears for 4 seconds when fingerprint authentication has failed more than five times whilst the vehicle is off. whilst the message is displayed, fingerprint authentication does not work even if you place your finger on the fingerprint sensor, and the vehicle does not start even if the Start/Stop button is pressed.

Try again after the time indicated in the message has passed. Start the vehicle with the smart key.

If fingerprint authentication still does not work, refer to the "Fingerprint authentication system" section in chapter 5.

Scan an authorised fingerprint to keep the vehicle running

tif equipped

If the vehicle is remotely started and **Start Vehicle** is selected from the Settings menu in the infotainment system for Driver 1 or Driver 2, this message appears for up to 30 seconds when a door is opened after unlocking the doors with the Genesis Connected Services app.

To drive your vehicle, have an authorised fingerprint verified on the fingerprint sensor when this message appears.

Vehicle is On (started by fingerprint)

tif equipped

This message appears for up to 10 seconds if the driver's door is opened and the driver's seat belt is not fastened after turning on the vehicle with a fingerprint. After the message appears, a warning sounds when the door is closed.

i Information

Since the vehicle was started with a fingerprint, if the vehicle is turned off, and there is no smart key or a registered fingerprint in the vehicle, it may be difficult to start the vehicle again.

Check user authentication system

tif equipped

This message appears if there is a problem with the Fingerprint Authentication System. We recommend that you contact an authorised Genesis repairer.

12 V battery discharging due to additional electrical devices

This message appears if the 12 V battery voltage is low or if a current draw is detected that could drain the vehicle battery. Do not connect any external electronic devices to the battery system or battery discharge may occur.

If this message appears on the instrument cluster display and there are no other external electronic devices connected to the vehicle, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Check Rear Wheel Steering system

tif equipped

This message appears if there is a problem with the Rear Wheel Steering system or related devices. If the message still appears after the vehicle is restarted, we recommend that you have the vehicle inspected by an authorised Genesis repairer.

Door, Bonnet, Boot open indicator



This warning appears if any door, bonnet or the boot is left open. The warning will indicate which door is open on the cluster display.

A CAUTION

Before driving the vehicle, confirm that the doors, bonnet and boot are fully closed.

Low tyre pressure



This warning message appears if the tyre pressure is low. The corresponding tyre on the vehicle illuminates.

For more information, refer to the "Tyre Pressure Monitoring System (TPMS)" section in chapter 8.

Lights



This indicator displays which exterior light is selected using the lighting control.

You can activate or deactivate Wiper/Lights display function from the Settings menu in the infotainment system. Select:

 Setup > Vehicle > Cluster > Content selection > Wiper/Lights display

Wiper



This indicator displays which wiper speed is selected using the wiper control.

You can activate or deactivate Wiper/Lights display function from the Settings menu in the infotainment system. Select:

 Setup > Vehicle > Cluster > Content selection > Wiper/Lights display

Low washer fluid

This message appears if the washer fluid level in the reservoir is nearly empty.

Have the washer fluid reservoir refilled.

Check haptic steering wheel system

This message appears if there is a problem with the haptic steering wheel system. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Check headlamp

This message appears if the headlamps are not operating properly.

Replace the burned out bulb with a new one with the same wattage rating.

Check turn signal

This message appears if the turn signal lamps are not operating properly.

Replace the burned out bulb with a new one with the same wattage rating.

Check headlamp LED

This message appears if there is a problem with a LED headlamp. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Check recuperative brakes

This message appears when the recuperative brake system does not work properly. If this occurs, we recommend that you have the vehicle inspected by an authorised Genesis repairer.

Instrument cluster display

Instrument cluster display control




	Switch	Operation	Function
(SELECT/ RESET, Optical mouse)		Press	SELECT/RESET switch for selecting pop up. SELECT/RESET switch for entering or exiting widget navigation mode.
	■ (SELECT/	Press and hold	SELECT/RESET switch for selecting certain pop up. SELECT/RESET switch for hiding or showing widget mode.
	Press 2 times	SELECT/RESET switch for resetting the selected Normal view mode.	
	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	Tap up, down, left, right	When in widget mode, the switch is used to navigate the widgets. When not in widget mode, the switch is used to change to previous or next song.
[B]	⇔ (MODE)	Press	MODE button for changing gauge mode.
נטן	^,∨ (UP, DOWN)	Press	UP, DOWN switch for changing View modes.

View modes

View modes	Explanation
Normal view	Show trip computer or widget on centre without background information.
Driving Assist view	Driving Assist view displays the status of the vehicle's Driver Assistance systems.
Map view	Show map and navigation related information.
Wide Map	Show map and navigation related information.
AR view	Show AR navigation and navigation related information.

The information provided may differ depending on which functions are available on your vehicle.



Normal view, Driving Assist view, Map view, Wide Map view, and AR view mode are displayed in the instrument cluster display [C].

Normal view is also shown in the widget mode.

Normal view

In the Normal view, using the • (Optical mouse), you may change through items in the following order.

Current trip



Trip distance, total driving time, average energy consumption, and instant energy consumption are displayed.

The information is combined for each ignition cycle. However, when the vehicle has been OFF for 3 minutes or longer the Drive Info screen is reset.

To reset manually, press the button two times on the steering wheel when "Current trip" appears.

After charging



Trip distance, total driving time, average energy consumption, and instant energy consumption after the vehicle has been recharged are displayed.

To reset manually, press the button two times on the steering wheel when "After charging" appears.

Since last reset



Accumulated trip distance, total driving time, average energy consumption, and instant energy consumption are displayed.

The information is accumulated starting from the last reset.

To reset manually, press the button two times on the steering wheel when "Since last reset" appears.

Tyre pressure



The tyre pressure of each tyre is displayed.

For more information, refer to the "Tyre Pressure Monitoring System (TPMS)" section in chapter 8.


Drive power distribution



Displays information related to AWD driving force distribution.

For more information, refer to the "All Wheel Drive (AWD)" section in chapter 6.

Driving Assist view



Displays the state of Smart Cruise Control, Lane Following Assist, Lane Keeping Assist, Highway Driving Assist, etc., when Driving Assist view is selected. For more information, refer to each

For more information, refer to each system information section in chapter 7.

Vehicle settings (infotainment system)



Vehicle Settings in the infotainment system provide user options for the settings including door lock/unlock features, convenience features, driver assistance, etc.

Vehicle Settings menu

- Driver Assistance
- · Drive Mode
- · Active Sound Design
- · Head-Up Display
- Cluster
- Climate
- Seat
- · Lights
- Door
- Convenience

A WARNING

Do not operate the Vehicle Settings whilst driving. You may be distracted from the task of driving and cause a collision.

Setting your vehicle

1. Press the **SETUP** button on the main keyboard.



2. Select **Vehicle** and change the settings for features.

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

5. Convenience features

Accessing your vehicle	
Smart key	
Immobiliser system	5-11
Fingerprint authentication system	5-12
Fingerprint authentication system settings	
Fingerprint authentication system operation	
Limitations of the system	5-14
When purchasing a used vehicle	5-14
Door locks	5-15
Operating door locks from outside the vehicle	
Operating door locks from inside the vehicle	
Rear seat easy door close	
Automatic door lock and unlock features	5-21
Electronic child safety lock	5-21
Theft alarm system	5-23
Rear Occupant Alert (ROA)	5-24
System setting	
System operation	
Advanced Rear Occupant Alert (ROA)	
System setting	
System operation	
Advanced Rear Occupant Alert precautions	
Declaration of Conformity	
Integrated memory system	
Storing memory positions	
Recalling memory positions	
Resetting the system	
Seat easy access	
Steering wheel	5-29
Motor Driven Power Steering (MDPS)	
Rear Wheel Steering (RWS)	
Tilt / Telescopic steering	
Horn	
Heated steering wheel	
Steering wheel grip sensor	5-33
Haptic warning / Steering Wheel Vibration Warning	5-33

Mirrors	5-34
Reverse parking aid	5-36
Windows Power windows Remote window opening/closing feature (Remote Window Control)	5-38
Bonnet	
Opening the bonnet	5-41
Non-Powered Boot	5-42
Opening the boot Closing the boot Emergency boot safety release	5-42
Power boot	
Power boot operating conditions	5-44
Setting the power boot	5-47
Emergency boot safety release	5-48
Using smart boot	5-49 5-50
Detecting area Electric charging door	
Opening the electric charging door	5-51
Head-Up Display (HUD)	5-52
Head-up display information Precautions whilst using the head-up display	5-53
OTA software update	
Downloading software undate	
Approving software updatePreparing software update	
Updating software	

5. Convenience features

Exterior lights	5-56
Lighting control	5-56
High beam operation	
Turn signals and lane change signals	5-58
Battery saver function	
Headlamps delay function	
Headlamps levelling device	
Headlamps moisture removal function	
Reversing guide lamp	
Intelligent Front-lighting System (IFS)	5-60
System settings	5-60
System operation	
System malfunction and limitations	
High Beam Assist (HBA)	
High Beam Assist setting	
High Beam Assist operation	
High Beam Assist malfunction and limitations	
Welcome system	
Puddle lamp and door handle lamp	
Dynamic welcome light	
Interior lamp	
Interior lamps	
Interior lamp AUTO cut	
Front lamps	
Rear interior lamp	
Vanity mirror lamp	
Rear mirror lamp	
Glove box lamp	
Door handle lamp/Foot lamp/Door courtesy lamp	
Mood lamp	
Interior lights always on	
Luggage compartment lamp	
Boot emergency lamp	
Puddle light	
Wipers and washers	5-71
Front windscreen wipers	

Front windscreen washers	5-72
Automatic climate control system	5-73
Automatic heating and air conditioning	5-76
Manual heating and air conditioning	5-76
System operation	
System maintenance	5-86
Windscreen defrosting and defogging	5-88
To defog inside windscreen	5-88
To defrost outside windscreen	5-89
Rear window defroster	5-89
Climate control additional features	5-90
Air conditioning auto-drying	5-90
Auto defogging system	
Auto dehumidify	
Recirculating air when washer fluid is used	
Automatic controls linked to climate control settings (for driver's seat)	
Recirculating air when entering a tunnel	5-92
Rear climate auto Off	5-93
Storage compartment	5-93
Centre console storage	5-93
Rear console storage	5-94
Glove box	5-94
Sunglasses holder	5-94
Interior features	5-95
Cup holder	5-95
Armrest warmer (front)	5-96
UV-C sterilizer system	5-96
Sunvisor	5-98
Rear mirror	5-98
Power outlet	5-99
USB charger	5-99
Wireless smartphone charging system	
Clock	
Coat hook	
Floor mat anchors	
Rear side window sunshades	
Rear window sunshade	5-104

5. Convenience features

Luggage net holder	5-105
Infotainment system	5-106
USB Port	5-106
Antenna	5-106
Steering wheel remote controls	5-106
Infotainment system	5-107
Voice recognition	5-108
Bluetooth® Wireless Technology	5-108
BANG & OLUFSEN sound system	5-108

Accessing your vehicle

Smart key

Your Genesis vehicle uses a Smart key, which you can use to lock or unlock the doors and boot, and start the vehicle.



- (1) Boot open/close
- (2) Door unlock
- (3) Door lock
- (4) Remote start
- (5) Remote Smart Parking Assist (Forward/Rearward) (if equipped)

Locking your vehicle



To lock:

- 1. Close all doors, bonnet, and boot.
- 2. Take the smart key with you.
- Touch the door handle touch sensor or press the Door lock button (3) on the smart key. The hazard warning lights blink.
- Make sure the doors are locked by pulling the door handle.

i Information

- The outside rear-view mirrors will unfold if On Door Unlock is selected from the Settings menu in the infotainment system. Select:
 - Setup > Vehicle > Lights > Welcome mirror/light > On door unlock
- The door handle touch sensor only operates when the smart key is within 1 m from the outside door handle.
- If you lock the doors using the door handle button or touch sensor, the doors are not locked under the following circumstances:
 - The smart key is in the vehicle.
 - The Start/Stop button is in POWER ON or DRIVE READY position.
 - Any door is open.

If this occurs, a chime sounds for a few seconds. Check the vehicle before attempting to lock the vehicle again.

A WARNING

Do not leave the Smart Key in your vehicle with children that are unsupervised. Children could unintentionally press the Start/Stop button or could operate the power windows or other vehicle controls or even cause the vehicle to move. This may result in serious injury or death.

Unlocking your vehicle



To unlock:

- 1. Take the smart key with you.
- Put your hand in the door handle or press the Door unlock button (2) on the smart key. All doors unlock and the hazard warning lights blink two times.

i Information

- The outside rear-view mirrors will fold if On Door Unlock is selected from the Settings menu in the infotainment system. Select:
 - Setup > Vehicle > Lights > Welcome mirror/light > On door unlock
- The door handle touch sensor only operates when the smart key is within 1 m from the outside door handle.
- After unlocking the doors, the doors are locked automatically after 30 seconds unless a door is opened.
- The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Setting the door lock/unlock prevention feature

The doors may lock or unlock if the touch sensor of the outside door handle is recognised whilst washing your car or due to heavy rain.

To prevent unintentional door lock or unlock, press the lock button on the smart key and immediately press the unlock button along with the lock button for more than 4 seconds. The hazard warning lights blink four times.

At this time, the doors will not lock or unlock even though the touch sensor is touched on the outside door handle.

To deactivate the function, press the door lock or unlock button on the smart key.

i Information

- During a car wash or rain, in order to minimise unintentional operation of the touch sensor, the touch sensor may become insensitive. This is not a malfunction.
- The doors may not lock or unlock in the following situations.
 - If the touch sensor is touched with gloves on
 - If the door is suddenly approached

Opening the boot



To open the boot:

- 1. Have the smart key with you.
- Press the boot open/close button on the vehicle or press and hold the Boot open/close button (1) on the smart key for more than one second. The hazard warning lights blink two times and the boot opens.

i Information

The boot open/close button only operates when the smart key is within 1 m from the boot.

Remotely starting vehicle

To start the vehicle remotely:

- 1. Press the door lock button on the smart key within about 10 m from the vehicle.
- Press and hold the Remote start button

 on your smart key within 4 seconds
 from when you have pressed the door
 lock button.
- 3. The vehicle starts.
- 4. To turn off the vehicle, press the Remote start button (4) once.

i Information

- The vehicle must be in P (Park) for the remote start function to start.
- The vehicle displays "Smart key must be present to keep the vehicle running" if you get into the vehicle without a registered smart key.
- The vehicle turns off if you do not get inside the vehicle within 10 minutes after remotely starting the vehicle.
- The Remote start button (4) may not operate if the smart key is not within 10 m from the vehicle.
- The vehicle does not remotely start if the bonnet or boot is open.

Remotely moving vehicle forward or rearward

eguipped if eguipped

Some models are equipped with the Remote Smart Parking Assist feature. With the smart key, the vehicle can be moved forward or rearward remotely using the Forward or Rearward button (5) on the smart key.

For more information, refer to the "Remote Smart Parking Assist 2 (RSPA 2)" section in chapter 7.

Starting the vehicle

Your vehicle is equipped with Start/Stop button instead of a key cylinder. You can leave your smart key in your pocket or purse when you start your vehicle.

For more information, refer to the "Start/Stop button" section in chapter 6.

i Information

If the smart key is not moved for some time, the detection function for smart key operation will pause. Lift the smart key to activate the detection function again.

NOTICE

To prevent damaging the smart key:

- Keep the smart key in a cool, dry place to avoid damage or malfunction. Exposure to moisture or high temperature may cause the internal circuit of the smart key to malfunction. This may not be covered under warranty.
- Avoid dropping or throwing the smart key.
- Protect the smart key from extreme temperatures.

Using mechanical key

If the smart key does not operate normally, you can lock or unlock the driver's door by using the mechanical key.



- 1. Press the **GENESIS** text section of the Mechanical key to remove the case.
- 2. Remove the mechanical key from the case.



3. After use, reinstall the mechanical key in the reverse order of removal.

Loss of a smart key

A maximum of two smart keys can be registered to a single vehicle. If you happen to lose your smart key, it is recommended that you should immediately take the vehicle and remaining key to your authorised Genesis repairer or tow the vehicle, if necessary.

Smart key precautions

The smart key may not work if any of the following occur:

- The smart key is close to a radio transmitter such as radio station or airport that may interfere with normal operation of the transmitter.
- The smart key is near a mobile two way radio system or a mobile phone.
- Another vehicle's smart key is being operated close to your vehicle.
- The smart key is near any normal electronic devices or credit cards.
- If your windows are tinted, especially with metallic window tint, it may cause frequency interference, reducing the smart key operating range.
- · The vehicle battery is discharged.
- Connecting an external device to the power outlet and placing the smart key near the external device.
- If the smart key does not move for a certain period of time, the detection function for operating the smart key may be paused. Lifting the smart key will activate the detection function again.

If the smart key does not work correctly, open and close the door with the mechanical key. To start the vehicle, press the Start/Stop button directly with the smart key. If you have a problem with the smart key, it is recommended that you contact an authorised Genesis repairer.

If the smart key is in close proximity to your mobile phone, the signal could be blocked by your mobile phone's normal operational signals. This is specifically relevant when the phone is active such as making and receiving calls, text messaging, and/or sending/receiving emails. If possible, avoid keeping the smart key and your mobile phone in the same location such as pants or jacket pocket to avoid interference between the two devices.

▲ WARNING

People with medical devices such as implanted pacemakers or cardiac defibrillators should not carry the smart key near the heart. The smart key system may affect the operation of such implanted medical devices. Failure to do so may result in interference with the medical device, which could result in serious injury.

NOTICE

- Keep the smart key away from electromagnetic material that blocks electromagnetic waves to the key surface.
- Always have the smart key with you when leaving the vehicle. If the smart key is left near the vehicle, the vehicle battery may be discharged.

Replacing the battery

If the smart key is not working properly, replace the battery.

Battery Type: CR2032 To replace the battery:

 Press the button [A] to remove the keyring fixed appliance.



- Insert a flat head screwdriver into the inner groove to remove the smart key cover.
- 3. Remove the old battery.
- 4. Install a new battery and reinstall the smart key cover in the reverse order of removal. Make sure the battery position is correct. An improperly positioned battery may discharged the battery, causing smart key failure.



If you suspect your smart key might have sustained some damage, or you feel your smart key is not working correctly, it is recommended that you contact an authorised Genesis repairer.

A WARNING

THIS PRODUCT CONTAINS A BUTTON BATTERY.

If swallowed, a lithium button battery can cause severe or fatal injuries within 2 hours. Keep batteries out of reach of children.

If you think batteries may have been swallowed or placed inside any part of the body, seek immediate medical attention.

i Information



An inappropriately disposed battery may be harmful to the environment and human health. Always dispose used batteries in accordance with local law(s) or regulations.

Immobiliser system

The immobiliser system helps protect your vehicle from theft. If an improperly coded key (or other device) is used, the vehicle is disabled.

When the Start/Stop button is pressed to the POWER ON or DRIVE READY, the immobilizer system indicator should come on for a moment, then go off.

If the indicator starts to blink, the system does not recognise the coding of the key. Press the Start/Stop button to the POWER ON or DRIVE READY again.

In some circumstances, the vehicle system may not recognise your smart key if another smart key device is nearby or a metal object such as a key chain is causing interference with the smart key.

If this occurs, your vehicle may not start. Remove any metal objects or additional keys near the smart key before attempting to start the vehicle again.

If the system repeatedly does not recognise the coding of the key, it is recommended that you contact an authorised Genesis repairer.

Do not attempt to alter this system or add other devices to it. Electrical problems could result that may make your vehicle inoperable.

i Information

To prevent theft of your vehicle, do not leave spare keys anywhere in your vehicle.

NOTICE

Avoid exposing the key to moisture, static electricity, and rough handling. The immobiliser system may malfunction.

Fingerprint authentication system

Fingerprint Authentication system provides features such as starting the vehicle, having access to personal information, unlocking profile, and exiting valet mode using a registered fingerprint.

A fingerprint must be registered in the User Profile Settings from the infotainment system to use the system.

The maximum of two fingerprints can be registered. Driver 1 and Driver 2 can register one fingerprint each.

i Information

If no fingerprint is registered in the infotainment system, Fingerprint Authentication system does not operate.

Fingerprint authentication system settings

You can set or delete a fingerprint through the infotainment system. Complete the following procedure.

Registering fingerprint



- [A] Fingerprint sensor
- Have both of your smart keys with you in the vehicle.

- Turn on the vehicle and select Setup > User profile > Driver 1 > Fingerprint identification from the infotainment system.
- 3. After entering the profile password, select **Set/Delete fingerprint** > **Set**.
- 4. Place the finger that you wish to register on the fingerprint sensor according to the instruction.
- Following the instructions, place several parts of your fingerprint until the scanning process is complete.

When scanning is complete, the "Saving fingerprint...." appears and the fingerprint registering process is completed.

i Information

- Remove all substances including protection film on the fingerprint sensor, and then register your fingerprint.
- The fingerprint registering process is cancelled when the following conditions occur:
 - The infotainment system screen is altered.
 - The Start/Stop button turns on or off.
 - The gear is shifted, and the vehicle is driven.

Deleting fingerprint

- 1. Have one of your smart key with you in the vehicle.
- Turn on the vehicle and select Setup >
 User profile > Driver 1 > Fingerprint
 identification from the infotainment
 system.
- 3. After entering the profile password, select **Set/Delete fingerprint** > **Delete**.
- Delete the registered fingerprint according to the message "Delete all driver 1 fingerprints?".

A CAUTION

Do not participate in duplicating your fingerprint with anyone.

Fingerprint authentication system operation

Using features with touch control

The convenience features such as starting the vehicle, accessing personal information, unlocking profile, and exiting valet mode are available with the Fingerprint Authentication system.

When the fingerprint shape appears on the infotainment system screen, you should place your finger on the fingerprint sensor in the vehicle according to the instruction message for authorization and then you can operate the linked features without entering the password.

If the Fingerprint Authentication system does not work, pull your finger away from the fingerprint authentication sensor and then try again.

Fingerprint linked features can be turned on or off from the Settings menu.

Select: Setup > User profile > Driver 1 (or Driver 2) > Fingerprint identification

Fingerprint linked features	Characteristic	
Starting vehicle	Start vehicle with fingerprint but without smart key.	
Personal information access	Use features with fingerprint but without a password.	
Profile unlock		
Valet mode exit		

i Information

If the same fingerprint is registered for Driver 1 and Driver 2, the authentication result is linked to Driver 1, when authentication is successful.

Starting the vehicle

Place your finger on the fingerprint sensor (1) to verify your fingerprint. After it is successfully verified, start the vehicle by pressing the Start/Stop button (2) within 30 seconds.



Fingerprint authentication status	Light colour	Message on instrument cluster
Standby	White	-
Succeed	Blue	"Authenticated . The vehicle can now be started"
Fail	Yellow	-
Restricted due to consecutive failure	Red	"Fingerprint authorization is locked out. Try again in XX min"

i Information

- Fingerprint authorization is restricted for 1 minute, 3 minutes, or 5 minutes when failed every 5 times.
- For more information on how to start your vehicle with the Start/Stop button, refer to the "Start/Stop button" section in chapter 6.
- If you are in the vehicle for an extended period without starting the vehicle, the fingerprint sensor may turn off. If this occurs, press the brake pedal and verify your fingerprint again when the fingerprint sensor illuminates.

Limitations of the system

- Fingerprint Authentication system may not work when:
 - Fingerprint authentication is performed with an unregistered fingerprint.
 - The fingerprint is not placed on the centre of the fingerprint sensor.
 - The fingerprint sensor or fingerprint is wet or dirty.
 - The film on the sensor is not removed.
 - The registered fingerprint is wounded or swollen.
 - The hand is overly dry.
 - The sensor is touched too briefly.
- If fingerprint authentication fails repeatedly, fingerprint recognition is temporarily restricted. You should try it later or try other methods such as inputting your password.
- All registered fingerprints may be deleted during repair due to a malfunction of the fingerprint authentication system or related parts. Have your smart key when you visit an authorised Genesis repairer.

- You cannot use the fingerprint sensor when the vehicle is discharged.
- Gently place your finger on the fingerprint sensor. Fingerprint authentication attempts with excessive force may fail.

A WARNING

Do not register children's fingerprints in the vehicle.

If you register children's fingerprints and leave them in the vehicle, unexpected accidents may occur.

When purchasing a used vehicle

If you purchase a used vehicle, you should confirm and delete all of the registered fingerprints in Driver 1 and Driver 2 profile.

Door locks

Operating door locks from outside the vehicle

Using mechanical key



[A] Lock [B] Unlock

- 1. Pull the door handle (1).
- Insert the mechanical key into the key cylinder (2) and rotate clockwise to lock [A] the vehicle and anti-clockwise to unlock [B] the vehicle.

Once the doors are unlocked, they may be opened by pulling the door handle.

NOTICE

Do not apply excessive force to the door and door handle

Using smart key


For more information, refer to the "Smart key" section in the previous pages.

i Information


- In cold and wet climates, door lock and door mechanisms may not work properly due to freezing conditions.
- If the door is locked/unlocked multiple times in rapid succession with either the vehicle key or door lock switch, the system may stop operating temporarily in order to protect the circuit and prevent damage to system components.

In case of an emergency

Front



Rear



Doors without an outside key hole can be locked as follows:

- 1. Open the door.
- Insert a small flat blade tool (like a screwdriver or similar) into the emergency door lock hole and turn it anti-clockwise for left side door, or turn it clockwise for right side door.
- 3. Close the door securely.

i Information

If the electrical power door lock switch does not operate (for example, dead car battery) and the boot is closed, you will not be able to open the boot until power is restored.

Power door latch

tif equipped



If a door does not close completely but is closed to the first detent position, the door closes automatically.

A CAUTION

To reduce the risk of injury:

- Before closing the door, check there are no obstructions in the path of the door.
- Keep your fingers away from the edge of the door or they may become caught when the power door latch operates.

Resetting the power door latch

The power door latch may need to be reset after the battery is discharged or disconnected or a related fuse has been replaced or disconnected.

To reset the power door latch, perform the following steps:

- 1. Close the door to the first detent positon.
- 2. Open the door.

When this is complete, the power door latch is reset.

If the power door latch does not operate properly after resetting, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Operating door locks from inside the vehicle

With the door inside handle



Front door


If the inner door handle is pulled when the door is locked, the door is unlocked and opened.

Rear door

If the inner door handle is pulled once when the door is locked, the door is unlocked. If the inner door handle is pulled once more, the door is opened.

With the rear door inside button

Using the door open button



Press the door open button from inside the vehicle to open the door.

- Always close and lock the doors when the vehicle is moving. Locking the doors prevent others from entering the vehicle whilst the vehicle is stopped or moving slowly.
- If any door is open, the doors will not lock even though the central door lock switch is pressed.

NOTICE

- Do not open the door excessively multiple times using the door open button. It may engage the protection circuit and temporarily disable the button.
- If equipped with the Easy door close feature, the door will open about 20 cm. Check for any obstacles before opening the door.

MARNING

Only open the door with the door open button when the vehicle has completely stopped.

The door may open whilst the vehicle is in motion if you press the button.

Opening the door manually



If the door does not open with the door open button due to battery discharge or vehicle breakdown, pull up the emergency open lever as much as possible under the door pocket twice to open the door. You may use the emergency open lever even if there is no problem with the door open button.

A CAUTION

Do not apply excessive force on the door, door handle and emergency open lever to avoid damage.

▲ WARNING

- Be careful when opening doors and watch for vehicles, motorcycles, bicycles or pedestrians approaching the vehicle in the path of the door.
 Opening a door when something is approaching may cause damage or injury.
- If you press the Start/Stop button or press the door lock button whilst the smart key is located inside the vehicle, all the doors can be locked. Therefore, do not leave unsupervised children or people who are not aware of the system since it can result in serious injury or death.

 Do not leave the elderly, children or animals unattended in your vehicle. An enclosed vehicle can become extremely hot, causing death or serious injury to the elderly, unattended children or animals who cannot escape from the vehicle

Children might operate features of the vehicle that could injure them, or they could encounter other harm, possibly from someone gaining entry to the vehicle.

 Do not pull the emergency open lever whilst the vehicle is in motion.

If a door opens whilst driving, it may lead to a serious injury or death.

With the central door lock/unlock switch

Driver and passenger door

Driver's door



Front passenger's door




When pressing the diportion (1) on the switch, all vehicle doors are locked.

- If any door is open, the doors are not locked even though the lock switch (1) of the door is pressed.
- If the smart key is in the vehicle and any door is open, the doors are not locked even though the lock switch (1) of the door is pressed.

When pressing the diportion (2) on the switch, all vehicle doors are unlocked.

When all vehicle doors are locked, the indicator lights on the driver's door and passenger's door turn off. If any door is unlocked, the indicator turns on.

Rear door



When the lock switch (1) is pressed, the corresponding door will lock.

When the unlock switch (2) is pressed (door indicator light ON), the corresponding door will unlock.

i Information

If all doors are locked with the front door lock button, and the electronic child safety lock button (if equipped) in the driver's seat is turned ON (indicator light ON), the rear doors cannot be opened. If you want to open the rear doors:

- Unlock the door with the smart key from outside.
- Press the electronic child safety lock button on the driver's door to turn it off (indicator light OFF), then unlock the doors with the driver's or passenger's central door lock switch. (Electronic child lock OFF → Door unlocked)

 Press the electronic child safety lock button on the driver's door to turn it off (indicator light OFF), then pull the rear inner door handle twice.

A WARNING

- Always close and lock the doors whilst the vehicle is moving. If the doors are unlocked, the risk of being thrown from the vehicle in a collision increases.
- Do not pull the inner door handle of the driver's or passenger's door whilst the vehicle is moving.

A WARNING

Do not leave the elderly, children, or animals unsupervised in your vehicle. An enclosed vehicle can become extremely hot and the elderly, unsupervised children or animals who cannot escape the vehicle may be seriously injured or killed.

A WARNING

Always park your vehicle properly.

Press the brake, shift the gear to the P (Park), apply the parking brake, press the Start/Stop button to the OFF position, close all windows, lock all doors, and always take the key with you.

A WARNING

Be careful when opening doors and watch for vehicles, motorcycles, bicycles, or pedestrians approaching the vehicle to prevent serious injury or death.

Rear seat easy door close

tif equipped



Rear door closes automatically with a door open button or sensor.

i Information

If the vehicle is equipped with the easy door close feature, pressing the door open button whilst the door is closed will automatically open the door about 20 cm.

Closing door with button or sensor

Rear door handle/Front centre console



Rear door trim/Rear armrest console



Touch the lock/unlock sensor (engraved part) of the rear door handle from the outside, or press the open button from the inside, or press the close button on the console.

Resetting rear seat easy door close

To reset the rear seat easy door close feature, close the door to the second detent position and open the door again.

Reset the rear seat easy door close feature in the following conditions.

- The discharged battery is recharged
- The disconnected battery is reconnected
- Related fuses are disconnected and reinstalled

A CAUTION

If the rear seat easy door close feature does not work properly after reset, we recommend that you contact an authorised Genesis repairer.

i Information

- The following situations are normal and may happen when using the rear seat easy door close feature.
 - Before resetting rear seat easy door close, opening and closing the door manually may require more strength.
 - When the door opens about 20 cm and stops, or is automatically opened or closed, a sound may occur due to motor rotation.
 - If the door is repeatedly opened and closed manually, a noise may sound due to the motor brake.
 - When the battery is low, starting the vehicle whilst the door is open may cancel the initial setting of the rear seat easy door close feature. When cancelled, manually opening and closing the door requires more force. Pressing the door close button or closing the door manually will normalize the setting of the rear seat easy door close feature.
- During cold weather, opening and closing the door manually may require more strength due to low lubrication.
 If the door can be automatically closed with the door button or key, the doors

are working properly.

A WARNING

If you stay in the vehicle for a long time whilst the weather is very hot or cold, there are risks of injuries or danger to life. Do not lock the vehicle from the outside when someone is in the vehicle.

Automatic door lock and unlock features

Your vehicle is equipped with features that will automatically lock or unlock your vehicle based on settings you select in the infotainment system.

Auto Lock Enable on speed

When this feature is set in the infotainment system, all the doors will be locked automatically when the vehicle exceeds 15 km/h.

Auto Lock Enable on shift

When this feature is set in the infotainment system, all the doors will be locked automatically when the vehicle is shifted out of P (Park) whilst the vehicle is running.

Auto Unlock On shift to P

When this feature is set in the infotainment system, all the doors will be unlocked automatically when the vehicle is shifted back into P (Park) whilst the vehicle is running.

Auto Unlock Upon vehicle off

When this feature is set in the infotainment system, all the doors will be unlocked automatically when the vehicle is turned off.

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Additional unlock safety feature airbag deployment

As an additional safety feature, all doors will be automatically unlocked when an impact causes the airbags to deploy.

Electronic child safety lock



When the electronic child safety lock button is pressed and the indicator light on the button illuminates, the rear doors cannot be opened from inside the vehicle.

- The rear door window cannot be opened or closed whilst the electronic child safety lock button is in the LOCK position (indicator light ON).
 - For more information, refer to the "Windows" section in this chapter.
- Electronic child safety lock does not automatically turn on unless the driver presses the electronic child safety lock button.

- If 3 minutes passes after the Start/Stop button is pressed to the OFF position, the indicator on the button turns off, and the driver cannot turn off electronic child safety lock by pressing the button. To turn off the function, press the Start/Stop button to the POWER ON or DRIVE READY position, and then press the electronic child safety lock button.
- If the power is supplied again after removing the battery or battery is discharged whilst the electronic child safety lock button is in the LOCK position, press the button once more to match the state of the indicator on the electronic child safety lock button and the actual state of the electronic child safety lock function.
- If the airbag is activated whilst the electronic child safety lock button is in the LOCK position (indicator light ON), the rear doors will unlock automatically.
- Vehicles equipped with the electronic child safety lock feature are not provided with a manual child safety lock.

A WARNING

Never allow children to open the rear doors whilst the vehicle is moving. They may fall out of the vehicle. Be sure to use the electronic child safety lock whenever children are in the vehicle.

NOTICE

Child safety lock error

When electronic child safety lock does not work even though the button is pressed, the message "Child safety lock error" may be displayed and an alarm sounds. If this occurs, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Safe Exit Assist (with electronic child safety lock)

Safe Exit Assist helps prevent the rear occupant from opening the rear door. When an approaching vehicle from the rear area is detected after the vehicle stops, the rear doors will not unlock even when the driver tries to unlock the rear doors using the electronic child safety lock button.

For more information, refer to the "Safe Exit Assist (SEA)" section in chapter 7.

Theft alarm system

This system helps protect your vehicle and valuables. The horn sounds and the hazard warning lights blink continuously if any of the following occur:

- A door is opened without using the smart key.
- The boot is opened without using the smart key.
- · The bonnet is opened.

The alarm continues for 30 seconds, then the system resets. To turn off the alarm, unlock the doors with the smart key.

The Theft Alarm System automatically sets 30 seconds after you lock the doors and the boot. For the system to activate, you must lock the doors and the boot from outside the vehicle with the smart key or by touching the touch sensor on the outside of the door handle with the smart key in your possession.

The hazard warning lights blink and the chime sounds once to indicate the system is armed.

Once the security system is set, opening any door, boot, or bonnet without using the smart key causes the alarm to activate.

The Theft Alarm System is not set if the bonnet, boot or any door is not fully closed. If the system is not set, check the bonnet, boot and doors are fully closed.

Do not attempt to modify this system or add other devices to it.

i Information

- Do not lock the doors until all passengers have left the vehicle. If a door is opened after the system is armed, the alarm is activated.
- If the vehicle is not disarmed with the smart key, open the doors by using the mechanical key and start the vehicle by directly pressing the Start/Stop button with the smart key.
- If the system is disarmed by unlocking the vehicle, but a door or boot is not opened within 30 seconds, the doors are relocked and the system is rearmed automatically.

i Information



Vehicles equipped with a theft alarm system have a label attached to the vehicle with the following words:

- WARNING
- SECURITY SYSTEM

Rear Occupant Alert (ROA)

Rear Occupant Alert is provided to help prevent the driver from leaving the vehicle with the rear passenger left in the vehicle.

System setting

To use Rear Occupant Alert, it can be enabled from the Settings menu in the infotainment system. Select:

Setup > Vehicle > Convenience > Rear occupant alert

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

System operation

When you turn off the vehicle and open the driver's door after opening and closing the rear door, the "Check rear seats for passengers and belongings" warning message appears on the instrument cluster display.

i Information

To turn the warning message off, press the **OK** button.



WARNING

Always check the rear seats before you leave the vehicle.

The Rear Occupant Alert system does not actually detect the presence of objects or occupants in the rear seat but just informs you to check the rear seat by using the record of the rear door opening and closing.

i Information

The record of the rear door opening and closing resets only when the driver turns the vehicle off and locks the vehicle door.

Even if the rear door has not been reopened, an alert may occur if the door record is not reset. For example, if the driver opens the door and exits the vehicle again without locking the door after the Rear Occupant Alert operates, the alert may occur again.

Advanced Rear Occupant Alert (ROA)

tif equipped

Advanced Rear Occupant Alert is provided to help prevent the driver from leaving the vehicle with the rear passenger left in the vehicle.

System setting

To use Advanced Rear Occupant Alert, enable it from the Settings menu in the infotainment system. Select:

Setup > Vehicle > Convenience > Rear occupant alert

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

System operation

· First alert

When you turn off the vehicle and open the driver's door after opening and closing the rear door, the "Check rear seats for passengers or belongings" warning message appears on the instrument cluster.


· Second alert

After the first alert, the second alert operates when any movement is detected in the vehicle after the driver's door is closed and all the doors are locked. The horn will sound for about 25 seconds. Also, a text message is sent to members of Genesis Connected Services (if equipped). If the system continues to detect a movement, the alert operates up to 8 times. Unlock the doors with the smart key to stop the alert.

 The system detects movement in the vehicle for 10 minutes after the door is locked.

i Information

- The second alert is available for vehicles equipped with the ROA sensor.
- The second alert is activated only after the prior activation of the first alert.
- If you do not want to use Advanced Rear Occupant Alert, press the OK button on the steering wheel when the first alert is displayed on the instrument cluster. Doing so will deactivate the second alert one time.





[A] Instrument cluster [B] Steering wheel

- If the vehicle is started remotely (if equipped with Remote Start), inside movement detection will stop.
- Members of Genesis Connected Services can stop the alert through the app.

Advanced Rear Occupant Alert precautions

- Make sure that all the windows are closed. If any window is open, the alert may occur when the sensor has detected any movement (for example, wind or bugs).
- Movement is not detected in areas other than the rear seats.
- If all doors are locked with a passenger in the vehicle, the alert may occur.
- The alert may occur if there is an impact on the vehicle.
- If boxes or objects are stacked in the vehicle, the system may not detect passengers. The alert may occur if the boxes or objects fall off or move.
- The alert may occur with the doors locked if the vehicle is pushed or shaken, or washed, or if there is sufficient external vibration or noise.
- The alert may occur when there are metallic or liquid objects in the vehicle.

▲ WARNING

Even if your vehicle is equipped with Advanced Rear Occupant Alert (ROA), always check the rear seats area before you leave the vehicle.

Advanced Rear Occupant Alert (ROA) may not operate when:

- Movement does not continue for a certain period of time or the movement is small.
- A child is not seated in a child restraint system.
- The detection signal is weak because the signal is obscured by seat or CRS (for example, child is restrained in the forward-facing CRS).
- The rear passenger is a child over 6 years.

- The rear passenger is covered with a fabric containing metallic substance such as a blanket.
- An object in the vehicle blocks the sensor.
- The sensor is contaminated by foreign material.
- Attaching objects or modifying the interior ceiling, or the interior ceiling is deformed or damaged.
- There is electronic interference around the vehicle.
- Other environmental reasons that may affect the system.

Declaration of Conformity

The radio frequency components (ROA Radar Sensor) complies:

Model name: ICR010

R-NZ

Integrated memory system

tif equipped



The Integrated Memory System for the seat and the front passenger's seat allows the occupant to store and recall the following memory settings with a simple button operation.

- · Driver's seat
 - Driver's seat position
 - Steering wheel position (power adjustment)
 - Outside rear-view mirrors position
 - Head-Up Display (HUD) position (if equipped)
- · Passenger's seat
 - Passenger's seat position (if equipped)
- · Rear seat
 - Rear seat position (if equipped)

A WARNING

Never attempt to operate the Integrated Memory System whilst the vehicle is moving to prevent serious injury or death.

i Information

- If the battery is disconnected, the memory settings are erased.
- If Integrated Memory System does not operate normally, we recommend that you contact an authorised Genesis repairer.

Storing memory positions

- Shift to P (Park) whilst the Start/Stop button is in the POWER ON or DRIVE READY position.
- 2. Adjust the seat position, outside rear-view mirrors, steering wheel, and head-up display to the desired position.
- Press the SET button. The system beeps once. And then press one of the memory buttons (1 or 2) within 4 seconds when "Press button to save settings" appears on the infotainment system.
 - Or just press and hold one of the memory buttons (1 or 2) without using the SET button.

The system beeps twice when successfully stored and "Setting 1(or 2) saved" appears on the infotainment system.

Recalling memory positions

- 1. Make sure the Start/Stop button is in the POWER ON or DRIVE READY position and the gear is in P (Park).
- Press the desired memory button (1 or 2). The system beeps once, and then the seat position, outside rear-view mirrors position, steering wheel position, and head-up display position are automatically adjusted to the stored positions.
- 3. "**Settings 1 (or 2) applied**" appears on the infotainment system.

i Information

 If you press the SET button or the corresponding IMS memory (1 or 2) for which the settings are being recalled, the IMS temporarily deactivates.

If you press the **SET** button or the number 1 button with the number 1 setting in operation, the IMS temporarily deactivates.

If you press the number 2 button, the IMS memory settings activate according to number 2.

 If you adjust the seat whilst IMS is adjusting the seat and the mirror, the system stops the adjustments.

Resetting the system

Take the following procedures to reset integrated memory system, when it does not operate properly.

Resetting the Integrated Memory System

- Make sure that the gear is in P (Park) and the vehicle is DRIVE READY, and then open the corresponding door of the seat
- 2. Adjust the corresponding seat and seatback to the foremost position.
- Press the number 1 button and push forward the seat movement switch over 2 seconds simultaneously.
- 4. Release the number **1** button and the seat switch when a beep sounds.

Whilst resetting the Integrated Memory System

A notification sound is heard and the seat is adjusted to the most reward position. Then the seat and seatback move to the default centre position.

The resetting procedure and the notification sound may stop if:

- The memory button is pressed.
- The seat control switch is operated.
- The gear is shifted out of P (Park).
- The driving speed exceeds 5 km/h.
- The corresponding door is closed.

NOTICE

- If the seat movement or notification sound stops before the process is complete, restart the resetting procedure.
- Before resetting the IMS, make sure there are no objects on or around the seat.

Seat easy access

The system moves the seat, steering wheel and seat bolster automatically as follows:

· Exiting the vehicle:

The seat and steering wheel move as follows when the Start/Stop button is in the OFF position with the gear in P (Park), and the driver's door open.

- Seat: Moves rearward depending on the distance selected from the Settings menu in the infotainment system.
- Steering wheel: Moves upward
- Seat bolster (if equipped): Adjusted to the default position.

i Information

- On a regular basis, the steering wheel moves forward to adjust its location by itself.
- The driver's seat or the front passenger's seat may not move rearward if there is not enough space between the driver's seat or the front passenger's seat and the second row seats.

· Entering the vehicle:

The driver's seat and steering wheel move back to its original position when the Start/Stop button is pressed to the POWER ON or DRIVE READY position or whilst carrying the smart key, the driver's door is closed with the Start/Stop button in the OFF position.

- The passenger seat moves forward or rearward when the passenger side door is closed or opened. (if equipped)
- The rear seat moves rearward when each door is opened. (if equipped)
- You can set the Seat Easy Access function from the Settings menu in the infotainment system. Select:
 - Driver seat

Setup > Vehicle > Seats > Seat easy access > Driver seat easy access > Normal/Extended/Off

- Passenger seat (if equipped)
 - Setup > Vehicle > Seats > Seat easy access > Passenger seat
- Steering wheel
 - Setup > Vehicle > Seats > Seat easy access > Steering easy access
- The second row seat moves rearward when each door is opened. (if equipped)
 - Left rear seat (if equipped)
 - Setup > Vehicle > Seats > Seat easy access > Left rear seat
 - Right rear seat (if equipped)
 Setup > Vehicle > Seats > Seat easy access > Right rear seat

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Steering wheel

Motor Driven Power Steering (MDPS)

The system assists you with steering the vehicle. If the vehicle is turned off or if the power steering system becomes inoperative, you can still steer the vehicle, but it requires increased steering effort.

If you notice any change in the effort required to steer during normal vehicle operation, we recommend that you contact an authorised Genesis repairer.

NOTICE

If Motor Driven Power Steering (♠!) warning light and the message "Check motor driven power steering" appear on the instrument cluster, you can continue to steer the vehicle, but it requires increased effort. We recommend that you contact an authorised Genesis repairer and have the system inspected as soon as possible.

i Information

During normal vehicle operation:

- The steering effort may be high immediately after pressing the Start/Stop button to the DRIVE READY position.
 - This happens as the system performs the MDPS system diagnostics. When the diagnostics are completed, the steering wheel effort returns to its normal condition.
- When the battery voltage is low, you may have to use more effort to steer. This is a temporary condition and returns to normal condition after charging the battery.

- A click noise may be heard from the MDPS relay after the Start/Stop button is in the DRIVE READY or OFF position.
- Motor noise may be heard when the vehicle is at a stop or at low speeds.
- When you operate the steering wheel in low temperatures, abnormal noise may occur. When the temperature rises, the noise disappears.
- When an error is detected from MDPS, the steering effort assist function is not activated. Instrument cluster warning lights may illuminate or the steering effort may be high. If these symptoms occur, drive the vehicle to a safe location as soon as possible. We recommend that your vehicle be inspected by an authorised Genesis repairer as soon as possible.

Rear Wheel Steering (RWS)

tif equipped

The Rear Wheel Steering system helps increase vehicle maneuverability and improve vehicle stability by using an electric motor to control the steering angle of the rear wheels according to the driving speed of the vehicle and the steering angle of the front wheels.

When driving at low speed, turning radius is reduced by steering the rear wheels in the opposite direction of the front wheels to increase maneuverability. At high speeds, the rear wheels are steered in the same direction as the front wheels to improve stability when turning and changing direction.

NOTICE

When using snow chains, be sure to turn off the Rear Wheel Steering by selecting "Snow chains installed" from the Settings menu in the infotainment system to protect the vehicle. After removing the snow chains, deselect "Snow chains installed" from the Settings menu in the infotainment system. If it is not deselected, Rear Wheel Steering will not operate. For more details on setting the menu, refer to the "Winter driving" section in chapter 6.

A CAUTION

- If there is a problem with the Rear Wheel Steering system, a warning light and warning message appears on the instrument cluster and Rear Wheel Steering system stops working. If the warning light and warning message are still displayed even when the vehicle is stopped and the vehicle is restarted, have the vehicle checked by an authorised Genesis repairer.
- If the Rear Wheel Steering system operation is stopped when the rear wheels are not straight, the vehicle may lean to one side whilst driving.

i Information

With no warning light on the instrument cluster, the following conditions are normal:

- Immediately after starting the vehicle, Rear Wheel Steering system performs diagnostics and operates normally after about 2 seconds.
- When turning the vehicle on or off, Rear Wheel Steering system can operate for about 2 seconds even though the steering wheel is not steered to check system condition.

- Motor noise may be heard when you steer the vehicle whilst stopping or driving at low speed.
- In driving conditions in which the rear wheels are steered in the same direction as the front wheels when (⋈) is on the instrument cluster by pressing the Lane Following Assist button on the steering wheel or Highway Driving Assist function is activated, keep the rear wheels straight to improve Lane Keeping Assist performance.
- When the Remote Smart Parking Assist function is activated, the Rear Wheel Steering system will stop and the real wheels will remain straight.
- If 'Snow Chains Installed' is selected from the Settings menu in the infotainment system, the Rear Wheel Steering system stops operating, and the rear wheels are straightened.

Tilt / Telescopic steering

Adjust the steering wheel toward your chest, not toward your face. Make sure you can see the instrument cluster warning lights and gauges. After adjusting, push the steering wheel up and down to be in the locked position.

A WARNING

Never adjust the steering wheel whilst driving. This may cause loss of vehicle control resulting in a collision.

NOTICE

Whilst adjusting the steering wheel height, please do not push or pull it hard since the fixture can be damaged.

Power adjustment



To adjust:

- Push the switch (1) up and down to adjust the angle (2).
- Push the switch (1) forward or rearward to adjust the height (3).

NOTICE

Do not adjust the steering wheel longer than necessary when the vehicle is turned off. This may result in unnecessary battery drain.

Resetting the steering wheel power adjustment

If adjustment is no longer possible within the operable range whilst adjusting the steering wheel position (angle or height), reset as follows:

- From the position the steering wheel has stopped, push the control switch (1) for 10 seconds in the direction you were adjusting the steering wheel. The steering wheel moves in the direction the control switch is pushed.
- Continue pushing the switch (1) for at least 2 seconds after the steering wheel has stopped. Resetting is completed after the operational range is recognised.

If the adjustment is still not possible after resetting the steering wheel power adjustment, we recommend that the system be inspected by authorised Genesis repairer.

Horn



To sound the horn, press the area indicated by the horn symbol on your steering wheel (see illustration). The horn operates only when this area is pressed.

NOTICE

Do not strike the horn severely or hit it with your fist. Do not press on the horn with a sharp-pointed object.

Heated steering wheel

tif equipped



Whilst the vehicle is running, touch the heated steering wheel icon to warm the steering wheel.

Manually adjusting temperature

Each time you press the heated steering icon, the temperature changes as follows:

- · Off > High > Low
- Pressing the icon when temperature is low, the heated steering wheel turns off.

Automatically adjusting temperature

- When high is manually selected, the heated steering wheel automatically changes to the low position after 30 minutes. You can turn off the heated steering wheel by pressing the icon to the OFF position.
- When Low is manually selected, the heated steering wheel is not controlled automatically.

Automatic Controls Linked to Climate Control Settings

The heated steering wheel automatically controls the steering wheel temperature depending on the ambient temperature when the vehicle is running.

 To use this feature, enable it from the Settings menu in the infotainment system.

Select: Setup > Vehicle > Seat > Heating/Ventilation > Automatic controls linked to climate control settings > Steering wheel heating

- If you press the heated steering wheel icon when the feature is set, you must control the heated steering wheel manually.
- The heated steering wheel defaults to the OFF position whenever the Start/Stop button is pressed to the DRIVE READY position. However, if the Automatic Controls Linked to Climate Control Settings feature is ON, the heated steering wheel turns on and off depending on the outside temperature.

i Information

The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference quide.

NOTICE

- Do not install any cover or accessories on the steering wheel to prevent damage to the heated steering wheel system.
- Do not strike the steering wheel grip surface with sharp sharp-pointed objects. This may damage the heating element in the steering wheel.
- Do not clean the steering wheel surface using the following products.
 - Organic solvents such as thinner, alcohol, and petrol
 - Chemical products such as leather cleaner, coating agent, and wax

Steering wheel grip sensor

Whilst driving the vehicle with the Driver Assistance system on, it detects whether the driver is holding the steering wheel and displays the Hands-off warning when the driver is not holding the steering wheel. Refer to "Hands-off warning" from "Lane Keeping Assist (LKA)", "Lane Following Assist (LFA)", and "Highway Driving Assist (HDA)" sections in chapter 7 for details.

In the following situations, the sensor may fail to detect the driver's hands even though the driver is holding the steering wheel.

- · When the driver is wearing gloves.
- When accessories such as a cover is attached on the steering wheel.
- When an electronic device is touching the steering wheel.
- · When the steering wheel is wet.

A CAUTION

The steering wheel sensor may not work properly if the following precautions are not followed.

- Do not modify the steering wheel cover.
- Do not attach accessories on the rim of the steering wheel.
- Do not touch the steering wheel with electronic devices. (for example, laptop, tablet PC, etc.)
- Do not touch the steering wheel with metallic or conductive objects. (for example, tumbler, soda can, etc.)
- Do not excessively wet the steering wheel. (for example, spilled water, wet tissue, vapour from steam wash)

Haptic warning / Steering Wheel Vibration Warning

If equipped with haptic steering wheel, the Driver Assistance system vibrates the steering wheel to warn the driver when the system indicates hazardous situations.

Setting haptic warning

Whilst the vehicle is running, select:

Setup > Vehicle > Driver assistance > Warning methods> Haptic warning in the infotainment system.

See description of each function from "Driver assistance system" in chapter 7 for details.

Mirrors

Inside rear-view mirror

Before driving your vehicle, check to see that your inside rear-view mirror is properly positioned. Adjust the rear-view mirror so that the view through the rear window is properly centred.

A WARNING

Make sure your line of sight is not obstructed. Do not place objects on the rear seat or in the luggage compartment that may interfere with your vision through the rear window.

A WARNING

To prevent serious injury during a collision or deployment of the airbag, do not modify the rear-view mirror and do not install a wide mirror.

A WARNING

Never adjust the mirror whilst driving. This may cause loss of vehicle control and result in a collision.

NOTICE

When cleaning the mirror, use a paper towel or similar material dampened with glass cleaner. Do not spray glass cleaner directly on the mirror as this may cause the liquid cleaner to enter the mirror housing.

Electric Chromic Mirror (ECM)



[A] Sensor

When the vehicle is running, the glare from vehicle headlamps behind you is automatically controlled by the sensor mounted in the rear-view mirror.

Whenever the the gear is shifted to R (Reverse), the mirror automatically goes to the brightest setting in order to improve the driver's view behind the vehicle.

Outside rear-view mirrors



Your vehicle is equipped with both left-hand and right-hand outside rear-view mirrors. The mirrors can be adjusted remotely with the mirror adjustment control switch. Adjust the outside rear-view mirrors to your desired position before driving.

A WARNING

Both outside rear-view mirrors are convex. Objects seen in the mirror are closer than they appear.

Use the inside rear view mirror or turn your head and look directly to determine the actual distance of other vehicles prior to changing lanes.

A WARNING

Do not adjust or fold the outside rear-view mirrors whilst driving. This may cause loss of vehicle control resulting in a collision.

NOTICE

- Do not scrape ice off the mirror face.
 This may damage the surface of the glass.
- If the mirror is jammed with ice, do not adjust the mirror by force. Use an approved de-icer (not radiator antifreeze) spray, or a sponge or soft cloth with very warm water, or move the vehicle to a warm place and allow the ice to melt.
- Do not clean the mirror with harsh abrasives, fuel, or other petroleum based cleaning products.

Adjusting the rear-view mirrors



- Press the L (Left side) or R (Right side) button (1) to select the rear-view mirror you want to adjust.
- 2. Use the mirror adjustment control (2) to position the selected mirror up, down, left, or right.
- After adjustment, press both L and R button off (indicator light off) to prevent unintended adjustment.

NOTICE

- The mirrors stop moving when they reach the maximum adjusting angles, but the motor continues to operate whilst the switch is pressed. Do not press the switch longer than necessary, because this can damage the motor.
- Do not adjust the outside rear-view mirrors by hand to prevent damage to the motor.

Folding the rear-view mirrors

Folding button

Press the button to fold or unfold the outside rear-view mirrors.



Infotainment system setting

- Enable on door unlock
 - If Setup > Vehicle > Welcome mirror/light > Enable on door unlock is selected from the Settings menu in the infotainment system,
 - The mirrors folds or unfolds when the door is locked or unlocked by the smart key.
 - The mirrors folds or unfolds when the door is locked or unlocked by the touch sensor on the outside door handle.
- Enable on driver approach

If Setup > Vehicle > Welcome mirror/light > Enable on driver approach is selected from the Settings menu in the infotainment system, the mirror unfolds when the vehicle is approached with the smart key in possession.

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

NOTICE

The electric type outside rear-view mirrors operates even though the Start/Stop button is in the OFF position. However, to prevent unnecessary battery discharge, do not adjust the mirrors longer than necessary whilst the vehicle is not running.

NOTICE

Do not fold the electric type outside rear-view mirrors by hand. It could cause motor failure.

Reverse parking aid

tif equipped



When the gear is shifted to the R (Reverse) position, the outside rear-view mirrors rotates downward to aid with driving in reverse.

The state of the outside rear-view mirrors button (1) determines whether or not the mirrors move:

How it works

- When the L or R button (1) is pressed (indicator lights ON), both outside rear-view mirrors move.
- If the L and R buttons (1) are not pressed (indicator lights OFF), both outside rear-view mirrors do not move.

The outside rear-view mirrors automatically revert to their original positions if any of the following occur:

- The Start/Stop button is pressed to either the OFF position or the POWER ON position.
- The gear is shifted to any position except R (Reverse).
- The outside rear-view mirrors adjustment button is not selected.

Reverse parking aid user settings mode

You may change the angle of an outside rear-view mirror if it is difficult to see the rear view with the basic downward mirror angle provided when reversing.

When the vehicle is first delivered, the set downward angle of the left and right outside rear-view mirrors are different to ensure driver visibility.

- 1. Make sure the vehicle is stopped.
- Press the brake pedal and shift the gear to R (Reverse). When L (Left) or R (Right) button is pressed, both outside rear-view mirror angle will move downward to the basic set position.
- 3. Press either L or R button to select the outside rear-view mirror you would like to adjust. Then press "▼, △, ◄, ▶" switch to adjust that outside rear-view mirror to the desired angle.
- 4. After adjusting the angle to save the adjusted outside rear-view mirror angle, shift the gear to another position other than R (Reverse), or change the L and R buttons to the neutral position (L and R buttons are not pressed).
- 5. Set the other outside rear-view mirror following the above procedure 1 to 4.


Resetting reverse parking aid user settings mode

To change the outside rear-view mirrors angle back to the basic angle, shift the gear to R (Reverse), and adjust the mirror angle higher than when the gear is in P (Park), N (Neutral) and D (Drive).

NOTICE

When changing the angle of both outside rear-view mirrors, it is recommended to change the angle one side at a time following the procedure 1 to 4.

Windows



- (1) Driver's door power window switch
- (2) Front passenger's door power window switch
- (3) Rear door (right) power window switch
- (4) Rear door (left) power window switch
- (5) Power window lock switch

Power windows

The Start/Stop button must be in the POWER ON or DRIVE READY position to be able to raise or lower the windows. Each door has a Power Window switch to control the door's window. The driver has a Power Window Lock button that can block the operation of rear passenger windows. The power windows operate for about 3 minutes after the Start/Stop button is in the ACC or OFF position, as long as the front doors remain closed.

If the front doors are opened, the battery power is turned OFF and the Power Windows do not operate.

Window opening and closing



To open:

Press the window switch down to the first detent position (1). Release the switch when you want the window to stop.

To close:

Pull the window switch up to the first detent position (1). Release the window switch when you want the window to stop.

Auto up/down window

Pressing or pulling up the power window switch momentarily to the second detent position (2) completely lowers or lifts the window even when the switch is released. To stop the window at the desired position whilst the window is operating, pull up or press down and release the switch.

Resetting the power windows

If the power windows do not operate normally, the automatic power window system must be reset as follows:

- 1. Press the Start/Stop button to the POWER ON or DRIVE READY position.
- Close the window and continue pulling up on the power window switch for at least one second.

If the power windows do not operate properly after resetting, we recommend that you contact an authorised Genesis repairer.

A WARNING

Make sure body parts or other objects are out of the way before closing the windows. The automatic reverse feature does not operate whilst resetting the power window system.

Automatic reversal



If a window senses any obstacle whilst it is closing automatically, it stops and lowers about 30 cm to allow the object to be cleared.

If the window detects any resistance whilst the power window switch is pulled up continuously, the window stops upward movement and then lowers about 2.5 cm.

If the power window switch is pulled up continuously again within 5 seconds after the window is lowered by the automatic window reverse feature, the automatic window reverse does not operate.

i Information

The automatic reverse feature is active only when the "Auto Up" feature is used by fully pulling up the switch to the second detent.

NOTICE

Do not install any accessories on the windows. The automatic reverse feature may not operate.

WARNING

Make sure body parts or other objects are safely out of the way before closing the windows to avoid injuries or vehicle damage.

Objects less than 4 mm in diameter caught between the window glass and the upper window channel may not be detected by the automatic reverse window and the window does not stop and reverse direction.

Power window lock button



The driver can disable the power window switches on the rear passenger doors by pressing the power window lock button.

When the power window lock button is pressed:

- The driver's master control can operate all the power windows.
- The front passenger's control can operate the front passenger's power window.
- The rear passenger's control cannot operate the rear passengers' power window.

WARNING

Do not allow children to play with the power windows. Keep the driver's door power window lock button in the LOCK position. Serious injury or death may result from unintentional window operation by a child.

NOTICE

- To prevent possible damage to the power window system, do not open or close two windows or more at the same time. This also ensures the longevity of the fuse.
- Never try to operate the main switch on the driver's door and the individual door window switch in opposite directions at the same time. If this is done, the window stops and cannot be opened or closed.

Remote window opening/closing feature (Remote Window Control)



You can open or close the window remotely with the smart key.

Closing the window

Press and hold the door lock button (2) for more than 3 seconds, whilst the vehicle is turned off.

- Windows move up after the doors are locked.
- Window movement stops when you release the door lock button.

Opening the window

Press and hold the door unlock button (1) for more than 3 seconds, whilst the vehicle is turned off.

- Windows move down after the doors are unlocked.
- Window movement stops when you release the door unlock button.

A CAUTION

- If the distance between the vehicle and your smart key changes whilst the window is being opened or closed, the window may stop operating. Do not stand too far away from the vehicle when remotely opening or closing the window.
- Windows stop closing if they encounter a certain force. After you close the windows remotely, make sure all windows are properly closed.
- The doors are unlocked when you open the windows with the remote opening feature.

Bonnet

Opening the bonnet

- 1. Park the vehicle and apply the parking brake.
- 2. Pull the release lever to unlatch the bonnet. The bonnet pops open slightly.



 Go to the front of the vehicle, raise the bonnet slightly, push up the secondary bonnet release lever (1) inside of the bonnet centre and lift the bonnet (2).

After the bonnet has been lifted halfway, it is raised completely by itself.



Closing the bonnet

- Before closing the bonnet, check in and around the motor compartment to ensure the following:
 - Any tools or other loose objects have been removed.
 - All glove, rags, or other combustible material have been removed.
 - All filler caps are tightly and correctly installed.
- 2. Lower the bonnet until it is about 30 cm above the closed position and then let it drop.



Check the bonnet has locked properly.
 If the bonnet is raised slightly, open it again and drop it from a little higher.
 Check again.

WARNING

- Before closing the bonnet, ensure all obstructions are removed from around the bonnet opening.
- Always double check to make sure that the bonnet is firmly latched before driving away. Check there is no bonnet open warning light or message displayed on the instrument cluster. Driving with the bonnet open may cause a total loss of visibility, resulting in a collision.
- Do not move the vehicle with the bonnet raised. It may block your vision and may result in a collision.

Non-Powered Boot



Opening the boot

- 1. Make sure the vehicle is shifted to P (Park) and engage the parking brake.
- 2. Then do one of the following:
 - Press the Smart Key Boot Open button (1) for more than one second.
 - Press the button on the boot itself with the Smart Key in your possession.

Outside



· Use the boot release button.

Inside



3. Lift the boot lid up.

Closing the boot

Lower the boot lid and press down until it locks. To be sure the boot lid is securely fastened, always check by trying to pull it up again.

A WARNING

Always keep the boot lid completely closed whilst the vehicle is in motion. If it is left open or ajar, poisonous exhaust gases containing carbon monoxide (CO) may enter the vehicle and serious illness or death may result.

i Information

To prevent damage to the boot lift cylinders and the attached hardware, always close the boot before driving.

NOTICE

In cold and wet climates, boot lock and boot mechanisms may not work properly due to freezing conditions.

A WARNING

Your vehicle should be kept locked and keys should be kept out of the reach of children. Parents should teach their children about the dangers of playing in the boot.

Emergency boot safety release



Your vehicle is equipped with an Emergency Boot Safety Release lever located inside the boot. When someone is inadvertently locked in the boot, the boot can be opened by moving the lever in the direction of the arrow and pushing the boot open.

▲ WARNING

- You and your passengers must be aware of the location of the Emergency Boot Safety Release lever in this vehicle and how to open the boot in case you are accidentally locked in the boot.
- NEVER allow anyone to occupy the boot of the vehicle at any time. If the boot is partially or totally latched and the person is unable to get out, serious injury or death could occur due to lack of ventilation, exhaust fumes and rapid heat build-up, or because of exposure to cold weather conditions. The boot is also a highly dangerous location in the event of a crash because it is not a protected occupant space but is a part of the vehicle's crush zone.
- Your vehicle should be kept locked and the Smart Key should be kept out of the reach of children. Parents should teach their children about the dangers of playing in boots.
- Use the release lever for emergencies only.


Boot release lever

When the vehicle battery is discharged or the boot needs to be opened manually:

 Open the cover at the centre of the rear seat. Pull the lever on the back of the cover all the way.



2. With the lever pulled to the end, fix the lever (2) on the projecting part (1).



- 3. Lift and open the boot manually.
- 4. Remove the inserted lever to close the boot.

▲ WARNING

Make sure to at least have minimum space at the back and in the upper area of the boot when opening or closing the boot. If not, the boot may hit the surrounding objects (wall, ceiling, vehicle, etc.) and result in damaging the vehicle or injuring the person near.

Power boot



Power boot operating conditions

The power boot operates when vehicle speed is below 3 km/h.

WARNING

- Never leave children or animals unsupervised in your vehicle. Children may operate the power boot. Doing so can result in injury to themselves or others and can damage the vehicle.
- Make sure there are no people or objects and enough space around the boot before operating the power boot or smart boot prior to use. Serious injury, damage to the vehicle or damage to surrounding objects (for example, walls, ceilings, vehicles, etc.) may result if contact with the boot occurs.
- Make sure there are no people or objects around the boot before operating the power boot. Wait until the boot is opened fully and stopped before loading or unloading cargo from the vehicle.
- Always keep the boot lid completely closed whilst the vehicle is in motion. If it is left open or ajar, poisonous exhaust gases containing carbon monoxide (CO) may enter the vehicle and serious illness or death may result.
- If there are obstacles such as snow on the boot, the boot may not open automatically. After removing the obstacle, try to open it again.

- The boot may not open or may close unintentionally injuring people around the boot in the following situations:
 - There is a lot of snow on the boot.
 - There is a heavy object on the boot such as a bicycle carrier, ladder, etc.

Do not open the boot before removing snow or heavy object on the boot.

NOTICE

- Do not close or open the power boot manually. This may cause damage to the power boot. If it is necessary to close or open the power boot manually when the battery is discharged or disconnected, do not apply excessive force.
- Do not operate the power boot more than 10 times continuously when the vehicle is not running. Use the power boot with the vehicle running when the power boot is used repeatedly to prevent battery discharge.
- Do not leave the boot open for a long period of time. This may drain the battery.
- Do not modify or repair any part of the power boot by yourself. This must be done by an authorised Genesis repairer.
- Do not operate the power boot under the following conditions. The power boot may not operate properly.
 - One side of the vehicle is lifted to inspect the vehicle or change a tyre.
 - Parking on an uneven road such as a slope, etc.
- Close the boot completely and lock all doors and boot using the central door lock button before using an automatic car wash.
- Do not spray high pressure water directly on the power boot outside open/close button. The boot may open unintentionally.

i Information

- In cold and wet climates, the outside power boot open button may not work properly due to freezing conditions. If this occurs, remove the ice before using the outside power boot open/close button or use the power boot open/close button on the smart key or the instrument panel.
- If you leave the smart key in the boot and close the boot, a warning will sound for about 5 seconds. If this occurs, open the boot by pressing the power boot open button on the outside of the boot.
- Be careful where there is an incline, as the boot lid may drop slightly when it is stopped before it fully opens.

Operating the power boot

Power boot open/close button (Smart key, Instrument panel)

Smart key



When the boot is closed, press the power boot open/close button for 1.5 second. The boot will open with a warning sound.

When the boot is opened, press and hold the power boot open/close button to close the boot. If you release the button whilst the boot is closing, power boot operation will stop with a warning sound for 5 seconds. Also, if the Smart key is not within operation range from the vehicle, boot operation will stop with a warning sound for 5 seconds.

Instrument panel



When the boot is closed, press the power boot open/close button for 1 second. The power boot will open with a warning sound.

When the boot is opening, press the button to stop power boot operation.

When the boot is opened, press and hold the boot open/close button to close the power boot. If you release the button whilst the boot is closing, power boot operation will stop with a warning sound for 5 seconds.

Power boot open button (Outside the power boot)



When the boot is closed, press the power boot open button (1) to open the boot.

If the vehicle is locked, press the power boot open button with the smart key in your possession.

Whilst the boot is opening, press the button to stop power boot operation.

Power boot close button (Inside the power boot)



Press the power boot close button. The boot will close with a warning sound.

When the boot is closing, press the button to stop power boot operation.

Power boot lock button (Inside the power boot)



Press the power boot lock button whilst carrying the smart key. The power boot will close and lock with a warning sound. Additionally, all doors will lock.

The boot will close and lock, and all doors will lock only when the vehicle is off.

Switching the power boot from manual to automatic

If you apply over a certain amount of power manually when the boot is opened, the power boot system detects the direction and closes or opens automatically.

- The power boot fully opens when the boot is raised
- The power boot closes completely when the boot is lowered

i Information

The power boot may not operate properly if the boot is not opened above a certain height.

Automatic reversal

During power boot operation if the power boot senses any obstacle, the boot stops or fully opens. The automatic reverse feature may not operate properly, or it may operate unexpectedly under the following circumstances:

- The automatic reverse feature may not detect the resistance if the detected resistance is below a certain level, or if the boot is almost fully closed near the latched position.
- The automatic reverse feature may operate if a strong impact is applied with no obstructions placed.

A WARNING

Never intentionally place any object or part of your body in the path of the power boot to test the automatic reverse feature operation. Serious injury, or damage to the vehicle or object may occur.

i Information

The power boot may stop operating if the automatic reverse feature operates more than two times whilst attempting to open or close the boot. If this occurs, carefully open or close the boot manually, and then after 30 seconds try to operate the power boot automatically again.

Setting the power boot

To use each feature, you must select the opening height from the settings menu. Deselect the settings when you do not want to use the feature.

Power boot opening height

To adjust the power boot opening height, select Setup > Vehicle > Door > Power Trunk height > Full open/Level 3/Level 2/Level 1/User height setting in the infotainment system.

User height setting

- 1. Position the boot manually to the height you prefer.
- Press the power boot open/close button located inside the boot for more than 3 seconds.

If **User height setting** is selected for the power boot opening height, the power boot will automatically open to the height manually set by you.

i Information

- If the power boot opening height has not been manually set, the power boot will fully open when User height setting from the infotainment system is selected.
- If one of the height setting (Full open/Level 3/Level 2/Level 1) is selected from the settings menu in the infotainment system, and then User height setting is selected, the boot will open to the height manually set by you.
- The power boot opening speed and opening height settings change according to the linked User Profile. If the User Profile is changed, power boot opening speed and opening height settings will change accordingly.

 The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Resetting the power boot

In some circumstances resetting the power boot operation may need to be performed. Some instances where resetting the power boot may be required include:

- When the 12 V battery is recharged
- When the 12 V battery is reinstalled after removal or replacement
- When the related fuse is reinstalled after removal or replacement
- 1. With the vehicle off or running, put the gear in P (Park).
- Press the power boot open outside button. The power boot will open with a chime sound.

Wait until the boot fully opens to complete resetting. If the boot stops before it is fully open, resetting cannot be completed.

- 3. Slowly close the boot manually.
- Wait until the boot fully opens to complete resetting. If the boot stops before it is fully open, resetting cannot be completed.

i Information

If the power boot does not operate properly after the above procedure, we recommend that the system be inspected by an authorised Genesis repairer.

Emergency boot safety release

Inside the boot



Your vehicle is equipped with an emergency boot safety release lever located inside the boot. When someone is inadvertently locked in the boot, the boot can be opened by moving the lever in the direction of the arrow and pushing the boot lid to open.


Inside the vehicle

Follow the below procedure to open the boot manually when the battery is discharged or when there is a problem with the vehicle:

1. Open the pass through cover at the centre of the rear seat.



- 2. Pull the boot release lever, that is located behind the left side of the pass through cover, all the way back.
- 3. With the lever pulled to the end, fix the lever (2) on the projecting part (1).



- 4. Lift and open the boot manually.
- 5. Place manual boot release lever back to original position or boot will not close.

WARNING

- For emergencies, be fully aware of the location of the emergency boot safety release latch in the vehicle and how to open the boot if you are accidentally locked in the boot.
- No one, including animals, should be allowed to occupy the boot of the vehicle at any time. The boot is a very dangerous location in the event of a collision.
- Use the release latch for emergencies only. Use extreme caution, especially whilst the vehicle is moving.

Smart boot

+if equipped



Using smart boot

The hands-free smart boot system can be used when:

- The smart boot option is enabled in the Settings menu in the infotainment system.
- The smart boot is activated and ready 15 seconds after all the doors are closed and locked.
- The smart boot opens when the smart key is detected in the area behind the vehicle for 3 seconds.

i Information

The smart boot does not operate when:

- A door is not locked or closed.
- The smart key is detected within 15 seconds from when the doors were closed and locked.
- The smart key is detected within 15 seconds after the doors are closed and locked, and within 1.5 m from the front door handles. (for vehicles equipped with Welcome light).
- The smart key is in the vehicle.

1. Settings

To use smart boot, enable it from the Settings menu in the infotainment system. Select:

 Setup > Vehicle > Door/Boot > Smart boot

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

2. Detect and Alert



The smart boot detecting area extends about 50-100 cm behind the vehicle. If you are positioned in the detecting area and are carrying the smart key, the hazard warning lights blink and the chime sounds 6 times before opening.

i Information

If you unintentionally enter the detecting area and the hazard warning lights and chime starts, move away from the vehicle with the smart key. The boot remains closed.

3. Automatic opening

After the hazard warning lights blink and the chime sounds 6 times, the smart boot opens.

Deactivating smart boot

If you press any button on the smart key during the Detect and Alert stage, the smart boot is deactivated.

- If you press the door unlock button, the smart boot is deactivated temporarily.
 If you do not open any door for 30 seconds, the smart boot is activated again.
- If you press the boot open button for more than 1 second, the boot opens.
- The smart boot is still activated if you press the door lock button or boot open/close button as long as the smart boot is not in the Detect and Alert stage.

Detecting area


i Information

- The smart boot may not operate properly if any of the following occur:
 - The smart key is close to a radio transmitter such as a radio station or airport that may interfere with normal operation of the transmitter.
 - The smart key is near a mobile two way radio system or a mobile phone.
 - Another vehicle's smart key is being operated close to your vehicle.
- Smart boot detecting area may change when:
 - The vehicle is parked on an incline or slope.
 - One side of the vehicle is lifted or lowered relative to the opposite side.

Electric charging door

Opening the electric charging door

- 1. Press the brake pedal and apply the parking brake.
- 2. Shift to P (Park), and turn the vehicle off.
- 3. [Outside] With the vehicle door unlocked, press the triangle symbol (A) to open the charging door.



[Inside] Press the charging door button in the instrument panel.



4. Open the charging inlet cover and charge the vehicle.

i Information

- The charging door automatically closes when:
 - The charging connector is disconnected
 - The door is opened and the charging connector is not connected for a certain period of time

- The gear is not in P (Park)
- After replacing battery (12 V), open and close the charging door once to check that the charging door automatic opening mechanism is functioning properly.

NOTICE

Do not pry on the charging door or use unauthorised tools to open the charging door.

NOTICE

- If the charging door does not open because ice has formed around it, tap lightly or push on the door to break the ice and release the door. If necessary, use hand temperature to melt down the ice or move the vehicle to a warm place and allow the ice to melt.
- Make sure that the charging door is closed before driving the vehicle. If the charging door is open, mechanical parts of the charging door can be damaged.
- After closing the charging door, be sure to check the warning light is off.
- After charging the vehicle, close the charging inlet properly. If not, the charging inlet and the charging door can be damaged.
- Whilst washing the vehicle, do not spray high pressure water onto the charging door directly. The high pressure can damage the charging door.
- Do not hold the hinge. It may damage the charging door

For more information, refer to the "Charging your electric vehicle" section in chapter 1.

Head-Up Display (HUD)



The head-up display is an optional feature that allows the driver to view information projected onto a transparent screen whilst still keeping your eyes safely on the road ahead whilst driving.

Head-up display settings




- Head-up display can be enabled from the Settings menu in the infotainment system. Select:
 - Setup > Vehicle > Head-up display > Enable head-up display
- After turning on the head-up display, you can change the settings of **Display** adjustment and **Content selection** of the head-up display.

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Head-up display information



- (1) Turn by Turn (TBT) navigation information
- (2) Surrounding vehicle information (if equipped)
- (3) SCC vehicle distance
- (4) Traffic signs or speed limit
- (5) Blind-Spot Safety
- (6) Highway Driving Assist
- (7) SCC set speed
- (8) Lane Following Assist
- (9) Highway Auto Speed Change
- (10)Speedometer
- (11) Lane Safety

Precautions whilst using the head-up display

- It may sometimes be difficult to read information on the head-up display in the following situations:
 - The driver is improperly positioned in the driver's seat.
 - The driver wears polarizing-filter sunglasses.
 - An object is located above the head-up display cover.
 - The vehicle is driven on a wet road.
 - Any improper lighting accessory is installed inside the vehicle, or there is light coming in from outside the vehicle.
 - The driver wears glasses.
 - The driver wears contact lenses.

When it is difficult to read the head-up display information, adjust the image height or brightness level from the Settings menu in the infotainment system.

- Only change the settings after parking your vehicle at a safe location.
- Do not tint the front windscreen glass or add other types of metallic coating. Otherwise, the head-up display image may be invisible.
- Do not place any accessories on the instrument panel or attach any objects on the windscreen glass.
- When replacing the front windscreen glass, replace it with a windscreen glass designed for head-up display operation. Otherwise, duplicated images may be displayed on the windscreen glass.

WARNING

The warning information of Blind-Spot Safety on the head-up display is a supplemental function only. Do not solely depend on the function to change lanes. Always take a look around before changing lanes.

i Information

Head-Up Display includes GPL, LGPL, MPL and other open source licence softwares. All licence notices including related source code are provided at http://www.mobis.co.kr/opensource/list. do. If the driver requests on-board software open source code via MOBIS_OSSrequest@mobis.co.kr within 3 years after buying this product, a CD-ROM or other storage device will be sent with the minimum cost covering storage device cost and delivery cost.

OTA software update

The OTA (Over-the-Air) software update feature allows you to wirelessly update software to the latest version. Using this feature, you can keep your vehicle system up to date with the latest software.

i Information

The OTA software update feature is only available for Genesis Connected Services users.

Downloading software

The latest software can be downloaded automatically whilst driving. After the latest software has been successfully downloaded, you will receive a notification on your phone or the vehicle screen that the software update is available.

Approving software update



After the vehicle is turned off, the vehicle system allows you to start the update.

- To start the update, press Start (1).
- To postpone the update, press Later (2).

Preparing software update


If you press the **Start** button on the screen, the vehicle begins installing the update automatically. The following conditions must be satisfied:

- · The vehicle must be off.
- The gear must be in P (Park).
- The Electronic Parking Brake (EPB) must be applied.
- · The exterior lights must be turned off.
- · The bonnet must be closed.
- The battery level must be sufficient.
- The systems to be updated must not be running.



- To update immediately, press Update now.
- To cancel the update, press Cancel update.

Updating software



You can see the progress of the update on the screen.



After the update is complete, you will receive a notification on your phone, e-mail, or the vehicle screen that the software update is complete.

i Information

The screen turns off automatically after 3 minutes to save the battery. If the screen turns off automatically, you can check the update progress by pressing the Start/Stop button.

i Information

- After the update starts, you can exit the vehicle.
- The update details may vary depending on the installed software version.
- Check the notice for the OTA software update on the Genesis brand website.
- If the update fails, the update recovery will automatically proceed. If you want to retry the software update, even after a successful recovery, we recommend that you contact an authorised Genesis repairer.
- If the update or recovery fails, we recommend that you contact Genesis Call Centre.
- After the update is complete, it may provide new functions or improvements. For more information, refer to the "OTA Software Update" page on the Genesis brand website.

NOTICE

- Observe the following restrictions during the update.
 - You cannot use the vehicle during the update. Be sure to have enough time for the update, and safely park the vehicle before starting the update process.
 - You cannot use remote features, including remote start.
 - Vehicle charging is not available.
 Charge the vehicle after the update is complete.
 - The Rear Occupant Alert feature may not work. Check if there are any occupants in the rear seat.
- The update will be automatically cancelled if any vehicle conditions required for the update are changed before starting the update.
- Note that the high-voltage-related modules for charging the 12 V battery may work during the update.
- Once the update has started, you cannot cancel the update.
- You cannot use the OTA software update feature if you modify or replace any vehicle software.
- Do not open the bonnet or replace the battery in the vehicle during the update. The update may fail.
- If a diagnostic tool of any kind is connected to the vehicle OBD (On-Board Diagnostic) terminal, the vehicle cannot be updated. The vehicle can be updated by removing the diagnostic tool connected to the OBD terminal and then restarting the vehicle.
- If the update is not completed successfully, we highly recommend that you contact an authorised Genesis repairer.

Exterior lights

Lighting control

To operate the lights, turn the switch at the end of the control lever to one of the following positions:



- (1) OFF
- (2) AUTO headlamps
- (3) Parking lamps
- (4) Headlamps

Daytime Running Lights (DRL)

The Daytime Running Lights (DRL) can make it easier for others to see the front of your vehicle during the day, especially after dawn and before sunset.

The DRL system turns off the dedicated lamp when:

- The headlamps are ON.
- The parking brake is applied.
- · The vehicle is turned off.

AUTO headlamps





The parking lamps and headlamps are turned ON or OFF automatically depending on the amount of daylight as measured by the ambient light sensor [A] at the upper end of the windscreen glass. Even with the AUTO headlamps feature in operation, it is recommended to manually turn ON the headlamps when driving at night or in a fog, driving in the rain, or when you enter dark areas, such as tunnels and parking facilities.

NOTICE

- Do not cover or spill anything on the sensor [A] located at the upper end of the windscreen glass.
- Do not clean the sensor using a window cleaner, the cleaner may leave a light film which could interfere with sensor operation.
- If your vehicle has window tint or other types of metallic coating on the front windscreen, the AUTO headlamps system may not work properly.

Parking lamps



The parking lamps, licence plate lamps and instrument panel lamps are turned ON.

Headlamps



The headlamps, parking lamps, licence plate lamps, and instrument panel lamps are turned ON.

i Information

The Start/Stop button must be in the DRIVE READY position to turn on the headlamps.

High beam operation



To turn on the high beam headlamps, push the lever away from you. The lever returns to its original position.

The high beam indicator illuminates when the headlamps high beams are switched on.

To turn off the high beam headlamps, pull the lever toward you. The low beams turn on.



To flash the high beam headlamps, pull the lever toward you, then release the lever. The high beams remain ON as long as you hold the lever.

Turn signals and lane change signals



To signal a turn, push down on the lever for a right turn or up for a left turn in position [A].

If an indicator stays on and does not flash or if it flashes abnormally, one of the turn signal bulbs may be burned out and require replacement. We recommend that you contact an authorised Genesis repairer.

One touch turn signal

To use One Touch Turn Signal, push the turn signal lever up or down to position [B] and then release it.

The lane change signals blinks 3, 5 or 7 times.

You can enable the One Touch Turn Signal function or choose the number of blinking by selecting Setup > Vehicle > Lights > One-touch indicator > 3 flashes/5 flashes/7 flashes/Off in the infotainment system.

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Battery saver function

To prevent the battery discharging, the system automatically turns off the parking lamps when the driver turns the vehicle off and opens the driver's door.

To keep the lamps on when the vehicle is turned off:

- 1. Open the driver's door.
- Turn the parking lamps OFF and ON again using the headlamps switch.

Headlamps delay function

If the Start/Stop button is in the OFF position with the headlamps ON, the headlamps (and/or parking lamps) remain on for about 5 minutes. If the driver's door is opened and closed, the headlamps are turned off after 15 seconds. Also, with the vehicle off if the driver's door is opened and closed, the headlamps (and/or parking lamps) are turned off after 15 seconds.

The headlamps (and/or parking lamps) can be turned off by pressing the lock button on the smart key twice or turning the headlamp switch to the OFF or AUTO position.

You can enable the headlamp delay function by selecting **Setup** > **Vehicle** > **Lights** > **Head lamp delay** in the infotainment system.

i Information

- When the Headlamps delay function is turned on in the infotainment system, the dynamic welcome light function of the welcome system will also operate as well. For more information, refer to the "Welcome system" section in this chapter.
- The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

NOTICE

If the driver exits the vehicle through another door besides the driver's door, the battery saver function does not operate and the headlamps delay function does not turn OFF automatically.

To avoid battery discharge, turn OFF the headlamps manually before exiting the vehicle

Headlamps levelling device

Headlamps levelling device automatically adjusts the headlamps beam level according to the number of passengers and loading weight in the luggage compartment.

It also adjusts to the appropriate headlamp beam level for various situations.

A WARNING

If the function does not work properly, we recommend that the system be inspected by an authorised Genesis repairer. Do not attempt to inspect or replace the wiring yourself.

Headlamps moisture removal function

When moisture fogs up inside of the headlamps with the headlamps on for a certain period of time, the fan circulates air inside the headlamps to remove moisture. If moisture is not removed, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Reversing guide lamp

When the gear is in R (Reverse), the reversing lamp turns on and the reversing guide lamp at the back of the vehicle lights the floor.

The lamp informs nearby drivers that your vehicle is reversing.

Intelligent Front-lighting System (IFS)

tif equipped

Intelligent Front-Lighting System secures a clear view for the driver with the high beam on whilst driving at night.

System settings



With the Start/Stop button in the DRIVE READY position, select **Setup** > **Vehicle** > **Lights** > **Intelligent High Beams** from the Settings menu to turn on Intelligent Front-Lighting System and deselect to turn off the system.

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

MARNING

Only change the settings after parking your vehicle at a safe location.

System operation



After selecting **Intelligent High Beams** in the Settings menu to operate Intelligent Front-Lighting System:

- Place the headlamps switch in the AUTO position and push the headlamps lever toward the instrument cluster. The Intelligent Front-Lighting System (♣□) indicator light illuminates on the instrument cluster and the system is enabled.
- When the system is enabled, Intelligent Front-Lighting System operates according to the set speed in the infotainment system. The initial system is set to work when vehicle speed is above 40 km/h.
- The high beam LED partially turns off if an oncoming vehicle or a vehicle ahead is detected by the front view camera.
- If Intelligent Front-Lighting System detects an oncoming vehicle or a vehicle ahead whilst driving at high speed (about above 100 km/h, the driver's side headlamp turns off and only the passenger's side headlamp is controlled by the system.


System malfunction and limitations

System malfunction



When Intelligent Front-Lighting System does not work properly, the "Check driver assistance system." warning message may appear for a few seconds on the instrument cluster. After the message disappears, the AFS and A warning lights illuminate on the instrument cluster. We recommend that the system be inspected by an authorised Genesis repairer.

System disabled



When the front view camera is covered or blocked, the Intelligent Front-Lighting System may temporarily not work properly. The "Driver assistance system limited. Camera obscured." warning message may appear on the instrument cluster.

The system operates normally when such foreign material is removed.

WARNING

- Intelligent Front-Lighting System may not operate properly even if there is no warning message or warning light on the instrument cluster.
- Intelligent Front-Lighting System may not operate properly in open areas where no objects are detected (for example, empty car park) or when the detecting sensors are blocked immediately after turning on the vehicle.

Limitations of the system

Intelligent Front-Lighting System may not operate normally:

- The headlamps from an oncoming or front vehicle is damaged or out of the detection range.
- The headlamps from an oncoming or front vehicle are covered with dust, snow, or water.
- An oncoming or front vehicle's headlamps are off but the fog lamps are on.
- There are lamps that have a similar shape as a vehicle's lamp ahead.
- The headlamps are not repaired or replaced properly.
- · The headlamps are not aimed properly.
- You are driving on a narrow curved road, rough road, uphill, or downhill.
- A front vehicle is partially visible on a crossroad or curved road.
- There is a traffic light, reflecting sign, LED sign, or reflectors ahead.
- There is a temporary reflector or flash ahead (construction area).
- The road is wet or covered with snow or ice.
- A vehicle suddenly appears from a curve.
- The vehicle is tilted due to a flat tyre or being towed.
- There are many street lights or the ambient light is bright.
- Light from another vehicle is not detected because of exhaust fumes, smoke, fog, snow, etc.
- The front windscreen is covered with foreign material.

NOTICE

To prevent damage:

- Never disassemble the camera sensors or camera sensor assemblies.
- Only have the detecting sensor replaced or repaired by an authorised Genesis repairer.
- Never install any accessories, stickers, or tint the front windscreen.
- · Always keep the camera dry.
- Never place any reflective objects (for example, white paper, mirror) on the instrument panel.
- Do not use any cleanser containing acid or alkaline detergents when cleaning the camera lenses. Use only a mild soap or neutral detergent, and rinse thoroughly with water.

WARNING

- Always check road conditions, and if necessary, take appropriate actions to drive safely. It is the driver's responsibility to operate your vehicle in a safe manner.
- If Intelligent Front-Lighting System does not operate properly, use the turn signal lever to switch between high beam and low beam.

High Beam Assist (HBA)

tif equipped



High Beam Assist automatically adjust the headlamps between high beam and low beam depending on the light detected from oncoming vehicles or vehicles in front using the front view camera.

Detecting sensor



[A] Front view camera

The front view camera is used as a detecting sensor to detect ambient light and brightness whilst driving.

NOTICE

- Always keep the front view camera in good condition to maintain optimal performance of High Beam Assist.
- Refer to the "Driver Assistance System sensors" section in Chapter 7 for the location and the general precautions of front view camera.

High Beam Assist setting



With the Start/Stop button in the DRIVE READY position, select **Setup** > **Vehicle** > **Lights** > **HBA** (**High Beam Assist**) from the Settings menu to turn on High Beam Assist and deselect to turn off the function.

A WARNING

Only change the settings after parking your vehicle at a safe location.


High Beam Assist operation

- After selecting HBA (High Beam Assist) from the settings menu to operate High Beam Assist:
 - Place the headlamps switch in the **AUTO** position and push the headlamps lever toward the instrument cluster. The High Beam Assist () indicator light illuminates on the instrument cluster and the system will be enabled.
 - When High Beam Assist is enabled, high beams turn on when vehicle speed is above 30 km/h and the high beam (
 indicator illuminates on the instrument cluster.
 - When the vehicle speed is below 20 km/h, high beams do not turn on.

- · When High Beam Assist is operating:
 - If the turn signal lever is pulled toward you when the high beams are off, the high beams turn on. When you let go of the turn signal lever, High Beam Assist operates again.
 - If the turn signal lever is pulled towards you when the high beams are on by High Beam Assist, low beams turn on and High Beam Assist turns off
 - If the headlamps switch is moved from AUTO to another position (headlamps/position/off), the corresponding light turns on and High Beam Assist turns off.
- When High Beam Assist is operating, high beam switches to low beam if:
 - The headlamps of an oncoming vehicle is detected.
 - The tail lamps of a vehicle in front is detected
 - The headlamp or tail lamp of a motorcycle or a bicycle is detected.
 - The surrounding ambient light is bright enough so high beams are not required.
 - Streetlights or other lights are detected.

High Beam Assist malfunction and limitations

High Beam Assist malfunction



When High Beam Assist is not working properly, the "Check driver assistance system." warning message may appear and \(\triangle \) warning light may illuminate on the instrument cluster. We recommend that the system be inspected by an authorised Genesis repairer.

i Information

You can check it in the service message of the normal view mode of the cluster display window.

Limitations of High Beam Assist

High Beam Assist may not operate normally in the following situations if:

- The headlamps from an oncoming or front vehicle is damaged or out of the detection range.
- The headlamps from an oncoming or front vehicle headlamps are covered with dust, snow, or water.
- An oncoming or front vehicle's headlamps are off but the fog lamps are on.
- There are lamps that have a similar shape as a vehicle's lamp ahead.
- The headlamps are not repaired or replaced properly.
- The headlamps are not aimed properly.
- You are driving on a narrow curved road, rough road, uphill, or downhill.
- A front vehicle is partially visible at a crossroad or on a curved road.
- There is a traffic light, reflecting sign, LED sign, or reflectors ahead.
- There is a temporary reflector or flash ahead (construction area).
- The road conditions are bad such as being wet, iced or covered with snow.
- A vehicle suddenly appears from a curve.
- The vehicle is tilted due to a flat tyre or being towed.
- The headlamps from an oncoming or front vehicle is not detected because of exhaust fumes, smoke, fog, snow, blizzard, water spray on the road, or windscreen condensation, etc.

NOTICE

For more information on the limitations of the front view camera, refer to the "Driver Assistance System sensors" section in chapter 7.

A WARNING

- Always check road conditions, and if necessary, take appropriate actions to drive safely. It is the driver's responsibility to operate your vehicle in a safe manner.
- If High Beam Assist does not operate properly, use the turn signal lever to switch between high beam and low beam.

Welcome system



Welcome system helps keep the driver visible by turning on vehicle lights when the driver approaches the vehicle.

Puddle lamp and door handle lamp

When all the doors (and boot) are closed and locked, the puddle lamp and door handle lamp come on for about 15 seconds if:

- When the door unlock button is pressed on the smart key.
- When you put your hand in the outside door handle with the smart key in possession.
- If Setup > Vehicle > Convenience >
 Welcome mirror/light > Enable on
 driver approach is selected from the
 Settings menu in the infotainment
 system, the lights turn on when the
 vehicle is approached with the smart
 key in possession.

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Dynamic welcome light

When the headlamps switch is in the headlamps, parking lamps or AUTO position and all doors (and boot) are closed and locked, the dynamic welcome light comes on when the door unlock button is pressed on the smart key.

i Information

The dynamic welcome light turns on at night when the headlamps switch is in the AUTO position.

The dynamic welcome light operates for about 4 seconds, and at the same time the parking lamps come on for about 15 seconds.

If you press the door lock or door unlock button on the smart key, the dynamic welcome light turns off immediately.

- Select Setup > Vehicle > Lights > Head lamp delay from the Settings menu in the infotainment system to turn on this function.
- Select Setup > Vehicle > Lights >
 Dynamic welcome light > Comfort
 (default setting)/Natural/Dynamic
 from the Settings menu in the
 infotainment system to change modes.

Interior lamp

When the interior lamp switch is in the position and all doors (and boot) are closed and locked, the room lamp come on for 30 seconds when:

- The door unlock button is pressed on the smart key.
- You put your hand in the outside door handle.

If you press the door lock or unlock button on the smart key the lamps turn off immediately.

Interior lamps

A WARNING

Do not use the interior lamps when driving in the dark. The interior lamps may obscure your view and result in a collision.

NOTICE

Do not use the interior lamps for extended periods when the vehicle is turned off. Otherwise, the battery discharges.

Interior lamp AUTO cut


The interior lamps automatically go off about 20 minutes after the vehicle is turned off and the doors are closed. If a door is opened, the lamps go off 25 minutes after the vehicle is turned off. If the doors are locked by the remote key or smart key and the vehicle enters the armed stage of the theft alarm system, the lamps go off five seconds later.

Front lamps




- Map lamp (➣, ➣): Touch either icons to turn the map lamp on or off. This lamp produces a spot beam for convenient use as a map lamp at night or as a personal lamp for the driver and the front passenger.
- **Door lamp**(): The front or rear interior lamps come on when the front or rear doors are opened. When doors are unlocked by the smart key, the front and rear lamps come on for about 30 seconds as long as any door is not opened. The front and rear interior lamps go out gradually after about 30 seconds when the door is closed. However, if the Start/Stop button is in the POWER ON or DRIVE READY position or all doors are locked, the front and rear lamps turn off. If a door is opened with the Start/Stop button in the OFF position, the front and rear lamps stay on for about 5 minutes.
- Interior lamp(茶): Press the button to turn on the interior lamp for the front and rear seats.

Rear interior lamp



- ≈, □: Touch the icon to turn either lamp on or off.
- 달: Touch the icon to turn the mood lamp on or off.

Vanity mirror lamp



Opening the lid of the vanity mirror. The vanity mirror lamp turns on when the lid is opened and off when the lid is closed.

Rear mirror lamp

+if equipped



Press the mirror cover. The cover opens slowly and the mirror lamp turns on.

Glove box lamp



The glove box lamp turns on when the glove box is opened.

Door handle lamp/Foot lamp/Door courtesy lamp



- Door handle lamp [A]: The lamp turns on when the parking lamps are on.
- Foot lamp [B]: The lamp always on.
- Door courtesy lamp [C]: The lamp turns on when a door is open and turns off when the door is closed.

Mood lamp



[A] Door [B] Crash pad [C] Console

If Setup > Vehicle > Lights > Ambient light is selected from the infotainment system, you can adjust the brightness and select colour.

- If Link to drive mode is selected, the mood lamps change colour according to the selected drive mode.
- To turn off the mood lamps, set the brightness level to "0" in the infotainment system.

i Information

- The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.
- The colour of the mood lamp may seem different under some conditions depending on the colour of the interior and the set mood colour.

Interior lights always on

The Interior Lights Always On function turns on the interior button lights regardless of the day or night condition.

You can enable the Interior Lights Always On function by selecting **Setup** > **Vehicle** > **Lights** > **Interior lights on** in the infotainment system.

After the function is enabled, the interior button lights are turned on or off in the following situations:

- When all doors are closed and locked, if you unlock the door, the interior button lights illuminates for about 5 minutes.
- When the vehicle is turned off, the interior button lights are turned on for about 5 minutes. At this time, if you open and close the door or lock the doors, the interior button lights are turned off immediately.

Luggage compartment lamp



The luggage compartment lamp turns on when the boot is opened and off when the boot is closed.

Boot emergency lamp



The boot emergency lamp turns on when the boot is opened.

In case of emergency such as a vehicle breakdown, open the boot to inform surrounding vehicles of the emergency, and activate the emergency warning lights to prevent accidents.

i Information

Keep the boot open when it is necessary, as it may cause battery discharge.

Puddle light



Welcome light

When all doors (and boot) are closed and locked, the puddle light turns on for 15 seconds if the door is unlocked by the smart key or when you put your hand in the outside door handle with the smart key in possession.

For more information, refer to the "Welcome system" section in this chapter.


Escort light

When the Start/Stop button is in the OFF position and the driver's door is opened, the puddle light turns on for 30 seconds. If the driver's door is closed within the 30 second period, the puddle light turns off after 15 seconds. If the driver's door is closed and locked, the puddle light turns off immediately.

The escort light turns on only the first time the driver's door is opened after the vehicle is turned off.

Wipers and washers

Front windscreen wipers



[A] Wiper speed control [B] Intermittent or Auto control wipe time adjustment

Operates as follows when the Start/Stop button is in the DRIVE READY position.

- HI: The wiper runs at a higher speed.
- LO: The wiper runs at a lower speed
- AUTO:

The rain sensor located on the upper end of the windscreen glass senses the amount of rainfall and controls the interval of the wiping cycle.

To change the sensitivity setting, turn the sensitivity control switch.

- OFF: Wipers are not in operation.
- MIST: For a single wiping cycle, push the lever down and release. The wipers operate continuously if the lever is held in this position.

NOTICE

If there is heavy accumulation of snow or ice on the windscreen, defrost the windscreen for about 10 minutes, or until the snow and/or ice is removed to prevent damage to the wiper and washer system.

AUTO (Automatic) control



The rain sensor located at the top of the windscreen glass senses the amount of rainfall and controls the interval of the wiping cycle.

To change the sensitivity setting, turn the sensitivity control switch.

If the wiper switch is set in the AUTO mode when the Start/Stop button is in the DRIVE READY position, the wiper operates once to perform a self-check of the system. Set the wiper to the OFF position when the wiper is not used.

WARNING

To prevent personal injury:

- Do not touch the top of the windscreen glass near the rain sensor.
- Do not wipe the top of the windscreen glass with a damp or wet cloth.
- Do not put pressure on the windscreen glass.

NOTICE

To prevent damage:

- · When washing the vehicle, set the wiper to the **OFF** position to stop the auto wiper operation.
- · Do not remove the sensor cover located at the top of the passenger side windscreen glass.

Front windscreen washers



In the **OFF** position, pull the lever gently toward you to spray washer fluid on the windscreen and to run the wipers 1-3 cycles. The spray and wiper operation continues until you release the lever. If the washer does not work, you may need to add washer fluid to the washer fluid reservoir.

Recirculating air when washer fluid is used

When washer fluid is used, in order to reduce any objectionable scent of the washer fluid from entering the cabin, recirculation mode and air conditioning are automatically activated depending on the outside temperature. If you select fresh mode whilst the function is operating, the function resumes after a certain amount of time. It may not work in some conditions such as cold weather or vehicle OFF.

For more information, refer to the "Climate control additional features" section in this chapter.

A WARNING

When the outside temperature is below freezing, always warm the windscreen using the defroster to help prevent the washer fluid from freezing on the windscreen and obscuring your vision that could lead to a collision and serious injury or death. Always use appropriate washer fluids in the winter season or cold weather.


NOTICE

To prevent damage:

- Do not operate the washer when the fluid reservoir is empty or when the windscreen is dry.
- Do not attempt to move the wipers manually.

Automatic climate control system

Front seat control



The actual shape of climate control system may differ from the illustration.

- (1) Passenger's temperature control
- (2) Air intake control
- (3) SYNC
- (4) Passenger's mode selection
- (5) Rear control
- (6) Blower speed control
- (7) Driver's mode selection
- (8) AUTO (automatic control)
- (9) OFF (system off)
- (10)Driver's temperature control
- (11) Rear window defroster
- (12) Clean air system (if equipped)
- (13)A/C (air conditioning)
- (14) Driver only mode
- (15) Front windscreen defroster

i Information

Use a microfiber cloth when wiping fingerprints off the touchscreen.

Rear seat control from the front



The actual shape of climate control system may differ from the illustration.

- (1) OFF (system off)
- (2) Blower speed control (if equipped)
- (3) AUTO (automatic control)
- (4) Mode selection
- (5) Temperature control

$m{i}$ Information

Use a microfiber cloth when wiping fingerprints off the touchscreen.

Rear seat control

tif equipped



The climate control system may differ depending on vehicle specification.

- (1) Blower speed display
- (2) Mode selection
- (3) Temperature display
- (4) Blower speed control
- (5) OFF (system off)
- (6) AUTO (automatic control)
- (7) Temperature control

i Information

- Temperature, Mode selection (air flow direction), and Blower speed can be controlled from the rear seat. However, if Setup > Vehicle > Climate > Climate features > Lock rear climate controls is selected, the rear climate control can be operated only from the front seat.
- Use the climate control system with the vehicle running for a more effective system, and to prevent battery discharge.

Automatic heating and air conditioning

The Automatic Climate Control System is controlled by setting the desired temperature.

1. Press the AUTO button.

The mode selection, blower speed, air intake and air conditioning are controlled automatically by the temperature setting.

You can control the blower speed in three stages by pressing the **AUTO** button during automatic operation.

- High: Provides rapid air conditioning and heating with the maximum blower speed setting.
- Medium: Provides air conditioning and heating with the mid-level blower speed setting.
- Low: Blower speed is set to the lowest setting range.
- 2. Turn the temperature control knob to set the desired temperature. If the temperature is set to the lowest setting, the air conditioning system operates continuously. After the interior has cooled sufficiently, adjust the knob to a higher temperature set point whenever possible.

To turn off the automatic operation, select any of the following buttons:

- Front windscreen defroster button (Press the button one more time to deselect the front windscreen defroster function. The "AUTO" illuminates on the information screen once again.)
- Blower speed control icon or knob
- A/C (air conditioning) icon

The selected function is controlled manually whilst other functions operate automatically.

For your convenience and to improve the effectiveness of the climate control, use the **AUTO** button and set the temperature to 22 °C (72 °F).

i Information



Never place anything near the sensor to ensure better control of the heating and cooling system.

Manual heating and air conditioning

- 1. Start the vehicle.
- Set the mode to the desired position.For improving the effectiveness of heating and cooling, select:
 - Heating: ﴿
 - Cooling: →م
- 3. Set the temperature control to the desired position.
- 4. Set the air intake control to the outside (fresh) air position.
- 5. Set the blower speed control to the desired speed.
- 6. If air conditioning is desired, turn on the air conditioning system.
- 7. Press the **AUTO** button to convert to full automatic control of the system.

Mode selection

Front seat mode selection



- Touch each air flow direction on the information screen to select the desired flow direction.
- Press the SYNC button and when the indicator light on the button turns off, the air flow direction of the driver's seat, passenger seat, and rear seats can be controlled individually. The front passenger and rear passenger seats cannot select a position.
- Touch Rear (1) to control the rear seat's mode selection from the front seats.
- You may select 2-3 modes at the same time.

Rear seat mode selection



- Press the button to select the direction of the air flow to the desired position.
- You may select 2 modes at the same time.

Air flow direction



The mode selection icon or button controls the direction of the air flow through the ventilation system.

Front seat

• Defrost (A, D)



Most of the air flow is directed to the windscreen.

• Face-level (B, D)



Air flow is directed toward the upper body and face. Additionally, each outlet can be controlled to direct the air discharged from the outlet.

• Floor-level (A, C, D)



Most of the air flow is directed to the floor, with a small amount of the air being directed to the windscreen and side window defrosters.

Rear seat

Face-level (E)



Air flow is directed toward the upper body and face.

Floor-level (F)



Most of the air flow is directed to the floor.

Front windscreen defroster



Defrost-level (A, D)


Press the button, and the indicator light on the button illuminates.

Most of the air flow is directed to the windscreen with a small amount of air directed to the side window defrosters.

Press the button again, the indicator light turns off and the previous settings are selected.

Instrument panel vents

Front seat



Rear seat



The instrument panel vent air flow can be directed up/down or left/right using the vent adjustment lever.

The air flow can be closed using the vent adjustment lever.

Move the lever to ⊗ position to close, and to ⊜ position to open.

Temperature control

Front seat control



Rear seat control from the front



Rear seat control from the rear (if equipped)



The temperature setting increases when you turn the knob to the right or press the

+ or ↑ arrow on the touchscreen.

The temperature setting decreases when you turn the knob to the left or press the - or \vee arrow on the touchscreen.

Temperature conversion

If the battery has been discharged or disconnected, the temperature mode display is reset to Celsius.

To change the temperature unit from °C to °F or °F to °C:

- For infotainment system, select: Setup > General > Units > Temperature unit > °C/°F
- For vehicles equipped with Automatic Climate Control, you can also:

Press the **A/C** button for 3 seconds, and then within 5 seconds press the driver's side face-level (¬¬¬) position for more than 3 seconds.

Both the temperature unit on the instrument cluster and climate control information screen is changed.

DRIVER ONLY



If you press the **DRIVER ONLY** button (indicator light ON), most of the air flow is directed toward the driver's seat.

i Information

Some of the airflow may be directed to other seating position to keep indoor air pleasant whilst using DRIVER ONLY.

When using the front windscreen defroster, the air flow on the both sides of windscreen will continue to operate regardless of the activation of DRIVER ONLY.

SYNC



Adjusting the temperature, air flow direction, and blower speed equally

Press the **SYNC** button from the front seat, (indicator light ON), to adjust the driver, front passenger, and rear passenger side temperature, air flow direction, and blower speed equally.

Adjusting the temperature, air flow direction, and blower speed individually Press the **SYNC** button (indicator light OFF) from the front seat again to adjust the driver, front passenger, and rear passenger side temperature, air flow direction, and blower speed individually.

Air intake control



To select outside (fresh) air or recirculated air, press this button.

Recirculated air position



With the recirculated air selected, air from the passenger compartment is drawn through the climate control system.

Outside (fresh) air position



With the outside (fresh) air selected, air enters the vehicle from outside and is drawn through the climate control system.

i Information

Using the system in the fresh air position is recommended.

Prolonged operation of the heating in the recirculated air position (without air conditioning selected) can cause fogging of the windscreen and side windows and the air within the passenger compartment will become stale.

In addition, prolonged use of the air conditioning with the recirculated air position selected will result in excessively dry air in the passenger compartment.

A WARNING

To prevent serious injury or death:

- Continued climate control system operation in the recirculated air position may allow humidity to increase inside the vehicle that could fog the windscreen and the side windows and obscure visibility.
- Do not sleep in a vehicle with the air conditioning or heating system on.
- Continued climate use of recirculated air may cause drowsiness or sleepiness, and loss of vehicle control. Set the air intake control to the outside (fresh) air position whilst driving.

Blower speed control

Front seat control



Rear seat control from the front



Rear seat control from the rear (if equipped)



Press the **\$** or **\$** button to increase blower speed and airflow. Press the **\$** or **\$** button to decrease blower speed and airflow.

Pressing the **OFF** button turns off the blower.

NOTICE

Operating the blower when the Start/Stop button is in the POWER ON position may cause the battery to discharge.

Air conditioning



Press the **A/C** button to manually turn the air conditioning on (indicator light ON) and off.

Clean Air system



The fine dust concentration in the cabin is measured by the fine dust sensor installed in the vehicle. The cabin air status is displayed on the screen.

If necessary, the system prevents contaminated air from entering the cabin and the cabin air filter purifies the cabin air by filtering the fine dust.

Cabin air status display

The air status is displayed in four levels when the climate control system turns on.

Cabin air system	Level displayed			
Cabin Air Condition	Good	Normal	Poor	Very poor
Operation Indicator	Green	Yellow	Orange	Red

i Information

- The cabin air filter should be replaced every 15,000 km to maximise performance of the clean air system.
- If the vehicle is being driven in an inner-city area with high air pollution or severe
 conditions such as dusty or rough roads or the indoor fine dust concentration is not
 presented as Good on the screen due to prolonged heavy fine dust, more frequent
 cabin air filter changes are required than every 15,000 km.
 - Driving in an inner-city area with high air pollution
 - Frequently driving on dusty or rough roads
 - Prolong air pollution such as fine dust
- We recommend using genuine cabin air filter to maintain the optimal performance of the clean air system.
- The dust concentration level measured inside the vehicle is in real-time. The measured value differs from the dust concentration in the atmosphere.
- The displayed level may differ depending on the measurement method or location. The displayed levels are for reference only.

OFF

Front seat control



Rear seat control from the front



Rear seat control fromt the rear



Press the **OFF** button to turn off the climate control system. You can still operate the mode buttons and air intake buttons as long as the Start/Stop button is in the DRIVE READY position.

- If OFF is pressed from the front seat, the front and rear climate control system turns off.
- If OFF is pressed from the rear seat, only the rear climate control system turns off.

System operation

Cooling/Ventilation

- 1. Set the mode to the -, position.
- 2. Set the air intake control the outside (fresh) air or recirculated air position.
- 3. Set the temperature control to the desired position.
- 4. Set the blower speed control to the desired speed.

Heating

- 1. Set the mode to the vi position.
- 2. Set the air intake control the outside (fresh) air or recirculated air position.
- 3. Set the temperature control to the desired position.
- 4. Set the blower speed control to the desired speed.
- If desired, turn the air conditioning ON with the temperature control knob set to heat in order to dehumidify the air hefore it enters into the cabin

If the windscreen fogs up, set the mode to the $\widehat{\mathbb{W}}$ position.

Operation Tips

- To keep dust or unpleasant fumes from entering the vehicle through the ventilation system, temporarily set the air intake control to the recirculated air position. Return the control to the to outside (fresh) air position when the unpleasant air outside has diminished. This can help keep the driver alert and comfortable.
- To help prevent the inside of the windscreen from fogging, set the air intake control to outside (fresh) air position and the blower speed to the desired position, turn on the air conditioning system, and adjust the temperature control to the desired temperature.

Air conditioning

- Start the vehicle. Press the air conditioning button.
- 2. Set the mode to the → position.
- 3. Set the air intake control to the recirculated air position temporarily to allow the cabin to cool quickly. When the desired temperature in the cabin is reached, change the air intake control back to the outside (fresh) air position.
- 4. Adjust the blower speed control and temperature control to as desired.
 When maximum cooling is desired, set the temperature control to the lowest position, then set the blower speed control to the highest setting.

Air conditioning system operation tips

- If the vehicle has been parked in direct sunlight during hot weather, open the windows for a short time to let the hot air inside the vehicle escape.
- After sufficient cooling has been achieved, switch back from the recirculated air position to the outside (fresh) air position.
- To help reduce moisture inside of the windows on rainy or humid days, decrease the humidity inside the vehicle by operating the air conditioning system with the windows closed.
- Use the air conditioning system every month only for a few minutes to ensure maximum system performance.
- If you operate air conditioner excessively, the difference between the temperature of the outside air and that of the windscreen may cause the outer surface of the windscreen to fog up, causing loss of visibility. In this case, set the mode selection to the → position and blower speed control to the lowest speed.

System maintenance

Cabin air filter

The cabin air filter is installed behind the glove box. It filters the dust or other pollutants that enter the vehicle through the heating and air conditioning system.

We recommend that the cabin air filter be replaced by an authorised Genesis repairer according to the maintenance schedule. If the vehicle is being driven in severe conditions such as dusty or rough roads, more frequent cabin air filter inspections and changes are required.

Checking the amount of air conditioner refrigerant and compressor lubricant

If the amount of refrigerant is too low or too high, the performance of the air conditioning is reduced. We recommend that the system be inspected by an authorised Genesis repairer.

NOTICE

The refrigerant system should only be serviced by trained and certified technicians in a well-ventilated area to ensure proper and safe operation.

A WARNING

Vehicles equipped with R-134a




To prevent serious injury, have the air conditioning system be serviced by only trained and certified technicians. R-134a is operated at high pressure.

Reclaim all refrigerants with proper equipment. Venting refrigerants directly to the atmosphere is harmful to individuals and environment.

Air Conditioning refrigerant label



You can find out which air conditioning refrigerant is applied to your vehicle on the label located inside of the bonnet. Each symbols and specification on the air conditioning refrigerant label is represented as below:



- (1) Classification of refrigerant
- (2) Amount of refrigerant
- (3) Classification of compressor lubricant
- (4) Caution
- (5) Service manual

Windscreen defrosting and defogging

A WARNING

Do not use the defrost-level (#) position during the cooling operation in extremely humid weather. The outer surface of the windscreen may fog and reduce visibility, causing a collision that results in serious injury or death. Set the mode selection button to the face-level (->) position and blower speed control knob to a lower speed.

- For maximum defrost performance, set the temperature control to the highest temperature setting and the blower speed control to the highest setting.
- If warm air to the floor is desired whilst defrosting or defogging, select the floor-defrost position.
- Before driving, clear all snow and ice from the windscreen, rear window, outside rear-view mirrors, and all side windows.
- Clear all snow and ice from the bonnet and air inlet to improve heater and defroster efficiency and to reduce the probability of fogging up the inside of the windscreen.

To defog inside windscreen



- 1. Select the desired blower speed.
- 2. Select the desired temperature.
- 3. Press the defroster # button.
- Fresh mode will be selected automatically.

The air conditioning turns on according to the detected ambient temperature, the outside (fresh) air position and higher blower speed are selected automatically. If the air conditioning, outside (fresh) air position and higher blower speed are not selected automatically, adjust the corresponding button or knob.

If the defrost-level (##) position is selected, lower blower speed is adjusted to higher blower speed.

To defrost outside windscreen



- 1. Set the blower speed to the highest position.
- 2. Set the temperature to the hottest position.
- 3. Press the defroster # button.
- 4. Fresh mode will be selected automatically.

The air conditioning turns on according to the detected ambient temperature and the outside (fresh) air position is selected automatically.

If the front defrost-level (#) position is selected, lower blower speed is adjusted to a higher blower speed.

Rear window defroster

NOTICE

Never use sharp instruments or window cleaners containing abrasives to clean the window to prevent damage to the rear window defroster.



The defroster heats the window to remove frost, fog, and thin ice from the interior and exterior of the rear window, whilst the vehicle is running.

- To activate it press the rear window defroster button located in the centre control panel. The indicator on the rear window defroster button illuminates when the defroster is ON.
- To turn it off press the rear window defroster button again.

i Information

- If there is heavy accumulation of snow on the rear window, brush it off before operating the rear defroster.
- The rear window defroster automatically turns off after about 20 minutes or when the Start/Stop button is in the OFF position.

Outside rear-view mirror defroster

tif equipped

The outside rear-view mirror defrosters operate when you turn on the rear window defroster.

Climate control additional features

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Air conditioning auto-drying

tif equipped

The Air Conditioning Auto Drying feature dries the moisture in the air conditioning and reduces air conditioning odour. The blower motor automatically operates after 30 minutes the vehicle is turned off.

Turning Air Conditioning Auto Drying on or off

The Air Conditioning Auto Drying feature can be turned on and off by selecting Setup > Vehicle > Climate > Air conditioner auto-drying.

If the operating conditions are satisfied after setting the feature, the operating condition appears on the infotainment system and the blower motor automatically operates.

When the Air Conditioning Auto Drying feature is activated, the air conditioning sets the blower speed to the third level, selects outside (fresh) air position, and directs the air flow to the floor.

Operating conditions

- The vehicle is turned off after operating the air conditioning for a certain period.
- The 12 V battery level is sufficient and the outside temperature is above a certain level.

Non-operating conditions

- The Air Conditioning Auto Drying feature has operated for 10 minutes.
- The Start/Stop button is pressed, or the vehicle is POWER ON or DRIVE READY position.
- The climate control system is operated remotely.

i Information

The Air Conditioning Auto Drying feature reduces air conditioning odours but may not remove all odours.

Auto defogging system



Auto defogging helps reduces the likelihood of fogging up the inside of the windscreen by sensing the moisture on the inside of the windscreen.

The Auto Defogging system operates when the heater or air conditioning is on.

i Information

The Auto Defogging system may not operate normally, when the outside temperature is below -10 °C.

If high amount of humidity is detected in the vehicle, the Auto Defogging system is enabled.

The following steps are performed automatically:

- 1. Air conditioning turns on and outside (fresh) air is selected.
- 2. Defrost-level is selected.
- 3. Blower speed is set to MAX.

Turning the Auto Defogging System ON or OFF

Climate control system

Press the front windscreen defroster button for 3 seconds when the Start/Stop button is in the POWER ON or DRIVE READY position to turn the system on or off.

To check whether the system is on or off, go to the settings menu in the infotainment system and see if **Auto defog** is selected or not.

Infotainment system

Auto Defogging system can be turned on and off by selecting **Setup** > **Vehicle** > **Climate** > **Defog/Defrost options** > **Auto defog** from the Settings menu.

i Information

- Do not select recirculated air whilst the Auto defogging system is operating.
- When Auto Defogging system is operating, blower speed adjustment, temperature adjustment, and air intake control selection are all disabled.

NOTICE

Do not remove the sensor cover located on the top of the windscreen glass. Damage may not be covered by your vehicle warranty.

Auto dehumidify

tif equipped

Recirculated air position switches off automatically after about 5 to 30 minutes, depending on the outside temperature, and the air intake will change to outside (fresh) air position.

Turning Auto Dehumidify ON or OFF

Climate control system

To turn the Auto Dehumidify feature on or off, select face-level (¬¬¬) position and press the air intake control (¬¬¬) button at least five times within three seconds. When Auto Dehumidify is turned on, the air intake control button indicator blinks 6 times. When turned off, the indicator blinks 3 times.

Infotainment system

Auto Dehumidify can be turned on and off by selecting **Setup** > **Vehicle** > **Climate** > **Automatic ventilation** > **Auto dehumidify** from the Settings menu.

Recirculating air when washer fluid is used

Recirculated air position automatically activates to reduce the scent of the washer fluid entering the cabin when the windscreen washer is used.

However, in cold weather to prevent the windscreen from fogging up, the recirculated air position may not be selected.

Turning Activate upon Washer Fluid Use ON or OFF

Climate control system

To turn the Activate upon Washer Fluid Use feature on or off, select floor-level (¬¬) position, and then press the air intake control (¬¬) button five times within three seconds.

When Activate upon Washer Fluid Use ON is turned on, the air intake control button indicator blinks 6 times. When turned off, the indicator blinks 3 times

Infotainment system

Activate upon Washer Fluid Use can be turned on and off by selecting **Setup** > **Vehicle** > **Climate** > **Recirculate** air > **Activation on washer fluid use** from the Settings menu.

Automatic controls linked to climate control settings (for driver's seat)

The temperature of the driver's seat warmer, the air ventilated seat, and heated steering wheel is automatically controlled depending on the inside and outside temperature of the vehicle when the vehicle is running.

To use these features, it can be enable the Settings menu in the infotainment system. Select:

Setup > Vehicle > Seat >
 Heating/Ventilation > Automatic
 controls linked to climate control
 settings

For more information on Auto Comfort Control, refer to the "Seat warmers" and "Air ventilation seats" sections in chapter 3 and "Heated steering wheel" section in chapter 5.

Recirculating air when entering a tunnel



To prevent the inflow of polluted air into the vehicle when passing through a tunnel, this function automatically closes the windows and switches the climate control system to recirculated air position for about 7 seconds before entering a tunnel based on the map information of the navigation and the speed of the vehicle.

The windows automatically close before entering a tunnel and area requiring air recirculation. The windows open to the previous position after passing through the area. If the power window switch is operated before the windows open, the windows do not open to the previous position.

To use this feature, it can be enabled from the Settings menu in the infotainment system. Select:

 Setup > Vehicle > Climate > Recirculate air > When entering tunnels

Operating conditions

One or more of the windows are opened or outside (fresh) air position is selected.

i Information

- The activation time for the function may differ depending on the gap between the GPS data and vehicle speed.
- The function activates until you have passed through continuous tunnels.
- When entering a tunnel, recirculated air position may cause fogging of the windscreen. Press the windscreen defroster button.
- The function does not operate in short tunnels.
- The function may not activate if the GPS is not working properly.

Rear climate auto Off

tif equipped

This feature automatically turns off the rear seat climate when there is no passenger in the rear seat.

To use this feature, it can be enabled from the Settings menu in the infotainment system. Select:

 Setup > Vehicle > Climate features > Rear climate auto Off

Operating conditions

When the vehicle is stopped or parked with all doors closed, and the rear seat ventilation is in operation.

i Information

The Rear climate auto Off may not operate in the following situations:

- If the vehicle moves due to the movement of another vehicle nearby whilst the function is operating.
- When the window is open and affected by other external movements.
- If there is a water bottle, clothes, etc. indoors and there is shaking in the vehicle.
- In case of movement of passengers in front seat, adjustment of seats, etc.

Storage compartment

A WARNING

Never store cigarette lighters, propane cylinders, or other flammable/explosive materials in the vehicle. These items may catch fire and/or explode if the vehicle is exposed to hot temperatures for an extended period of time.

A WARNING

Always keep the storage compartment covers closed securely whilst driving. Items inside your vehicle are moving as fast as the vehicle. If you have to stop or turn quickly, or if there is a crash, the items may fly out of the compartment and may cause an injury if they strike the driver or a passenger.

NOTICE

To avoid possible theft, do not leave valuables in the storage compartments.

Centre console storage



To open:
Press the button.


Rear console storage



To open:

Press the button.

Glove box



The glove box can be locked and unlocked with the mechanical key (1).

To open:

Pull the lever (2).

A WARNING

Always close the glove box door after use.

An open glove box door may cause serious injury to a passenger in a collision, even if the passenger is wearing a seat helt.

Sunglasses holder



To open:

Push and release the cover and the holder will slowly open. Place your sunglasses in the compartment door with the lenses facing out.

To close:

Push back into position.

Make sure the sunglasses holder is closed whilst driving.

WARNING

- Do not keep objects except sunglasses inside the sunglasses holder. Such objects can be thrown from the holder in the event of a sudden stop or an accident, possibly injuring the passengers in the vehicle.
- Do not open the sunglasses holder whilst the vehicle is moving. The rear view mirror of the vehicle can be blocked by an open sunglasses holder.
- Do not put the glasses forcibly into a sunglasses holder. It may cause personal injury if you try to open it forcibly when the glasses are jammed in holder.

Interior features

Cup holder

Front



Rear (Type A)



Rear (Type B)



Cups or small beverage cups may be placed in the cup holders.

WARNING

- Avoid abrupt starting and braking when the cup holder is used to prevent spilling your drink. If hot liquid spills, you may be burned. Such a burn to the driver may cause loss of vehicle control resulting in a collision.
- Do not place uncovered or unsecured cups, bottles, cans, etc., in the cup holder containing hot liquid whilst the vehicle is moving.
- · Only use soft cups in the cup holders.

NOTICE

- Keep your drinks sealed whilst driving to prevent spilling. If spilled, it may damage the vehicle's electrical/electronic system.
- When cleaning spilled liquids, do not use hot air to blow out or dry the cup holder.
- Keep cans or bottles out of direct sun light and do not put them in a hot vehicle. Otherwise, they may explode.

Armrest warmer (front)



Press the front warmer button to warm the front or rear seat and armrest

Enable the armrest warmer from the Settings menu in the infotainment system. Select:

Setup > Vehicle > Seat >
 Heated/Ventilated features > Auto.
 Controls that use climate control
 settings > Driver armrest warmer or
 Passenger armrest warmer

i Information

- The temperature is automatically controlled to prevent low temperature burns.
- The armrest warmer defaults to the OFF position whenever the Start/Stop button is in the DRIVE READY position.
- For more information on armrest warmer operation, refer to the "Seat warmers" section in chapter 3.

UV-C sterilizer system



- (1) UV-C sterilizer system button indicator
- (2) Console storage button
- (3) UV-C sterilizer system button

The front seat console is equipped with an antibacterial sterilization system for personal belongings.

WARNING

- Press the button to turn UV-C function off when it is not in use. Being exposed to ultraviolet rays from UV-C LED may be harmful to your skin and eyes.
- Do not place magnetic items (magnets, etc.) near the upper part of the UV-C storage box. It may cause malfunction to the UV-C sensor and unnecessarily operate the UV-C function.

NOTICE

- Press the button to turn UV-C function off when it is not in use. Prolonged exposure under ultraviolet rays may change the colour and shape of the object.
- Do not sterilize food. Food cannot be sterilized. Prolonged exposure to ultraviolet rays may damage the wrapping or container and affect the food inside.

Using UV-C sterilizer system

Place the item in the UV-C storage box and turn it on. Within 10 minutes, up to 99.9 % of germs on the surface can be removed

- 1. Open the UV-C storage box whilst the vehicle is running.
- 2. Press the button inside the storage box.
 - UV-C sterilizer system indicator light illuminates.
 - · Antibacterial tray is ready to operate.
- 3. Place the item in the centre inside the storage box and close the cover.
 - · UV-C indicator light illuminates.
 - UV-C LED is turned on and sterilization begins.
 - After 10 minutes, the UV-C indicator light turns off as sterilization is complete.
 - Press the UV-C sterilizer system button to turn off the function, after you are finished using the system.

i Information

- Only place the item which requires sterilization. Storing other items in the storage box may reduce the sterilization effect.
- UV-C sterilizer system does not guarantee 99.9 % sterilization. The sterilization effect varies depending on the degree of exposure to UV-C light and the shape of the item. For effective use, change the position of the item and run additional sterilization.
- If the UV-C indicator light blinks or does not operate properly, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Unit item verification number


Unit item verification number			
	Туре А	Registration Number: R-R-HdG-89910 -T4AHO	
12	Туре В	Registration Number: R-R-EpS-846R0 -T4000	
F©	Туре А	DECLARATION OF CONFORMITY	
\$EPA	Туре А	ESTABLISHMEN T NUMBER: 100891-KOR-1	
c MET us	Туре А	LISTING NUMBER: E115351	
C€	Type A/B	DECLARATION OF CONFORMITY	

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- This appliance complies with the applicable standards and regulations (Low Voltage Directive, Electromagnetic Compatibility, Environmental, etc.).
- This product uses the vehicle's battery voltage and should be used only at DC 9 V-16 V.

WARNING

This product emits ultraviolet rays. Do not gaze upon the UV rays whilst using the product. Exposing the eyes or skin to UV rays may have harmful effect to the body.

Sunvisor



To use the sunvisor, pull it downward.

To use the sunvisor to block the sun from the side window, pull it downward, release it from the bracket and swing it to the side toward the window.

To use the vanity mirror [A], pull down the sunvisor and slide the mirror cover.

Adjust the sunvisor forward or rearward as needed (if equipped). Use the ticket holder [B] to hold tickets.

Close the vanity mirror cover securely and return the sunvisor to its original position after use.

A WARNING


Do not block your view when using the sunvisor.

NOTICE

The ticket holder [B] adjacent to the vanity mirror on the sunvisor can be used for toll road tickets or self parking tickets. Use caution when inserting tickets into the ticket holder to avoid damage. Refrain from putting several tickets in the ticket holder as this could also damage the retaining tab.

Rear mirror

tif equipped



To open:

Press the cover and it will slowly opens and the mirror lamp turns on.

To close:

Push back into position.

Power outlet



The power outlet is designed to provide power for mobile phones or other devices designed to operate with vehicle electrical systems. The devices should draw less than 180 watts with the vehicle running.

A WARNING

Avoid electrical shocks. Do not place your fingers or foreign objects (pin, etc.) into a power outlet or touch the power outlet with a wet hand.

NOTICE

To prevent damage to the power outlets:

- Use the power outlet only when the vehicle is running and remove the accessory plug after use. Using the accessory plug for an extended period of time with the vehicle off may cause the battery to discharge.
- Only use 12 volts electric accessories that are less than 180 watts in the electric capacity.
- Adjust the air conditioning or heating to the lowest operating level when using the power outlet.
- · Close the cover when not used.

- Some electronic devices may cause electronic interference when plugged into a vehicle's power outlet. These devices may cause excessive audio static and malfunctions in other electronic systems or devices used in your vehicle.
- Push the plug in as far as it goes. The plug may overheat and the fuse may open.
- Only connect devices with reverse current protection or the current from the device battery may cause the vehicle's electrical/electronic system to malfunction.

USB charger

Front



Rear



The USB charger is designed to recharge batteries of small size electronic devices using a USB cable.

The electrical devices can be charged whilst the vehicle is running.

i Information

- The battery charging state may be monitored on the electronic device.
- Disconnect the USB cable from the USB port after use.
- A smartphone or a tablet PC that does not use a USB cable to charge should be charged using its own charger.
- Do not attempt to use the charging terminal to turn ON an audio or to play media with the infotainment system.
- Charging may not be possible when using a Type-C to A converter sold by a mobile phone manufacturer or if commercially available.

NOTICE

- Use the USB charger when the vehicle is running. Using USB charger for prolonged periods of time with the vehicle off may cause the battery to discharge.
- To prevent damage to the USB charger:
 - Do not insert foreign objects or spill liquid into the outlet. The USB charging terminal may be damaged.
 - Do not use devices with working current exceeding 2,100 mA (2.1 A).

Wireless smartphone charging system

Front



Rear (if equipped)



[A] Indicator light [B] Charging pad

Charging your smartphone

The wireless smartphone charging system charges only the Qi-enabled smartphones (Φ). Visit your smartphone manufacturer's website to check whether your smartphone supports the Qi technology.

The wireless charging process starts when you put a Qi-enabled smartphone on the wireless charging unit.

 The wireless smartphone charger is available when all doors are closed, and when the Start/Stop button is in the POWER ON or DRIVE READY position.

- 2. Turn on the wireless charging function in the infotainment system. Select:
 - Setup > Vehicle > Convenience > Wireless charging system for mobile devices

Set the indicator type to be displayed when a smartphone is being charged. Select:

- Setup > Vehicle > Convenience > Mobile phone wireless charging indicator
- Place the smartphone on the centre of the wireless charging pad. The indicator light is displayed depending on the type selected whilst the smartphone is being charged.

i Information

- Remove other items, including the smart key from the wireless charging pad.
- For flip type smartphones, when using wireless charging, place the smartphone folded with the device's back placed on the centre of the wireless charging unit.

If your smartphone is not charging:

- Move the smartphone on the charging pad.
- · Make sure the indicator light is orange.

The indicator light will blink orange for 10 seconds if there is a malfunction in the wireless charging system.

The system warns you with a chime if the smartphone is still on the wireless charging pad after the vehicle is turned OFF and the front door is opened.

NOTICE

- The wireless smartphone charging system may not support certain smartphones, that do not meet the Qi specification (Φ).
- When placing your smartphone on the charging pad, position the phone in the middle of the mat for optimal charging performance. If your smartphone is off to the side, the charging rate may be less and in some cases the smartphone may experience higher heat conduction.
- The wireless charging may stop temporarily when the smart key is used, either when starting the vehicle or locking/unlocking the doors, etc.
- For some manufacturer's smartphones, the system may not warn you even though the smartphone is left on the wireless charging unit. This is due to the particular characteristic of the smartphone and not a malfunction of the wireless charging.
- When charging certain smartphones, the charging indicator may not change to blue when the smartphone is fully charged.
- The wireless charging process may temporarily stop, when temperature abnormally increases inside the wireless smartphone charging system. The wireless charging process does not restart, until the temperature falls.
- The wireless charging process may temporarily stop when there is any metallic item, such as a coin, between the wireless smartphone charging system and smartphone.
- When charging some smartphones with a self-protection feature, the wireless charging speed may decrease and the wireless charging may stop.

- If the smartphone has a thick case, it may not charge.
- If the smartphone is not completely contacting the charging pad, wireless charging may not operate properly.
- Some magnetic items like credit cards, phone cards, or transit cards may be damaged if left with the smartphone during the charging process.
- When any smartphone without a
 wireless charging function or a metallic
 object is placed on the charging pad, a
 small noise may sound. This small
 sound because the vehicle discerns
 compatibility of the object placed on
 the charging pad. It does not affect
 your vehicle or the smartphone in any
 way.
- If the Start/Stop button is in the OFF position, the charging stops.
- Some smartphones may not be able to charge depending on the internal structure of the smartphone. If this occurs, try charging the smartphone by moving it to the left or right side of the wireless charging pad. However, for some foldable smartphones that have magnets inside the smartphone, try charging the smartphone whilst holding it close to the left side of the wireless charging pad.

Clock

The clock can be set from the infotainment system.

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

A WARNING

Do not attempt to adjust the clock whilst driving.

Coat hook

Type A



Type B



These hooks are not designed to hold large or heavy items.

WARNING



Only hang soft clothing without heavy, sharp or breakable objects in the pockets. In a collision or when the curtain airbag is inflated, the objects could move and cause serious injury.

Floor mat anchors

ALWAYS use the Floor Mat Anchors to attach the front floor mats to the vehicle and prevent the mats from sliding forward.

A WARNING

To prevent serious injury or death from a floor mat interfering with the brake or accelerator pedals:

- Remove any protective film on the carpet before installing a floor mat.
- Check floor mats are securely attached to the vehicle's floor mat anchors before driving.
- Do not use ANY floor mat that cannot be firmly attached to the vehicle's floor mat anchors.
- Do not stack floor mats on top of another mat (for example, all weather rubber mat on top of a carpeted floor mat). Only a single floor mat must be installed in each position.
- To avoid any interference with pedal operation, install only Genesis floor mats designed for use in your vehicle.

Rear side window sunshades

tif equipped

Use to block sunlight coming through the rear windows



- (1) Rear left window and sunshade
- (2) Rear right window and sunshade
- 1. Pull the switch up on the driver's or rear seat to completely close the window.
- Once the window is closed, pull the same switch again to close the sunshades.
 - To open the window when the sunshade is closed, push down the switch to first open the sunshade.
 Then push the switch again to open the window.

i Information

If the operating sunshade is blocked by an object, the sunshade stops opening or closing. The sunshade is only able to open (move downward) once stopped by obstruction.

NOTICE

Do not apply excessive external force on the rear side window sunshade whilst operating. It may cause a malfunction.

Resetting the rear side window sunshades

If the sunshade is not operating normally, It must be reset as follows:

- 1. Start the vehicle.
- Continue pulling up on the power window switch for at least 10 seconds when the window is closed.

If the rear side window sunshade does not work properly after following the above procedure, it is recommended that the system be checked by an authorised Genesis repairer.

i Information

If the temperature inside the vehicle is below -15 °C, the rear side window sunshade may stop in some sections whilst closing. If this occurs, operate the switch again after raising the temperature. The rear side window sunshades will operate normally.


Rear window sunshade



Rear (Type A)



Rear (Type B)



 To raise or lower the sunshade, press the button.



- The rear window sunshade will be lowered automatically when the vehicle is shifted to R (Reverse) and raised automatically when the vehicle is shifted from R (Reverse) to P (Park).
- After the rear window sunshade is lowered by shifting the vehicle to R (Reverse), if you drive more than 20 km/h with the shift lever in D (Drive), the rear window sunshade will be raised automatically.

NOTICE

Do not apply excessive force when operating the rear window sunshade. This could cause damage to the rear window sunshade.

Luggage net holder





To keep items from shifting in the luggage compartment use the 4 holders located in the luggage compartment side trim to attach the luggage net.

Make sure the luggage net is securely attached to the holders in the luggage board.

If necessary, we recommend that you contact an authorised Genesis repairer to obtain a luggage net.

A WARNING

Avoid eye injury. Do not overstretch the luggage net. Always keep your face and body out of the luggage net's recoil path. Do not use the luggage net when the strap has visible signs of wear or damage.

 Use the luggage net to keep only light items from shifting in the luggage compartment.

Infotainment system

NOTICE

Do not install an aftermarket HID headlamp. Your vehicle's audio and electronic devices may not function properly.

USB Port



The USB port can be used whilst the vehicle is running.

 After connecting a media storage device such as a MP3 or USB to the USB port, you can listen to music through the vehicle's speakers or play it on the infotainment system.

i Information

When using a portable audio device connected to the power outlet, noise may occur during playback. If this happens, disconnect the USB cable and use the portable audio device's power source.

Antenna



The shark fin antenna receives transmitted data (for example, AM/FM).

Steering wheel remote controls



NOTICE

Do not operate multiple audio remote control buttons simultaneously.

1. SEEK/PRESET **(<, >**)

If the SEEK/PRESET switch (optical mouse) is swiped to the left or right and held for 0.8 seconds or more, it functions in the following modes:

 RADIO mode: It functions as the AUTO SEEK select button. It seeks until you release the button. MEDIA mode: It functions as the FF/RW button.

If the SEEK/PRESET switch (optical mouse) is swiped to the left or right, it will function in the following modes:

- RADIO mode: It functions by moving between stored PRESET STATIONS.
- MEDIA mode: It functions as the TRACK UP/DOWN button.

2. Custom (★)

Press the Custom button to set frequently used features.

3. Mode (←)

Press the Mode button to toggle through Radio mode or Media mode.

4. Volume (+, -)

- Rotate the Volume up to increase volume.
- Rotate the Volume down to decrease volume.

Mute (♥)

- Press the Mute button to mute the sound.
- Press the Mute button again to activate the sound.

Infotainment system

Front



Rear (if equipped)



i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Voice recognition



i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Bluetooth® Wireless Technology



- Call/Answer/Call end button (Steering wheel)
- (2) Microphone

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

WARNING

To prevent driver distraction, minimise your use of these features whilst driving. Distraction may cause a collision, resulting in serious injury or death.

BANG & OLUFSEN sound system

A CAUTION

BANG & OLUFSEN sound system is equipped with door speaker grills made of stainless steel. The grill surface can become hot when the vehicle is exposed to hot weather for a long period of time. Keep away from the speaker grill when it is hot.

6. Driving your vehicle

Before driving	6-3
Before entering the vehicle	6-3
Before starting	6-3
Start/Stop button	6-4
Start/Stop button positions	
Starting the vehicle	
Turning off the vehicle	
Remote start	6-8
Reduction gear	6-9
Instrument cluster display messages	
Good driving practices	
Recuperative braking system	6-14
Using recuperative braking system	6-14
Recuperative braking system limitations	6-15
One Pedal Driving	6-15
Using i-PEDAL	6-16
Smart recuperation system	6-17
Smart recuperation system on/off	
Smart recuperation system operating condition	6-18
Smart recuperation level settings	
Pausing smart recuperation system	
Front sensors (Front radar)	
System malfunction due to sensor problems	
Smart recuperation system precautions	6-20
Braking system	6-23
Power-assist brakes	6-23
Disc brakes wear indicator	6-24
High performance brakes	6-24
Electronic Parking Brake (EPB)	6-24
Auto Hold	6-27
Brake Disc Cleaning	6-29
Anti-lock Brake System (ABS)	6-29
Electronic Stability Control (ESC)	6-31
Vehicle Stability Management (VSM)	6-33
Hill-Start Assist Control (HAC)	
Emergency Stop Signal (ESS)	6-34

	Multi-Collision Brake (MCB) Brake Assistant System (BAS) Good braking practices	6-36
	All Wheel Drive (AWD)	
	Emergency precautions	
	Electronic control suspension	6-40
	System malfunction	6-40
	Electronically controlled suspension with road preview	6-41
	System malfunction	
	Limitations of the system	
	Drive mode integrated control system	
	Drive mode	
	Road active noise control	
	System malfunction	
	Active sound design	
ı	Special driving conditions	
	Hazardous driving conditions	
J	Rocking the vehicle	6-47
	C	C 47
	Smooth cornering	
	Driving at night	6-48
	Š	6-48 6-48
	Driving at night	6-48 6-48
	Driving at night	6-48 6-48 6-49
	Driving at night	6-48 6-48 6-49 6-49
	Driving at night	6-48 6-48 6-49 6-49 6-49 6-52
	Driving at night	6-48 6-48 6-49 6-49 6-49 6-52
	Driving at night	6-48 6-48 6-49 6-49 6-49 6-52

Before driving

Before entering the vehicle

- Make sure all windows, outside rear-view mirrors, and outside lights are clean and unobstructed.
- Remove frost, snow, or ice from both the front windscreen and rear window as well as the front side windows.
- Visually check the tyres for uneven wear and damage.
- Check under the vehicle for any sign of leaks.
- Make sure there are no obstacles behind you if you intend to reverse.

Before starting

- Make sure the bonnet, the boot, and the doors are securely closed and locked.
- Adjust the position of the seat and steering wheel.
- · Adjust the inside and outside mirrors.
- · Verify all the lights work.
- Fasten your seat belt. Check that all passengers have fastened their seat belts.
- Check the gauges and indicators in the instrument panel and the messages on the instrument display when the Start/Stop button is in the POWER ON position.
- Check that any items you are carrying are stored properly or fastened down securely.

WARNING

To reduce the risk of serious injury or death:

- Always wear your seat belt. All
 passengers must be properly restrained
 whenever the vehicle is moving. For
 more information, refer to the "Seat
 belts" section in chapter 3.
- Always drive defensively. Do not assume that the other drivers are seeing your vehicle. They may not act as you expect. Be prepared to react to avoid a possible collision. Plan your movements anticipating the "worst-case" scenario.
- Stay focused on driving. Driver distraction may cause a collision.
- Leave plenty of space between you and the vehicle in front of you.

A WARNING

Never drink or take drugs whilst driving. Drinking or taking drugs whilst driving is dangerous and may result in a collision, causing serious injury or death.

Drunk driving is a significant contributor to the highway death toll each year. Even a small amount of alcohol can affect your reflexes, perceptions, and judgment. Just one drink may reduce your ability to respond to changing conditions and emergencies and your reaction time gets worse with each additional drink.

Driving whilst under the influence of drugs is as dangerous as or more dangerous than driving under the influence of alcohol.

You are much more likely to have a serious accident if you drink or take drugs whilst driving. If you are drinking or taking drugs, never drive. Do not travel with a driver who has been drinking or taking drugs. Choose a designated driver or call a taxi.

Start/Stop button



Whenever the front door is opened, the Start/Stop button illuminates and goes off 30 seconds after the door is closed.

WARNING

To turn the vehicle off in an emergency: Press and hold the Start/Stop button for more than two seconds. Or rapidly press and release the Start/Stop button three times (within three seconds).

If the vehicle is still moving, you can restart the vehicle without pressing the brake pedal by pressing the Start/Stop button with the gear in the N (Neutral) position.

WARNING

- NEVER press the Start/Stop button
 whilst the vehicle is moving except in
 an emergency. This may result in the
 vehicle turning off and loss of power
 assist for the steering and brake
 systems. This may cause loss of
 directional control and braking
 function, which could cause a collision.
- Before leaving the driver's seat, always make sure the gear is in the P (Park) position, apply the parking brake, press the Start/Stop button to the OFF position, and take the smart key with you to prevent unintended vehicle movement.
- Never reach through the steering wheel for the Start/Stop button or any other control whilst the vehicle is moving. The presence of your hand or arm in this area may cause a loss of vehicle control resulting in a collision.

Start/Stop button positions

Button Position	Action	Notes
OFF	To turn off the vehicle, press the Start/Stop button with the vehicle shifted to P (Park). If the Start/Stop button is pressed with the vehicle shifted to D (Drive), R (Reverse), or N (Neutral), the gear automatically shifts to P (Park). The steering wheel locks to protect the vehicle from theft. (if equipped)	If the steering wheel is not locked properly when you open the driver's door, the warning chime will sound.
POWER ON	Press the Start/Stop button whilst it is in the OFF position without pressing the brake pedal. The warning lights can be checked before the vehicle is started.	 In 14 minutes after POWER ON, the infotainment system screen shows the message. To continue to use the vehicle power, press 'Start utility mode'. If POWER ON is maintained for 15 minutes without converting to the utility mode, the power is turned OFF.
DRIVE READY	To start the vehicle, press the brake pedal and press the Start/Stop button with the gear shifted to the P (Park) position.	If you press the Start/Stop button without pressing the brake pedal, the vehicle does not start and the Start/Stop button changes as follows: OFF > POWER ON > OFF

i Information

To prevent vehicle battery discharge, the Start/Stop button changes to the OFF position when the Start/Stop button is in the POWER ON position with the gear in P (Park) for a certain period of time. When the function operates, the tail lamps will turn off. To use the tail lamps again, turn the headlamps switch located on the steering column to the OFF and ON position again.

Starting the vehicle

WARNING

- Always wear appropriate shoes when operating your vehicle. Unsuitable shoes such as high heels, ski boots, sandals, and thongs may interfere with your ability to use the brake and accelerator pedals. Do not drive barefoot.
- Do not start your vehicle with the accelerator pedal pressed. Place your foot firmly on the brake pedal whilst starting your vehicle.

MARNING

People with medical devices such as implanted pacemakers or cardiac defibrillators should not carry the smart key near the heart. The smart key system may affect the operation of such implanted medical devices.

Failure to do so may result in interference with the medical device, which could result in serious injury

i Information

- The vehicle will start by pressing the Start/Stop button, only when the smart key is in the vehicle.
- The vehicle may not start even if the smart key is in the vehicle but it is not near you (for example, in the luggage compartment).
- When the Start/Stop button is in the POWER ON position, if any door is open, the system checks for the smart key. When the smart key is not in the vehicle, the indicator blinks and the warning "Key not in vehicle" appears. When all doors are closed, the chime also sounds for a few seconds.

Keep the smart key in the vehicle when in the POWER ON position or if the vehicle is in the ready mode (READY indicator ON).

- 1. Always carry the smart key with you.
- 2. Make sure the parking brake is applied.
- 3. Make sure the gear is in P (Park).
- 4. Press the brake pedal.
- 5. Press the Start/Stop button. If the vehicle starts, the READY indicator will come on.

i Information

- Always start the vehicle with your foot on the brake pedal. Do not press the accelerator whilst starting the vehicle. Do not race the motor whilst warming it up.
- If ambient temperature is low, the (
 indicator may remain illuminated
 longer than the normal amount of time.

NOTICE

To prevent damage to the vehicle:

- Do not press the Start/Stop button for more than 10 seconds except when the stop lamp fuse is blown.
- When the stop lamp fuse is blown, replace the fuse. If you cannot replace the fuse, start the vehicle by pressing and holding the Start/Stop Button for 10 seconds with the Start/Stop button in the OFF position. Pressing the brake pedal many times whilst READY indicator light is off will increase the possibility of discharging the 12 V battery.

For your safety always press the brake pedal before starting the vehicle.

- If the READY indicator turns off whilst you are in motion, do not attempt to shift the gear to the P (Park) position.
 If traffic and road conditions permit, you may put the gear in N (Neutral) whilst the vehicle is still moving and press the Start/Stop button in an attempt to restart the vehicle.
- Do not push or tow your vehicle to start the vehicle.
- The vehicle enters the ready mode (READY indicator on) if you get in the vehicle with a smart key whilst scheduled climate or remote climate control is operating.

If a smart key is not detected in the vehicle after the door is closed or the brake pedal is pressed, a warning message appears.

When the vehicle is in the ready mode, be careful as the vehicle may move when shifting the gear from P (Park) to another gear position.

i Information

Virtual Engine Sound System (VESS)

VESS generates virtual engine sound to make pedestrians to aware. VESS operates when the vehicle can be driven. When the vehicle in P (parking) gear status, VESS doesn't work.

A CAUTION

- Because the vehicle doesn't make the engine sound, pay attention to the surrounding environment and drive carefully.
- After parking or waiting for a traffic light, please check around (children, obstacle, etc.) before departure.
- When reversing, check directly behind you before driving. Pedestrians may not be able to recognise vehicle sounds.

If the smart key battery is weak or the smart key does not work correctly, press the Start/Stop button with the smart key.



Turning off the vehicle

- 1. Stop the vehicle and press the brake pedal fully.
- 2. Make sure the gear is in P (Park).
- 3. Apply the Electronic Parking Brake (EPB).
- 4. Press the Start/Stop button to the OFF position.
- 5. Make sure the READY indicator light is off in the instrument cluster.

If the READY indicator light on the instrument cluster is still on, the vehicle is not turned off and can move when the gear is in any position except P (Park).

Remote start



You can start the vehicle using the Remote Start button on the smart key.

To start the vehicle remotely:

- 1. Press the door lock (1) button within 10 m from the vehicle.
- 2. Press and hold the remote start (2) button within 4 seconds.

To turn off the vehicle:

Press the remote start (2) button once.

i Information

- The vehicle does not remotely start if the bonnet or boot is open.
- The vehicle must be in P (Park).
- The vehicle displays "Smart Key must be present to keep the vehicle running" if you get on the vehicle without a registered smart key.
- The vehicle turns off if you get in the vehicle without a registered smart key or you do not get in the vehicle within 10 minutes.

Reduction gear



- [A] P release cap cover
- [B] P button
- [C] Rotary shifter (Rotary gear shift dial)

Press the brake pedal whenever rotating the shift dial to change gear or shifting to P (Park).

A WARNING

To reduce the risk of serious injury or death:

- Always check the area surrounding your vehicle for people, especially children, before shifting into D (Drive) or R (Reverse).
- Before leaving the driver's seat, always make sure the vehicle is shifted to the P (Park) position, then apply the parking brake, and press the Start/Stop button to the OFF position. Unexpected and sudden vehicle movement may occur if these precautions are not followed.

Rotary shifter/Rotary gear shift dial

P (Park)

Always come to a complete stop before shifting into P (Park).



To shift the gear to P (Park), press the **P** button whilst pressing the brake pedal.

If you turn the vehicle off in R (Reverse), N (Neutral) or D (Drive), the gear automatically shifts to P (Park).

▲ WARNING

- Shifting into P (Park) whilst the vehicle is moving may cause you to lose control of the vehicle.
- When parking on an incline, shift the gear to P (Park) and apply the parking brake, and turn the wheels toward the kerb to prevent the vehicle from rolling downhill.
- Do not use the P (Park) position instead of the parking brake.

Automatic gear shift to P (Park)

The gear is shifted to P (Park) automatically for safety reasons under the following conditions:

- When the vehicle is turned off with the gear in R (Reverse), D (Drive), or N (Neutral).
- When the driver's door is opened with the vehicle running, the gear in R (Reverse), D (Drive) or N (Neutral), the seat belt unfastened and the vehicle at a standstill.
- When the driver's or front passenger's door is opened with the gear in N (Neutral) and the vehicle is turned off.

In situations in which the gear must be in P (Park), always check if the gear is shifted to P (Park) by checking the instrument cluster.

R (Reverse)

Use this position to drive the vehicle rearward.



To shift the gear to R (Reverse), rotate the shift dial anti-clockwise whilst pressing the brake pedal.

When the vehicle is stopped in the R (Reverse) or D (Drive), if the driver's door is opened and the driver's seat belt is unfastened, the gear shifts to P (Park) automatically.

If the vehicle is moving in R (Reverse) or D (Drive) and the driver's door is opened and the driver's seat belt is unfastened, the gear may not shift to P (Park) automatically to prevent reduction gear damage.

The direction of the rotary gear shift dial is the same as that of the wheel.

NOTICE

Always come to a complete stop before shifting into or out of R (Reverse) to prevent damaging the reduction gear.

N (Neutral)



To shift the gear to N (Neutral), rotate the shift dial clockwise from R (Reverse) or anti-clockwise from D (Drive) whilst pressing the brake pedal.

Always press the brake pedal when you are shifting from N (Neutral) to another gear.

If you turn the vehicle off in N (Neutral), the gear shifts to P (Park).

⚠ WARNING

Do not shift gears unless your foot is firmly on the brake pedal.

A CAUTION

The vehicle can be started with the gear in N (Neutral), but for your safety, be sure to start the vehicle with the gear in P (Park).

D (Drive)



To shift the gear to D (Drive), rotate the shift dial clockwise whilst pressing the brake pedal.

The reduction gear automatically activates the recuperative braking system according to the road conditions.

When the vehicle is stopped in the D (Drive), if you open the driver's door with the seat belt unfastened, the gear shifts to P (Park).

If the vehicle is moving in D (Drive), and the driver's door is opened and the seat belt is unfastened, the gear may not shift to P (Park) automatically to protect the reduction gear.

NOTICE

Always come to a complete stop before shifting into D (Drive) to prevent damaging the reduction gear.

A CAUTION

When you start after stopping on a steep incline, even if the gear is in D (Drive), if the accelerator or brake pedal is not pressed, the vehicle may roll rearwards, that may cause an accident.

When the battery is discharged:

You cannot shift gears, when the battery is discharged.

In an emergency:

- Connect the jumper cables from another vehicle or from another battery following the "Jump starting (12 V Battery)" directions in chapter 8.
- Release the parking brake with the Start/Stop button in the DRIVE READY position.
- 3. Press the Start/Stop button to the OFF position.
- 4. Remove the P release cap cover (1) and press and hold the button (2) whilst pressing the brake pedal.



- The gear changes to the N (Neutral) position.
- The button (2) must be pressed within 3 minutes after the vehicle is turned off.
- The gear can be changed between P (Park) and N (Neutral) for 20 seconds.

i Information

In situations when the gear needs to be shifted from P (Park) to N (Neutral) when the Start/Stop button is in the OFF position, refer to step 4.

Shift-lock system

For your safety, your vehicle has a shift-lock system which prevents shifting the gear from P (Park) or N (Neutral) into R (Reverse) or D (Drive) unless the brake pedal is pressed.

To shift from P (Park) or N (Neutral) into R (Reverse) or D (Drive), from R (Reverse) into D (Drive):

- 1. Press and hold the brake pedal.
- 2. Start the vehicle.
- 3. Shift the gear in R (Reverse) or D (Drive).

i Information

The gear cannot be shifted whilst the charging cable is connected.

Parking

Always come to a complete stop and continue to press the brake pedal. Shift the gear to P (Park), apply the parking brake, and press the Start/Stop button to the OFF position. Take the key with you when leaving the vehicle.

Instrument cluster display messages

Press brake pedal to change gear

This message appears when the brake pedal is not pressed whilst shifting out of gear.

Press the brake pedal and then shift the gear.

Shift to P after stopping

This message appears when the gear is shifted to P (Park) whilst the vehicle is moving.

Stop the vehicle before shifting to P (Park).

Shifting system error

This message appears when the shift gear or the shift button does not properly operate in the P (Park) position.

Immediately we recommend that your vehicle be inspected by an authorised Genesis repairer.

Check rotary gear shift dial

This message appears when there is a malfunction with the shift dial.

Immediately we recommend that your vehicle be inspected by an authorised Genesis repairer.

Check P button

This message appears when there is a problem with the P button.

Immediately we recommend that your vehicle be inspected by an authorised Genesis repairer.

Rotary gear shift dial stuck

This message appears when the shift dial does not return back to it's normal position after rotating it.

Immediately we recommend that your vehicle be inspected by an authorised Genesis repairer.

Good driving practices

- Never shift the gear from P (Park) or N (Neutral) to any other gear when the accelerator pedal is pressed.
- Never shift the gear into P (Park) when the vehicle is moving.
 Completely stop before shifting into R (Reverse) or D (Drive).
- Do not shift the gear to N (Neutral) when driving. If the gear is shifted to N (Neutral) whilst driving, doing so may increase the risk of an accident.
 - Also, shifting the gear back to D (Drive) whilst the vehicle is moving may severely damage the reduction gear.
- When driving uphill or downhill, always shift to D (Drive) for driving forward or shift to R (Reverse) for driving rearwards. After selecting D (Drive) or R (Reverse), check the gear position indicated on the instrument cluster before driving. If the vehicle moves in the opposite direction of the selected gear, the vehicle may turn off and a serious accident might occur due to degraded brake performance.
- Do not drive with your foot resting on the brake pedal. Even light, but consistent pedal pressure may result in the brakes overheating, brake wear, and possibly even brake failure.
- Always apply the parking brake when leaving the vehicle. Do not depend on placing the shift gear in P (Park) to keep the vehicle from moving.

- Exercise extreme caution when driving on a slippery surface. Be especially careful when braking, accelerating, or shifting gears. On a slippery surface, an abrupt change in vehicle speed may cause the drive wheels to lose traction and may cause loss of vehicle control resulting in a collision.
- Optimum vehicle performance and economy is obtained by smoothly pressing and releasing the accelerator pedal.

WARNING

To reduce the risk of serious injury or death:

- Always wear your seat belt. In a collision, an unrestrained occupant is significantly more likely to be seriously injured or killed than a properly restrained occupant.
- Avoid high speeds when cornering or turning.
- Do not make quick steering wheel movements, such as sharp lane changes or fast, sharp turns.
- The risk of rollover greatly increases if you lose control of your vehicle at highway speeds.
- Loss of control often occurs if two or more wheels drop off the roadway and the driver over steers to reenter the roadway.
- In the event your vehicle leaves the roadway, do not steer sharply. Instead, slow down before pulling back into the travel lanes.
- Genesis vehicle recommends you to follow all posted speed limits.

Recuperative braking system

Recuperative braking system operates the paddle shifter to control the recuperative braking intensity of the vehicle. It improves the energy efficiency of the vehicle and helps the driver to have a better driving experience.

i Information

The recuperative braking system uses the electric motor to engage the brake. The electric motor converts the kinetic energy generated from decelerating the vehicle to electricity and charges the high voltage battery.

Using recuperative braking system

Operating paddle shifter

Operate the paddle shifter as shown below to use the recuperative braking system.



- (1) Left paddle shift (+9) (2) Right paddle shift (-9)
- Pull the left paddle shifter (+9) once to raise the recuperative braking intensity level by 1. It increases deceleration intensity.

- Pull the right paddle shifter (-1) once to lower the recuperative braking intensity level by 1. It decreases deceleration intensity.
- Pull and hold the left paddle shifter
 (+9) for over 0.5 seconds to keep
 raising the recuperative braking
 intensity level. Keeping a hold of the
 paddle shifter stops the vehicle. (For
 more information, refer to the "One
 Pedal Driving" section in this chapter.)
- (Whilst the smart recuperation system is turned on) Pull and hold the right paddle shifter (-10) for over 1 second to turn off the smart recuperation system.
 (For more information, refer to the "Smart recuperation system" section in this chapter.)

Checking the amount of recuperative braking



The selected recuperative braking level is displayed on the instrument cluster. When the vehicle is turned off and on again after the recuperative braking level is lowered to 0, the braking level changes to 1.

Recuperative braking system limitations

Recuperative braking intensity cannot be changed using the paddle shifter in the following situations:

- When the both paddle shifters are pulled at the same time.
- When the vehicle is decelerating by pressing the brake pedal.
- · When Smart Cruise Control is activated.
- When recuperative braking is continuously operated with the battery fully charged.

Initial setting of the recuperative braking level and adjustable range vary according to the selected Drive mode.

Drive mode	Adjustable Range
ECO	0 to 3
COMFORT	0 to 3
SPORT	0 to 3
SNOW	0 to 1

For more information, refer to the "Drive mode integrated control system" section in this chapter.

One Pedal Driving

One pedal driving operates the paddle shifter whilst coasting to control the intensity of recuperative braking. It assists the driver to stop the vehicle without pressing the brake pedal.

i Information

Coasting is the process of driving a vehicle without the brake pedal and the accelerator pressed. Coasting uses the inertia of driving energy instead of the vehicle power.

Using one pedal driving

Pull and hold the left paddle shifter (+9) for over 0.5 seconds whilst coasting to enable the one pedal driving mode.

- Release the paddle shifter when the vehicle speed is above 3 km/h to return to the previously set recuperative braking level.
- If the vehicle speed is below 3 km/h, the vehicle will keep engaging the brake although the driver releases the paddle shifter.
- Releasing the paddle shifter after the vehicle comes to a stop maintain the vehicle stationary.

A CAUTION

- The vehicle may not come to a stop although the one pedal driving function is active, depending on the condition of the vehicle and the road. Check the surroundings and press the brake pedal to decelerate.
- If the driver presses the accelerator whilst pulling and holding the left paddle shifter (+0) to increase the braking level, one pedal driving function will work like i-PEDAL function. In this case, the vehicle speed is no longer controllable through the paddle shifter.

One pedal driving limitations

In the following conditions, the vehicle may not come to a stop although the one pedal driving function is active. Press the brake pedal to stop the vehicle.

- When driving on a slope, or when the vehicle is repeatedly driven and stopped.
- When the vehicle is driving through the end of the slope.
- When driving on a slippery surface such as an icy, rainy, or muddy road.
- When the wheels are not properly aligned.
- When a wheel slip or wheel spin occurs.
- When the weight on board is too heavy.
- · When the vehicle is tilted to one side.
- · When a tyre is worn too much.

Automatic engagement of EPB

Use one pedal driving function to bring the vehicle to a stop and automatically engage the Electronic Parking Brake (EPB).

After the vehicle is stopped, EPB is automatically engaged when any of the following conditions are satisfied:

- The driver's seatbelt is unfastened and the driver's door is open.
- · The vehicle shifts to N (Neutral).
- · The bonnet is opened.
- The tailgate is opened.
- 5 minutes have passed since the vehicle was stopped.
- One pedal driving is limited due to other reasons.

Using i-PEDAL

i-PEDAL assists the driver to accelerate, decelerate, and stop the vehicle with only the accelerator pedal.

Turning on/off the i-PEDAL

• Turning on i-PEDAL:

Pull the left paddle shifter (++10) once when the recuperative braking level is at 3. i-PEDAL is turned on and the instrument cluster displays the "i-PEDAL". i-PEDAL is not available whilst the smart recuperation system is ON. Turn off the smart recuperation system first before using i-PEDAL.

• Turning off i-PEDAL:

Pull the right paddle shifter (②) once whilst the function is ON. Otherwise, shift the vehicle to R (Reverse) then to D (Drive) whilst the function is ON. i-PEDAL is disabled and recuperative braking level is set to 3.

A CAUTION

Depending on the vehicle and road conditions, the vehicle may not come to a stop although the i-PEDAL function is active. Check the surroundings and press the brake pedal to control the vehicle speed.

Do not use i-PEDAL on slippery roads.

i-PEDAL limitations

In the following conditions, the vehicle may not come to a stop even though i-PEDAL is properly activated. Press the brake to stop the vehicle.

- When driving on a slope, or when the vehicle is repeatedly driven and stopped.
- When the vehicle is driving through the end of the slope.
- When driving on a slippery surface such as an icy, rainy, or muddy road.
- When the wheels are not properly aligned.
- When a wheel slip or wheel spin occurs.
- · When the weight on board is too heavy.
- · When the vehicle is tilted to the side.
- · When a tyre is worn too much.

Smart recuperation system

The smart recuperation system recognises vehicle-to-vehicle distance, road gradient, and speed cameras and controls the recuperative braking level whilst coasting. It reduces unnecessary pressing of pedals to improve energy efficiency and driver convenience.

i Information

- Coasting is the process of driving a vehicle without the brake pedal and the accelerator pedal pressed. Coasting uses the inertia of driving energy instead of the vehicle power.
- The recuperative braking system uses the electric motor to engage the brake.
 The electric motor converts the kinetic energy generated from decelerating the vehicle to electricity and charges the high voltage battery.

Smart recuperation system on/off

Operate the paddle shifter as shown below to use the smart recuperation system.

 Turning on the smart recuperation system: Whilst the READY indicator is ON, shift the vehicle to D (Drive), and pull and hold the right paddle shifter (2) for over a second.



The smart recuperation system is ON and the recuperative braking level is displayed as 'AUTO'.

- Turning off the smart recuperation system: Whilst the smart recuperation system is ON, pull and hold the right paddle shifter (-20) for over a second. The instrument cluster will display the recuperative braking level instead of 'AUTO', and the smart recuperation system turns off.
- Using one pedal driving: Whilst the smart recuperation system is ON, pull and hold the left paddle shifter (±0) for over 0.5 seconds (For more information, refer to the "One Pedal Driving" section in this chapter.)

i-PEDAL is not available whilst the smart recuperation system is ON. Turn off the smart recuperation system first before using i-PEDAL.

Smart recuperation system operating condition

When the recuperative braking level is displayed as 'AUTO' and the vehicle speed is above 10 km/h, the system automatically controls the recuperative braking level under the following conditions:

- · The road gradient changes.
- Distance from the vehicle ahead reduces or increases.
- Speed of the vehicle ahead reduces or increases.

A CAUTION

- When the Forward Safety warning light is ON, the smart recuperation system does not work properly. Press the brake pedal to decelerate.
- The function that adjusts the recuperative braking intensity depending on the road gradient is only effective when the recuperative braking level is 0. Braking intensity does not significantly change depending on the road gradient if the recuperative braking level is 1 or above.

Smart recuperation level settings



The instrument cluster displays 'AUTO' (1) when the smart recuperation system is ON. Depending on the conditions, the system adjusts the recuperative braking level (2). The indicator light (3) illuminates when the vehicle recognises a vehicle.

Smart recuperation default setting

The default braking level of the smart recuperation system can be changed. Set the default braking level to the lowest and let the system adjust the braking intensity automatically.

To change the default level of the smart recuperation system, pull the right paddle shifter (-\(\Delta\)) once whilst the system is ON.

Smart recuperation intensity setting

Recuperative braking intensity of the smart recuperation system can be adjusted to match the driver's preference. Adjust the braking intensity to make the deceleration faster or slower.



To adjust the recuperative braking level of the smart recuperation system, go to Home screen and select **Electric vehicle** > ♥ > Smart recuperation from the infotainment system.

Pausing smart recuperation system

The smart recuperation system is temporarily turned off in the following conditions. Whilst the system is turned off, the driver must keep eyes on the surroundings and press the brake pedal to decelerate.

- The vehicle is shifted to N (Neutral), R (Reverse) or P (Park).
- Smart Cruise Control is ON.
- ESC (Electronic Stability Control) is operating.
- · ABS is operating.

Front sensors (Front radar)



[A] Front radar

The front radar recognises the distance from the vehicle ahead to control the recuperative braking intensity. When the front radar is covered with snow, rain, or other foreign substances, the performance of the sensors may reduce, and the smart recuperation system may turn off. Always keep the sensors clean.

System malfunction due to sensor problems



If the smart recuperation system is turned off due to the front radar being covered with foreign substances or due to other causes, the "Check smart recuperation system" warning message appears. Also the recuperative braking level is displayed instead of 'AUTO'.

The system operates normally when such foreign material is removed, and the system is turned on by pulling and holding the right paddle shifter (1991) for over a second.

If the smart recuperation system does not operate normally after the front radar has been uncovered or unblocked, we recommend that you take your vehicle to an authorised Genesis repairer and have the system checked.

Smart recuperation system precautions

- Always monitor the distance to vehicles ahead on the road. The smart recuperation system is not a substitute for safe driving practices, but a supplemental function only.
- Always maintain a safe distance from the vehicles ahead and adjust your vehicle speed to the road conditions.
 The smart recuperation system may not recognise unexpected and sudden situations or complex driving situations.

General precautions

- Always maintain a safety distance from the vehicle ahead, and adjust your vehicle speed depending on the road conditions.
- Always prepare for unexpected situations and press the brake pedal to decelerate when necessary. The smart recuperation system cannot react to pedestrians, vehicles making a sudden stop, and vehicles coming from the opposite lane.
- If the vehicle ahead frequently changes the lane, keep your eyes forward to be prepared for hazardous situations. In this case, the smart recuperation system may respond late and may inappropriately respond to vehicle movements from the side lanes.
- The driver must press the brake pedal when stopping the vehicle.


- Press the brake pedal to decelerate in the following conditions when:
 - The front part of the vehicle is lifted up because of the cargo loaded on the rear part of the vehicle.
 - You are operating the steering wheel.
 - You are not driving in the centre of the lane.
 - You are driving on a road that is too narrow or too curved.
- The smart recuperation system may temporarily turn off when exposed to strong electromagnetic waves.

Front sensor precautions

- Make sure that no physical impact is applied to the sensor or its surroundings. If the sensor is dislocated due to the force, the system may not work properly and the instrument cluster may not display any warnings. If the sensor is exposed to physical impacts, we recommend that you take your vehicle to an authorised Genesis repairer and have the system checked.
- The sensors and their surroundings, the sensor covers, and the vehicle grille should always be kept clean.
- Do not attach any accessories such as molding or stickers on the sensor or its detection range, or change the vehicle grille. It may affect sensor performance.
- Always use genuine parts for the sensor cover, and do not paint it.
- Use soft fabric to prevent damage to the sensor cover when washing the car.
- Do not spray the sensor or the surrounding with high pressure water.

Precautions for vehicle recognition

 The front sensors may suddenly recognise the vehicle ahead when the smart recuperation system reacts slowly, or the vehicle is going through the end of a slope or curve. In this case, the recuperative braking intensity is increased and the vehicle may slow down.



- The front sensors may be unable to recognise the vehicle ahead in the following situations even if it is on the same lane.
 - Narrow vehicles such as motorcycles or bicycles
 - Vehicles offset to one side
 - Slow-moving vehicles or sudden decelerating vehicles
 - Vehicles with small rear profile such as trailers with no loads
 - Vehicles with higher ground clearance or cargo that extends rearward from the cab
- When the vehicle in front of the vehicle ahead is at a stop and the vehicle ahead of you changes lane, the front sensors may be unable to recognise the stopped vehicle.

Precautions on curves



- The front sensors may be unable to recognise the vehicle ahead if you are coasting on a curve. The recuperative braking intensity may automatically be lowered, which may accelerate the vehicle.
- On a curved road, the front sensors may recognise the vehicles in another lane as the vehicle ahead in the same lane. It may increase the recuperative braking intensity and the vehicle may decelerate. Check the surroundings and press the accelerator to prevent unnecessary reduction in speed.
- If the front sensors suddenly recognise the vehicle ahead, recuperative braking intensity may rise and the vehicle may decelerate.

Precautions on the slope



- When the vehicle is coasting through the end of a slope or where the gradient is changing, the front sensors may be unable to recognise, or may suddenly recognise the vehicle ahead. It may adjust the recuperative braking intensity and change the vehicle speed.
- When driving up or down the slope, check for the surroundings and press the brake pedal to decelerate.

Precautions for shifting lanes



- [A] Your vehicle[B] Lane changing vehicle
- If a vehicle in the next lane is moving in front of your vehicle, the front sensors can only recognise the vehicle when it is completely inside the detection range.
- The front sensors may recognise any vehicles late that change lane suddenly.

Braking system

Power-assist brakes

Your vehicle has power-assisted brakes that adjust automatically through normal usage.

In the event of a vehicle power failure, the power assist for the brakes will not work. You can still stop your vehicle, but it will require greater force and increased pedal travel than normal. The stopping distance, however, will be longer than with power brakes.

i Information

- When the brake pedal is pressed under certain driving conditions or weather conditions, you may temporarily hear a noise. This is normal and does not indicate a problem with your brakes.
- Whilst driving on a road with deicing chemicals, brake noise or abnormal tyre wear may occur due to deicing chemicals. In a safe traffic condition, additionally apply the brakes to remove deicing chemicals on the brake discs and pads.

A WARNING

Take the following precautions:

 Do not drive with your foot resting on the brake pedal. This will create abnormal high brake temperatures, excessive brake lining and pad wear, and increased stopping distances.

So increase the recuperation braking level with the left paddle shift lever to decrease the speed.

- When descending down a long or steep hill, use the paddle shifter to increase the recuperation braking level in order to decrease your speed without using the brake pedal excessively. Applying the brakes continuously will cause the brakes to overheat and could result in a temporary loss of braking performance.
- Wet brakes may impair the vehicle's ability to safely decelerate because wet brakes increase braking distance and cause noise troubles, select 0 step of the recuperative braking system. Press the brake pedal around 10 times lightly, whilst keeping a safe distance from other vehicles in order to dry the braking system. Such actions may decrease the driving distance by restraining the recuperative braking system, which is not a system malfunction. Inspect the braking system after a car wash or driving on wet road conditions.

NOTICE

- Do not continue pressing the brake pedal if the READY indicator is OFF. The battery may be discharged.
- Noise and vibration generated during braking is normal.
- Under normal operation, electric brake pump noise and motor vibration may occur temporarily in below cases.
 - When the pedal is pressed suddenly.
 - When the pedal is repeatedly pressed in short intervals.
 - When the ABS function is activated whilst braking.

Disc brakes wear indicator

When your brake pads are worn and new pads are required, you may hear a high pitched warning sound from your front or rear brakes. You may hear this sound come and go or it may occur whenever you press the brake pedal.

i Information

Always replace both the left and right brake pads on the front and rear axles at the same time.

NOTICE

To avoid costly brake repairs, do not continue to drive with worn brake pads.

▲ WARNING

Frequent braking may deform components and worn the disc brake causing vibration when braking.

Observe the speed limit to prevent brake damage from excessive braking.

Brake wear, noise, vibration from excessive braking or deformation of the brakes caused by repeatedly braking at high speed, racing on tracks, etc., can be excluded from warranty coverage.

High performance brakes

For vehicles equipped with the High Performance Brakes (large diameter monoblock brakes with enhanced braking performance), noise such as a squeal, squeak or groan is generated whilst braking. This is normal and the friction may create circle patterns on the disc surface. This is also a normal condition which does not affect braking performance.

Electronic Parking Brake (EPB)

Applying the parking brake



To apply EPB (Electronic Parking Brake):

- 1. Press and hold the brake pedal.
- 2. Pull up the EPB switch.

Make sure the Parking Brake warning light comes on.

EPB (Electronic Parking Brake) may be automatically applied when:

- Requested by other systems.
- The driver turns the vehicle off whilst Auto Hold is operating.
- The gear is shifted to P (Park).

Emergency braking

If there is a problem with the brake pedal whilst driving, emergency braking is possible by pulling up and holding the EPB switch. Braking is possible only when you are holding the EPB switch. However, braking distance may be longer than normal.

MARNING

To reduce the risk of serious injury or death, do not operate the EPB whilst the vehicle is moving except in an emergency situation. It may damage the brake system and cause a collision.

i Information

During emergency braking, the Parking Brake warning light illuminates and you may hear a clicking noise.

NOTICE

If you notice a noise or burning smell when the EPB is used for emergency braking, we recommend that the system be inspected by an authorised Genesis repairer.

Releasing the parking brake



To release EPB (Electronic Parking Brake):

- Press the Start/Stop button to the POWER ON or DRIVE READY position.
- 2. Press the EPB switch whilst pressing the brake pedal.

Make sure the Parking Brake warning light goes off.

To release EPB (Electronic Parking Brake) automatically:

Gear in P (Park) or in N (Neutral)

With the vehicle running, press the brake pedal and shift out of P (Park) or N (Neutral) to R (Reverse) or D (Drive). Make sure the doors, bonnet, and boot are closed and the seat belt is fastened.

i Information

- You can engage EPB even though the Stop/Start button is in the OFF position (only if battery power is available), but you cannot release it.
- Press the brake pedal and release the parking brake manually with the EPB switch before you drive downhill or when reversing the vehicle.

NOTICE

- If the Parking Brake warning light is still on even though the EPB has been released, we recommend that the system be inspected by an authorised Genesis repairer.
- Do not drive your vehicle with EPB applied. It may cause excessive brake pad and brake rotor wear.

Warning messages

To release EPB, close the doors, bonnet and boot and fasten the seatbelt

If the driver's seat belt is unfastened, or the bonnet, boot, doors are open, and you try to drive with EPB applied, a warning sounds and a message appears.

A WARNING

To prevent serious injury or death from unintended vehicle movement:

- Always come to a complete stop and continue to press the brake pedal before parking, shift the gear into P (Park), pull up the EPB switch, and move the Start/Stop button to the OFF position. Take the key with you when leaving the vehicle.
- Never allow anyone who is unfamiliar with the vehicle to touch the EPB switch.

 Only release EPB when you are seated inside the vehicle with your foot firmly on the brake pedal.

A CAUTION

In winter, the EPB related device may freeze and cannot be released. Do not use the EPB, but park on a flat surface with the gear in P (Park). Use wheel chocks under the wheels if necessary.

If the EPB applies automatically when the gear is shifted to P (Park), turn off Auto Hold, and press the EPB switch to release the parking brake.

NOTICE

Driving with the parking brake on may overheat the braking system and cause premature wear or damage to brake parts.

i Information

- A clicking sound may be heard whilst operating or releasing the EPB. These conditions are normal and indicate that EPB is functioning properly.
- When leaving your keys with a parking attendant or assistant, be sure to inform them how to operate the EPB.

Turning off AUTO HOLD. Press brake pedal

When the conversion from Auto Hold to EPB is not working properly, a warning sounds and a message appears.

Parking brake automatically applied When EPB is applied whilst Auto Hold is activated, a warning sounds and a message appears.

EPB malfunction

Electronic Parking Brake (EPB) warning light illuminates if the Start/Stop button is pressed to the POWER ON position and goes off in about 3 seconds if the system is operating normally.

If the EPB warning light remains on, comes on whilst driving, or does not come on when the Start/Stop button is pressed to the POWER ON position, the EPB may have malfunctioned.

If this occurs, we recommend that the system be inspected by an authorised Genesis repairer.

The EPB warning light may illuminate when the ESC indicator light comes on to indicate that ESC is not working properly, but it does not indicate a malfunction of EPB.

NOTICE

- If the Parking Brake warning light does not illuminate or blinks after the EPB switch has been pulled, the EPB may not be applied.
- If the EPB warning light is still on or the Parking Brake warning light blinks when the EPB warning light is on, press the switch, and then pull it up. Repeat this one more time. If the EPB warning does not go off, we recommend that your vehicle be towed on a flatbed tow truck to an authorised Genesis repairer.

Parking brake warning light



This light illuminates when the parking brake is applied with the Start/Stop button in the POWER ON position.

Before driving, make sure the parking brake is released and the Parking Brake warning light is OFF.

If the Parking Brake warning light remains on after the parking brake is released whilst the motor is running, there may be a malfunction in the brake system.

If possible, stop driving the vehicle immediately. If that is not possible, use extreme caution whilst operating the vehicle and only continue to drive the vehicle until you can reach a safe location.

Auto Hold

Auto Hold maintains the vehicle in a standstill even though the brake pedal is not pressed after the driver brings the vehicle to a complete stop by pressing the brake pedal.

i Information

When the vehicle is restarted, the last setting for Auto Hold is applied.

To apply:



 With the driver's door, bonnet, and boot closed press the brake pedal and then press the AUTO HOLD switch. The white AUTO indicator comes on and the system is in standby.



[A] White [B] Green

When you stop the vehicle completely by pressing the brake pedal, Auto Hold maintains the brake pressure to hold the vehicle stationary. The indicator changes from white to green.

The vehicle remains stationary even if you release the brake pedal.

To release:

If you press the accelerator pedal with the gear in D (Drive) or R (Reverse), the Auto Hold is released automatically and the vehicle starts to move. The Auto indicator changes from green to white.

▲ WARNING

Always look around your vehicle before pressing the accelerator pedal to release Auto Hold.

To cancel:



- 1. Press and hold the brake pedal.
- 2. Press the **AUTO HOLD** switch.

The first indicator will turn off.

A WARNING

To prevent unintended vehicle movement, always press your foot on the brake pedal to cancel the Auto Hold before you:

- · Drive downhill.
- · Drive the vehicle in R (Reverse).
- · Park the vehicle.

i Information

- The Auto Hold does not operate when:
 - The gear is in P (Park).
 - EPB is applied.
- The Auto Hold automatically switches to FPB when:
 - The driver's door or bonnet is opened.
 - The vehicle is in a standstill for more than 10 minutes.
 - The vehicle is standing on a steep slope.
 - The vehicle moved several times.
 - The boot is opened.

In these cases, the Parking Brake warning light comes on, the AUTO indicator changes from green to white, and a warning sounds and a message appears to inform you that EPB has been automatically engaged. Before driving, press the brake pedal, check the surrounding area, and release the parking brake manually with the EPB switch.

NOTICE

If the ATE indicator changes to yellow, or the driver's door, bonnet, or boot open detection system malfunctions, Auto Hold does not work properly. We recommend that you contact an authorised Genesis repairer.

Warning messages

Parking brake automatically applied When EPB is applied whilst Auto Hold is activated, a warning sounds and a message appears.

Turning off AUTO HOLD. Press brake pedal.

When the conversion from Auto Hold to EPB is not working properly a warning sounds and a message appears.

When this message is displayed, Auto Hold and EPB may not operate. For your safety, press the brake pedal.

Press brake pedal to deactivate AUTO HOLD

If you did not apply the brake pedal when you release Auto Hold by pressing the **AUTO HOLD** switch, a warning sounds and a message appears on the instrument cluster display.

Brake Disc Cleaning

Use the Brake Disc Cleaning function if noise is generated when pressing the brake whilst driving or if the brake disc gets rusty. It helps reduce the noise and rust. Recuperative braking is restrained whilst Brake Disc Cleaning is operated, which may lower the electric energy efficiency.

Press and hold the **AUTO HOLD** switch for over 3 seconds.

- Brake Disc Cleaning starts operating when the message "Brake Disc Cleaning" is displayed on the instrument cluster.
- Recuperative braking is restrained whilst the brake is pressed about 10 times whilst driving (it may differ depending on driving conditions). This helps reduce the noise and rust.

 Brake Disc Cleaning function will turn off automatically when the operation is completed. It can also be turned off before operation is completed by turning off the vehicle or pressing the AUTO HOLD switch for over 3 seconds.

Anti-lock Brake System (ABS)

A WARNING

Anti-Lock Braking System (ABS) or Electronic Stability Control (ESC) system does not prevent accidents due to improper or dangerous driving manoeuvres. Even though vehicle control is improved during emergency braking, always maintain a safe distance between you and objects ahead of you. Vehicle speeds should always be reduced during extreme road conditions. The braking distance for vehicles equipped with ABS or ESC may be longer than for those without these systems in the following road conditions, and so you should drive at reduced speeds:

Drive your vehicle at reduced speeds during the following conditions:

- Rough, gravel, or snow-covered roads.
- On roads where the road surface is pitted or has different surface height.
- Tyre chains are installed on your vehicle.

Never test the safety features of an ABS or ESC equipped vehicle by high speed driving or cornering. It may cause a collision and endanger the safety of yourself or others.

ABS is an electronic braking system that helps prevent a braking skid. ABS allows the driver to steer and brake at the same time.

Using ABS

To obtain the maximum benefit from your ABS in an emergency situation, do not attempt to modulate your brake pressure and do not try to pump your brakes. press your brake pedal as hard as possible.

When you apply your brakes under conditions that may lock the wheels, you may hear sounds from the brakes, or feel a corresponding sensation in the brake pedal. This is normal and it means your ABS is active.

ABS does not reduce the time or distance to stop the vehicle.

Always maintain a safe distance from the vehicle in front of you.

ABS does not prevent a skid that results from sudden changes in direction, such as trying to take a corner too fast or making a sudden lane change. Always drive at a safe speed for the road and weather conditions.

ABS cannot prevent a loss of stability. Always steer moderately when braking hard. Severe or sharp steering wheel movement can still cause your vehicle to veer into oncoming traffic or off the road.

On loose or uneven road surfaces, operation of the anti-lock brake system may result in a longer stopping distance than for vehicles equipped with a conventional brake system.

The ABS ((((iii))) warning light stays on for several seconds after the Start/Stop button is in POWER ON position.

During that time, ABS goes through self-diagnosis and the light will go off if everything is normal. If the light stays on, we recommend that you contact an authorised Genesis repairer as soon as possible.

WARNING

If the ABS (((a)) warning light is on and stays on, you may have a problem with the ABS. Your power brakes work normally. To reduce the risk of serious injury or death, we recommend that you contact an authorised Genesis repairer as soon as possible.

NOTICE

When you drive on a road having poor traction, such as an icy road, and apply your brakes continuously, ABS is active continuously and the ABS () warning light may illuminate. Pull your vehicle over to a safe place and turn off the vehicle.

Restart the vehicle. If the ABS warning light is off, your ABS system is normal. If not, we recommend that you contact an authorised Genesis repairer as soon as possible.

i Information

When you jump start your vehicle because of a drained battery, the ABS (((a))) warning light may turn on at the same time. It does not mean your ABS is malfunctioning. Have the battery recharged before driving the vehicle.

Electronic Stability Control (ESC)



Electronic Stability Control helps stabilize the vehicle during cornering manoeuvres.

ESC checks where you are steering and where the vehicle is actually going. ESC applies braking pressure to any one of the vehicle's brakes and intervenes in the electric vehicle control system to assist the driver with keeping the vehicle on the intended path. It is not a substitute for safe driving practices. Always adjust your speed and driving to the road conditions.

A WARNING

Never drive too fast for the road conditions when cornering. ESC does not prevent a collision.

Excessive speed in turns, abrupt manoeuvres, and hydroplaning on wet surfaces may result in severe collisions.

ESC operation

ESC ON condition

When the Start/Stop button is in POWER ON position, ESC and the ESC OFF indicator lights illuminate for about three seconds. After both lights go off, ESC is enabled.

When operating



When ESC is operating, the ESC indicator light blinks:

- When you apply your brakes under conditions that may lock the wheels, you may hear sounds from the brakes, or feel a corresponding sensation in the brake pedal.
- When ESC activates, the vehicle may not respond to the accelerator as it does under routine conditions.
- If Cruise Control has been used when ESC activates, Cruise Control automatically disengages. Refer to the "Smart Cruise Control (SCC)" section in chapter 7.

ESC OFF condition



To cancel ESC operation:

State 1

Press the ESC OFF button briefly. The ESC OFF indicator light and the message, "Traction control disabled" illuminates. The traction control function of ESC (electric vehicle control management) is disabled, but the brake control function of ESC (braking management) still operates.

State 2

Press and hold the ESC OFF button continuously for more than 3 seconds. The ESC OFF indicator light and the message, "Traction & Stability control disabled" illuminates and a warning chime sounds. In this state, both the traction control function of ESC (electric vehicle control management) and the brake control function of ESC (braking management) are disabled.

If the Start/Stop button is pressed to the OFF position when ESC is off, ESC remains off. Upon restarting the vehicle, ESC automatically turns on again.

When ESC (electric vehicle control) is deactivated, the vehicle will loose the traction and stability if the vehicle is driven by abrupt steering wheel control.

We recommend that you do not turn off ESC whilst driving the vehicle for your safety.

Indicator lights

ESC indicator light (blinks)



ESC OFF indicator light (comes on)



When the Start/Stop button is pressed to the POWER ON position, the ESC indicator light illuminates, then goes off if the ESC system is operating normally.

The ESC indicator light blinks whenever ESC is operating.

If the ESC indicator light stays on, we recommend that your vehicle be inspected by an authorised Genesis repairer as soon as possible.

The ESC OFF indicator light comes on when ESC is turned off.

M WARNING

When ESC is blinking, this indicates ESC is active:

- Drive slowly and NEVER attempt to accelerate.
- Never turn off ESC whilst the ESC indicator light is blinking. You may lose control of the vehicle and have a collision.

i Information

Driving with wheels and tyres with different sizes may cause the ESC system to malfunction. Before replacing tyres, make sure all four tyres and wheels are the appropriate size for your vehicle. Never drive the vehicle with different sized wheels and tyres installed.

ESC OFF usage

When Driving

The ESC OFF mode should only be used briefly to help free the vehicle if stuck in snow or mud, by temporarily stopping operation of ESC, to maintain wheel torque.

To turn off ESC whilst driving, press the ESC OFF button whilst driving on a flat road surface.

NOTICE

To prevent damage to the reduction gear:

- Do not allow wheel(s) of one axle to spin excessively whilst the ESC, ABS, and Parking Brake warning lights appear. The repairs would not be covered by the vehicle warranty. Reduce motor power and do not spin the wheel(s) excessively whilst these lights appear.
- When operating the vehicle on a dynamometer, make sure ESC is turned off (ESC OFF light illuminated).

i Information

Turning off ESC does not affect ABS or standard brake system operation.

Vehicle Stability Management (VSM)

Vehicle Stability Management is a function of the Electronic Stability Control (ESC) system. It helps the vehicle stay stable when accelerating or braking suddenly on wet, slippery, and rough roads where traction over the four tyres can suddenly become uneven.

WARNING

VSM is not a substitute for safe driving practices. To prevent serious injury or death:

- Always monitor the speed and the distance to the vehicle ahead of you.
- Never drive too fast for the road conditions. Excessive speed in bad weather or on slippery and uneven roads may result in severe collisions.

VSM operation

When operating

When you apply your brakes under conditions that can activate ESC, you may hear sounds from the brakes, or feel a corresponding sensation in the brake pedal. This is normal and it means your VSM is active.

i Information

VSM does not operate when:

- Driving on a banked road such as gradient or incline.
- · Driving in reverse.
- · The ESC OFF indicator light is on.
- The MDPS (Motor Driven Power Steering) (♠!) warning light is on or blinks.

VSM OFF condition

To cancel VSM operation, press the ESC OFF button. ESC OFF (景) indicator light illuminates.

To turn on VSM again, press the ESC OFF button again. The ESC OFF indicator light will goes out.

A WARNING

If the ESC (\$\mathbb{B}\$) indicator light or MDPS (\(\overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Overline{\Ov

NOTICE

Driving with wheels and tyres with different sizes may cause the VSM system to malfunction. Before replacing tyres, make sure all four tyres and wheels are the same size. Never drive the vehicle with different sized tyres and wheels installed.

Hill-Start Assist Control (HAC)

Hill-Start Assist Control helps prevent the vehicle from rolling rearwards when starting from a stop on a hill.

A WARNING

Always be ready to press the accelerator pedal when starting from a stop on an uphill slope. Hill-Start Assist Control activates only for about 5 seconds.

i Information

- Hill-Start Assist Control does not operate when the gear is shifted to P (Park) or N (Neutral).
- Hill-Start Assist Control activates even when the ESC (Electronic Stability Control) is off. It does not activate, if the ESC is not operating normally.

Emergency Stop Signal (ESS)

Emergency Stop Signal alerts the driver behind by blinking the stop lights, whilst sharply and severely braking.

The system is activated when:

- The vehicle suddenly stops. (The deceleration power exceeds 7 m/s², and the driving speed exceeds 55 km/h.)
- · ABS is activated.

The hazard warning flasher automatically turns ON after blinking the stop lights when:

- The vehicle speed is below 40 km/h.
- · ABS is deactivated, and
- The sudden braking situation is over.

The hazard warning flasher turns OFF when:

 The vehicle drives at a low speed for a certain period of time.

The driver manually turns OFF the hazard warning flasher by pressing the button.

i Information

Emergency Stop Signal does not activate, when the hazard warning flashers are already on.

Multi-Collision Brake (MCB)

Multi-Collision Brake controls the brakes automatically in the event of an accident where the airbag deploys to reduce the risk of additional collisions that may occur.

System operation

- From the time the airbag deploys, Multi-Collision Brake monitors the pressure intensity of the brake pedal and accelerator pedal for a short period. The system operates when the following conditions are met:
 - Vehicle speed is under 180 km/h at the time of collision.
 - The brake pedal and accelerator pedal are firmly pressed.
- When the driver steps on the brake pedal over a certain level whilst Multi-Collision Brake is active, the braking power takes priority over automatic braking by Multi-Collision Brake system. However, if the driver takes their foot off the brake pedal, the Multi-Collision Brake system will maintain automatic braking.

System off

Multi-Collision Brake is cancelled in the following situations:

- The accelerator pedal is pressed over a certain level.
- · The vehicle stops.
- ESC (Electronic Stability Control) or electronic devices has malfunctioned.
- In a situation system cannot operate normally.
- Ten seconds have passed since the brakes have been controlled automatically by Multi-Collision Brake system.

WARNING

- Multi-Collision Brake decreases vehicle speed after a collision and reduces the risk of a second collision, but it does not prevent a second collision. You may drive away from the collision spot to avoid other dangerous situations by pressing the accelerator pedal.
- After the vehicle is stopped by Multi Collision Brake, the system stops controlling the brakes. Depending on the situation, the driver should press the brake or the accelerator pedal to prevent further accidents.

Brake Assistant System (BAS)

The Brake Assistant System provides additional pressure when the brake pedal is momentarily and strongly pressed in a situation sudden braking is required whilst driving.

The Brake Assistant System reduces the time for ABS (Anti-Lock Brake System) control to enter and consequently reduces the braking distance, by providing additional pressure up to the point of ABS intervention.

A WARNING

The system may not operate depending on the driver's driving habits, vehicle speed, the degree to which the brake pedal is pressed and the road surface condition.

Good braking practices

WARNING

Whenever leaving the vehicle or parking, always come to a complete stop and continue to press the brake pedal. Shift the gear to the P (Park) position, apply the parking brake, and press the Start/Stop button to the OFF position.

Vehicles parked with the parking brake not applied or not in P (Park) may roll unintentionally and may cause injury to the driver and others

Wet brakes can be dangerous! The brakes may get wet if the vehicle is driven through standing water or if it is washed. Your vehicle may not stop quickly if the brakes are wet. Wet brakes may cause the vehicle to pull to one side.

To dry the brakes, apply the brakes lightly until the braking action returns to normal. If the braking action does not return to normal, stop as soon as it is safe to do so and we recommend that you contact an authorised Genesis repairer for assistance.

DO NOT drive with your foot resting on the brake pedal. Even light, but constant pedal pressure may result in the brakes overheating, brake wear, and possibly even brake failure.

If a tyre goes flat whilst you are driving, apply the brakes gently and keep the vehicle pointed straight ahead whilst you are slowing down. When you are moving slowly enough for it to be safe to do so, pull off the road and stop in a safe location.

Keep your foot firmly on the brake pedal when the vehicle is stopped to prevent the vehicle from rolling forward.

All Wheel Drive (AWD)

When All Wheel Drive (AWD) is activated, driving forces are distributed appropriately to front and rear wheels. It could improve driving performance by maximising the driving force of vehicles on severe road conditions such as steep hills, unpaved, slippery, etc.

Advantage of electronic AWD

- 1. Improvement of straight stability.
- 2. Improvement of driving performance on curve.
- 3. Secure stability on severe condition such as wet and sandy roads.
- 4. Improvement of energy efficiency from driving mode automatic control.

i Information

AWD vehicles could change the engagement status of the motor according to the situation required. Auto changing the driving mode (2WD/AWD) helps improve energy efficiency and driving stability.

A WARNING

To reduce the risk of serious injury or death:

- Avoid high speeds when cornering or turning.
- Do not make quick steering wheel movements, such as sharp lane changes or fast, sharp turns.
- The risk of a rollover is greatly increased if you lose control of your vehicle at highway speeds.
- Loss of control often occurs if two or more wheels drop off the roadway and the driver over steers to reenter the roadway.
- In the event your vehicle leaves the roadway, do not steer sharply. Instead, slow down before pulling back into the travel lanes.

NOTICE

- Do not drive in water if the water level is higher than the bottom of the vehicle.
- Check your brake condition once you are out of mud or water. Press the brake pedal several times as you move slowly until you feel normal braking condition return.
- Shorten your scheduled maintenance interval if you drive in off-road conditions such as sand, mud, or water (refer to the "Maintenance under severe usage conditions" section in chapter 9).
- Always wash your vehicle thoroughly after off-road use, especially the bottom of the vehicle.
- Be sure to equip the vehicle with four tyres of the same size and type.
- Make sure that a full time AWD vehicle is towed by a flat-bed tow truck.

For safe AWD operation

Before driving

- Make sure all passengers always wear their seat belts.
- Sit upright and closer to the steering wheel than usual. Adjust the steering wheel to a position comfortable for you to drive.

Driving on snow-covered or icy roads

- Start off slowly by applying the accelerator pedal gently.
- · Use snow tyres or tyre chains.
- Keep a sufficient distance between your vehicle and the vehicle in front.
- Using recuperative braking helps the steering on the downhill. However, it may be difficult to adjust the vehicle whilst coasting using recuperative braking, so avoid using the third level of recuperative braking as much as possible.

- Avoid speeding, rapid acceleration, sudden brake applications, and sharp turns to prevent skids.
- It is difficult to start again if the vehicle stops on an uphill road. Keep your distance from other vehicles and drive slowly.

i Information

- When using snow tyres, mount them on all four wheels.
- When using tyre chains, install them on the rear tyres. However, driving speed must be below 30 km/h and minimise the driving distance. High-speed or long-term driving with the chains installed may malfunction or damage the AWD system.
 - For more information on Snow tyres and Tyre Chains, refer to the "Winter driving" section later in this chapter.

Driving in sand or mud

- Maintain slow and constant speeds.
- Use tyre chains when driving in mud if necessary.
- Keep a distance between your vehicle and the vehicle in front.
- Reduce the vehicle speed and always check the road condition.
- Avoid speeding, rapid acceleration, sudden brake applications, and sharp turns to prevent getting stuck.

NOTICE

When the vehicle is stuck in snow, sand, or mud, place a nonslip material under the drive wheels to provide traction OR slowly spin the wheels in forward and reverse causing a rocking motion that may free the vehicle.

Driving up or down hills

- · Driving uphill
 - Before starting off, check if it is possible to drive uphill.
 - Drive as straight as possible.
- Driving downhill
 - Do not change gears whilst driving downhill. Select a gear before driving downhill.
 - Drive straight as possible.

A WARNING

- Exercise extreme caution driving up or down steep hills. The vehicle may roll over on the gradient, terrain, and water/mud conditions.
- Do not drive across the contour of steep hills. A slight change in the wheel angle may destabilize the vehicle. A stable vehicle may lose stability if the vehicle stops its forward motion. Your vehicle may roll over, resulting in a serious injury or death.

Additional driving conditions

- Become familiar with the off-road conditions before driving.
- Always pay attention when driving off-road and avoid dangerous areas.
- Drive slowly when driving in heavy wind.
- Reduce vehicle speed when cornering.
 The centre of gravity of AWD vehicles is
 higher than conventional 2WD vehicles.
 The vehicle is more likely to roll over if
 you turn the steering wheel too quickly.
- Always hold the steering wheel firmly when you are driving off-road.

A WARNING

Do not grab the inside of the steering wheel when you are driving off-road. You may hurt your arm by a sudden steering manoeuvre or from steering wheel rebound due to an impact with objects on the ground. You may lose control of the steering wheel that may lead to serious injury or death.

Emergency precautions

Tyres

- Do not use tyres or wheels with different size and type from the one installed on your vehicle. It may affect the safety and performance of your vehicle, which could cause steering failure or rollover causing serious injury.
- When replacing the tyres, be sure to equip all four tyres with the same size, type, tread, brand, and load-carrying capacity. If you equip your vehicle with any tyre/wheel combination not recommended by Genesis vehicle for off-road driving, do not use these tyres for highway driving.

MARNING



Never start or run the vehicle whilst an AWD vehicle is raised on a jack. The vehicle may slip or roll off of a jack causing serious injury or death.

Towing


AWD vehicles must be towed with a wheel lift and dollies or flatbed equipment with all the wheels off the ground. For more information, refer to the "Towing" section in chapter 8.

Vehicle inspection

- If the vehicle needs to be operated on a vehicle lift, do not attempt to stop any of the four wheels from turning. This may damage the AWD system.
- Never apply the parking brake whilst running the vehicle on a vehicle lift. This may damage the AWD system.

Dynamometer testing

An AWD vehicle must be tested on a special four wheel chassis dynamometer.



[A] Roll tester (Speedometer), [B] Temporary free roller

If a 2WD roll tester must be used:

- 1. Check the tyre pressures recommended for your vehicle.
- 2. Place the rear wheels on the roll tester for a speedometer test as shown in the illustration.
- 3. Release the parking brake.
- 4. Place the front wheels on the temporary free roller as shown in the illustration.

NOTICE

- Never engage the parking brake whilst performing the test.
- When the vehicle is lifted up, do not operate the front and rear wheel separately. All four wheels should be operated.

▲ WARNING

Keep away from the front of the vehicle whilst the vehicle is in gear on the dynamometer. The vehicle may jump forward and cause serious injury or death.

Electronic control suspension



Electronic Control Suspension controls the vehicle suspension automatically using vehicle sensors to maximise driving comfort by taking into account the driving conditions such as speed, surface of the road, cornering, stopping requirements, and acceleration.

System malfunction

Check Electronic Suspension
When Electronic Control Suspension is not working properly, this warning message appears on the instrument cluster display. If this occurs, we recommend that the system be inspected by an authorised Genesis repairer.

Electronically controlled suspension with road preview

tif equipped

Electronically Controlled Suspension with Road Preview helps control the vehicle suspension automatically using the front view camera and vehicle sensors to maximise driving comfort by taking into account the driving conditions such as speed, surface of the road, cornering, stopping requirements, and acceleration.

Front view camera



[A] Front view camera

The front view camera is a sensor that detects the front road. When the front view camera is covered or blocked, its detecting performance is reduced, and the data collected by the camera may be limited.

NOTICE

To prevent vehicle damage:

- Never disassemble the camera sensors or camera sensor assemblies.
- Only have the detecting sensor replaced or repaired by an authorised Genesis repairer.
- Never install any accessories, stickers, or tint the front windscreen.
- · Always keep the camera dry.
- Never place any reflective objects (for example, white paper or mirror) on the instrument panel.

i Information

We recommend that the system be inspected by an authorised Genesis repairer when:

- · The windscreen glass is replaced.
- The front view camera or cover gets damaged or replaced.

System malfunction

Check Electronic Suspension

When Electronically Controlled Suspension with Road Preview is not working properly, the "Check electronic suspension" warning message may appear on the instrument cluster display. If this occurs, we recommend that the system be inspected by an authorised Genesis repairer.

NOTICE

If the battery level is high or low, Electronically Controlled Suspension with Road Preview may not work temporarily to protect the system. If this occurs, "Check electronic suspension" warning message may appear.

Limitations of the system

Electronically Controlled Suspension with Road Preview always operates whilst driving according to the vehicle's movement, and the preview function starts to work when the front view camera detects road conditions such as speed bumps. Therefore, the preview function is limited when there is an extreme condition and the front view camera may not work normally. In this case, the electronic control suspension function operates without the preview function in accordance with vehicle movement.

Drive mode integrated control system

The drive mode can be selected according to the driver's preference or road condition.

Drive mode

The mode changes whenever the **DRIVE MODE** button is pressed.



The mode changes, as the following, whenever the **DRIVE MODE** button is pressed.

ECO > COMFORT > SPORT > MY > SNOW

Hold: CHAUFFEUR

MY DRIVE mode features

MY DRIVE mode allows driver to personalize the setting of the motor, steering wheel and suspension.

To set MY DRIVE mode, go to **Setup** > **Vehicle**> **Drive mode** > **MY DRIVE MODE** in the infotainment system.

Motor: ECO/COMFORT/SPORT

Steering: COMFORT/SPORT

Suspension: COMFORT/SPORT

Setting BRAKE mode

tif equipped

To set the BRAKE mode to adjust brake response, park the vehicle and shift the gear to P (Park). Go to **Setup > Vehicle > Drive mode > Brakes mode** in the infotainment system and select a mode.

- COMFORT: Brake response appropriate for comfort driving.
- SPORT: Brake response appropriate for dynamic driving.
- CHAUFFEUR: Brake response appropriate for rear seat comfort.

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Drive mode features

COMFORT mode

COMFORT mode provides a balanced motor response which is suited for everyday driving. The vehicle is usually driven with 2WD (Rear-wheel drive), but automatically shifts to AWD depending on the road and driving conditions.

ECO mode

ECO mode is a driving mode that helps improve energy efficiency by limiting maximum vehicle power (torque), providing smooth vehicle response and driving the vehicle with the rear wheels (2WD).

Energy efficiency varies according to the driver's driving habit and road condition.

 When ECO mode is selected, the ECO indicator will illuminate on the instrument cluster and theme of the instrument cluster will change.

When ECO mode is activated:

- All wheel drive and sharp acceleration and deceleration is limited.
- The vehicle will automatically convert between 2WD to AWD when:
 - i-Pedal or One Pedal Driving is operating.
 - The temperature is low.
 - Driving on a slope or a slippery road.

SPORT mode

SPORT mode is a driving mode that provides sporty but firm ride by making the motor response more quickly, making the steering wheel heavier and driving the vehicle with all four wheels (AWD).

In SPORT mode, the energy efficiency may decrease.

- When SPORT mode is selected, the SPORT indicator will illuminate on the instrument cluster and theme of the instrument cluster will change.
- Whenever the vehicle is restarted, the drive mode will revert back to COMFORT mode. If SPORT mode is required, re-select SPORT mode.

SNOW mode

SNOW mode is a driving mode improving driving performance by changing the engagement status of the motor according to the situation required. Auto changing the driving mode (2WD/AWD) helps improve driving stability.

- Press and hold the drive mode button to select SNOW mode
- When SNOW mode is selected, the SNOW indicator will illuminate on the instrument cluster and the colour of the mood lamp will change.
- When SNOW mode is activated, the driving power is distributed to four wheels automatically, increasing the stability of the vehicle.

NOTICE

- Press the accelerator pedal softly on the snow and the ice.
- Keep the distance from the vehicle in the front.
- Prevent rapid acceleration, deceleration and steering control.
 Abrupt driving on the snow may cause the accident.

CHAUFFEUR mode features

CHAUFFEUR mode controls the motor, steering wheel and suspension to provide a comfortable driving experience to rear seat passengers.

Drive modes characteristic

The characteristic of each components varies according to which drive mode is selected.

Drive mode	ECO	COMFORT	SPORT	SNOW
Characteristics	High electric energy efficiency mode	Comfort driving mode	Sporty driving mode	Snow driving
Button activation	Press	Press	Press	Press more than 1 sec.
Indicator on the cluster	ECO	-	SPORT	SNOW
Climate system control	ECO/COMFORT	COMFORT	COMFORT	COMFORT
Speed limit	-	-	-	-
Recuperative braking level	0-3	0-3	0-3	0-1

i Information

- The infotainment system may change after software updates. For more information, refer to the user's manual provided in the infotainment system and the quick reference guide.
- You can set the driving condition for each drive mode, at the Drive Mode > Climate Control ECO Mode in the infotainment system.

Road active noise control

Road Active Noise Control helps reduce noise caused whilst driving.

The system may not operate properly in the following conditions:

- · Any of the windows are open.
- · Any of the doors are open.
- The boot is open.
- Vehicle's microphone and speaker are blocked by loads.

System malfunction

When Road Active Noise Control is not working properly, the "Check road active noise control system" warning message may appear on the instrument cluster display. If this occurs, we recommend that the system be inspected by an authorised Genesis repairer.

Active sound design

tif equipped

- Active sound design provides various virtual driving sounds based on the driving mode, vehicle speed, and accelerator pedal. You can adjust the volume and change the settings for acceleration pedal response and sound style.
- You can activate or deactivate the Active Sound Design function from the Settings menu in the infotainment system. Select:
 - Setup > Vehicle > Active sound design > Horizon/Heritage: Black
- Any unauthorised replacement of the vehicle's speaker and amplifier may cause Active Sound Design to malfunction.

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Special driving conditions

Hazardous driving conditions

When hazardous driving conditions are encountered such as water, snow, ice, mud, and sand:

- Drive cautiously and allow for longer braking distances.
- · Avoid abrupt braking or steering.
- When your vehicle is stuck in snow, mud, or sand, accelerate slowly to avoid unnecessary wheel spin.
- Put sand, rock salt, tyre chains, or other non-slip materials under the wheels to provide additional traction if stuck in ice, snow, or mud.

A WARNING

Changing the tyre speed suddenly could cause the tyres to skid whilst driving on slippery surfaces. Be careful when driving on slippery surfaces.

Rocking the vehicle

If it is necessary to rock the vehicle to free it from snow, sand, or mud, first turn the steering wheel right and left to clear the area around your front wheels. Then, shift back and forth between R (Reverse) and a forward gear.

Try to avoid spinning the wheels, and do not race the vehicle.

To prevent reduction gear wear, wait until the wheels stop spinning before shifting gears. Release the accelerator pedal whilst shifting, and press lightly on the accelerator pedal whilst the reduction gear is in gear. Slowly spinning the wheels in forward and reverse directions causes a rocking motion that may free the vehicle.

WARNING

Always turn off the ESC system before rocking the vehicle. If the vehicle is stuck and excessive wheel spin occurs, the temperature in the tyres may increase very quickly. If the tyres become damaged, a tyre blow out or tyre explosion may occur - you and others may be injured. Do not attempt this procedure if people or objects are near the vehicle.

If you attempt to free the vehicle, the vehicle may overheat quickly, possibly causing an motor compartment fire or other damage. Try to avoid spinning the wheels as much as possible to prevent overheating of the tyres or the motor. DO NOT allow the vehicle to spin the wheels above 56 km/h.

If you are still stuck after rocking the vehicle a few times, have the vehicle pulled out by a tow vehicle to avoid motor overheating, possible damage to the gear, and tyre damage. Refer to the "Towing" section in chapter 8.

Smooth cornering

Avoid braking or gear changing in corners, especially when roads are wet. Ideally, cornering should be taken under gentle acceleration.

Driving at night

Night driving presents more hazards than driving in the daylight. Here are some important tips to remember:

- Slow down and keep more distance between you and other vehicles, because it may be more difficult to see at night, especially in areas where there are no street lights.
- Adjust your mirrors to reduce the glare from other drivers' headlamps.
- Keep your headlamps clean and properly aimed. Dirty or improperly aimed headlamps can make it much more difficult to see at night.
- Avoid staring directly at the headlamps of oncoming vehicles. You could be temporarily blinded, and it takes several seconds for your eyes to readjust to the darkness.

Driving in the rain

Rain and wet roads can make driving dangerous. When driving in the rain or on slick payement:

- Slow down and allow extra following distance. A heavy rainfall makes it harder to see and increases the distance needed to stop your vehicle.
- · Turn OFF your Smart Cruise Control.
- Replace your windscreen wiper blades when they show signs of streaking or missing areas on the windscreen.
- Make sure your tyres have enough tread. If your tyres do not have enough tread, making a quick stop on wet pavement may cause a skid and possibly collision. Refer to the "Tyre replacement" section in chapter 9.
- Turn on your headlamps to make it easier for others to see you.

- Driving too fast through large puddles may affect your brakes. If you must go through puddles, try to drive through them slowly.
- If you believe your brakes may are wet, apply them several times whilst the vehicle is moving slowly.

Hydroplaning

If the road is wet enough and you are driving fast enough, your vehicle may have little or no contact with the road surface and actually ride on the water. The best advice is SLOW DOWN when the road is wet.

The risk of hydroplaning increases as the depth of tyre tread decreases, refer to the "Tyre replacement" section in chapter 9.

Driving in flooded areas

Avoid driving through flooded areas unless you are sure the water is not deeper than the bottom of the wheel hub. If you are not sure, turn around and find a different route.

Drive through any water slowly. Allow adequate stopping distance because the brake performance can be reduced.

After driving through water, dry the brakes by gently applying them several times whilst the vehicle is moving slowly.

Highway driving

Tyres

Adjust the tyre inflation pressure, as specified. Under-inflation may overheat or damage the tyres.

Do not install worn-out or damaged tyres, which may reduce traction or fail.

i Information

Never over-inflate your tyres above the maximum inflation pressure, as specified on your tyres.

Coolant and high voltage battery

Driving at higher speeds on the highway consumes more electric energy and is less efficient than driving at a slower, more moderate speed. Maintain a moderate speed in order to conserve electric energy when driving on the highway. Be sure to check both the coolant level and the electric energy level before driving.

Winter driving

Snow or icy conditions

You need to keep sufficient distance between your vehicle and the vehicle in front.

Apply the brakes gently. Speeding, rapid acceleration, sudden brake applications, and sharp turns are very hazardous practices. Sudden brake applications on snowy or icy roads may cause the vehicle to skid.

To drive your vehicle in deep snow, it may be necessary to use snow tyres or to install tyre chains on your tyres.

Always carry emergency equipment. You may want to carry tyre chains, tow straps or chains, a flashlight, emergency flares, sand, a shovel, jumper cables, a window scraper, gloves, ground cloth, coveralls, a blanket, etc.

Summer tyres

- Summer tyres are used to maximise the driving performance on dry roads.
 If the temperature is below 7 °C or you are driving on snowy or icy roads, the summer tyres lose their brake performance and traction as the tyre grip weakens significantly.
- If the temperature is below 7 °C or you are driving on snowy or icy roads, mount snow tyres or all-season tyres of the same size with your vehicle's standard tyre for safe driving. Both snow and all-season tyres have M+S markings.
- When using the M+S tyres, use tyres with the same tread produced by the same manufacturer for safe driving.
- When driving with the M+S tyres with the lower maximum allowable speed than that
 of the vehicle's standard summer tyre, be careful not to exceed the speed allowed for
 the M+S tyres.

Snow tyres



⚠ WARNING

Snow tyres should be equivalent in size and type to the vehicle's standard tyres. Otherwise, the safety and handling of your vehicle may be adversely affected.

We recommend that you use snow tyres when road temperature is below 7 $^{\circ}$ C (45 $^{\circ}$ F). Refer to the below chart, and mount the recommended snow tyre for your vehicle.

Standard tyre		Recommended snow tyre		
Tyre size	Wheel size	Tyre size	Wheel size	
245/45ZR19	8.5J X 19	245/45R 19	8.5J X 19	
275/40ZR19 9.5J	9.5J X 19	245/45R19	8.5J X 19	
	9.33 X 19	275/40R19	9.5J X 19	

If you mount snow tyres on your vehicle, be sure to use the same inflation pressure as the original tyres. Mount snow tyres on all four wheels to balance your vehicle's handling in all weather conditions. The traction provided by snow tyres on dry roads may not be as high as your vehicle's original equipment tyres. Check with the tyre dealer for maximum speed recommendations.

Tyre chains



Since the sidewalls on some radial tyres are thinner than other types of tyres, they may be damaged by mounting certain types of tyre chains on them. Do not mount tyre chains on vehicles equipped with aluminium wheels. Install the tyre chains after reviewing the instructions provided with the tyre chains. Damage to your vehicle caused by improper tyre chain use is not covered by your vehicle manufacturer's warranty.

When using tyre chains, attach them to the rear wheels.

Disabling Rear Wheel Steering system to install snow chains

If the Rear Wheel Steering system is applied, disable the system to protect the vehicle when snow chains are installed.

- Select Setup > Vehicle > Convenience
 Snow Chains Installed in the
 infotainment system to disable the
 Rear Wheel Steering system.
- After selecting 'Snow Chains Installed' in the infotainment system, turn the steering wheel 180 degrees to the left and right 2 to 3 times whilst the vehicle is stopped, and check if the rear wheels are straight before driving.

A CAUTION

- For your safety, change the Settings after parking the vehicle in a safe location.
- After removing the snow chains, be sure to deselect 'Snow Chains Installed' in the infotainment system to operate the Rear Wheel Steering system again.

NOTICE

If you drive without disabling the Rear Wheel Steering system in the infotainment system after installing snow chains, the snow chains can damage your vehicle's body or chassis parts. When you hear the snow chain hitting the vehicle, stop the vehicle and check whether the snow chains are installed properly and whether the Rear Wheel Steering system is disabled.

A WARNING

The use of snow chains may adversely affect vehicle handling:

- Drive less than 30 km/h or the chain manufacturer's recommended speed limit, whichever is lower.
- Drive carefully and avoid bumps, holes, sharp turns, and other road hazards, which may cause the vehicle to bounce.
- Avoid sharp turns or locked wheel braking.
- Install snow chains only in pairs and on the rear tyres. Installing snow chains on the tyres provides a greater driving force, but does not prevent side skids.

i Information

Do not install studded tyres without first checking local and municipal regulations for possible restrictions against their use.

Chain installation

When installing snow chains, follow the manufacturer's instructions and mount them as tightly as possible. Drive slowly (less than 30 km/h or the chain manufacturer's recommended speed limit) with chains installed. If you hear the chains contacting the body or chassis, stop and tighten them. If they still make contact, slow down until the noise stops. Remove the snow chains as soon as you begin driving on cleared roads.

When mounting snow chains, park the vehicle on level ground away from traffic. Turn on the vehicle's Hazard Warning Flasher and place a triangular emergency warning device behind the vehicle (if available).

Always place the vehicle in P (Park), apply the parking brake, and turn off the vehicle before installing tyre chains.

NOTICE

When using snow chains:

- Wrong size chains or improperly installed chains may damage your vehicle's brake lines, suspension, body, and wheels.
- If you hear noise caused by chains contacting the body, retighten the chains to prevent contact with the vehicle body.
- To prevent body damage, retighten the chains after driving 0.5-1.0 km.

Winter precautions

Check battery and cables

Winter temperatures affect battery performance. Inspect the battery and cables, as specified in chapter 9. We recommend that the system be inspected by an authorised Genesis repairer.

To prevent locks from freezing

Spray approved de-icing fluid or glycerin into key holes. When a lock opening is already covered with ice, spray approved de-icing fluid over the ice to remove it. When an internal part of a lock freezes, try to thaw it with a heated key. Carefully use the heated key to avoid an injury.

Use approved window washer anti-freeze solution

Add window washer anti-freeze solution, as specified on the window washer container. We recommend using the window washer anti-freeze solution is available from an authorised Genesis repairer, and most vehicle accessory outlets.

NOTICE

Do not use coolant or other types of anti-freeze solution, to prevent any damage to the vehicle paint.

Do not let your parking brake freeze

Under some conditions, your parking brake may freeze in the engaged position. This is most likely to happen when there is an accumulation of snow or ice around or near the rear brakes or the brakes are wet. When there is the risk that your parking brake may freeze: temporarily apply the parking brake with the gear in P (Park), then block the rear wheels, and then release the parking brake.

Do not let ice and snow accumulate underneath

Under some conditions, snow and ice may build up under the fenders and interfere with the steering. When driving in such conditions during the severe winter, you should check underneath the vehicle on a regular basis, to make sure that the front wheels and the steering components is are not blocked.

Carry emergency equipment

In accordance with weather conditions, carry appropriate emergency equipment, whilst driving. Some of the items you may want to carry include tyre chains, tow straps or chains, flashlight, emergency flares, sand, shovel, jumper cables, window scraper, gloves, ground cloth, coveralls, blanket, etc.

Do not place objects or materials in the motor compartment

Putting objects or materials in the motor compartment may cause an motor failure or a fire, because they may block the motor cooling. Such damage is not be covered by the manufacturer's warranty.

Trailer towing

We do not recommend using this vehicle for trailer towing.

Vehicle weight

Before loading your vehicle, familiarise yourself with the following terms for determining your vehicle's weight ratings, from the vehicle's specifications:

Base Kerb Weight

This is the weight of the vehicle including high voltage battery and all standard equipment. It does not include passengers, luggage, or optional equipment.

Vehicle Kerb Weight

This is the weight of your new vehicle when you picked it up from your dealer plus any aftermarket equipment.

Luggage Weight

This figure includes all weight added to the Base kerb Weight, including luggage and optional equipment.

GAW (Gross Axle Weight)

This is the total weight placed on each axle (front and rear) - including vehicle kerb weight and all payload.

GAWR (Gross Axle Weight Rating)

This is the maximum allowable weight that can be carried by a single axle (front or rear). The total load on each axle must never exceed its GAWR.

GVW (Gross Vehicle Weight)

This is the Base kerb Weight plus actual luggage Weight plus passengers.

GVWR (Gross Vehicle Weight Rating)

This is the maximum allowable weight of the fully loaded vehicle (including all options, equipment, passengers and luggage).

Overloading

A WARNING

Exceeding the Gross Axle Weight Rating (GAWR) and the Gross Vehicle Weight Rating (GVWR) ratings for your vehicle can cause an accident or vehicle damage. You can calculate the weight of your load by weighing the items (and people) before putting them in the vehicle. Be careful not to overload your vehicle.

7. Driver assistance system

Before Using Driver Assistance System	7-4
Driver Assistance System sensors	7-4
Forward Collision-Avoidance Assist (FCA)	7-7
Forward Collision-Avoidance Assist settings	7-10
Forward Collision-Avoidance Assist operation	
Forward Collision-Avoidance Assist malfunction and limitations	7-24
Lane Keeping Assist (LKA)	7-33
Lane Keeping Assist settings	
Lane Keeping Assist operation	
Lane Keeping Assist malfunction and limitations	
Blind-Spot Collision-Avoidance Assist (BCA)	7-39
Blind-Spot Collision-Avoidance Assist settings	
Blind-Spot Collision-Avoidance Assist operation	
Blind-Spot Collision-Avoidance Assist malfunction and limitations	
Safe Exit Assist (SEA)	
Safe Exit Assist settings	
Safe Exit Assist operation	
Safe Exit Assist malfunction and limitations	
Manual Speed Limit Assist (MSLA)	
Manual Speed Limit Assist operation	7-53
Intelligent Speed Limit Assist (ISLA)	7-55
Intelligent Speed Limit Assist settings	7-56
Intelligent Speed Limit Assist operation	
Intelligent Speed Limit Assist malfunction and limitations	7-58
Driver Attention Warning (DAW)	7-61
Driver Attention Warning settings	
Driver Attention Warning operation	
Driver Attention Warning malfunction and limitations	
Forward Attention Warning (FAW)	7-66
Forward Attention Warning settings	
Forward Attention Warning operation	
Forward Attention Warning malfunction and limitations	
Blind-Spot View Monitor (BVM)	
Blind-Spot View Monitor settings	
Blind-Spot View Monitor operation	7-70

Blind-Spot View Monitor malfunction7-70	
Smart Cruise Control (SCC)7-71	
Smart Cruise Control settings7-71	
Smart Cruise Control operation7-72	
Smart Cruise Control malfunction and limitations	
Navigation-based Smart Cruise Control (NSCC)7-85	
Navigation-based Smart Cruise Control settings7-86	
Navigation-based Smart Cruise Control operation7-86	
Limitations of Navigation-based Smart Cruise Control	
Lane Following Assist (LFA)7-90	
Lane Following Assist settings	
Lane Following Assist operation7-91	
Lane Following Assist malfunction and limitations7-93	
Highway Driving Assist (HDA)7-94	
Highway Driving Assist settings7-95	
Highway Driving Assist operation	
Highway Lane Change Assist	
Highway Driving Assist malfunction and limitations	
Rear View Monitor (RVM)7-104	
Rear View Monitor settings7-104	
Rear View Monitor operation7-105	
Rear View Monitor malfunction and limitations	
Surround View Monitor (SVM)	
Surround View Monitor settings	
Surround View Monitor operation7-108	
Surround View Monitor malfunction and limitations	
Rear Cross-Traffic Collision-Avoidance Assist (RCCA)	
Rear Cross-Traffic Collision-Avoidance Assist settings	
Rear Cross-Traffic Collision-Avoidance Assist operation	
Rear Cross-Traffic Collision-Avoidance Assist malfunction and limitations 7-117	
Parking Distance Warning (PDW)	
Parking Distance Warning settings7-121	
Parking Distance Warning operation7-122	
Parking Distance Warning malfunction and limitations7-125	
Forward/Side/Reverse Parking Collision-Avoidance Assist (PCA)7-127	

Parking Collision-Avoidance Assist settings	7-127
Parking Collision-Avoidance Assist operation	7-128
Parking Collision-Avoidance Assist malfunction and limitations	
Remote Smart Parking Assist 2 (RSPA 2)	7-134
Remote Smart Parking Assist settings	7-135
Remote Smart Parking Assist operation	7-136
Remote Smart Parking Assist malfunction and limitations	7-152
Declaration of conformity	7-158
Front radar	7-158
Front corner radar/Rear corner radar	7-158

Before Using Driver Assistance System

A WARNING

Always maintain a safe distance from the vehicles ahead and adjust your vehicle speed to the road conditions. Driver Assistance system may not operate in all situations and cannot avoid all collisions.

To prevent serious injury or death:

- Control your vehicle at all times. In some cases, the Driver Assistance system may provide unwanted braking or steering.
- Never attempt to activate any Driver Assistance system by intentionally driving toward people, animals, objects, or other vehicles.
- The steering, braking, and acceleration inputs from you may override the responses from Driver Assistance system.
- Do not use Driver Assistance system when towing a trailer or using a towbar mounted carrier.
- Do not use Driver Assistance system if you believe the sensors or the systems may not be functioning properly.

i Information


Depending on the infotainment software version, the description of each function of the driver assistance system may differ from the owner's manual.

Driver Assistance System sensors

The Driver Assistance Systems on your vehicle use cameras and sensors to detect potential hazards in the vicinity of your vehicle.

Detecting sensors

Cameras





The actual shape may differ from the image.

- [A] Front view camera
- B] Wide-front view camera (if equipped)
- [C] Wide-side view camera (if equipped)
- [D] Wide-rear view camera (if equipped)

CAUTION

To prevent serious injury or death:

- Never disassemble the camera sensors or camera sensor assemblies.
- We recommend that the detecting sensor be replaced or repaired by an authorised Genesis repairer.

- Never install any accessories, stickers, or tint the front windscreen.
- Always keep the camera dry.
- Never place any reflective objects (for example, white paper and mirror) on the instrument panel.
- Do not use any cleanser containing acid or alkaline detergents when cleaning the camera lenses. Use only a mild soap or neutral detergent, and rinse thoroughly with water.

Radars





The actual shape may differ from the image.

- [A] Front radar [B] Front corner radar (if equipped)
- [C] Rear corner radar

↑ CAUTION

To prevent serious injury or death:

- Never disassemble the radar or radar assembly, and never apply any impact on it.
- If there is impact on or near the radar, the sensors may be damaged or not be properly aligned near the radar, even though a warning message does not appear on the instrument cluster. Driver Assist system may not operate properly. We recommend that your vehicle be inspected by an authorised Genesis repairer.
- If a radar have been replaced or repaired, we recommend that your vehicle be inspected by an authorised Genesis repairer.
- We recommend that genuine Genesis parts are used to repair the bumper where the radar is located. Their performance have been proven.
- Do not install a licence plate frame or other objects such as bumper sticker, film, bumper quard, or bumper wrap near the radar
- Driver Assistance system may not work properly if the bumper has been replaced, or the area surrounding the radar has been damaged or painted.
- If a trailer or towbar mounted carrier is attached, it may adversely affect the performance of the rear corner radar or the function may not operate.

Ultrasonic sensors





The actual shape may differ from the image.

- [A] Front ultrasonic sensors
- [B] Front side ultrasonic sensors (if equipped)
- [C] Rear ultrasonic sensors [D] Rear side ultrasonic sensors (if equipped)


A CAUTION

To prevent serious injury or death:

- Always keep the ultrasonic sensors clean.
- Do not spray the ultrasonic sensors or the surrounding area directly with high pressure water.
- Do not apply objects such as bumper sticker or bumper guard, near the ultrasonic sensors or never apply paint to the bumper or other locations.
- · Never disassemble or strike the ultrasonic sensors components.
- Do not modify the vehicle bumper height or ultrasonic sensor installations. Any non-factory installed equipment or accessories may also interfere with the sensor performance.
- If the ultrasonic sensors have been forcibly moved out of proper alignment or are damaged, we recommend that the vehicle be inspected by an authorised Genesis repairer.

Forward Collision-Avoidance Assist (FCA)

Basic function



Forward Collision-Avoidance Assist helps detect a vehicle, a motorcyclist, a pedestrian, or a cyclist ahead on the road and may warn you of a possible collision with a warning message on the instrument cluster and a warning sound. Also, Forward Collision-Avoidance Assist may assist with braking your vehicle to help reduce collision speed or help avoid a collision.

In addition, when driving at high speeds, Forward Collision-Avoidance Assist helps detect vehicles in front and adjacent lanes. If a collision is imminent when changing lanes, Forward Collision-Avoidance Assist will apply emergency braking to help reduce collision speed or help avoid a collision. (if equipped)

NOTICE

A motorcyclist refers to the driver of a vehicle riding the following powered two-wheeler.


- Mopeds with 50 cc and restricted top speeds
- Motorcycles

Junction Turning function



Junction Turning function helps avoid a collision with an oncoming vehicle or motorcyclist in an adjacent lane when turning right at a crossroad with the turn signal on by applying emergency braking.

Direct Oncoming function



[A] Oncoming vehicle

Direct Oncoming function helps reduce the impact speed of a collision when a vehicle or motorcyclist approaching from the opposite side is detected.

Junction Crossing function



Junction Crossing function helps avoid a collision with oncoming vehicles on the left or right side when crossing an intersection by applying emergency braking.

Lane-Change Oncoming function



[A] Oncoming vehicle
Lane-Change Oncoming function helps
avoid a collision with an oncoming
vehicle or motorcyclist when changing
lanes by assisting the driver's steering.

Lane-Change Side function





[A] Front-side vehicle

Lane-Change Side function helps avoid a collision with the vehicle or motorcyclist ahead in the next lane when changing lanes by assisting the driver's steering.


Evasive Steering Assist function



- Driver steering assist
 Evasive Steering Assist function helps avoid a collision with a vehicle, a motorcyclist, pedestrian or cyclist ahead in the same lane. When a collision risk is detected, Evasive Steering Assist function warns the driver and if the driver steers to avoid
- Evasive steering assist
 Evasive Steering Assist function helps avoid a collision with a motorcyclist, pedestrian or cyclist ahead in the same lane. When a collision risk is detected, Evasive Steering Assist function warns the driver and if there is space to avoid collision in the lane, it assists the driver's steering.

collision it assists the driver's steering.

Evasive Steering Assist function operates when there is a collision risk and sufficient operating area between your vehicle and the detected pedestrian or cyclist ahead.



[A] Operating area of Evasive Steering Assist function

Forward Collision-Avoidance Assist settings

Forward Safety



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Driving safety** from the Settings menu in the infotainment system to select the following:

• If Forward safety is selected, Forward Collision-Avoidance Assist displays a warning message and sounds an audible warning depending on the collision risk levels. Braking assist is applied depending on the collision risk levels. If Forward safety is deselected, Forward Safety turns off. The (♣) warning light illuminates on the instrument cluster.

Forward Cross-Traffic Safety



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Driving safety** > **Forward cross-traffic safety** from the Settings menu to turn on Junction Crossing function and deselect to turn off the function.

Forward/Side Safety



With the vehicle on, select or deselect Setup > Vehicle > Driver assistance > Driving safety from the Settings menu to turn on Lane-Change Oncoming function, Lane-Change Side function, and Evasive Steering Assist function.

 If Forward/Side safety is selected, Forward Collision-Avoidance Assist warns the driver with steering wheel vibration, a warning message, an audible warning depending on the collision risk levels. Steering assist is applied depending on the collision risk levels. If Forward/Side safety is deselected, Forward/Side Safety turns off. The se warning light illuminates on the instrument cluster.

You can check whether Forward Collision-Avoidance Assist is on or off from the Settings menu. If the \$\frac{1}{2}\$ or \$\frac{1}{2}\$ warning light remains ON when Forward Collision-Avoidance Assist is on, we recommend that your vehicle be inspected by an authorised Genesis repairer.

A WARNING

Each time the vehicle is restarted, Forward Collision-Avoidance Assist turns on. If Forward safety, Forward-cross traffic safety, and Forward/Side safety are deselected the driver should always be aware of the surroundings and drive safely.

A CAUTION

- The setting for Forward safety includes 'Basic function' and 'Junction Turning'.
- The setting for Forward-cross traffic Safety includes 'Junction Crossing'. (if equipped)
- The setting for Forward/Side safety includes 'Lane-Change Oncoming', 'Lane-Change Side', and 'Evasive Steering Assist' (if equipped).
- If Forward safety is deselected, Junction Crossing function does not operate even when Forward-cross traffic safety and Forward/Side safety are selected.

 If a trailer or towbar mounted carrier is attached, it may adversely affect the performance of the Forward Collision-Avoidance assist

A CAUTION

When a trailer is connected to your vehicle, the Forward/Side Safety function of Forward Collision Avoidance Assist automatically turns off. In this case, Forward Collision-Avoidance Assist is not functional. Always have your eyes on the road. (if equipped with genuine Genesis parts)

Forward Safety Warning Timing



With the vehicle on, select Setup > Vehicle > Driver assistance > Driving safety > Forward Safety Warning Timing from the Settings menu in the infotainment system to change the initial warning activation time for Forward Collision-Avoidance Assist. The warning time can be set to either Normal or Later.

- Use Normal in normal driving conditions. If the Forward Safety Warning Timing seems sensitive, change it to Late.
- If Later is selected, Forward Collision-Avoidance Assist warns the driver more slowly.

A CAUTION

- Even though Normal is selected for Forward Safety Warning Timing, if the front vehicle suddenly stops, the warning may seem late.
- Select Later for Forward Safety
 Warning Timing when traffic is light and
 your speed is slow.

i Information

- The Forward Safety Warning Timing settings do not apply to Forward/Side safety.
- When the vehicle is restarted, the Forward Safety Warning Timing maintains its previous setting.

Warning methods



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Warning methods** from the Settings menu in the infotainment system to select the following:

- Warning volume: The warning volume can be adjusted. If you set the warning volume to '0', the warning volume does not turn off but sounds as '1'.
- **Haptic warning**: The steering wheel vibration can be set.
- Driving safety priority: Your vehicle lowers all other audio volumes when the Driver Assistance system warning sounds.

i Information

- If you change the warning methods, the warning methods of other Driver Assistance systems may change.
- The warning volume and haptic warning cannot be turned off at the same time. When one of the warning is turned off the other is activated.
- When the vehicle is restarted, the warning methods maintains its previous setting.
- The setting menu may not be available for your vehicle depending on the vehicle features and specifications.

Forward Collision-Avoidance Assist operation

Basic function

Forward Collision-Avoidance Assist may warn and brake your vehicle depending on the collision risk level.

Collision warning



- To warn the driver of a collision, the warning light blinks and the "Collision warning!" warning message appears on the instrument cluster, an audible warning sounds, and the steering wheel vibrates.
- If a vehicle or motorcyclist is detected in front, the function operates when your vehicle speed is between about 10-200 km/h.
- If a pedestrian or cyclist is detected in front, the function operates when your vehicle speed is between about 10-85 km/h.

Emergency braking



To warn the driver that emergency braking is assisted, the *€warning light blinks and the "Emergency braking" warning message appears on the instrument cluster, an audible warning sounds, and the steering wheel vibrates (if equipped).

Emergency braking operates under the following conditions:

Vehicle or motorcyclist:

	Driving vehicle	Stopped vehicle
Weak braking power	About 10-200 km/h	
Strong braking power	About10-130 km/h	About 10-85 km/h (10-100 km/h*)

- *: If Forward Collision-Avoidance Assist judges that avoiding a collision is difficult even by changing the driving lane, braking is assisted much earlier. (if equipped)
- · Pedestrian or cyclist:

The function operates when your vehicle speed is between about 10-65 km/h.

Stopping vehicle and ending brake control After your vehicle has stopped following an Emergency Braking event, the "Drive carefully" warning message may appear on the instrument cluster.

Press the brake pedal immediately and check the surroundings.

 Braking control ends about 2 seconds after your vehicle is stopped following an Emergency Braking event.

i Information

The audible warning can be turned off when the collision warning or emergency braking is operating by pressing the hazard warning flasher button.

Junction Turning function

Junction Turning function may warn and brake your vehicle depending on the collision risk level.

Collision warning



- To warn the driver of a collision, the warning light blinks and the "Collision warning!" warning message appears on the instrument cluster, an audible warning sounds, and the steering wheel vibrates.
- The function operates when your vehicle speed is between about 10-30 km/h, the oncoming vehicle speed is between about 30-70 km/h and the motorcyclist and cyclist speed* is between about 15-70 km/h.
 - *: The function operates even when you turn left.

Emergency braking



- To warn the driver that emergency braking is assisted, the *warning light blinks and the "Emergency braking" warning message appears on the instrument cluster, an audible warning sounds, and the steering wheel vibrates.
- In an emergency braking situation, braking is assisted with strong braking power by the function to help prevent collision with the oncoming vehicle.
- The function operates when your vehicle speed is between about 10-30 km/h, the oncoming vehicle speed is between about 30-70 km/h and the motorcyclist and cyclist speed* is between about 15-70 km/h.
 - *: The function operates even when you turn left.

Stopping vehicle and ending brake control After your vehicle has stopped following an Emergency Braking event, the "Drive carefully" warning message may appear on the instrument cluster.

Press the brake pedal immediately and check the surroundings.

 Braking control ends about 2 seconds after your vehicle is stopped following an Emergency Braking event.

i Information

- The audible warning can be turned off when the collision warning or emergency braking is operating by pressing the hazard warning flasher button.
- When turning right at a junction, braking is assisted to reduce or avoid collisions if there is a collision risk with a cyclist approaching at the speed of 15 to 20 km/h from the opposite side.

Direct Oncoming function

Direct Oncoming function may warn and brake your vehicle depending on the collision risk level.

Collision warning



- To warn the driver of a collision, the warning light blinks and the "Collision warning!" warning message appears on the instrument cluster, an audible warning sounds, and the steering wheel vibrates.
- The function operates when your vehicle speed is between about 30-130 km/h or (10-130 km/h*) and the detected oncoming vehicle or motorcyclist speed is about above 10 km/h.
 - *: If equipped

Emergency braking



- In an emergency braking situation, braking is assisted with strong braking power by the function to help prevent collision with the oncoming vehicle.
- The function operates when your vehicle speed is between about 30-130 km/h and the detected oncoming vehicle or motorcyclist speed is about above 10 km/h.

Stopping vehicle and ending brake control After your vehicle has stopped following an Emergency Braking event, the "Drive carefully" warning message may appear on the instrument cluster.

Press the brake pedal immediately and check the surroundings.

 Braking control ends about 2 seconds after your vehicle is stopped following an Emergency Braking event.

A CAUTION

If your vehicle or the oncoming vehicle is not driving straight, Direct Oncoming function warning and control may be late or may not operate.

i Information

The audible warning can be turned off when the collision warning or emergency braking is operating by pressing the hazard warning flasher button.

Junction Crossing function

Junction Crossing function may warn and brake your vehicle depending on the collision risk level.

Collision warning



- To warn the driver of a collision, the warning light blinks and the "Collision warning!" warning message appears on the instrument cluster, an audible warning sounds, and the steering wheel vibrates.
- The function operates when your vehicle speed is between about 10-55 km/h and the crossing vehicle speed is between about 10-60 km/h.

Emergency braking



- In an emergency braking situation, braking is assisted with strong braking power by the function to help prevent collision with the crossing vehicle.
- The function operates when your vehicle speed is between about 10-55 km/h and the crossing vehicle speed is between about 10-40 km/h.

Stopping vehicle and ending brake control After your vehicle has stopped following an Emergency Braking event, the "Drive carefully" warning message may appear on the instrument cluster.

Press the brake pedal immediately and check the surroundings.

 Braking control ends about 2 seconds after your vehicle is stopped following an Emergency Braking event.

A CAUTION

If your vehicle or the oncoming vehicle is not driving straight, Front Oncoming function's warning and vehicle control may be late or may not operate.

i Information

The audible warning can be turned off when the collision warning or emergency braking is operating by pressing the hazard warning flasher button.

Lane-Change Oncoming function

Lane-Change Oncoming function warn and steer your vehicle depending on the collision risk levels.

Collision warning



- The function operates when your vehicle speed is between about 40-145 km/h and the oncoming vehicle or motorcyclist speed is about above 10 km/h and the relative speed with your vehicle is about below 200 km/h.

Emergency steering



- To warn the driver that emergency steering is assisted, the **warning light blinks and the "Emergency steering" warning message appears on the instrument cluster, an audible warning sounds, and the steering wheel vibrates.
- In an emergency steering situation, steering is assisted by the function to help prevent collision with the oncoming vehicle.
- The function operates when your vehicle speed is between about 40-145 km/h and the oncoming vehicle or motorcyclist speed is about above 10 km/h and the relative speed with your vehicle is about below 200 km/h.

Lane-Change Side function

Lane-Change Side function may warn and steer your vehicle depending on the collision risk level.

Collision warning





- The function operates when your vehicle speed is between about 40-145 km/h.

Emergency steering





- To warn the driver that emergency steering is assisted, the sewarning light blinks and the "Emergency steering" warning message appears on the instrument cluster, an audible warning sounds, and the steering wheel vibrates.
- In an emergency steering situation, steering is assisted by the function to help prevent collision with the front-side vehicle.
- The function operates when your vehicle speed is between about 40-145 km/h and front-side vehicle and motorcyclist is driving.

A CAUTION

- Lane-Change Side function does not operate if the speed of the preceding yehicle from the front side is 0 km/h.
- The detecting range of the front corner radar and the rear corner radar is determined by a standard road width, therefore, on a narrow road, Lane-Change Side function may detect other vehicles two lanes over and warn you. In contrast, on a wide road, Lane-Change Side function may not be able to detect a vehicle driving in the next lane and may not warn you.
- Collision-avoidance assist will be cancelled under the following circumstances:
 - Your vehicle enters the next lane by a certain distance.
 - Your vehicle is away from the collision risk.
 - The steering wheel is sharply steered.
 - The brake pedal is pressed.
 - Forward Collision-avoidance assist is operating.
- After Lane-Change Side function operation or lane change, you must drive to the centre of the lane.
 Lane-Change Side function will not operate if the vehicle is not driven in the centre of the lane.

i Information

- When an additional accident is expected, Lane-Change Side function will not assist with steering and only warn the driver of a collision.
- As the driver's seat is on the right side, the system will operate when you turn right.

Evasive Steering Assist function

Evasive Steering Assist function may warn and steer your vehicle with Emergency steering.

Emergency Steering (Driver steering assist)



- To warn the driver that emergency steering is assisted, the sewarning light blinks and the "Emergency steering" message appears on the instrument cluster, an audible warning sounds, and the steering wheel vibrates.
- If there is a risk of collision with a vehicle, motorcyclist, pedestrian, or cyclist in front, the steering is assisted to help prevent collision when the driver steers the vehicle to avoid collision.
- The function operates when your vehicle speed is between about 40-85 km/h.

Emergency steering (Evasive steering assist)



- To warn the driver that emergency steering is assisted, the sewarning light blinks and the "Emergency steering" message appears on the instrument cluster, an audible warning sounds, and the steering wheel vibrates.
- If there is high risk of collision with a pedestrian and cyclist in front, and the vehicle speed to operate emergency braking has exceeded, the steering is assisted to help prevent collision when there is space to avoid collision in the driving lane.
- The function operates when your vehicle speed is between about 65-75 km/h.

A CAUTION

- The steering wheel may turn automatically when emergency steering is operating.
- Emergency steering automatically cancels when risk factors disappear. If necessary, the driver must steer the vehicle.
- Emergency steering may not operate or may cancel during operation if the steering wheel is held tightly or steered in the opposite direction.
- When steering is assisted to avoid collision with a vehicle, motorcyclist, pedestrian and cyclist, Evasive steering assist will be cancelled if collisions with other objects (vehicles, motorcyclist, pedestrians, or cyclists) are expected.
- Evasive steering assist may not operate if space to avoid collision in the driving lane is insufficient.
- When driving at night, the recognition performance for the motorcyclist may decrease, which may temporarily limit or disable the Forward Collision-Avoidance Assist.

i Information

For more information on warning messages, refer to Collision Warning in "Basic function".

A WARNING

Forward Collision-Avoidance Assist may not operate in all situations and cannot avoid all collisions.

To prevent serious injury or death:

- Only change the settings after parking your vehicle at a safe location.
- Forward Collision-Avoidance Assist does not operate in all situations or cannot avoid all collisions.
- Control your vehicle at all times. Do not depend on Forward
 Collision-Avoidance Assist to avoid a collision. Always maintain a safe distance from the vehicles ahead and reduce your vehicle speed as needed.
- Never attempt to test Forward Collision-Avoidance Assist by intentionally driving toward people, animals, objects, or other vehicles.
- Forward Collision-Avoidance Assist may not assist braking your vehicle if you press the brake pedal sufficiently in response to the potential hazard detected by the function to avoid all collisions.
- Depending on the road and driving conditions, Forward Collision-Avoidance Assist may warn the driver late or may not warn the driver.

- During Forward Collision-Avoidance
 Assist operation, your vehicle may stop
 suddenly. Always wear your seat belt,
 ensure ALL passengers have their seat
 belts fastened and secure loose objects
 that may become projectiles.
- When other system's warning message appears or audible warning is being generated, Forward Collision-Avoidance Assist may not warn you.
- You may not hear the audible warning of Forward Collision-Avoidance Assistif the surrounding environment is too noisy.
- Forward Collision-Avoidance Assist may stop operating, or may not operate properly, or may operate unnecessarily depending on the road conditions and the surroundings.

WARNING

- Even if there is a problem with Forward Collision-Avoidance Assist, the vehicle's basic braking system operates normally.
- During emergency braking, braking by Forward Collision-Avoidance Assist automatically cancels if you excessively press the accelerator pedal or sharply steer your vehicle.

A CAUTION

- Depending on the condition of the vehicle, motorcyclist, pedestrian, and cyclist detected in front, and the surroundings, the speed ranges Forward Collision-Avoidance Assist may be reduced. Forward Collision-Avoidance Assist may only warn the driver, or it may not operate.
- Forward Collision-Avoidance Assist operates only under certain conditions that determine the risk level:
 - Condition of other vehicles
 - The direction vehicles are driven
 - Vehicle speed
 - Surroundings
- If your vehicle speed is too fast or the speed difference with the other vehicle, motorcyclist, or cyclist is large, Forward Collision-Avoidance Assist may be limited or may not operate properly.
- When a collision with a surrounding vehicle is expected, Lane-Change Oncoming, Lane-Change Side and Evasive Steering Assist does not assist you with steering but only warn the you of a collision (if equipped).

i Information

- When a collision is imminent, braking may be assisted if you press the brake pedal insufficiently.
- The images and colours in the instrument cluster may differ depending on the instrument cluster type or theme selected from the settings menu.


Forward Collision-Avoidance Assist malfunction and limitations

Forward Collision-Avoidance Assist malfunction



When Forward Collision-Avoidance Assist is not working properly, the "Check driver assistance system." warning message may appear, and the ①, ♣ and ﷺ warning lights illuminate on the instrument cluster. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Forward Collision-Avoidance Assist disabled



If the front view camera, front radar, bumper, or sensor is covered or blocked by foreign material, such as snow, rain, or dirt, or when a trailer or towbar mounted carrier is installed, the detecting performance may decrease and temporarily limit or disable Forward Collision-Avoidance Assist.

The "Driver assistance system limited. Camera obscured." or the "Driver assistance system limited. Radar blocked." warning message may appear, and the A, & and & warning lights may illuminate on the instrument cluster.

The function operates normally when such foreign material, trailer, or carrier is removed, and the vehicle is restarted.

If Forward Collision-Avoidance Assist does not operate normally after anything covering or blocking the sensors is removed, we recommend that your vehicle be inspected by an authorised Genesis repairer.

WARNING

- Forward Collision-Avoidance Assist may not operate properly even if there is no warning message or warning light on the instrument cluster.
- Forward Collision-Avoidance Assist may not operate properly in open areas where no objects are detected (for example, empty car park) or when the detecting sensors are blocked immediately after turning on the vehicle.
- If the vehicle is turned off and restarted whilst the camera is blocked or malfunctioned, the condition is maintained and may not operate properly.

i Information

You can check for this in the service message of the normal view mode of the cluster display window.

Detecting sensors

Refer to the "Driver Assistance System sensors" section in this chapter for the location and the general precautions of the front view camera, front radar, front corner radar (if equipped), and rear corner radar (if equipped).

Limitations of Forward Collision-Avoidance Assist

Forward Collision-Avoidance Assist may not operate normally or may operate unexpectedly if:

- The detecting sensor or the surroundings are blocked, covered, or damaged by snow, water, or dirt, etc.
- The temperature near the front view camera is hot or cold.
- The camera lens is covered or blocked by windscreen tint, the windscreen is damaged, or a sticky material (sticker, bug, etc.) is on the glass.
- Moisture is not removed or frozen on the windscreen.
- Washer fluid is sprayed continuously, or the wiper is on.
- You are driving in heavy rain or snow, or thick fog.
- The front view camera's field of view is obstructed by glare from the sun.
- Sunlight, streetlight or light from an oncoming vehicle is reflected on the wet road surface such as a puddle on the road.
- An object is placed on the instrument panel.
- · Your vehicle is being towed.
- The surroundings are very bright or very dark (nighttime, tunnel, etc.).
- The light level changes suddenly, for example when entering or exiting a tunnel.
- The light level outside is low, and the headlamps of the front vehicle are turned off or are not bright.
- A front vehicle, motorcyclist, pedestrian, or cyclist is partially visible.
- The vehicle in front is a bus, heavy truck, truck with an unusual shape, trailer, etc.
- The vehicle or motorcyclist in front has no tail lamps, tail lamps are located in an unusual location.

- In low light conditions, the tail lamps of the front vehicle are turned off or not bright.
- The rear of the front vehicle is small or the vehicle does not look normal, such as when the vehicle is tilted, overturned, or the side of the vehicle is visible, etc.
- The front vehicle's ground clearance is too low or high
- A vehicle, motorcyclist, pedestrian, or cyclist suddenly cuts in front.
- The bumper around the front radar has been damaged or modified, and the radar is out of position.
- The temperature around the front radar is very hot or cold.
- A material is near that reflects very well on the front radar, such as guardrail, nearby vehicle, etc.
- The bicycle in front is made of material that does not reflect on the front radar well
- The vehicle or motorcyclist in front is detected late.
- The vehicle or motorcyclist in front is suddenly blocked by an obstacle.
- The vehicle or motorcyclist in front changes lane or reduces the speed.
- The vehicle or motorcyclist in front is bent out of shape.
- The speed of the vehicle or motorcyclist in front is slow or fast.
- The vehicle or motorcyclist in front steers in the opposite direction of your vehicle to avoid a collision.
- Your vehicle changes lane at low speed with a vehicle or motorcyclist in front.
- The vehicle in front is covered with snow.
- You are departing or returning to the lane.
- You are on curve or roundabout and the vehicle or motorcyclist in front is not detected

- · You are continuously driving in a circle.
- The vehicle in front has an unusual shape.
- The vehicle in front is driving uphill or downhill.
- Only part of a pedestrian or cyclist is detected. For example, if the pedestrian is leaning over or is not walking upright.
- The pedestrian or cyclist is wearing clothing or equipment that makes it difficult to detect.



The illustration above shows the image the front view camera and front radar are capable of detecting as a vehicle, motorcyclist, pedestrian, and cyclist.

- The pedestrian or cyclist in front is moving very quickly.
- The pedestrian or cyclist in front is short.
- The pedestrian or cyclist in front has impaired mobility.
- The pedestrian or cyclist in front is moving at an angle to the path of your vehicle.
- There is a group of pedestrians, cyclists in front of your vehicle.
- The pedestrian or cyclist is wearing clothing that easily blends into the background, making it difficult to detect.
- The pedestrian or cyclist is difficult to distinguish from the similar shaped structure in the surroundings.

- You are driving by a pedestrian, cyclist, traffic signs, and other structure near an intersection.
- You are driving through steam, smoke, or shadow.
- You are driving through a tunnel or an iron bridge.
- You are driving in large, open areas where there are few vehicles or structures (for example, desert, meadow, empty suburb).
- You are driving in a car park.
- You are driving through a tollgate, construction area, unpaved road, partial paved road, uneven road, speed bumps, etc.
- You are driving on roads with railroad tracks or other embedded metal objects.
- You are driving on an inclined road or curved road.
- You are driving on a road with trees or streetlights.
- You are driving on a narrow road where trees or grass are overgrown.
- You are driving in an area with strong radio waves or electrical noise interference
- The vehicle moves unstably or vibrates excessively.
- Your vehicle height is low or high due to heavy loads, abnormal tyre pressure, etc.
- The vehicle is installed with a snow chain or different size wheel.

Junction Crossing, Lane-Change Oncoming, Lane-Change Side, Evasive Steering Assist function

- The temperature near the front corner radar or rear corner radar is very hot or cold.
- A trailer or towbar mounted carrier is installed and it blocks the rear corner radar.
- The front corner radar or rear corner radar is covered by snow, rain, dirt, etc.
- The area near the front corner radar or rear corner radar is covered with objects, such as a bumper sticker, bumper guard, bike rack, etc.
- The bumper around the front corner radar or rear corner radar has been damaged or modified, and the radar is out of position.
- The front corner radar or rear corner radar is blocked by a vehicle, wall, or pillar.
- You are driving on an entrance/exit ramp or through a tollbooth.
- There is a fixed object near your vehicle, such as sound barriers, guardrails, central dividers, entry barriers, streetlights, signs, tunnels, walls, etc.
- Another vehicle drives very close behind your vehicle, or passes by your vehicle in close proximity.
- The speed of the other vehicle is so fast that it passes by your vehicle in a short time.
- · Your vehicle passes another vehicle.
- Your vehicle has started at the same time as the vehicle next to you and has accelerated.
- The vehicle in the next lane moves two lanes away from you, or the vehicle moves two lanes away to the next lane.
- · A motorcycle or bicycle is detected.
- A vehicle such as a flat trailer is detected.

- A large vehicle such as a bus or truck is detected
- A moving obstacle such as a pedestrian, animal, shopping cart, or a baby stroller is detected.
- A vehicle with lower height, such as a sports car is detected.
- The lane is difficult to distinguish because:
 - The lane markings are damaged or covered with rain, snow, dirt, oil, etc.
 - The colour of the lane marking road surface is wet.
 - There are markings on the road or near the lane that looks similar to the lane markings.
 - The lane markings are covered by the shadow of objects around the road, such as median strip, guardrails, noise barriers, and trees.
- The lane number increases or decreases, or the lane markings are crossing.
- There are more than two lane markings on the road.
- The lane markings are complicated or a structure substitutes for the lines, such as a construction area or tollbooth area.
- There are road markings, such as zigzag lanes, crosswalk markings, and road signs.
- The lane suddenly disappears, such as at an intersection.
- · The lane is very wide or narrow.
- There is a kerb or road edged without a lane.
- You are driving on the left or right side of a bus lane or on the bus lane.
- The distance to the front vehicle is extremely short or the vehicle in front is covering the lane marking.

Limitations of Evasive Steering Assist

Evasive Steering Assist function may not work properly in the following situations when:

 The pedestrians or cyclists are positioned outside of the operating area.



• The pedestrians or cyclists are moving perpendicular to your vehicle.



 The pedestrians or cyclists are positioned inside of the operating area, but there is not enough space available for evasive steering.



A WARNING

· Driving on curves





Forward Collision-Avoidance Assist may not detect other vehicles, motorcyclists, pedestrians, or cyclists in front of you when driving on a curve adversely affecting the performance of the sensors. A warning, brake assist, or steering assist (if equipped) may not be activated when needed.

When driving on a curve, always maintain a safe distance from others on the road. Reduce your vehicle speed or steer your vehicle as needed.






If a vehicle, motorcyclist, pedestrian, or cyclist is detected in the next lane or outside the lane when driving on a curve. Forward Collision-Avoidance Assist may warn you and may brake or steer (if equipped) your vehicle even when not needed.

Always check road conditions, and if necessary, take appropriate actions and drive safely.

· Driving on hills









Forward Collision-Avoidance Assist may not detect other vehicles, motorcyclists, pedestrians, or cyclists in front of you whilst driving uphill or downhill, adversely affecting the performance of the sensors. A warning, brake assist, or steering assist (if equipped) may not be activated when needed.

Also, vehicle speed may rapidly decrease when a vehicle, motorcyclist, pedestrian or cyclist ahead is suddenly detected. Always maintain a safe distance from the others on the road. Adjust your vehicle speed or steer your vehicle depending on the road conditions.


· Changing lanes



[A] Your vehicle
[B] Lane changing vehicle

When a vehicle moves into your lane from an adjacent lane, it cannot be detected by the sensor until it is in the sensor's detection range. Forward Collision-Avoidance Assist may not immediately detect the vehicle when the vehicle changes lanes suddenly.

Always maintain a safe distance from the vehicles ahead. Adjust your vehicle speed or steer your vehicle depending on the road conditions.



[A] Your vehicle


[B] Lane changing vehicle

[C] Same lane vehicle

When a vehicle in front of you departs the lane, Forward Collision-Avoidance Assist may not immediately detect another vehicle in your lane of travel.

Always maintain a safe distance from the vehicles ahead. Adjust your vehicle speed or steer your vehicle depending on the road conditions.

· Detecting a vehicle



Forward Collision-Avoidance Assist may not be able to detect all potential hazards, like if the vehicle in front of you has luggage that extends rearward past the end of the vehicle or if the vehicle in front of you has higher ground clearance. Always maintain a safe distance from the vehicles ahead. Adjust your vehicle speed or steer your vehicle depending on the road conditions.

A WARNING

- Always turn off Forward Collision-Avoidance Assist when towing a trailer or another vehicle.
- Forward Collision-Avoidance Assist may operate if objects that are similar in shape or characteristics to vehicles, motorcyclists, pedestrians and cyclists are detected.
- Forward Collision-Avoidance Assist does not operate on bicycles, or smaller wheeled objects, such as luggage bags, shopping carts, or strollers.
- Forward Collision-Avoidance Assist may not operate properly if there is interference from strong electromagnetic waves.
- Forward Collision-Avoidance Assist may not operate for 15 seconds immediately after the vehicle is started or when the front view camera is initialised.

i Information

For more details on the limitations of detecting rear corner vehicles and cautions regarding the rear corner sensor, please refer to the "Blind-Spot Collision-Avoidance Assist (BCA)" in this chapter.

Lane Keeping Assist (LKA)

Lane Keeping Assist helps detect lane markings (or road edges) whilst driving over a certain speed. Lane Keeping Assist may warn you if your vehicle leaves the lane without using the turn signal and may steer the vehicle to prevent it from departing its travel lane.

Lane Keeping Assist settings

Lane Safety



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Driving safety** from the Settings menu in the infotainment system to select the following:

 If Lane safety is selected, Lane Keeping Assist automatically assists with steering your vehicle to help prevent your vehicle from departing its travel lane. If Lane safety is deselected, Lane Keeping Assist turns off and the yellow /=\ indicator light appears on the instrument cluster.

WARNING

- Lane Keeping Assist does not assist with steering if you drive near the middle of the lane.
- Always be aware of the surroundings. If Lane safety is deselected, Lane Keeping Assist does not assist you.

Warning methods



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Warning methods** from the Settings menu in the infotainment system to select the following:

- Warning volume: The warning volume can be adjusted.
- Haptic warning: The steering wheel vibration can be set.
- Lane Safety Audible Warning: The warning volume of Lane Safety can be turned on and off when the haptic warning is selected.
- Driving safety priority: Your vehicle lowers all other audio volumes when the Driver Assistance system warning sounds.

i Information

- If you change the warning methods, the warning methods of other Driver Assistance systems may change.
- Lane Safety Audible Warning Off can be set when both the Warning volume and the haptic warning are on.
- If you turn off the haptic warning when the warning volume is '0', the warning volume does not turn off but sounds as '2'.
- If you set the warning volume to '0' when the haptic warning is off, the haptic warning turns on.
- When the vehicle is restarted, the warning methods maintains their previous setting.

Lane Keeping Assist operation

Turning Lane Keeping Assist On/Off



Whenever the vehicle is turned on, Lane Keeping Assist always turn on. The grey /➡\ indicator light illuminates on the instrument cluster. When Lane Keeping Assist is on, press and hold the Lane Driving Assist (/圖\) button to turn off the function.

When Lane Keeping Assist is off, the An indicator turns yellow.

i Information


- When Lane Keeping Assist is ready to operate, (/=\) indicator turns grey on the instrument cluster.
- When Lane Keeping Assist is operating, (/♠\) indicator turns green on the instrument cluster.

Warning and control

Left



Right



Lane Departure Warning

- If your vehicle detects it is departing from the projected lane ahead, the green /≅\ indicator light blinks on the instrument cluster the lane line blinks on the instrument cluster depending on which direction the vehicle is veering, and an audible warning sounds.
- Lane Departure Warning operates when your vehicle speed is about 60-200 km/h.

Lane Keeping Assist

- If your vehicle detects it is departing from the projected lane in front, the green /=\ indicator light blinks on the instrument cluster, and the steering wheel makes adjustments to keep vehicle inside the lane.
- Lane Keeping Assist operates when your vehicle speed is about 60-200 km/h.

Hands-off warning



If you take your hands off the steering wheel for several seconds, the "**Keep hands on steering wheel**" warning message may appear on the instrument cluster, and an audible warning may sound in successive stages.

▲ WARNING

Lane Keeping Assist may not operate in all situations and cannot avoid all collisions.

To prevent serious injury or death:

- Lane Keeping Assist may not steer if the steering wheel is held too tightly or the steering wheel is turned too far left or right.
- Always steer your vehicle. Lane Keeping Assist is not an autonomous driving system and does not steer your vehicle at all times.
- If the steering wheel is held very loosely or you have gloves on, the hands-off warning message may appear because the Lane Keeping Assist may not recognise that you have your hands on the steering wheel.
- The hands-off warning message may appear late or not at all depending on the road condition.
- If you attach objects to the steering wheel, the hands-off warning may not work properly.

i Information

- You can steer your vehicle even when steering is assisted by Lane Keeping Assist.
- It may require more or less force to turn the steering wheel when Lane Keeping Assist is providing steering assistance.
- When lane markings (or road edges) are detected, the lane lines on the instrument cluster change from grey to white.
- When the lane markings (or road edges) are detected and Highway Lane Change Assist is on, the lane lines on the instrument cluster may change to green. (if equipped)

Lane undetected



Lane detected



 The images and colours in the instrument cluster may differ depending on the instrument cluster type or theme selected from the instrument cluster.

Lane Keeping Assist malfunction and limitations

Lane Keeping Assist malfunction



When Lane Keeping Assist is not working properly, the "Check driver assistance system." warning message may appear, and the yellow /=\ warning light may illuminate on the instrument cluster. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Lane Keeping Assist disabled



If the front view camera or front radar is covered or blocked, its detecting performance is reduced, and Lane Keeping Assist may be temporarily limited or disabled.

The "Driver assistance system limited. Camera obscured." warning message may appear, and the A or A warning light may illuminate on the instrument cluster.

The function operates normally when such foreign material is removed, and the vehicle is restarted.

If Lane Keeping Assist does not operate normally after the sensor has been uncovered or unblocked, we recommend that your vehicle be inspected by an authorised Genesis repairer.

A WARNING

- Lane Keeping Assist may not operate properly even if there is no warning message or warning light on the instrument cluster.
- If the vehicle is turned off and restarted when the camera is blocked or malfunctioned, the condition is maintained and may not operate properly.

i Information

You can check it in the service message of the normal view mode of the instrument cluster display window.

Detecting sensors

Refer to the "Driver Assistance System sensors" section in this chapter for the location and the general precautions of the front view camera.

Limitations of Lane Keeping Assist

Lane Keeping Assist may not operate normally or may operate unexpectedly if:

- The lane is difficult to distinguish because:
 - The lane markings (or road edge) are damaged or covered with rain, snow, dirt, oil, etc.
 - The colour of the lane marking (or road edge) is not distinguishable from the road
 - There are markings (or road edges) on the road or near the lane that looks similar to the lane markings (or road edge)
 - The lane markings are covered by the shadow of objects around the road, such as median strip, guardrails, noise barriers, and trees.
- The lane number increases or decreases, or the lane markings (or road edges) are crossing.
- There are more than two lane markings (or road edges) on the road.
- The lane markings (or road edges) are complicated or a structure substitutes for the lines, such as a construction area or tollbooth area.
- There are road markings, such as zigzag lanes, crosswalk markings and road signs.
- The lane suddenly disappears, such as at an intersection.
- The lane (or road width) is very wide or narrow.
- There is a road edge without a lane.
- There is a boundary structure in the road, such as sidewalk or kerb.
- The distance to the front vehicle is extremely short or the vehicle in front is covering the lane marking (or road edge).

i Information

For more information on the limitations of the front view camera, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

A WARNING


- Always monitor your vehicle speed and the distance to vehicles ahead on the road. Lane Keeping Assist is not a substitute for safe driving practices, but a supplemental function only.
- Lane Keeping Assist may be cancelled or may not work properly depending on the road conditions and the surroundings.
- If your vehicle is driven at high speed, Lane Keeping Assist may not steer the vehicle.
- When other system's warning message appears or audible warning is being generated, Lane Keeping Assist may not warn you.
- You may not hear the audible warning of Lane Keeping Assist if the surroundings are noisy.
- If you attach objects to the steering wheel, steering may not be assisted properly.
- Lane Keeping Assist may not operate for 15 seconds immediately after your vehicle is started or when the front view camera is initialised.
- Lane Keeping Assist does not operate when:
 - Either the turn signal or hazard warning flasher is turned on.
 - Your vehicle is not driven in the centre of the lane after turning on Lane Keeping Assist or after changing lanes.

- ESC (Electronic Stability Control) or VSM (Vehicle Stability Management) is controlling the brake force to the wheels.
- Your vehicle is driven on sharp curves.
- Driving below 40 km/h or above 210 km/h.
- Your vehicle makes sharp lane changes.
- Your vehicle brakes suddenly.
- Loading in excess of the maximum load allowance or concentrated loading at one point in the luggage compartment can reduce the vehicle's driving stability, which can in turn reduce the effectiveness of Lane Keeping Assist.

Blind-Spot Collision-Avoidance Assist (BCA)

Blind-Spot Collision-Avoidance Assist helps detect approaching vehicles in the driver's blind spot areas and warn you of a possible collision with a warning message and audible warning.

If there is a collision risk when exiting a parallel space, Blind-Spot Collision-Avoidance Assist may assist with braking your vehicle to help avoid a collision.



Blind-Spot Collision-Avoidance Assist helps detect and warns you that a vehicle is in the blind spot area.


A CAUTION

The detection range may differ depending on the speed of your vehicle. Vehicles in the blind spot area may not be detected by Blind-Spot Collision-Avoidance Assist when you pass other vehicles at high speeds.

Blind-Spot Collision-Avoidance Assist helps detect and warns you that a vehicle is approaching at high speed from the blind spot area.

A CAUTION

The warning timing may differ depending on the speed of the vehicle approaching you at high speed.



Blind-Spot Collision-Avoidance Assist may brake your vehicle if there is a detected collision risk in the blind spot area when driving forward out of a parking space.


Blind-Spot Collision-Avoidance Assist settings

Blind-Spot Safety



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Driving safety** from the Settings menu to select the following:

 If Blind-spot safety is selected, Blind-Spot Collision-Avoidance Assist displays a warning message and sounds an audible warning depending on the collision risk levels. Braking assist is applied for parking exit depending on the collision risk levels.



If you select **Blind-spot safety**, the warning lights on the outside rear-view mirrors blink for three seconds.

In addition, if the vehicle is turned on, when **Blind-spot safety** is selected, the warning lights on the outside rear-view mirrors blink for three seconds.

When the vehicle is restarted with Blind-Spot Collision-Avoidance Assist off, the "Blind spot safety system is Off" message appears on the instrument cluster.

A WARNING

Always be aware of the surroundings. If **Blind-spot safety** is deselected, the function does not assist you.

i Information

When the vehicle is restarted, Blind-Spot Collision-Avoidance Assist maintains its previous setting.

Warning methods



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Warning methods** from the Settings menu in the infotainment system to select the following:

- Warning volume: The warning volume can be adjusted.
- Haptic warning: The steering wheel vibration can be set.
- Driving safety priority: Your vehicle lowers all other audio volumes when the Driver Assistance system warning sounds.

i Information

- If you change the warning methods, the warning methods of other Driver Assistance systems may change.
- If you turn off the haptic warning when the warning volume is '0', the warning volume does not turn off but sounds as '2'.
- If you set the warning volume to '0' when the haptic warning is off, the haptic warning turns on.
- When the vehicle is restarted, the warning methods maintains its previous setting.

Blind-Spot Collision-Avoidance Assist operation

Collision warning (whilst driving)



When a vehicle is detected in a blind spot, the warning light on the corresponding outside rear-view mirror and head-up display (if equipped) may illuminate.

 Vehicle detection operates when your vehicle speed is above 20 km/h and the speed of the vehicle in the blind spot area is above 10 km/h.

Collision warning may operate when the turn signal is turned on in the direction of a detected vehicle.

- To warn you of a potential collision, the warning light on the corresponding outside rear-view mirror and head-up display (if equipped) may blink, an audible warning may sound, and the steering wheel may vibrate.
- Collision warning operates when your vehicle speed is above 40 km/h and the speed of the vehicle in the blind spot area is above 10 km/h.
- When the turn signal is turned off or you move away from the vehicle in the blind spot, the system returns to vehicle detection state.

WARNING

- The detecting range of the rear corner radar is determined by a standard road width. On narrow roads, Blind-Spot Collision-Avoidance Assist may detect other vehicles two lane over and warn you. On wide roads, Blind-Spot Collision-Avoidance Assist may not be able to detect a vehicle driving in the next lane and may not warn you.
- When the hazard warning flasher is on, the collision warning initiated by activating the turn signal may not operate.

Collision-avoidance assist (whilst parallel exiting)



To warn you of a potential collision, the warning light on the corresponding outside rear-view mirror and head-up display (if equipped) may blink, a warning message may appear on the instrument cluster, an audible warning may sound, and the steering wheel may vibrate.

- Collision-Avoidance Assist operates when your vehicle speed is below 3 km/h and the speed of the vehicle in the blind spot area is above 5 km/h.
- Emergency braking is assisted to help avoid collision with the vehicle in the blind spot area.

After your vehicle is stopped following an Emergency Braking event, the "**Drive carefully**" warning message appears on the instrument cluster.

Press the brake pedal immediately and check the surroundings.

 Braking control ends about 2 seconds after your vehicle is stopped following an Emergency Braking event.

▲ WARNING

Blind-Spot Collision-Avoidance Assist may not operate in all situations and cannot prevent all collisions. To prevent serious injury or death:

- Only change the settings after parking your vehicle at a safe location.
- Blind-Spot Collision-Avoidance Assist may not operate if the function determines you have pressed the brake pedal sufficiently in response to the potential hazard detected by the function.
- If Blind-Spot Collision-Avoidance Assist is assisting braking your vehicle and you excessively press the accelerator pedal or sharply steer your vehicle, it stops assisted braking.
- During Blind-Spot Collision-Avoidance Assist operation, your vehicle may stop suddenly. Always wear your seat belt, check your passengers have their seat belts fastened and secure loose objects that may become projectiles.
- Even if there is a problem with Blind-Spot Collision-Avoidance Assist, your vehicle's braking system operates normally.
- Blind-Spot Collision-Avoidance Assist may warn you or may not warn you depending on the road and driving conditions.
- Control your vehicle at all times. Always maintain a safe distance from the vehicles ahead and adjust your vehicle speed depending on the road conditions. Press the brake pedal to reduce driving speed or to stop the vehicle.
- Never attempt to test Blind-Spot Collision-Avoidance Assist by intentionally driving toward people, animals, objects, or other vehicles.

- When other system's warning message appears or audible warning is heard, Blind-Spot Collision-Avoidance Assist may not warn you.
- You may not hear the audible warning of Blind-Spot Collision-Avoidance Assist if the surrounding environment is too noisy.

M WARNING

Braking is not assisted and only a warning is provided when:

- The ESC (Electronic Stability Control) warning light is on.
- ESC (Electronic Stability Control) is engaged in a different function.

Blind-Spot Collision-Avoidance Assist malfunction and limitations

Blind-Spot Collision-Avoidance Assist malfunction



When Blind-Spot Collision-Avoidance Assist is not working properly, the "Check driver assistance system." warning message may appear for several seconds, and the \(\triangle \) warning light may illuminate on the instrument cluster. We recommend that your vehicle be inspected by an authorised Genesis repairer.



When the outside rear-view mirror warning lights are not working properly, the "Check outside mirror warning icon" warning message may appear for several seconds, and the \(\triangle \) warning light may illuminate on the instrument cluster. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Blind-Spot Collision-Avoidance Assist disabled



If the rear corner radar is blocked or covered, or when the rear bumper around the rear corner radar or sensor is covered by any foreign material, such as snow, rain, or dirt, or when a trailer or towbar mounted carrier is installed, the detecting performance may reduce and temporarily limit or disable Blind-Spot Collision-Avoidance Assist.

The "Driver assistance system limited. Radar blocked." warning message may appear on the instrument cluster.

The function operates normally when such foreign material, trailer, or carrier is removed, and the vehicle is restarted.

If Blind-Spot Collision-Avoidance Assist does not operate normally after anything covering or blocking the sensors is removed, we recommend that your vehicle be inspected by an authorised Genesis repairer.

WARNING

- Blind-Spot Collision-Avoidance Assist may not operate properly even if there is no warning message or warning light on the instrument cluster. Blind-Spot Collision-Avoidance Assist may not properly operate.
- Blind-Spot Collision-Avoidance Assist may not operate properly in open areas where no objects are detected (for example,. empty parking lot) or when the detecting sensors are blocked immediately after turning on the vehicle.

i Information

You can check it in the service message of the normal view mode of the instrument cluster display window.

Detecting senors

Refer to the "Driver Assistance System sensors" section in this chapter for the location and the general precautions of the rear corner radar.

Limitations of Blind-Spot Collision-Avoidance Assist

Blind-Spot Collision-Avoidance Assist may not operate normally or may operate unexpectedly if:

- There is inclement weather, such as heavy snow, heavy rain, etc.
- The rear corner radar or the area near the rear corner radar is covered by snow, water, or dirt.
- The rear corner radar or the area near the rear corner radar is blocked by a vehicle, wall, or pillar.
- The temperature near the rear corner radar is very hot or cold.
- You are driving on an entrance/exit ramp or through a tollbooth.
- The road pavement (or the ground near your vehicle) contains metallic components (for example, possibly due to subway construction).
- There is a fixed object near the vehicle, such as sound barriers, guardrails, central dividers, entry barriers, streetlights, signs, tunnels, walls, etc. (including double structures)
- You are driving on a narrow road where trees or grass are overgrown.
- You are driving on a narrow road where trees or grass are overgrown.
- You are driving in large, open areas where there are few vehicles or structures (for example, desert, meadow, empty parking lot).
- The other vehicle drives very close behind your vehicle, or passes by your vehicle in close proximity.
- The speed of the other vehicle is so fast that it passes by your vehicle in a short time
- Your vehicle passes another vehicle.
- · Your vehicle changes lane.

- Your vehicle has started at the same time as the vehicle next to you and has accelerated.
- The vehicle in the next lane moves two lanes away from you, or the vehicle moves two lanes away to the next lane.
- The area near the rear corner radar is covered with objects, such as bumper sticker, bumper guard, bike rack, etc.
- The bumper around the rear corner radar has been damaged or modified, and the radar is out of position.
- Your vehicle height is lower or higher than normal due to heavy loads, abnormal tyre pressure, etc.

Blind-Spot Collision-Avoidance Assist may not operate normally or may operate unexpectedly when the following objects are detected:

- · A motorcycle or bicycle.
- · A vehicle such as a flat trailer.
- · A large vehicle such as a bus or truck.
- A moving obstacle such as a pedestrian, animal, shopping cart, or baby stroller.
- A vehicle with lower height, such as sports car.

Blind-Spot Collision-Avoidance Assist may not assist braking when:

- Your vehicle severely vibrates whilst driving over a bumpy road, uneven road, or concrete patch.
- You are driving on a slippery surface due to snow, water puddle, ice, etc.
- The tyre pressure is low or a tyre is damaged.
- The braking system is adjusted differently from the factory default settings.
- Your vehicle makes abrupt lane changes.

WARNING

· Driving on curves



Blind-Spot Collision-Avoidance Assist may not detect a vehicle in an adjacent lane when driving on curves and may not activate a warning or brake your vehicle.


Always check road conditions, and if necessary, take appropriate actions to drive safely.



Blind-Spot Collision-Avoidance Assist may detect a vehicle in the same lane when driving on curves and activate a warning and brake your vehicle.

Always check road conditions, and if necessary, take appropriate actions to drive safely.

· Driving on hills



Blind-Spot Collision-Avoidance Assist may not detect a vehicle in an adjacent lane or may incorrectly detect the ground or another object when driving on hills and activate a warning or brake your vehicle.

Always check road conditions, and if necessary, take appropriate actions to drive safely.


Driving where the road is merging/dividing



Blind-Spot Collision-Avoidance Assist may not detect a vehicle in an adjacent lane when the road merges or divides, and may not activate a warning or brake your vehicle.

Always check road conditions, and if necessary, take appropriate actions to drive safely.

Driving where the heights of the lanes are different




Blind-Spot Collision-Avoidance Assist may not operate properly when driving where the heights of the lanes are different. The system may not detect a vehicle on a road with a different lane height (underpass joining section, grade separated intersections, etc.) and not activate a warning or brake your vehicle.

Always check road conditions, and if necessary, take appropriate actions to drive safely.

♠ WARNING

- Blind-Spot Collision-Avoidance Assist may not operate normally if there is interference from strong electromagnetic waves.
- Blind-Spot Collision-Avoidance Assist may not operate for 3 seconds immediately after your vehicle is started or when the rear corner radars are initialised.

Safe Exit Assist (SEA)



Safe Exist Assist helps detect a vehicle approach the rear corner of your vehicle, after the vehicle is stopped and a passenger opens a door.

Safe Exist Assist may warn you with an audible warning and a warning message to help avoid a collision.



In addition, if an approaching vehicle from the rear area is detected, Safe Exit Assist prevents the doors from opening in the following situation:

 When the electronic child safety lock (00) button is in the LOCK position and an approaching vehicle from the rear area is detected, the electronic child safety lock button does not unlock even if the button is pressed to prevent the rear doors from opening.

A CAUTION

The warning timing may differ depending on the speed of the detected vehicle.

Do not use Safe Exit Assist instead of the electronic child safety lock button to protect rear seat passengers, use the electronic child safety lock button.

For more information, refer to the "Electronic child safety lock" section in chapter 5.

Safe Exit Assist settings

Safe Exit Assist



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Driving safety** > **Safe exit** from the Settings menu in the infotainment system to turn on Safe Exit Assist and deselect to turn off the function.

A WARNING

Always be aware of the surroundings. If **Safe exit** is deselected, the function does not assist you.

i Information

When the vehicle is restarted, Safe Exit Assist maintains the previous setting.

Warning methods



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Warning methods** from the Settings menu in the infotainment system to select the following:

- Warning volume: The warning volume can be adjusted. If you set the warning volume to '0', the warning volume does not turn off but sounds as '1'.
- Driving safety priority: Your vehicle lowers all other audio volumes when the Driver Assistance system warning sounds.

i Information

- If you change the warning methods, the warning methods of other Driver Assistance systems may change.
- When the vehicle is restarted, the warning methods maintains its previous setting.

Safe Exit Assist operation

Collision warning when exiting your vehicle





When an approaching vehicle from the rear is detected whilst a door is being opened, the warning light on the corresponding outside rear-view mirror may blink, the "Collision warning!" warning message may appear on the instrument cluster, and an audible warning may sound.

 Safe Exit Assist may warn you when your vehicle speed is below 3 km/h, and the speed of the vehicle approaching the rear of your vehicle is above 6 km/h.

Safe Exit Assist linked with Electronic child safety lock



When Electric child safety lock is operating and an approaching vehicle from the rear area is detected, the rear doors cannot be unlocked even if you try to unlock the rear doors using the electronic child safety lock button. The warning light on the corresponding outside rear-view mirror may blink and the "Check traffic in the blind spot, then try again" warning message may appear on the instrument cluster.

 Safe Exit Assist may warn you when vehicle speed is below 3 km/h and the speed of the vehicle approaching the rear of your vehicle is above 6 km/h.

i Information

For more information on electric child safety lock (��) button, refer to the "Electronic child safety lock" section in chapter 5.

A CAUTION

If the you press the electronic child lock (��) button again within 10 seconds after the warning message appears, Safe Exit Assist judges that the driver has unlocked the doors acknowledging the rear status. The electronic child safety lock turns off (button indicator OFF) and the rear doors unlock. Always check the surroundings before turning off the electronic child safety lock button.

i Information

If a rear door is opened from the outside, it opens regardless of Safe Exit Assist operation.

▲ WARNING

Safe Exit Assist may not operate in all situations and cannot avoid all collisions.

To prevent serious injury or death:

- Always check the surroundings before you or your passengers exit your vehicle.
- Only change the settings after parking your vehicle at a safe location.
- When other system's warning message appears or audible warning is heard, Safe Exit Assist may not warn you.
- You may not hear the audible warning of Safe Exit Assist if the surrounding environment is too noisy.
- Safe Exit Assist may stop operating, or may not operate, or operate unnecessarily depending on the road conditions and surroundings.

i Information

- After the vehicle is turned off, Safe Exit Assist may detect approaching vehicles for up to 3 minutes, but does not function after the doors are locked.
- The images and colours in the instrument cluster may differ depending on the instrument cluster type or theme selected from the settings menu.

Safe Exit Assist malfunction and limitations

Safe Exit Assist malfunction




When Safe Exit Assist is not working properly, the "Check driver assistance system." warning message may appear for several seconds, and the A warning light may illuminate on the instrument cluster. We recommend that your vehicle be inspected by an authorised Genesis repairer.



When the outside rear-view mirror warning lights are not working properly, the "Check outside mirror warning icon" warning message may appear for several seconds, and the \(\triangle \) warning light may illuminate on the instrument cluster. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Safe Exit Assist disabled



If the rear corner radar is blocked or covered, or when the rear bumper around the rear corner radar or sensor is covered by any foreign material, such as snow, rain, or dirt, the detecting performance may decrease and temporarily limit or disable Safe Exit Assist.

The "Driver assistance system limited. Radar blocked." warning message may appear on the instrument cluster.

The function operates normally when such foreign material or carrier is removed, and the vehicle is restarted.

If Safe Exit Assist does not operate normally after anything covering or blocking the sensors is removed, we recommend that your vehicle be inspected by an authorised Genesis repairer.

A WARNING

- Safe Exit Assist may not operate properly even if there is no warning message or warning light on the instrument cluster.
- Safe Exit Assist may not operate properly in open areas where no objects are detected (for example, empty parking lot) or when the detecting sensors are blocked immediately after turning on the vehicle.

i Information

You can check it in the service message of the normal view mode of the instrument cluster display window.

Detecting sensors

Refer to the "Driver Assistance System sensors" section in this chapter for the location and the general precautions of the front radar, front corner radar (if equipped), and rear corner radar.

Limitations of Safe Exit Assist

Safe Exit Assist may not operate normally, or may operate unexpectedly if:

- Trees or grass near your vehicle are overgrown.
- · The road is wet.
- The approaching vehicle is very fast or slow.

i Information

For more information on the limitations on the rear corner radar, refer to the "Driver Assistance System sensors" section in this chapter.

WARNING

- Safe Exit Assist may not operate properly if there is interference from strong electromagnetic waves.
- Safe Exit Assist may not operate for 3 seconds right immediately your vehicle is started or when the rear corner radars are initialised.

Manual Speed Limit Assist (MSLA)



- (1) Speed Limit indicator
- (2) Set speed

If you drive over the preset speed limit, Manual Speed Limit Assist operates (set speed limit blinks and chime sounds) until the vehicle speed returns within the speed limit.

Manual Speed Limit Assist operation

Setting speed limit

1. Press and hold the Driving Assist ((and button at the desired speed. The Speed Limit ((and LIMIT)) indicator light illuminates on the instrument cluster.



- 2. Push the + switch up or switch down, and release it at the desired speed.
 - A short push of the switch upward or downward will increase or decrease the set speed by 1 km/h.
 - A long push of the switch upward or downward will increase or decrease the set speed by 10 km/h.



- 3. Check the set speed limit on the instrument cluster.
 - If you want to drive over the set speed limit, press the accelerator pedal far enough to activate the kickdown mechanism.
 - The set speed limit blinks and chime sounds until your vehicle speed decreases below the set speed.



i Information

When the accelerator pedal is not pressed beyond the pressure point, your vehicle speed remains within the speed limit.

Temporarily pausing Manual Speed Limit Assist



Press the I Switch to temporarily cancel the set speed limit. The set speed limit turns off, but the Speed Limit (❤️LIMIT) indicator light stays on.

Resuming Manual Speed Limit Assist



Push the +, -, or $|| \supset$ switch.

If you push the + switch up or - switch down, the set speed is set to the current speed.

If you press the $| \bigcirc$ switch, the vehicle speed resumes to the previously set speed limit.

Turning off Manual Speed Limit Assist



Press the Driving Assist (A) button to turn off Manual Speed Limit Assist. The Speed Limit (S) LIMIT) indicator off.

Always press the Driving Assist ((??)) button to turn off Manual Speed Limit Assist when not in use.

A WARNING

To prevent serious injury or death:

- Set your vehicle speed to the speed limit for the road and use the appropriate unit (km/h) for your country.
- Keep Manual Speed Limit Assist off when not in use, to avoid unintentionally setting a speed. Check that the Speed Limit (अLIMIT) indicator light is off.
- Always drive defensively and pay attention to the task of driving.

Intelligent Speed Limit Assist (ISLA)

Intelligent Speed Limit Assist uses information from the detected road sign and navigation system to inform you of the speed limit and additional information, and help maintain within the speed limit on the road.

A CAUTION

- Intelligent Speed Limit Assist may not operate properly if used in other countries.
- Intelligent Speed Limit Assist may not operate properly if the navigation system is not updated regularly.

Intelligent Speed Limit Assist settings

Speed limit



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Speed limit** from the Settings menu in the infotainment system to select the following:

- Speed limit assist: Intelligent Speed Limit Assist informs you of the speed limit and additional road signs. The function informs you when to change the set speed of Manual Speed Limit Assist or Smart Cruise Control if needed.
- Speed limit warning: Intelligent Speed Limit Assist informs you of the speed limit and additional road signs. The function warns you when your vehicle has been driven faster than the speed limit.
- Speed limit information: Intelligent Speed Limit Assist informs you of the speed limit and additional road signs.

WARNING

- When the vehicle is restarted, Intelligent Speed Limit Assist will always turn on. However, if "Off" and the vehicle is restarted, "Speed Limit Warning" is selected.
- Only change the settings after parking your vehicle at a safe location.

Warning methods



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Warning methods** from the Settings menu in the infotainment system to select the following:

 Warning volume: The warning volume can be adjusted. If you set the warning volume to '0', the warning volume does not turn off but sounds as '1'.

i Information

- If you change the warning methods, the warning methods of other Driver Assistance systems may change.
- When the vehicle is restarted, the warning methods maintains its previous setting.
- The setting menu may not be available for your vehicle depending on the vehicle features and specifications.

Intelligent Speed Limit Assist operation

Displaying speed limit



Speed limit information is displayed on the instrument cluster.

i Information

- If speed limit information of the road cannot be recognised, '---' appears.
- Intelligent Speed Limit Assist provides additional road sign information in addition to speed limit information. Additional road sign information provided may differ depending on your country.
- Supplementary signs appear under the speed limit or overtaking restriction sign. If a supplementary sign is not recognised, it appears as blank.
- The images and colours in the instrument cluster may differ depending on the instrument cluster type or theme selected from the instrument cluster.

Warning overspeed



When driving at a speed higher than the displayed speed limit, the speed limit is blinks in red and the warning sounds.

Changing set speed



If the speed limit changes when using Manual Speed Limit Assist or Smart Cruise Control, an arrow in the direction of up or down appears to inform you to change the set speed by pushing the + or - switch.

You can change the set speed according to the speed limit by using the + or - switch.

Set speed auto change (if equipped with navigation)



Manual Speed Limit Assist or Smart Cruise Control helps you adjust the vehicle speed according to the speed limit. When the set speed is same as the speed limit, the set speed automatically changes to the current speed limit if the speed limit changes. The function operates on the road which has a speed limit of 70 km/h or higher. When the function is active, the set speed on the instrument cluster appears in green.

A WARNING

- If necessary, reduce your driving speed as needed. Even after changing the set speed according to the speed limit for the road, your vehicle can still be driven over the speed limit.
- If the speed limit for the road is under 30 km/h, the set speed changing function does not work.
- Intelligent Speed Limit Assist operates using the speed unit set by you from the settings menu. If the speed unit is set to a unit other than the speed unit used in your country, Intelligent Speed Limit Assist may not operate properly.

i Information

- For more information on Manual Speed Limit Assist operation, refer to the "Manual Speed Limit Assist (MSLA)" section in this chapter.
- For more information on Smart Cruise Control operation, refer to the "Smart Cruise Control (SCC)" section in this chapter.

Intelligent Speed Limit Assist malfunction and limitations

Intelligent Speed Limit Assist malfunction



When Intelligent Speed Limit Assist is not working properly, the "Check driver assistance system." warning message may appear on the instrument cluster for several seconds, and the ⚠ and ⊖ warning lights may illuminate on the instrument cluster. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Intelligent Speed Limit Assist disabled



If the front view camera is covered or blocked, its detecting performance is reduced, and Intelligent Speed Limit Assist is temporarily limited or disabled.

The "Driver assistance system limited. Camera obscured." warning message may appear, and the ⊕ warning light may illuminate on the instrument cluster.

The function operates normally when such foreign material is removed, and the vehicle is restarted.

If Intelligent Speed Limit Assist does not operate normally after the sensor has been uncovered or unblocked, we recommend that your vehicle be inspected by an authorised Genesis repairer.

WARNING

- Intelligent Speed Limit Assist may not operate properly even if there is no warning message or warning light on the instrument cluster.
- If the vehicle is turned off and restarted whilst the camera is blocked or malfunctioned, the condition is maintained and may not operate properly.

i Information

You can check it in the service message of the normal view mode of the instrument cluster display window.

Detecting sensors

Refer to the "Driver Assistance System sensors" section in this chapter for the location and the general precautions of the front view camera.

Limitations of Intelligent Speed Limit Assist

Intelligent Speed Limit Assist may not operate or may be limited if:

- The road sign is damaged, difficult to see due to rain, snow, fog, dirt, sand, oil, etc., or obscured by surrounding objects or shadows.
- The road signs do not conform to the standard designs in your country.
 - The text or picture on the road sign are different from the standard designs in your country.
 - The road sign is installed between the main road and exit road or between diverging roads.
 - A sign is attached to another vehicle.
- The distance between the driving lane and road sign is far.
- · There are LED road signs.
- The numbers or pictures in the road sign is incorrectly recognised as the speed limit.
- Road signs on adjacent roads are incorrectly recognised as road signs you are driving on.
- Supplementary road signs or signboards are installed near the road sign.
- Multiple signs are installed close together.

- A minimum speed limit sign is incorrectly recognised as the maximum speed limit sign.
- The light levels changes suddenly, for example when entering or exiting a tunnel or passing under a bridge.
- Headlamps are not used, or the brightness of the headlamps are weak at night or in the tunnel.
- Road signs are difficult to recognise due to the reflection of sunlight, streetlights, or oncoming vehicles.
- The driver is driving on a new road that is not in the navigation system yet.
- The front view camera's field of view is obstructed by glare from the sun.
- You are driving on a road that is sharply curved or continuously curved.
- You are driving through speed bumps, or driving up and down, or left to right on steep inclines.
- · Your vehicle is shaking heavily.
- You are driving your vehicle on a newly opened road.
- There is an error in the navigation map data or GPS data.
- You are not driving your vehicle based on the route guidance.
- The navigation system is being updated or restarted whilst driving.

A WARNING

- Intelligent Speed Limit Assist may not display the correct speed limit or may not properly control the driving speed because it is a supplemental function to inform you of the speed limit on the road.
- Set your vehicle speed to the speed limit for the road and use the appropriate unit (km/h) for your country.
- Intelligent Speed Limit Assist may not operate for 15 seconds immediately after your vehicle is started or when the front view camera is initialised.

i Information

For more information on the limitations of the front view camera, refer to the "Driver Assistance System sensors" section in this chapter.

Driver Attention Warning (DAW)

Inattentive driving warning function

Driver Attention Warning monitors your driving pattern whilst driving. When the attention level is below a certain level it recommends a break.

Leading vehicle departure alert function

Leading Vehicle Departure Alert function informs you when a detected vehicle in front departs from a stop.

Driver Attention Warning settings

Leading vehicle departure alert

With the vehicle on, select Setup > Vehicle > Driver assistance > Driver attention and then enable Leading vehicle departure alert in the infotainment system to use the function.



 If Leading vehicle departure alert is selected, the function informs you when a detected vehicle in front departs from a stop. If Swaying warning is selected, Driver Attention Warning will inform the driver of the driver's attention level and will recommend taking a break if the level falls below a certain level.

i Information

Driver Attention Warning menu will not be displayed in a region where the Driver Attention Warning function operates frequently.

Driver Attention Warning operation

Inattentive driving warning function

Taking a break



The "Consider taking a break" message may appear and the bwarning light may blink on the instrument cluster and an audible warning may sound, when the attention level is below a certain level.

 Driver Attention Warning does not suggest a break if the total driving time is less than 4 minutes or 4 minutes has not passed since the last break was suggested.

▲ WARNING

Only change the settings after parking your vehicle at a safe location.

A CAUTION

- Driver Attention Warning may suggest a break depending on your driving pattern or habit, even if you do not feel fatigued.
- Driver Attention Warning is a supplemental function only and does not determine if you are paying attention to the driving task.
- If you feel fatigued or want to take a break, do so as needed at a safe location.

Leading Vehicle Departure Alert function



When a detected vehicle in front departs from a stop, Leading Vehicle Departure Alert displays the "Leading vehicle is driving on" message on the instrument cluster and an audible warning sounds.

A WARNING

- When other system's warning message appears or audible warning is heard, Leading Vehicle Departure Alert may not alert you.
- Always check road conditions, and if necessary, take appropriate actions to drive safely. It is the driver's responsibility to operate the vehicle in a safe manner.

A CAUTION

- Leading Vehicle Departure Alert is a supplemental function and may not alert you whenever the front vehicle departs from a stop.
- Always check your surroundings before driving even if the function alerts you that the front vehicle has departed.

i Information

The images and colours in the instrument cluster may differ depending on the instrument cluster type or theme selected from the settings menu.

Driver Attention Warning malfunction and limitations

Driver Attention Warning malfunction



When Driver Attention Warning is not working properly, the "Check driver assistance system." warning message may appear for several seconds, and the ⚠ and ➡ warning lights may illuminate on the instrument cluster. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Driver Attention Warning disabled



If the front view camera is covered or blocked, its detecting performance is reduced, and Driver Attention Warning may be temporarily limited or disabled.

The "Driver assistance system limited. Camera obscured." warning message may appear, and the A and warning lights may illuminate on the instrument cluster.

The function operates normally when such foreign material is removed, and the vehicle is restarted.

If Driver Attention Warning does not operate normally after the sensor has been uncovered or unblocked, we recommend that your vehicle be inspected by an authorised Genesis repairer.

WARNING

- Driver Attention Warning may not operate properly in open areas where no objects are detected (for example, empty car park) or when the detecting sensors are blocked immediately after turning on the vehicle.
- If the vehicle is turned off and restarted whilst the camera is blocked or malfunctioned, the condition is maintained and may not operate properly.

i Information

You can check this in the service message of the normal view mode of the instrument cluster display window.

Detecting sensors

Refer to the "Driver Assistance System sensors" section in this chapter for the location and the general precautions of front view camera.

Limitations of Driver Attention Warning


Driver Attention Warning may not work properly if:

- Your vehicle is driven aggressively or steered sharply from side to side.
- Your vehicle intentionally changes lanes frequently.
- Another Driver Assist system such as Lane Keeping Assist, is maintaining your vehicle's position within the lane.

Leading vehicle departure alert feature


· When the vehicle cuts in





[A] Your vehicle

If a vehicle cuts in front of your vehicle, Leading Departure Alert may not operate properly. · When the vehicle ahead sharply steers



- [A] Your vehicle [B] Front vehicle
 - If the vehicle in front makes a sharp turn, such as to turn left or right or make a U- turn, etc., Leading Vehicle Departure Alert may not operate properly.
- When the vehicle ahead abruptly departures




If the vehicle in front abruptly departures, Leading Vehicle Departure Alert may not operate properly.

 When a pedestrian or bicycle is between you and the vehicle ahead




If there is a pedestrian(s) or bicycle(s) in between you and the vehicle in front, Leading Vehicle Departure Alert may not operate properly.

When in a car park



If a vehicle parked in front drives away from you, Leading Vehicle Departure Alert may alert you that the parked vehicle is driving away. When driving at a tollbooth or intersection, etc.



If you pass a tollbooth or intersection with lots of vehicles or you drive where lanes are merged or divided frequently, Leading Vehicle Departure Alert may not operate properly.

A WARNING

Driver Attention Warning may not operate for about 15 seconds immediately after your vehicle is started or when the front view camera is initialised.

i Information

For more information on the precautions of the front view camera, refer to the "Driver Assistance System sensors" section in this chapter.

Forward Attention Warning (FAW)

+if equipped

Forward Attention Warning uses the in-cabin camera to help prevent the driver from being distracted whilst driving with an audible warning and warning light.

Forward Attention Warning settings

Forward attention warning



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Driver attention** from the Settings menu in the infotainment system to select the following:

 If Forward Attention is enabled, the function warns the driver when the driver's gaze is not focused on the road.

i Information

When the vehicle is restarted, Forward Attention Warning maintains its previous setting.

Forward Attention Warning operation

Forward Attention Warning

Forward Attention Warning determines whether the driver is focused on the road depending on information, such as the amount of time the driver is looking elsewhere, the amount of time the eyes are closed, etc. If Forward Attention Warning judges the driver is not focused, an audible warning sounds for about 1 second, and the warning light illuminates on the instrument cluster until off conditions are met.

The warning comes on:

- When the driver's gaze is not focused on the road continuously for 3 seconds whilst driving above 20 km/h.
- When the driver's gaze is not focused on the road for 10 seconds or more in total during a 30 seconds time span whilst driving above 20 km/h.
- When the driver's eyes are closed for over 2 seconds or more whilst driving above 10 km/h.

The warning goes off:

When the driver looks forward continuously for over 2 seconds.

M WARNING

If any other system's warning message is displayed or audible warning is being generated, Forward Attention Warning's warning message may not be displayed and an audible warning may not be generated.

A CAUTION

- Forward Attention Warning may warn the driver even though the driver is focused on the road because of driving style and driving patterns.
- Forward Attention Warning is a supplemental function and may not determine whether the driver is distracted whilst driving.
- The driver is responsible for safe driving and must focus on the road.

i Information

- Forward Attention Warning does not transmit recorded videos outside of the vehicle or store the video.
- The Warning Method for Forward Attention Warning cannot be changed.


Forward Attention Warning malfunction and limitations

Forward Attention Warning malfunction



When Forward Attention Warning is not working properly, the "Check forward attention warning system" warning message appears on the instrument cluster for several seconds, the warning light illuminates on the instrument cluster, and an audible warning sounds. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Forward Attention Warning disabled



If there is an object directly in front of the in-cabin camera or between you and the camera for a certain period of time Forward Attention Warning does not operate properly.

The "Forward attention warning disabled. Camera obscured" warning message appears on the instrument cluster for several seconds, the warning light illuminates on the instrument cluster, and an audible warning sounds.

If the object is removed or the camera is able to detect the your face, the function operates normally.

If Forward Attention Warning does not operate properly after the object is removed, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Limitations of Forward Attention Warning

Forward Attention Warning may not operate normally, or it may operate unexpectedly if:

- You wear sunglasses, special glasses, infrared cutoff glasses, refracting glasses or thick glasses.
- You have heavy eye makeup (eyeliner, mascara, colour makeup, false eyelash) or eye piercing.
- · Your view is blocked by hair, hat, etc.
- You are winking or wearing an eye patch on one eye.
- Your face is covered partially by a mask, muffler, etc.
- Your view is blocked by incoming light from outside of the vehicle.
- Light from outside, sunlight or infrared LED light of the camera is reflected by glasses or sunglasses.
- You have turned or lowered your head so that your face or an eye is hidden from the camera.
- You shake your head up and down, or adverse road conditions cause excessive vehicle vibrations whilst driving.
- You are positioned in your seat in such a way that your face is not detected.
- · You are too tall or short.
- The camera is blocked by the grip on the steering wheel.
- More than two people are looking at the instrument cluster simultaneously from the driver's seat.
- Your eyes are narrowed due to laughing or sun glare.
- A picture or mannequin that has a similar size to your face is misrecognised.
- There are other devices using infrared light in the vehicle.

A CAUTION



[A] In-cabin camera

- Do not impact the surface of the camera or around the camera. If the in-cabin camera is damaged, Forward Attention Warning may not work properly.
- Do not place anything on the camera or in front of the camera whilst driving.
 The in-cabin camera may not operate properly.
- When cleaning the camera, wipe with a soft and clean cloth to prevent damages on the surface of the camera lens. In addition, you should not use sharp tools near the camera, or use chemicals to clean the camera.
- Always keep the camera and around the area of the in-cabin camera clean and dry.
- Do not apply foreign objects, such as a sticker, around the infrared LED located near the camera.

Blind-Spot View Monitor (BVM)

tif equipped

Left



Right



Blind-Spot View Monitor uses the wide-side view cameras to display the rear blind spot areas of your vehicle on the instrument cluster when the turn signal is turned on to help with safe lane changes.

i Information

Two red lights may appear on the camera in the following conditions when:

- The outside light level is dim or driving at night.
- The vehicle drives inside a building, such as a basement car park, garage or tunnel.
- The camera case is partially broken.

Blind-Spot View Monitor settings

Setting features

With the vehicle on, select Setup > Vehicle > Driver assistance > Driving safety and then enable Blind-Spot View Monitor from the Setting menu in the infotainment system to turn on the Blind-Spot View Monitor.

Blind-Spot View Monitor operation



Turns on if:

The left or right side turn signal turns on, and the corresponding side view camera image appears on the instrument cluster.

Turns off if:

- · The turn signal turns off.
- The hazard warning flasher is on. Blind-Spot View Monitor turns off, independent of the turn signal status.
- Other warnings on the instrument cluster may replace the side view camera image when changing lanes.

Blind-Spot View Monitor malfunction

When Blind-Spot View Monitor is not working properly, or the instrument cluster display flickers, or the camera image does not display properly, we recommend that your vehicle be inspected by an authorised Genesis repairer.

WARNING

- The image shown on the instrument cluster may differ from the actual distance of the object. Make sure to directly check the vehicle's surroundings for safety.
- Always keep the camera lens clean. If the lens is blocked or covered, Blind-Spot View Monitor may not operate normally. Do not clean with strong chemicals containing high alkaline or volatile organic solvents (for example, petrol or acetone).

Smart Cruise Control (SCC)

Smart Cruise Control helps detect a vehicle ahead and maintain the desired speed and distance between your vehicle and the vehicle ahead.

Overtaking Acceleration Assist

Whilst Smart Cruise Control is operating, if the function judges you are attempting to overtake a vehicle in front, Smart Cruise Control accelerates your vehicle to assist you with this manoeuvre.

Based on Driving Style

Smart Cruise Control operates based on the driver's driving style, such as vehicle distance, acceleration, and reaction speed.

Smart Cruise Control settings

Smart Cruise Control



With the vehicle on, select Setup > Vehicle > Driver assistance > Driving convenience > SCC (Smart Cruise Control) from the Settings menu in the infotainment system to adjust Distance, Acceleration, and Response speed manually.

Based on Driving Style



With the vehicle on, if Setup > Vehicle > Driver assistance > Driving convenience > SCC (Smart Cruise Control) > Based on driving style is selected from the Settings menu, Smart Cruise Control operates based on your driving style, such as vehicle distance, acceleration, and reaction speed.

i Information

- Whilst Smart Cruise Control is operating with Based on driving style selected, if you press and hold the Vehicle Distance (2) button, Based on driving style deactivates. If you press and hold the Vehicle Distance (2) button again, View driving style analysis activates.
- Based on Driving Style setting continuously learns your driving style when the vehicle is being driven.
- When Based on driving style is deactivated, the driving style such as vehicle distance, acceleration, and reaction speed does not change.

Smart Cruise Control operation

Operating conditions

Basic function

Smart Cruise Control operates when the following conditions are met:

- The gear is in D (Drive)
- Your vehicle speed is within the operating speed range.
 - 10-180 km/h: when there is no vehicle in front
 - 0-180 km/h: when there is a vehicle in front
- ESC (Electronic Stability Control) or ABS is enabled.

Smart Cruise Control does not operate when:

- The driver's door is opened.
- EPB (Electronic Parking Brake) is applied.
- ESC (Electronic Stability Control) or ABS is controlling your vehicle.
- Forward Collision-Avoidance Assist braking control is operating.
- Remote Smart Parking Assist brake control is operating. (if equipped)

i Information

If stopped behind another vehicle, you have to press the brake pedal to turn on Smart Cruise Control.

Operating conditions for Acceleration Assist

Overtaking Acceleration Assist operates when the turn signal indicator is turned on to the left (left-hand drive) or turned on to the right (right-hand drive) whilst Smart Cruise Control is operating, and the following conditions are met:

- Your vehicle speed is above 60 km/h.
- A vehicle is detected in front of your vehicle.

Overtaking Acceleration Assist does not operate when:

- · The hazard warning flasher is on.
- Deceleration is needed to maintain the distance from the vehicle in front.

WARNING

- Be careful when your vehicle temporarily accelerates to overtake a vehicle in front.
- Overtaking Acceleration Assist operates when the conditions are met.

Turning on Smart Cruise Control



- Press the Driving Assist button to turn on Smart Cruise Control. The speed is set to the current speed on the instrument cluster.
- If there is no vehicle in front of you, the set speed is maintained.
- If there is a vehicle in front of you, your vehicle speed may be adjusted to maintain the set distance from the vehicle ahead.
- If the vehicle ahead accelerates and the distance between vehicles increase, your vehicle accelerates to the set speed, and then travels at a constant speed after your vehicle reaches the set distance.

i Information

- If your vehicle speed is between 0-30 km/h when you press the Driving Assist button, Smart Cruise Control speed is set to 30 km/h.
- If you shift from a higher gear to a lower gear using the paddle shifter, the vehicle speed may not accelerate to the set speed.

Setting vehicle distance



Each time the button is pressed, the vehicle distance changes as follows:



If you drive at 90 km/h:

- Distance 4: about 52.5 m
- Distance 3: about 40 m
- · Distance 2: about 32.5 m
- Distance 1: about 25 m

\overline{i} Information

When the vehicle is restarted or Smart Cruise Control is temporarily cancelled, the following distance maintains the previous setting.

Increasing set speed



- Push the + switch up and release it immediately to increase the cruising speed by 1 km/h.
- Push and hold the + switch up to increase to the nearest multiple of 10 km/h at first, and then increase by an additional 10 km/h each time.
- The speed can be set to a maximum of 180 km/h.

WARNING

Your vehicle speed may rapidly increase when you push and hold the + switch.

Decreasing set speed



- Push the switch down and release it immediately to decrease the cruising speed by 1 km/h.
- Push and hold the switch down to decrease to the nearest multiple of 10 km/h at first, and then decrease by 10 km/h each time.
- The speed can be set to a minimum of 30 km/h.

Temporarily cancelling Smart Cruise Control



Press the ∥⊃ switch or press the brake pedal to temporarily cancel Smart Cruise Control.

Resuming Smart Cruise Control



Push the +, -, or $|| \bigcirc$ switch.

If you push the + switch up or - switch down, your vehicle speed is set to the current speed on the instrument cluster.

If you press the $\| \bigcirc$ switch, your vehicle speed resumes to the previously set speed.

▲ WARNING

Your vehicle speed may rapidly increase or decrease when you press the $\| \mathcal{D} \|$ switch.

Turning off Smart Cruise Control



Press the Driving Assist (CA) button to turn off Smart Cruise Control.

i Information

If your vehicle is equipped with Manual Speed Limit Assist, press and hold the Driving Assist ((3)) button to turn off Smart Cruise Control and turn on Manual Speed Limit Assist.


A CAUTION

Do not operate multiple buttons or switches simultaneously. Smart Cruise Control may not operate properly.

Smart Cruise Control display

The status of the Smart Cruise Control operation appears in Driving Assist view on the instrument cluster. Refer to the "View modes" section in chapter 4.

Operating



Temporarily cancelled



- When operating
- (1) Displays whether there is a vehicle ahead and the selected distance level appears.
- (2) Set speed appears.
- (3) Displays whether there is a vehicle ahead and the target vehicle distance appears.
- When temporarily cancelled
- (1) Your vehicle appears in grey.
- (2) The previous set speed appears in grey.
- (3) Displays whether there is a vehicle ahead. If any, it appears in grey. (if equipped)

i Information

- The distance from the front vehicle on the instrument cluster appears according to the actual distance between your vehicle and the vehicle ahead.
- The target distance may differ depending on the vehicle speed and the set distance level. If the vehicle speed is low, even though the vehicle distance has changed, the change to the target vehicle distance may be small.
- The images and colours in the instrument cluster may differ depending on the instrument cluster type or theme selected from the settings menu.

Accelerating temporarily



If you press the accelerator pedal above a certain speed whilst Smart Cruise Control is operating, your vehicle can speed up temporarily without changing the set speed. The set speed, distance level, and target distance blink on the instrument cluster whilst pressing the accelerator pedal. Your vehicle speed may decrease if the accelerator pedal is not pressed far enough.

A WARNING

Be careful when accelerating temporarily, because Smart Cruise Control is not controlling the speed and distance even if there is a vehicle in front of you.

Always maintain a safe distance from the vehicles ahead and adjust your vehicle speed depending on the road conditions.

Based on Driving Style operation



When Based on driving style is operating, the vehicle distance level and target distance appears white based on the driving style.

Temporarily cancelling Smart Cruise Control



Smart Cruise Control is temporarily cancelled automatically when:

- Your vehicle speed is over 190 km/h.
- Your vehicle is stopped for a certain period of time.
- Your accelerator pedal is continuously pressed for a certain period of time.
- The conditions for the Smart Cruise Control to operate are not met.

If Smart Cruise Control is temporarily cancelled automatically, the "SCC (Smart Cruise Control) cancelled" warning message appears on the instrument cluster, and an audible warning sounds to warn you.

i Information

If Smart Cruise Control is temporarily cancelled when your vehicle is at a standstill with the function activated, the Electronic Parking Brake (EPB) may be applied.

▲ WARNING

Always maintain a safe distance from the vehicles ahead and adjust your vehicle speed to the road conditions. When Smart Cruise Control is temporarily cancelled, it is not controlling the speed and distance from the vehicle ahead.

Smart Cruise Control conditions not met



If the Driving Assist button, +, — or || \(\) switch is operated when Smart Cruise Control operating conditions are not satisfied, the "SCC (Smart Cruise Ctrl.) conditions not met" message appears on the instrument cluster, and an audible warning sounds.

In traffic situation



In traffic, your vehicle stops if the vehicle ahead of you stops. Also, if the vehicle ahead of you starts moving, your vehicle starts moving as well. In addition, after your vehicle has stopped and a certain time has passed, the "Use switch or pedal to accelerate" message appears on the instrument cluster. Press the accelerator pedal or push the +, -, or | > switch to start driving.

Warning road conditions ahead



The "Watch for surrounding vehicles" warning message appears on the instrument cluster, and an audible warning sounds if the vehicle in front disappears when Smart Cruise Control is maintaining the distance from the vehicle ahead whilst driving below a certain speed.

A WARNING

Always pay attention to vehicles or objects that may suddenly appear in front of you. Always maintain a safe distance from the vehicles ahead and adjust your vehicle speed to the road conditions.

Forward Collision Warning

Whilst Smart Cruise Control is operating, when the collision risk with the vehicle ahead is high, Forward Collision-Avoidance Assist may warn you of a possible collision.

Adjust your vehicle speed by pressing the brake pedal according to the road and driving conditions ahead.

For more information on Forward Collision-Avoidance Assist, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

A WARNING

Smart Cruise Control is not a substitute for proper and safe driving.

To prevent serious injury or death:

- Always monitor your vehicle speed and the distance to vehicles ahead on the road. Smart Cruise Control is not a substitute for safe driving practices, but a supplemental function only.
- Always maintain a safe distance from the vehicles ahead and adjust your vehicle speed to the road conditions. Smart Cruise Control may not recognise unexpected and sudden situations or complex driving situations.
- Keep Smart Cruise Control off when not in use to avoid inadvertently setting the speed.

- Do not open the door or leave your vehicle when Smart Cruise Control is operating, even if your vehicle is stopped.
- Always check the vehicle speed and distance to the front vehicle that have heen selected
- Keep a safe distance depending on the road condition and vehicle speed. If the distance to the front vehicle is too close whilst driving at high speeds, it may cause a serious collision.
- When maintaining distance from the vehicle ahead, if the front vehicle is no longer detected, Smart Cruise Control may suddenly accelerate to the set speed.
- The vehicle speed may slow down or speed up whilst driving uphill or downhill.
- Always be aware of situations such as when a vehicle cuts in suddenly.
- Turn off Smart Cruise Control when your vehicle is being towed.
- Smart Cruise Control may not operate normally if there is interference from strong electromagnetic waves.
- Smart Cruise Control may not detect obstacles in front and cause a collision.
- Vehicles frequently changing lanes may cause a delay or may cause Smart Cruise Control to react to a vehicle in an adiacent lane.
- When other system's warning message appears or audible warning is heard, Smart Cruise Control may not warn you.
- You may not hear the audible warning of Smart Cruise Control if the surrounding environment is too noisy.
- The vehicle manufacturer is not responsible for any traffic violation or collisions caused by you.

- Set your vehicle speed to the speed limit for the road and use the appropriate unit (km/h) for your country.
- Smart Cruise Control may not operate for 15 seconds immediately after your vehicle is started or when the front view camera, front radar, and front corner radar are initialised.

i Information

You may hear sounds when Smart Cruise Control is braking your vehicle. This is normal and does not indicate a malfunction.

Smart Cruise Control malfunction and limitations

Smart Cruise Control malfunction



When Smart Cruise Control is not working properly, the "Check driver assistance system." warning message may appear and the A warning light may illuminate on the instrument cluster. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Smart Cruise Control disabled



If the front radar is covered or blocked, its detecting performance is reduced, and Smart Cruise Control is temporarily limited or disabled.

The "Driver assistance system limited. Radar blocked." warning message may appear on the instrument cluster.

If Smart Cruise Control does not operate normally after the sensor has been uncovered or unblocked, we recommend that your vehicle be inspected by an authorised Genesis repairer.

WARNING

- Smart Cruise Control may not operate properly even if there is no warning message or warning light on the instrument cluster.
- Smart Cruise Control may not operate properly in open areas where no objects are detected (e.g. empty parking lot) or when the detecting sensors are blocked immediately after turning on the vehicle.

i Information

You can check it in the service message of the normal view mode of the instrument cluster display window.

Detecting sensors

Refer to the "Driver Assistance System sensors" section in this chapter for the location and the general precautions of the front view camera, front radar, and front corner radar.

Limitations of Smart Cruise Control

Smart Cruise Control may not operate normally or may operate unexpectedly if:

- The sensor or the area near the sensor is blocked, covered, or damaged.
- The temperature near the front view camera is very hot or cold.
- The camera lens is covered or blocked by windscreen tint, the windscreen is damaged, or a sticky material (sticker, bug, etc.) is on the glass.
- Moisture is not removed or is frozen on the windscreen.
- Washer fluid is sprayed continuously, or the wiper is on.
- You are driving in heavy rain, snow, or thick fog.
- The front view camera's field of view is obstructed by glare from the sun.
- Sunlight, streetlight, or light from an oncoming vehicle is reflected on the wet road surface such as a puddle on the road.
- An object is placed on the instrument panel.
- The surroundings are very bright or very dark (nighttime, tunnel, etc.).
- The light level changes suddenly, for example when entering or exiting a tunnel.
- The light level outside is low, and the headlamps of the front vehicle are turned off or are not bright.
- · A front vehicle is partially visible.
- The vehicle in front has no tail lamps or tail lamps are located in an unusual location.
- The rear of the front vehicle is small or the vehicle does not look normal, such as when your vehicle is tilted, overturned, or the side of your vehicle is visible.
- The front vehicle's ground clearance is so low or high.
- · Your vehicle is being towed.

- · A vehicle suddenly cuts in front.
- The bumper around the front radar has been damaged or modified, and the radar is out of position.
- A material is near that reflects very well on the front radar, such as guardrail, nearby vehicle, etc.
- The temperature near the front radar is very hot or cold.
- The vehicle in front is made of a material that does not reflect on the front radar well.
- The vehicle in front is detected late.
- The vehicle in front is suddenly blocked by an obstacle.
- The vehicle in front suddenly changes lanes or reduces the speed.
- The angle of the vehicle in front is out of the detection range.
- Your vehicle changes lanes at a low speed with a vehicle in front.
- The vehicle in front is covered with snow.
- You are on a curve or roundabout and the vehicle in front is not detected.
- You are continuously driving in a circle.
- Your vehicle moves unstably or vibrates excessively.
- Your vehicle height is low or high due to heavy loads, abnormal tyre pressure, etc.
- You are driving through steam, smoke, or shadow.
- You are driving through a tunnel or an iron bridge.
- You are driving in large, open areas where there are few vehicles or structures (e.g. desert, meadow, empty suburb).
- · You are driving in a car park.

- You are driving through a tollbooth, construction area, unpaved road, partial paved road, uneven road, speed bumps, etc.
- You are driving through roads with railroad tracks or other embedded metal objects.
- You are driving on an inclined road or curved road.
- You are driving on a sharply curved road.
- You are driving through a roadside with trees or streetlights.
- You are driving on a narrow road where trees or grass are overgrown.
- You are driving on a slippery surface due to snow, water puddle, ice, etc.
- You are driving in an area with strong radio waves or electrical noise interference

· Driving on curves



On curves, Smart Cruise Control may not detect a vehicle in the same lane, and may accelerate to the set speed. Your vehicle speed may be reduced if a vehicle is detected in an adjacent lane and your vehicle speed may rapidly decrease when a vehicle ahead is detected suddenly.

Select an appropriate set speed for curves and apply the brake pedal or accelerator pedal depending on the road and driving conditions.

· Driving on hills



During uphill or downhill driving, Smart Cruise Control may not detect a moving vehicle in your lane, and cause your vehicle to accelerate to the set speed. Also, your vehicle speed rapidly decreases when a vehicle ahead is detected suddenly.

Select an appropriate set speed on inclines and apply the brake pedal or accelerator pedal depending on the road and driving conditions.


Changing lanes




- [A] Your vehicle[B] Lane changing vehicle

When a vehicle moves into your lane from an adjacent lane, it cannot be detected by the sensor until it is in the sensor's detection range. Smart Cruise Control may not immediately detect the vehicle when your vehicle changes lanes abruptly. Brake as needed to reduce your driving speed.

· Situations when detecting are limited





Some vehicles, pedestrians, or animals in your lane may not be detected by the sensor:

- Vehicles offset to one side
- Slow-moving vehicles or sudden decelerating vehicles
- Vehicles with higher ground clearance or vehicles carrying loads that extend past the end of the vehicle
- Vehicles that have the front tilted due to heavy loads
- Vehicles within about 2 m from your vehicle
- Oncoming vehicles
- Stopped vehicles
- Vehicles with small rear profile, such as trailers
- Narrow vehicles, such as motorcycles or bicycles


- Special vehicles
- Animals and pedestrians
 Brake as needed to reduce your driving speed.
- In the following cases, the vehicle in front may not be detected by the sensor:
 - Making sharp steering inputs when driving
 - Driving on narrow or sharply curved roads
- When a vehicle ahead turns at an intersection and is no longer detected, your vehicle may accelerate.



 When a vehicle in front of you merges out of the lane, Smart Cruise Control may not immediately detect a new vehicle that is now in front of your vehicle.



 Always look out for pedestrians when your vehicle is maintaining a distance with the vehicle ahead.



Navigation-based Smart Cruise Control (NSCC)

Navigation-based Smart Cruise Control helps the vehicle maintain a certain speed depending on the road conditions when driving on highways (or motorways) by using information from the navigation system whilst Smart Cruise Control is operating.

i Information

- Navigation-based Smart Cruise Control is available only on controlled access highways (or motorways).
 - Controlled access highway is a road with limited entrances and exits that allow uninterrupted high speed traffic flow.
- Additional highways may be expanded by future navigation system updates.
- Navigation-based Smart Cruise Control operates on main roads of highways (or motorways), and does not operate on interchanges or junctions.

Highway Auto Curve Slowdown

If the vehicle speed is high, the Highway Curve Zone Auto Slowdown function temporarily slows your vehicle or limits acceleration based on the available curve information in the navigation system.

Navigation-based Smart Cruise Control settings



With the vehicle on, select Setup > Vehicle > Driver assistance > Driving convenience > Highway Auto Speed Change from the Settings menu in the infotainment system to turn on Navigation-based Smart Cruise Control and deselect to turn off the function.

i Information

When there is a problem with Navigation-based Smart Cruise Control, the function cannot be set from the settings menu.

Navigation-based Smart Cruise Control operation

Navigation-based Smart Cruise Control may be available when:

- · Smart Cruise Control is operating.
- You are driving on controlled access roads.

i Information

For more information on how to operate Smart Cruise Control, refer to the "Smart Cruise Control (SCC)" section in this chapter.

Navigation-based Smart Cruise Control display

The following may appear on the instrument cluster:



Navigation-based Smart Cruise Control standby

If the operating conditions are met, the green NAV indicator light illuminates.

Navigation-based Smart Cruise Control operating

Whilst the speed is being controlled, the green MAY indicator light blinks.

Temporarily cancelled or interrupted by the driver

If Navigation-based Smart Cruise Control cannot control the vehicle, such as when Smart Cruise Control is temporarily cancelled or the navigation system is searching for a route, the grey NAV indicator light illuminates.

When the driver presses the accelerator pedal, the white **NAV** indicator light blinks.

MARNING



The "**Drive carefully**" warning message appears if Navigation-based Smart Cruise Control is not able to slow down your vehicle.

i Information

The images and colours in the instrument cluster may differ depending on the instrument cluster type or theme selected from the settings menu.

Highway Auto Curve Slowdown


- Depending on the curve ahead on the motorway, your vehicle decelerates, and after passing the curve, your vehicle accelerates to Smart Cruise Control's set speed.
- Vehicle deceleration time may differ depending on your vehicle speed and the degree of the curve on the road. The higher the driving speed, deceleration starts faster.

Limitations of Navigation-based Smart Cruise Control

Navigation-based Smart Cruise Control may not operate normally if:


- · The navigation is not working properly.
- Map information is not transmitted due to an issue with the infotainment system.
- Speed limit and road information in the navigation system has not been updated.
- The map information differs from the actual road conditions because of real-time GPS data or map information error.
- The navigation system is searching for a route whilst driving.
- GPS signals are blocked in areas such as a tunnel.
- A road is divided into two or more roads and they join again.
- You go off the route set in the navigation system.
- The route to the destination is changed or cancelled by resetting the navigation system.
- Your vehicle enters a service station or rest area.
- Android Auto or Car Play is operating.
- The navigation system cannot detect the current vehicle position (for example, on elevated roads including overpasses adjacent to general roads or nearby roads which are parallel to the current road).
- The navigation system is updated whilst driving or restarts.
- The speed limits of some sections have changed according to the road situations (e.g. construction zone).
- You are driving on a road that is under construction.

- You are driving in lane-restricted driving situations.
- There is inclement weather, such as heavy rain or heavy snow.
- You are driving on a road with sharp curves.
- When your vehicle continues on the controlled access road and does not follow the navigation route to exit the highway, Highway Auto Curve Slowdown may not operate until it is determined that you are driving on the highway. When Highway Auto Curve Slowdown operates, your vehicle may decelerate gradually or rapidly depending on the distance to the curve and the vehicle speed.




- (1) Set route
- (2) Branch line
- (3) Driving route
- (4) Main road
- (5) Curved road section

 When your vehicle does not follow the navigation route and exits the highway at an interchange or junction, Highway Auto Curve Slowdown may temporarily operate until it is determined that you have exited the highway.



- (1) Set route
- (2) Branch line
- (3) Driving route
- (4) Main road
- (5) Curved road section
- If there is no destination set on the navigation, Highway Auto Curve Slowdown operates based on the curve information for the controlled access road in the navigation system.

When you exit the highway at an interchange or junction, Highway Auto Curve Slowdown may temporarily operate using the navigation information for the highway.



- (1) Driving route
- (2) Branch line
- (3) Curved road section
- (4) Main road

WARNING

Always have your eyes on the road. It is the driver's responsibility to avoid violating traffic laws. Navigation-based Smart Cruise Control is not a substitute for safe driving practices, but a supplemental function only.

To prevent serious injury or death:

- Always check the speed limit whilst driving. The navigation's speed limit information may differ from the actual speed limit on the road.
- Navigation-based Smart Cruise Control is automatically cancelled when you leave the highway and enter a general road, interchange, junction, or rest area.
- Navigation-based Smart Cruise Control may not operate depending on the configuration of vehicles detected ahead on the road.
- After you pass through a tollbooth on a highway, Navigation-based Smart Cruise Control operates based on the outermost lane. If you enter one of the other lanes, Navigation-based Smart Cruise Control may not operate properly.
- Your vehicle accelerates if you press the accelerator pedal whilst Navigation-based Smart Cruise Control is operating. If the accelerator pedal is not pressed far enough, your vehicle may decelerate.
- If you accelerate and release the accelerator pedal whilst Navigation-based Smart Cruise Control is operating, your vehicle may not decelerate sufficiently or may rapidly decelerate.
- If the curve is too sharp or if it is a slight curve, Navigation-based Smart Cruise Control may not operate.

i Information

- There may be a gap in time between the navigation system's guidance and when the Navigation-based Smart Cruise Control operation starts and ends
- The speed information on the instrument cluster may differ from the navigation system.
- Even if you are driving at a speed lower than the Smart Cruise Control's set speed, acceleration may be limited by the curves ahead on the road.
- If Navigation-based Smart Cruise Control is operating whilst leaving the highway and entering an interchange, junction, or rest area, the function may continue to operate for a whilst.
- Deceleration by Navigation-based Smart Cruise Control may not feel sufficient due to the road conditions such as uneven road surfaces or narrow lanes.

Lane Following Assist (LFA)

Lane Following Assist helps detect lane markings and/or a vehicle ahead on the road, and provide steering assist to your vehicle in the lane.

Lane Following Assist settings

Warning methods



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Warning methods** from the Settings menu in the infotainment system to select the following:

- Warning volume: The warning volume can be adjusted. If you set the warning volume to '0', the warning volume does not turn off but sounds as '1'.
- Driving safety priority: Your vehicle lowers all other audio volumes when the Driver Assistance system warning sounds.

i Information

- If you change the warning methods, the warning methods of other Driver Assistance systems may change.
- When the vehicle is restarted, the warning methods maintains their previous setting.

Lane Following Assist operation

Turning Lane Following Assist On/Off



With the vehicle on, press the Lane Driving Assist (/⊕\) button located on the steering wheel to turn on Lane Following Assist. The grey or green ⊖ indicator light illuminates on the instrument cluster.

Press the button again to turn off the function.

Lane Following Assist



If the both lane markings and/or vehicle ahead are detected and your vehicle speed is below 180 km/h, the green Θ indicator light illuminates on the instrument cluster, and Lane Following Assist helps centre the vehicle in the lane by assisting the steering wheel.

i Information

When the steering wheel is not assisted, the white ⊖ indicator light blinks and changes to grey.

Hands-off warning



If you take your hands off the steering wheel for several seconds, the "**Keep hands on steering wheel**" warning message may appear on the instrument cluster, and an audible warning sounds in successive stages.

- · First stage: Warning message
- Second stage: Warning message (red steering wheel) with a warning sound

i Information

For more details on precautions of the steering wheel grip sensor, refer to the "Steering wheel grip sensor" section in chapter 5.



If you do not have your hands on the steering wheel after the hands-off warning, the "LFA (Lane Following Assist) cancelled" warning message may appear and Lane Following Assist is automatically cancelled.

WARNING

Always safely steer your vehicle and maintain the position of your vehicle in its lane.

To prevent serious injury or death:

- Always have your hands on the steering wheel whilst driving.
- Lane Following Assist may not steer if the steering wheel is held too tightly, or the steering wheel is turned too far left or right.
- If the steering wheel is held very loosely or you have gloves on, the hands-off warning message may appear because the Lane Following Assist may not recognise that you have your hands on the steering wheel.
- The hands-off warning message may appear late or not at all depending on the road condition.
- If you attach objects to the steering wheel, the hands-off warning may not work properly.

i Information

- The status of the Lane Following Assist operation appears in Driving Assist view on the instrument cluster. Refer to the "View modes" section in chapter 4.
- When both lane markings are detected, the lane lines on the instrument cluster changes from grey to white.

Lane undetected



Lane detected



- The images and colours in the instrument cluster may differ depending on the instrument cluster type or theme selected from the settings menu.
- If lane markings are not detected, steering wheel control by Lane Following Assist can be limited depending on the vehicle in front or driving condition.
- You can steer your vehicle even when steering is assisted by Lane Following Assist.
- It may require more or less force to turn the steering wheel when Lane Following Assist is providing steering assistance.

Lane Following Assist malfunction and limitations

Lane Following Assist malfunction



When Lane Following Assist is not working properly, the "Check driver assistance system." warning message may appear for several seconds, and the A warning light may illuminate on the instrument cluster. We recommend that your vehicle be inspected by an authorised Genesis repairer.

i Information

You can check it in the service message of the normal view mode of the instrument cluster display window.

Detecting sensors

Refer to the "Driver Assistance System sensors" section in this chapter for the location and the general precautions of the front view camera.

Limitations of Lane Following Assist

i Information


For more information on Lane Following Assist limitations and precautions, refer to the "Lane Keeping Assist malfunction and limitations" section in this chapter.

▲ WARNING

Loading in excess of the maximum load allowance or concentrated loading at one point in the luggage compartment can reduce the vehicle's driving stability, which can in turn reduce the effectiveness of Lane Following Assist.


Highway Driving Assist (HDA)

Basic function



Highway Driving Assist helps maintain distance from the vehicle ahead, maintain the set speed, and centre the vehicle in the lane whilst driving on the highway (or motorway).

Highway Lane Change Assist



Highway Lane Change Assist function helps change lanes to the direction you operate the turn signal switch if the function judges that lane change is possible.

i Information

- Highway Driving Assist is available only on controlled access highways.
 - Controlled access highway is the road with limited entrances and exits that allow uninterrupted high speed traffic flow.
- Additional highways may be expanded by future navigation system updates.
- Highway Driving Assist does not operate on interchanges or junctions.

Highway Driving Assist settings



With the vehicle on, select or deselect **Setup > Vehicle > Driver assistance > Driving convenience** from the Settings menu to turn each function on and off.

Highway Driving Assist

If HDA (Motorway Driving Assist) is selected, the function helps maintain distance from the vehicle ahead, maintain the set speed, and help centre your vehicle in the lane whilst driving on the motorway.

Highway Lane Change Assist
If Lane change assist (motorway) is selected, the function helps you change lanes.

i Information

- When HDA (Motorway Driving Assist) is deselected, the setting for Lane change assist (motorway)"cannot be changed.
- When there is a problem with Highway Driving Assist, the function cannot be set from the Settings menu. We recommend that your vehicle be inspected by an authorised Genesis repairer.
- When the vehicle is restarted, the function maintains the previous setting.

A WARNING

Only change the settings after parking your vehicle at a safe location.

A CAUTION

When a trailer is connected to your vehicle, Highway Driving Assist automatically turns off. In this case, Highway Driving Assist is not functional. Always have your eyes on the road. (if equipped with genuine Genesis parts)

Warning methods



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Warning methods** from the Settings menu in the infotainment system to select the following:

- Warning volume: The warning volume can be adjusted. If you set the warning volume to '0', the warning volume does not turn off but sounds as '1'.
- Driving safety priority: Your vehicle lowers all other audio volumes when the Driver Assistance system warning sounds.

i Information

- If you change the warning volume, the warning volume of other Driver Assistance systems may change.
- When the vehicle is restarted, the warning methods maintains their previous setting.
- The setting menu may not be available for your vehicle depending on the vehicle features and specifications.

Highway Driving Assist operation

Basic function

Highway Driving Assist display

The status of the Highway Driving Assist operation appears in Driving Assist mode on the instrument cluster. Refer to the "View modes" section in chapter 4.

Operating state



Standby state



- 1. Indicates if there is a vehicle ahead and the selected distance level appears.
 - Highway Driving Assist indicator (HDA)
 - Green HDA: Operating state
 - Grey HDA: Standby state
 - White HDA blink: Accelerator pedal pressed
 - Non-display: Off state

- 2. Set speed appears.
- 3. Lane Following Assist light appears.
- 4. Detected ahead and the selected vehicle distance appears.
- 5. Whether the lane is detected or not appears.

i Information

- For more information on the display, refer to the "Smart Cruise Control (SCC)" and "Lane Following Assist (LFA)" sections in this chapter.
- The images and colours in the instrument cluster may differ depending on the instrument cluster type or theme selected from the settings menu.

Highway Driving Assist operationHighway Driving Assist operates when:

- You have pressed the Driving Assist button after entering or driving on controlled access roads.
- Entering or driving on controlled access roads with both Lane Following Assist and Smart Cruise Control operating.

Restarting after stopping



When Highway Driving Assist is operating, your vehicle stops if the vehicle ahead of you stops. Also, if the vehicle ahead of you starts moving within 30 seconds after the stop, your vehicle starts as well. If your vehicle has stopped and 30 seconds have passed, the "Use switch or pedal to accelerate" message appears on the instrument cluster. press the accelerator pedal or push the +, -, or \(\)\ \Circ\ S witch to accelerate.

Hands-off warning



If you take your hands off the steering wheel for several seconds, the "**Keep hands on steering wheel**" warning message may appear on the instrument cluster, and an audible warning sounds in successive stages.

First stage: Warning message

Second stage: Warning message (red steering wheel) and audible warning



If you do not have your hands on the steering wheel after the hands-off warning, the "HDA (Motorway Driving Assist) sys. cancelled" warning message may appear and Highway Driving Assist and Lane Change Assist are automatically cancelled.


Driving speed limit



When Highway Driving Assist is cancelled by the hands-off warning, The driving speed will be limited.

Whilst Driving Speed Limit function is operating, the "Driver's grasp not detected. Speed will be limited." warning message appears on the instrument cluster, and an audible warning sounds continuously.

Driving to one side within lane



When vehicle speed is above 60 km/h, if a detected vehicle around you is driving at a close distance, your vehicle controls the steering in the opposite direction of the vehicle. If a vehicle is detected at both sides of the lane and are driving close to you, the function does not veer to the opposite side of the lane.

Highway Driving Assist standby
When the Smart Cruise Control is
temporarily cancelled whilst Highway
Driving Assist is operating, Highway
Driving Assist goes into the standby state.
At this time, Lane Following Assist
operates normally.

i Information

- Driving Speed Limit helps you drive below 60 km/h. At this time, the vehicle decelerates due to the vehicle ahead. After the vehicle has decelerated, it cannot automatically accelerate.
- · Driving Speed Limit cancels when:
 - The driver grabs the steering wheel again
 - The driver turns on Lane Following Assist by pressing the Lane Driving Assist (/⊕\) button
 - +, -, ||○ switch, or 🖶 button is operated, or the accelerator pedal or the brake pedal is pressed

Highway Lane Change Assist

Highway Lane Change Assist display

The status of the Highway Lane Change Assist operation appears in Driving Assist mode on the instrument cluster. Refer to the "View modes" section in chapter 4.

Ready/Operating



Standby/Cancelled



- 1. Highway Lane Change Assist (47) indicator
 - · Green on: Ready state
 - · Green blink: Operating state
 - · Grey on: Standby state
 - White blink: Cancelled state (displayed only a certain time)

2. Lane line

 The lane line is displayed same as the Highway Lane Change Assist (††) indicator. However, if the function is in standby, it displays whether the lane line is detected.

- 3. Green arrow and shade
 - The green arrow is displayed when a certain amount of time has passed after the function has started operating, and until the lane change has completed.

4. Message

- Message appears when the function does not operate even though the turn signal is used.
- Message appears when the function is cancelled whilst operating.

To turn on Highway Lane Change Assist Highway Lane Change Assist function turns on when the Driving Assist button or Lane Driving Assist button is used to turn on Highway Driving Assist.

Highway Lane Change Assist ready to operate



Whilst Highway Lane Change Assist function is on, the function is ready to operate when all the following conditions are met:

- · Highway Driving Assist is operating.
- · Lane Following Assist is operating.
- A vehicle in the rear area of your vehicle is detected more than once after the vehicle is turned on.
- Your vehicle speed is above 30 km/h.

- When your vehicle is between 30-60 km/h, a vehicle is detected in the rear area to your vehicle's left and right sides, and there is no risk of collision when changing a lane.
- Hands-off warning is not displayed on the instrument cluster.
- Hazard warning flasher is off.


Whilst Lane Change Assist function is turned on (indicator on), Lane Following Assist does not cancel even if the turn signal indicator or hazard warning flasher is operating.

- Lane Change Assist function turns off automatically when driven in the following road conditions:
 - There is only one driving lane.
 - There is a road with a intersection or crosswalk ahead.
 - There is a road with no structure, such as a medium strip, guardrails, etc.
 - There is a pedestrian or cyclist on the road ahead.
- When the function is in the ready state, and vehicle speed is below 25 km/h, the function changes to the standby state.
- When your vehicle is between 30-60 km/h, and a vehicle is not detected in the rear area of your vehicle's left and right side lanes, the function changes to the standby state.
- If there is a collision risk, the function changes to the standby state.

▲ WARNING

When Highway Lane Change Assist function turns off whilst operating, steering assist is temporarily cancelled. Always be cautious whilst driving.

Highway Lane Change Assist operating



Highway Lane Change Assist function operates, when you push the turn signal lever up or down to the [A] or [B] position whilst the function is in the ready state (indicator is green), and all of the following conditions are met:

- You have your hand on the steering wheel
- There is no collision risk in the direction of lane change.
- There is a single dotted lane line in the direction of lane change.
- There are no Forward Collision-Avoidance Assist and Blind Spot Collision-Avoidance Assist warnings.
- The vehicle is driven in the middle of the lane (should not be driving close to one side of the lane).
- The road you are driving on, or the road you are about to change lane to, is a road that the function can operate.

 Highway Lane Change Assist operates when the turn signal lever is positioned at [A].

If the turn signal lever is released to the centre (1) before crossing the lane, Highway Lane Change Assist cancels. If the turn signal lever is released to the centre (1) after crossing the lane, Highway Lane Change Assist changes the lane and turns off the turn signal after the lane change is complete.

 When the turn signal lever is placed at [B] position for a certain period of time, the green arrow appears. At this time, even when the lever is released and returns to the original position (1), lane change is still assisted.

Whilst lane change is being made by the function, the turn signal indicator blinks even when the turn signal lever is not held, and the turn signal indicator turns off when lane change is complete.

Highway Lane Change Assist standby Highway Lane Change Assist function is in the standby state when one of the ready state conditions are not met, or when entering or driving on one of the following roads:

- Road within a certain distance from the tollbooth on the main road of the highway
- The road ahead ends without an interchange or junction
- Road with sharp curves
- · Road with narrow lanes
- · Road that is under construction

Highway Lane Change Assist cancel You may cancel the function by:

- Turning on the turn signal in the opposite direction of the lane change.
- · Turning the steering wheel sharply.


WARNING

- Highway Lane Change Assist automatically cancels when:
 - Highway Driving Assist is turned off.
 - Lane Following Assist or Smart Cruise Control is turned off or temporarily cancelled.
 - Hands-off warning message is displayed on the instrument cluster.
 - The hazard warning flasher is turned on
 - Forward Collision-Avoidance Assist or Blind-Spot Collision Avoidance Assist warning message is displayed.
 - A possible collision is detected in the next lane, even though there are no Forward-Collision Avoidance Assist and Blind-Spot Collision Avoidance Assist warning.
 - Entering a road under construction.
 - The target lane to cross into disappears.
 - There is a problem with the turn signal lights.
 - Highway Lane Change Assist function turns off (The function turns off when the function is turned off from the settings menu, when the road changes to a one-way road, when there is an intersection or crosswalk ahead, when you enter a road with no structure, such as a medium strip, guardrail, etc.,or when there is a pedestrian or cyclist on the driving lane.).
 - Your vehicle speed is below 25 km/h.

- When your vehicle is between 30-60 km/h, and a vehicle is not detected in the rear area of your vehicle's left and right side lanes.
- There is a risk of collision with a vehicle at the rear area of your vehicle.
- Whilst the function is operating, if the function is cancelled, depending on the driving conditions, the vehicle may drive to the middle of the driving lane or steering assist may stop. Always pay attention to road and driving conditions whilst driving.
- The function may not operate properly on roads with pedestrians or cyclists, such as an intersection or crossing.
 Always pay attention to road and driving conditions whilst driving.

Highway Driving Assist malfunction and limitations

Highway Driving Assist malfunction



When Highway Driving Assist is not working properly, the "Check driver assistance system." warning message may appear and the A warning light may illuminate on the instrument cluster. We recommend that your vehicle be inspected by an authorised Genesis repairer.

▲ WARNING

Always check road conditions, and if necessary, take appropriate actions to drive safely. Highway Driving Assist is a supplemental function only and it is not a self driving or autonomous driving system.

To prevent serious injury or death:

- Always have your hands on the steering wheel whilst driving.
- Always have your eyes on the road and pay attention. It is the driver's responsibility to avoid violating traffic laws.
- Highway Driving Assist may not be able to recognise all traffic situations and may not detect possible collision hazards. Obstacles such as vehicles, motorcycles, bicycles, pedestrians, or unspecified objects or structures (e.g. guardrails and tollbooth) may not be detected.

- Highway Driving Assist turns off automatically under the following situations:
 - You are driving on roads that Highway Driving Assist does not operate, such as a rest area, intersection, junction, etc. However, Highway Driving Assist may be maintained in some sections.
 - The navigation does not operate properly such as when the navigation system is updating or restarting.
- Highway Driving Assist may inadvertently operate or turn off depending on the road conditions (based on the navigation system information) and surroundings.
- Lane Following Assist may be temporarily disabled when the front view camera cannot detect lanes properly or the hands-off warning is on.
- The hands-off warning message may appear early or late depending on how the steering wheel is held or road conditions.
- You may not hear the audible warning of Highway Driving Assist if the surrounding environment is too noisy.
- When your vehicle is driven at high speeds through a curve, your vehicle may depart from your driving lane if you do not maintain control.
- Highway Driving Assist may not operate immediately after the vehicle is started or when the sensors or navigation system are initialised.

You can check it in the service message of the normal view mode of the instrument cluster display window.

Detecting sensors

Refer to the "Driver Assistance System sensors" section in this chapter for the location and the general precautions of the front view camera, front radar, front corner radar, and rear corner radar.

Limitations of Highway Driving Assist

Highway Driving Assist may not operate normally or may not operate if:

- The map information differs from the actual road conditions because the navigation system has not been updated, or there is a real-time GPS data or map information error.
- The infotainment system is overloaded by simultaneously performing functions such as route search, video playback, voice recognition, etc.
- GPS signals are blocked in an area such as tunnel.
- You depart from the navigation route or the route to the destination is changed or cancelled.
- Your vehicle enters a service station or rest area.
- Android Auto or Car Play is operating.
- The navigation system cannot detect the current vehicle position (for example, on elevated roads including overpasses adjacent to general roads or nearby roads which are parallel to the current road).

i Information

For more information on the limitations of the front view camera, front radar, front corner radar, and rear corner radar, refer to the "Forward Collision-Avoidance Assist (FCA)" section in this chapter.

Rear View Monitor (RVM)

+if equipped

Rear View Monitor displays the area behind your vehicle to assist you when parking or driving.

Rear View Monitor settings

Warning methods




With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Warning methods** from the Settings menu in the infotainment system to select the following:

 Parking safety priority: The vehicle lowers all other audio volumes when a parking assist view is active.

i Information

- If you change the warning methods, the warning methods of other Driver Assistance systems may change.
- When the vehicle is restarted, the warning methods maintains their previous setting.
- The setting menu may not be available for your vehicle depending on the vehicle features and specifications.

Camera settings



To change the settings of Rear View Monitor's display contents, press the setup icon (③) on the screen whilst Rear View Monitor is operating, or select **Setup** > **Vehicle** > **Driver assistance** > **Parking safety** > **Camera settings** from the Settings menu in the infotainment system whilst the vehicle is on.

 If Display contents is selected, you can change settings for Extend rear camera use and Rear view reference lines.

Extended rear view monitor

If **Extend rear camera use** is selected, the rear view maintains on the screen when shifting from R (Reverse) to N (Neutral) or D (Drive). When your vehicle exceeds a certain speed, the rear view stops displaying.

Rear view parking guide line

If **Rear view reference lines** is selected, the rear view parking guide appears when the rear view and rear top view is displayed.

i Information

- The rear view horizontal guideline shows the distance of about 0.5 m, 1 m, and 2.3 m from the vehicle.
- The rear top view horizontal guideline shows the distance of 0.5 m and 1.5 m from the vehicle.

Rear View Monitor operation

Parking/View button

Press the Parking/View button (1) whilst the gear is in P (Park), D (Drive) or N (Neutral) to turn on the Rear View Monitor.



Rear view



The rear view appears on the screen.

View modes can be selected by pressing the view buttons (2) on the Rear View Monitor screen.

Turns on if:

- You shift the gear to R (Reverse).
- You press the Parking/View button (1) when the gear is in P (Park), N (Neutral), or D (Drive), and your vehicle speed is 10 km/h or less.

Turns off if:

- You shift the gear to P (Park).
- You press the Parking/View button (1).
- · You press the Home button (3).
- You press the infotainment system buttons (4).
- You shift the gear to N (Neutral) or D (Drive), and your vehicle speed is above 10 km/h.

i Information

The rear view cannot be turned off when the gear is in R (Reverse).

Extended rear view function

The rear view maintains on the screen when you shift the gear from R (Reverse) to N (Neutral) or D (Drive)

Turns on if:

 You shift the gear from R (Reverse) to N (Neutral) or D (Drive), and your vehicle speed is 10 km/h or less.

Turns off if:

- You shift the gear to P (Park).
- You press the Parking/View button (1).
- You press the Home button (3).
- You press the infotainment system buttons (4).
- · Your vehicle speed is above 10 km/h.

Rear top view



Select the rear top view mode from the view buttons (2).

The top view appears on the screen and the distance from the vehicle appears in the back of your vehicle.

Rear view whilst driving

The rear view remains on the screen whilst driving, this is to assist reversing.

Turns on if:

 You press the Parking/View button (1) when the gear is in N (Neutral) or D (Drive), and your vehicle speed is above 10 km/h.

Turns off if:

- · You shift the gear to P (Park).
- You press Parking/View button (1).
- You press the Home button (3).
- You press the infotainment system buttons (4).

i Information

- The rear view in all modes cannot be turned off when the gear is in R (Reverse).
- When the rear view is turned on, the previously used view mode appears.
- The rear parking guidelines appear when the rear view or rear top view is displayed. (The parking guidelines appear only when Rear view reference lines is selected from the Settings menu in the infotainment system.).
- The rear view whilst driving does not turn off even when the vehicle speed is below 10 km/h.
- When the rear view whilst driving is on, the rear top view is disabled.

Rear View Monitor malfunction and limitations

Rear View Monitor malfunction

When Rear View Monitor is not working properly, or the screen flickers, or the camera image does not appear normally, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Detecting sensors

Refer to the "Driver Assistance System sensors" section in this chapter for the location and the general precautions of the wide-rear view camera.

Limitations of Rear View Monitor

When your vehicle is stopped for a long time in winter or your vehicle is parked in an indoor car park, the exhaust fumes may temporarily blur the image.

A WARNING

- Always turn your head to check blind spots. The rear view camera does not cover the entire area behind your vehicle.
- The distance to the object shown on the screen may differ from the actual distance. This is because the image shown on Rear View Monitor is displayed by calibrating the image from the camera.
 - When the vehicle is tilted by cargo loading, parking guidelines may not be correct. Make sure to directly check the vehicle's surroundings for safety.
- Always keep the rear view camera lens clean. If the lens is blocked or covered, the Rear View Monitor may not operate normally. Do not clean with strong chemicals containing high alkaline or volatile organic solvents (e.g. petrol, acetone).


Surround View Monitor (SVM)



Surround View Monitor displays images around your vehicle through the infotainment system screen when parking or driving.

Surround View Monitor settings

Warning methods




With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Warning methods** from the Settings menu in the infotainment system to select the following:

 Parking safety priority: The vehicle lowers all other audio volumes when a parking assist view is active.

i Information

- If you change the warning methods, the warning methods of other Driver Assistance systems may change.
- When the vehicle is restarted, the warning methods maintains their previous setting.
- The setting menu may not be available for your vehicle depending on the vehicle features and specifications.

Camera settings



To change the settings of Surround View Monitor's display contents, press the setup icon (③) on the screen whilst Surround View Monitor is operating, or select Setup > Vehicle > Driver assistance > Parking safety > Camera settings from the Settings menu in the infotainment system whilst the vehicle is on.

 If Display contents is selected, you can change settings for Parking distance warning, Top view reference lines and Rear view reference lines.

Parking distance warning

If **Parking distance warning** is selected, the parking distance warning appears on the right side of the Surround View Monitor screen.

Top view reference lines

If **Top view reference lines** is selected, the parking guideline appears on the right side of the Surround View Monitor screen.

i Information

The rear top view horizontal guideline shows the distance of 0.5 m and 1.5 m from the vehicle.

Rear view reference lines

If **Rear view reference lines** is selected, the parking guideline appears in the rear view.

i Information

The rear view horizontal guideline shows the distance of about 0.5 m, 1 m, and 2.3 m from the vehicle.

Surround View Monitor Auto On

With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Parking safety** > **Surround view monitor auto On** from the Settings menu in the infotainment system to use the function.

i Information

For more information on Surround view monitor auto On, refer to "Surround View Monitor operation" in this chapter.

Surround View Monitor operation

Press the Parking/View button (1) to turn on Surround View Monitor.

Press the button again to turn off the function.



Front view



The front view appears on the screen when the gear is in N (Neutral) or D (Drive) to assist parking. The front view has top view, front view, side view, and 3D view.

View modes can be selected by pressing the view buttons (2) on the Surround View Monitor screen

Turns on if:

- You shift the gear from R (Reverse) to N (Neutral) or D(Drive).
- You press the Parking/View button (1) when the gear is in P (Park), N (Neutral), or D (Drive), and your vehicle speed is 10 km/h or less.
- Surround view monitor auto On function is operating.

(**Surround view monitor auto On** must be selected from the Settings menu.)

i Information

When the front view is turned on, the previously used view mode appears.

Turns off if:

- You shift the gear to P (Park) or R (Reverse).
- You press the Parking/View button (1).
- You press the Home button (3).
- You press the infotainment system buttons (4).
- Your vehicle speed is above 10 km/h.

i Information

Surround View Monitor turns off when vehicle speed is above 10 km/h. The function does not turn on again even if vehicle speed is below 10 km/h.

Front view whilst driving

The front view remains on the screen whilst driving.

View modes can be selected by pressing the view buttons (2) on the Surround View Monitor screen.

Turns on if:

 You press the Parking/View button (1) when the gear is in N (Neutral), or D (Drive), and your vehicle speed is above 10 km/h.

Turns off if:

- You shift the gear to P (Park) or R (Reverse).
- You press the Parking/View button (1).
- · You press the Home button (3).
- You press the infotainment system buttons (4).

- When the front view whilst driving is turned on, the previously used view mode appears.
- The front view whilst driving does not turn off even when the vehicle speed is below 10 km/h once it is on.
- When the front view whilst driving is on, the front top view and side view are disabled.

Rear view



The rear view appears on the screen to assist parking. The rear view has top view, rear view, side view, and 3D view.

View modes can be selected by pressing the view buttons (2) on the Surround View Monitor screen.

Turns on if:

- · You shift the gear to R (Reverse).
- You press the Parking/View button (1) when the gear is in P (Park), N (Neutral), or D (Drive), and your vehicle speed is below 10 km/h.

Turns off if:

- You shift the gear from N (Neutral) or D (Drive) to P (Park).
- You press the Parking/View button (1) when the gear is in P (Park), N (Neutral), or D (Drive).
- You press the Home button (3) when the gear is in P (Park), N (Neutral), or D (Drive).
- You press the infotainment system buttons (4) when the gear is in P (Park), N (Neutral), or D (Drive).
- Your vehicle speed is above 10 km/h when the gear is in D (Drive).
- You shift the gear from R (Reverse) to P (Park).

i Information

The rear view cannot be turned off when the gear is in R (Reverse) even if the infotainment system buttons (4) are pressed.

Rear View whilst driving

The rear view remains on the screen whilst driving, this is to assist with reversing.

Turns on if:

 You press the rear view mode from view buttons (2) after pressing the Parking/View button (1) when the gear is in N (Neutral) or D (Drive), and your vehicle speed is above 10 km/h.

Turns off if:

- You shift the gear to P (Park).
- You press the Parking/View button (1).
- You press the Home button (3).
- You press the infotainment system buttons (4).

- When the rear view whilst driving is turned on, the previously used view mode appears.
- The rear parking guidelines do not appear when the rear view is displayed whilst driving.
- The rear view whilst driving does not turn off even when the vehicle speed is below 10 km/h.
- When the rear view whilst driving is on, the rear top view and rear side view are disabled.

3D view



The 3D view shows the image around the vehicle from various angles.

Tap the screen to change vehicle angles. Press the 3D view button (2) again to return to the initial angle.

Turns on if:

- You press the 3D view button (2) when the gear is in P (Park), N (Neutral), or D (Drive), and your vehicle speed is below 10 km/h.
- You press the 3D view button (2) when Surround View Monitor is turned on when the gear is in R (Reverse).

Turns off if:

- You shift the gear from N (Neutral) or D (Drive) to P (Park).
- You press the Parking/View button (1) when the gear is in P (Park), N (Neutral), or D (Drive).
- You press the Home button (3) when the gear is in P (Park), N (Neutral), or D (Drive).
- You press the infotainment system buttons (4) when the gear is in P (Park), N (Neutral), or D (Drive).
- Your vehicle speed is above 10 km/h when the gear is in D (Drive)
- You shift the gear from R (Reverse) to P (Park).

i Information

3D view does not display guidelines.

Surround View Monitor malfunction and limitations

Surround View Monitor malfunction

When Surround View Monitor is not working properly, or the screen flickers, or the camera image does not appear normally, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Detecting sensors

Refer to the "Driver Assistance System sensors" section in this chapter for the location and the general precautions of the wide-front view camera, wide-side view camera, and wide-rear view camera.

Limitations of Surround View Monitor

- When your vehicle is stopped for a long time in winter or your vehicle is parked in an indoor car park, the exhaust fumes may temporarily blur the image.
- The screen may not display the surround view properly and an icon may appear at the top left of the screen if:
 - The boot is opened.
 - The driver or front passenger door is opened.
 - The outside rear-view mirrors are folded.

WARNING


- Always look around your vehicle to make sure there are no objects or obstacles before driving.
- The distance to the object shown on the screen may differ from the actual distance. This is because the image shown on Surround View Monitor is displayed by calibrating the image from the camera.
 - When the vehicle is tilted by cargo loading, parking guidelines may not be correct. Make sure to directly check the vehicle's surroundings for safety.
- Surround View Monitor is designed to be used on a flat surface. When your vehicle is used on roads with different heights such as kerbs and speed bumps, the image on the screen may not look correct.
- Always keep the camera lens clean. If the lens is blocked or covered, the Surround View Monitor may not operate normally. Do not clean with strong chemicals containing high alkaline or volatile organic solvents (petrol, acetone etc.).

i Information

Surround View Monitor uses the cameras installed on the vehicle to show images around the vehicle through the infotainment system. The image shown on the screen may look unnatural depending on the surroundings.

Rear Cross-Traffic Collision-Avoidance Assist (RCCA)

Rear Cross-Traffic Collision-Avoidance Assist helps detect vehicles approaching from the rear left or right whilst your vehicle is reversing, and warns you of a possible collision with a warning message and an audible warning. Braking may also be assisted to avoid a collision.



- [A] Rear Cross-Traffic Collision Warning operating range
- [B] Rear Cross-Traffic Collision-Avoidance Assist operating range

A CAUTION

The warning timing may differ depending on the speed of the detected vehicle.

Rear Cross-Traffic Collision-Avoidance Assist settings

Rear Cross-Traffic Safety



With the vehicle on, select Setup > Vehicle > Driver assistance > Parking safety > Rear cross-traffic safety from the Settings menu in the infotainment system to turn on Rear Cross-Traffic Collision-Avoidance Assist and deselect to turn off the function.

A WARNING

When the vehicle is restarted, Rear Cross-Traffic Collision-Avoidance Assist turns on. If **Rear cross-traffic safety** is deselected after the vehicle is restarted, Rear Cross-Traffic Collision-Avoidance Assist does not function until the next time your vehicle is started.

A CAUTION

When a trailer is connected to your vehicle, Rear Cross-Traffic Collision-Avoidance Assist automatically turns off. In this case, Rear Cross-Traffic Collision-Avoidance Assist is not functional. Always have your eyes on the road. (if equipped with genuine Genesis parts)

Warning methods



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Warning methods** from the Settings menu in the infotainment system to select the following:

- Warning volume: The warning volume can be adjusted.
- Haptic warning: The steering wheel vibration can be set.


i Information

- If you change the warning methods, the warning methods of other Driver Assistance systems may change.
- If you set the warning volume to '0' when the haptic warning is off, the haptic warning turns on.
- When the vehicle is restarted, the warning methods maintains their previous setting.
- The setting menu may not be available for your vehicle depending on the vehicle features and specifications.

Rear Cross-Traffic Collision-Avoidance Assist operation

Collision warning





To warn you of an approaching vehicle from the rear left or right of your vehicle, the warning light on the corresponding outside rear-view mirror may blink, a warning message may appear on the instrument cluster, an audible warning may sound, and the steering wheel may vibrate.

When Rear View Monitor or Surround View Monitor is operating, a warning may appear on the infotainment system screen.

Collision warning may operate if:


- You shift the gear to R (Reverse) and your vehicle speed is below 8 km/h.
- The approaching vehicle is detected within about 25 m from the left or right of your vehicle.
- The speed of the vehicle approaching from the left or right is above 5 km/h.

i Information

- If the operating conditions are met, a warning is provided whenever a vehicle approaches from the left or right even though your vehicle speed is 0 km/h.
- The images and colours in the instrument cluster may differ depending on the instrument cluster type or theme selected from the instrument cluster.

Emergency braking





To warn you of an approaching vehicle from the rear left or right of your vehicle, the warning light on the corresponding outside rear-view mirror may blink, a warning message may appear on the instrument cluster, an audible warning may sound, and the steering wheel may vibrate.

When Rear View Monitor or Surround View Monitor is operating, a warning may appear on the infotainment system screen.

If a collision is imminent, emergency braking is assisted to help prevent collision with approaching vehicles from the left and right side or your vehicle. Emergency braking may operate if:

- The gear is shifted to R (Reverse) and your vehicle speed is below 8 km/h.
- The approaching vehicle is detected within about 1.5 m from the left or right of your vehicle.
- The speed of the vehicle approaching from the left or right is above 5 km/h.

A WARNING

Brake control ends when:

- The approaching vehicle is out of the detection range.
- The approaching vehicle passes behind your vehicle.
- The approaching vehicle does not drive toward your vehicle.
- The approaching vehicle speed slows down.
- You press the brake pedal sufficiently in response to the potential hazard detected by the function.

Stopping vehicle and ending brake control

After your vehicle is stopped following an Emergency Braking event, the "**Drive carefully**" warning message appears on the instrument cluster.

press the brake pedal immediately and check the surroundings.

- Braking control ends about 2 seconds after your vehicle is stopped.
- During Emergency Braking, braking control by Rear Cross-Traffic Collision-Avoidance Assist may be automatically cancelled when you press the brake pedal with sufficient force.

WARNING

Rear Cross-Traffic Collision-Avoidance Assist may not operate in all situations and cannot avoid all collisions.

To prevent serious injury or death:

- Only change the settings after parking the vehicle at a safe location.
- Always look over your shoulder for possible hazards and make sure it is safe to reverse.
- When another system's warning message appears or audible warning is heard, Rear Cross-Traffic Collision-Avoidance Assist may not warn you.
- You may not hear the audible warning of Rear Cross-Traffic Collision-Avoidance Assist if the surrounding environment is too noisy.
- During Rear Cross-Traffic Collision-Avoidance Assist operation, your vehicle may stop suddenly. Always wear your seatbelt, ensure ALL occupants have their seat belts fastened and secure loose objects that may become projectiles.
- Rear Cross-Traffic Collision-Avoidance
 Assist may not operate if you apply the
 brake pedal with sufficient force in
 response to the potential hazard
 detected by the system.
- Even if there is an issue with Rear Cross-Traffic Collision-Avoidance Assist, the vehicle's braking system operates normally.
- When Rear Cross-Traffic Collision-Avoidance Assist is operating, braking assist is automatically cancelled when you press the accelerator pedal with sufficient force.
- Rear Cross-Traffic Collision-Avoidance Assist may warn you late or may not warn you depending on the road and driving conditions.

- Control your vehicle at all times. It is the
 driver's responsibility to operate the
 vehicle in a safe manner. Do not solely
 rely on the Rear Cross-Traffic
 Collision-Avoidance Assist to avoid a
 collision. Rather, maintain a safe
 braking distance, and if needed, reduce
 your vehicle speed or press the brake
 pedal to reduce the driving speed or to
 stop your vehicle.
- Never attempt to test Rear Cross-Traffic Collision-Avoidance Assist by intentionally driving toward people, animals, objects, or other vehicles.

A WARNING

Braking is not assisted and only a warning is provided when:

- The ESC (Electronic Stability Control) warning light is on.
- ESC (Electronic Stability Control) is controlling the brake force to the wheels.

i Information

After shifting the gear to R (Reverse), Rear Cross-Traffic Collision-Avoidance Assist operates once for a left and a right side vehicle approach.

Rear Cross-Traffic Collision-Avoidance Assist malfunction and limitations

Rear Cross-Traffic Collision-Avoidance Assist malfunction



When Rear Cross-Traffic Collision-Avoidance Assist is not working properly, the "Check driver assistance system." warning message may appear for several seconds, and the A warning light may illuminate on the instrument cluster. We recommend that your vehicle be inspected by an authorised Genesis repairer.



When the outside rear-view mirror warning lights are not working properly, the "Check outside mirror warning icon" warning message may appear for several seconds, and the \(\triangle \) warning light may illuminate on the instrument cluster. If recommend that your vehicle be inspected by an authorised Genesis repairer.

Rear Cross-Traffic Collision-Avoidance Assist disabled



If the rear corner radar is blocked or covered, or when the rear bumper around the rear corner radar or sensor is covered by any foreign material, such as snow, rain, or dirt, or when a trailer or towbar mounted carrier is installed, the detecting performance may reduce and temporarily limit or disable Rear Cross-Traffic Collision-Avoidance Assist.

The "Driver assistance system limited. Radar blocked." warning message may appear on the instrument cluster.

The function operates normally when such foreign material, trailer, or carrier is removed, and the vehicle is restarted.

If Rear Cross-Traffic Collision-Avoidance Assist does not operate normally after anything covering or blocking the sensors is removed, we recommend that your vehicle be inspected by an authorised Genesis repairer.

A WARNING

- Rear Cross-Traffic Collision-Avoidance Assist may not operate properly even if there is no warning message or warning light on the instrument cluster.
- Rear Cross-Traffic Collision-Avoidance
 Assist may not operate properly in open
 areas where no objects are detected
 (for example, empty car pakr) or when
 the detecting sensors are blocked
 immediately after turning on the
 vehicle.

i Information

You can check this in the service message of the normal view mode of the instrument cluster display window.

Detecting sensors

Refer to the "Driver Assistance System sensors" section in this chapter for the location and the general precautions of the rear corner radar.

Limitations of Rear Cross-Traffic Collision-Avoidance Assist

Rear Cross-Traffic Collision-Avoidance Assist may not operate normally, or may operate unexpectedly if:

- Departing from where trees or grass are overgrown.
- · Departing from where roads are wet.
- Speed of the approaching vehicle is fast or slow.

Braking may not be assisted if:

- Your vehicle severely vibrates whilst driving over a bumpy road, uneven road, or concrete patch.
- You are driving on a slippery surface due to snow, water puddle, ice, etc.
- The tyre pressure is low or a tyre is damaged.
- The braking system is adjusted differently from the factory default settings.
- Remote Smart Parking Assist is operating (if equipped).

i Information

For more information on the limitations of the rear corner radar, refer to the "Driver Assistance System sensors" section in this chapter.

▲ WARNING

· Driving near a vehicle or structure



[A] Structure

Rear Cross-Traffic Collision-Avoidance Assist may be limited when driving near another vehicle or a structure, and it may not detect the vehicle approaching from the left or right. The system may not activate a warning or brake your vehicle.

Always check your surroundings whilst reversing.

When your vehicle is in a complex parking environment



Rear Cross-Traffic Collision-Avoidance Assist may detect vehicles that are parking or pulling out near your vehicle (for example, leaving beside your vehicle, parking or pulling out behind your vehicle, approaching your vehicle making a turn). If this occurs, the function may activate a warning and brake your vehicle even when not needed.

Always check your surroundings whilst reversing.


When your vehicle is parked diagonally



Rear Cross-Traffic Collision-Avoidance Assist may be limited when reversing diagonally, and may not detect any vehicle approaching from the left or right. If this occurs, the function may not activate a warning or brake your vehicle.

Always check your surroundings whilst reversing.


· When your vehicle is on or near a slope



Rear Cross-Traffic Collision-Avoidance Assist may be limited when your vehicle is on a uphill or downhill slope, and may not detect any vehicle approaching from the left or right. If this occurs, the function may activate a warning and brake your vehicle even when not needed.

Always check your surroundings whilst reversing.

Pulling into the parking space where there is a structure



[A] Structure [B] Wall

> Rear Cross-Traffic Collision-Avoidance Assist may detect vehicles passing by in front of you when reversing into a parking space with a wall or structure in the rear or side area. If this occurs, the function may activate a warning or brake your vehicle.

> Always check your surroundings whilst reversing.

· When your vehicle is parked rearward



Rear Cross-Traffic Collision-Avoidance Assist may detect vehicles passing by behind you when reversing into a parking space. If this occurs, the function may activate a warning and brake your vehicle even when not needed.

Always check your surroundings whilst reversing.

A WARNING

- Rear Cross-Traffic Collision-Avoidance Assist may not operate normally if there is interference from strong electromagnetic waves.
- Rear Cross-Traffic Collision-Avoidance Assist may not operate for 3 seconds immediately after your vehicle is started or when the rear corner radars are initialised.

Parking Distance Warning (PDW)



Parking Distance Warning uses the front ultrasonic sensors, side ultrasonic sensors (if equipped), and rear ultrasonic sensors to detect and warn you if an obstacle is within a certain distance when your vehicle is moving forward or in reverse at low speeds.

Parking Distance Warning settings

Warning methods



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Warning methods** from the Settings menu in the infotainment system to select the following:

 Warning volume: The warning volume can be adjusted. If you set the warning volume to '0', the warning volume does not turn off but sounds as '1'.

- If you change the warning methods, the warning methods of other Driver Assistance systems may change.
- When the vehicle is restarted, the warning methods maintains their previous setting.
- The setting menu may not be available for your vehicle depending on the vehicle features and specifications.

Parking Distance Warning Auto On

With the vehicle on, select Setup > Vehicle> Driver assistance > Parking safety > Auto PDW (Parking Distance Warning)) from the Settings menu in the infotainment system to use Parking Distance Warning Auto On.

i Information

When **Auto PDW (Parking Distance Warning)** is selected, the Parking Safety (P^m) button indicator stays on.

Parking Distance Warning operation

Parking Safety button



Press the Parking Safety (P™) button to turn on Parking Distance Warning. Press the button again to turn off the function.

 When Parking Distance Warning is off (button indicator light off), if you shift the gear to R (Reverse), Parking Distance Warning automatically turns on.

Forward Parking Distance Warning Forward Parking Distance Warning may

Forward Parking Distance Warning may operate if:

- You shift the gear from R (Reverse) to D (Drive).
- The gear is in D (Drive) and the Parking Safety button indicator light is on.
- An obstacle is detected whilst driving in D (Drive).

(Auto PDW (Parking Distance Warning)) must be selected from the Settings menu.)

- Forward Parking Distance Warning operates only when the vehicle's forward speed is below 10 km/h.
- If your vehicle speed is greater than 30 km/h, Forward Parking Distance
 Warning turns off (button indicator light off). Even when you slow down to less than 10 km/h again, Forward
 Parking Distance Warning does not turn on again.
- When the gear is shifted to R (Reverse), the front outer corner warning illuminates (within 60 cm).

Distance	Warning indicator		Warning
from object	Instrume nt cluster	Infotain ment	sound
60-120 cm		•	Buzzer beeps intermitte ntly (front inside)
30-60 cm		Î	Buzzer beeps more frequently
within 30 cm			Buzzer beeps continuou sly

 The corresponding indicator illuminates whenever each ultrasonic sensor detects a person or object in its sensing range and an audible warning sounds.

- When more than two objects are detected at the same time, an audible warning sounds for the object closest to your vehicle.
- When the distance from the vehicle to the object is above 60 cm, Forward Parking Distance Warning may not display the front outer corner warning in the instrument cluster.
- The shape of the indicator in the illustration may differ from the actual vehicle.

Side Parking Distance Warning

tif equipped

Side Parking Distance Warning may operate if:

- You shift the gear to R (Reverse).
- You shift the gear from R (Reverse) to D (Drive).
- The gear is in D (Drive) and the Parking Safety (P[®]) button indicator light is on.
- An obstacle is detected whilst driving in D (Drive).

(Auto PDW (Parking Distance Warning)) must be selected from the Settings menu.)

i Information

- Side Parking Distance Warning operates when the vehicle's forward speed is below 10 km/h.
- Side Parking Distance Warning operates only when Forward or Reverse Parking Distance Warning is on.

Distance	Warning indicator		Warning
from object	Instrume nt cluster	Infotainm ent	sound
60-120 cm	181		-
30-60 cm	181		-
within 30 cm	8		Buzzer beeps continuou sly

- The corresponding indicator illuminates whenever each ultrasonic sensor detects a person or object in its sensing range.
- If an object located within 30 cm from the side of the vehicle's path is detected, an audible warning sounds.
- If an object outside the side of the vehicle's path is detected, the warning indicator is appears.
- The shape of the indicator in the illustration may differ from the actual vehicle.

Reverse Parking Distance WarningReverse Parking Distance Warning may operate if:

• You shift the gear to R (Reverse).

Distance	Warning indicator		Warning
from object	Instrume nt cluster	Infotainm ent	sound
60-120 cm	B		Buzzer beeps intermitte ntly
30-60 cm	3		Buzzer beeps more frequently
within 30 cm			Buzzer beeps continuou sly

- The corresponding indicator illuminates whenever each ultrasonic sensor detects a person or object in its sensing range and an audible warning sounds.
- When more than two objects are detected at the same time, an audible warning sounds for the object closest to your vehicle.
- The shape of the indicator in the illustration may differ from the actual vehicle.

Parking Distance Warning malfunction and limitations

Parking Distance Warning malfunction

After starting the vehicle, a beep sounds when the gear is shifted to R (Reverse) to indicate Parking Distance Warning is operating normally.

If one or more of the following occurs, check whether the ultrasonic sensor is damaged or blocked.

- The audible warning does not sound.
- The buzzer sounds intermittently.
- The "Check driver assistance system." warning message appears on the instrument cluster.
- If it still does not work properly, we recommend that your vehicle be inspected by an authorised Genesis repairer.

Parking Distance Warning disabled



If the ultrasonic sensor is blocked or covered by any foreign material, such as snow, rain, or dirt, the detecting performance may reduce and temporarily limit or disable Parking Distance Warning.

The "Driver assistance system limited. Ultrasonic sensor blocked." warning message may appear on the instrument cluster.

The function operates normally when such foreign material or carrier is removed, and the vehicle is restarted.

If the Parking Distance Warning does not operate normally after anything covering or blocking the sensors is removed, we recommend that your vehicle be inspected by an authorised Genesis repairer.



- When the Parking Distance Warning is operating, if the function is not working normally or the ultrasonic sensor is blocked, the ∆ warning light may illuminate in the direction of the corresponding sensor.
- You can check this in the service message of the normal view mode of the instrument cluster display window.

Detecting sensors

Refer to the "Driver Assistance System sensors" section in this chapter for the location and the general precautions of the front, side (if equipped), and rear ultrasonic sensors.

Limitations of Parking Distance Warning

- Parking Distance Warning may not operate normally when:
 - Any sensor is covered or blocked with snow, water, or dirt. Parking Distance Warning operates normally again when unblocked or uncovered.
 - The weather is very hot or cold.
 - The sensor or sensor assembly is disassembled
 - The surface of the sensor has been damaged or scratched with a sharp object.
 - The sensors or its surrounding area is directly sprayed with high pressure washer
 - Objects generating excessive noise, such as vehicle horns, loud motorcycle engines, or truck air brakes, are near your vehicle.
- Parking Distance Warning may malfunction when:
 - Heavy rain or water spray is present.
 - Water flows on the surface of the sensor.
 - The sensor is covered with snow or ice.
 - An ultrasonic sensor with similar frequency is near your vehicle.
 - Driving on uneven road, gravel roads, or bushes.
 - Your vehicle's bumper height or ultrasonic sensor installation has been modified.
 - Equipment, licence plate, or accessories are attached near the ultrasonic sensors.

- The following objects may not be detected:
 - Slim objects such as ropes, chains, or small poles.
 - Narrow objects such as corners of a square column.
 - Objects that tend to absorb sensor frequency, such as clothes, spongy material, or snow.
 - Objects less than 100 cm high and less than 14 cm wide.
 - Pedestrians, animals, or objects that are very close to the ultrasonic sensors.
 - An object in the side area between the front side ultrasonic sensor and the rear side ultrasonic sensor or an object approaching the side area.

A WARNING

- The operation of Parking Distance Warning can be affected by several factors (including environmental conditions). Parking Distance Warning is a supplemental function only.
- Your new vehicle warranty does not cover any accidents or damage to the vehicle due to the malfunction of Parking Distance Warning.
- Always turn your head and look for potential hazards around your vehicle when parking.
- To prevent serious injury or death, pay close attention when driving near objects, pedestrians, and especially children. Some objects may not be detected by ultrasonic sensors, due to the object's distance, size, or material.

Forward/Side/Reverse Parking Collision-Avoidance Assist (PCA)

tif equipped

Forward/Side/Reverse Parking Collision-Avoidance Assist helps detect pedestrians or objects when driving at low speed. The function may warn you and assist you with braking to help reduce the possibility of a collision.

A CAUTION

When a trailer is connected to your vehicle, Parking Collision-Avoidance Assist automatically turns off. In this case, Parking Collision-Avoidance Assist is not functional. Always have your eyes on the road. (if equipped with genuine Genesis parts)

Parking Collision-Avoidance Assist settings

Warning methods



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Warning methods** from the Settings menu in the infotainment system to select the following:

- Warning volume: The warning volume can be adjusted. If you set the warning volume to '0', the warning volume does not turn off but sounds as '1'.
- Haptic warning: The steering wheel vibration can be set.

- If you change the warning methods, the warning methods of other Driver Assistance systems may change.
- If you set the warning volume to '0' when the haptic warning is off, the haptic warning turns on.
- When the vehicle is restarted, the warning methods maintains their previous setting.
- The setting menu may not be available for your vehicle depending on the vehicle features and specifications.

Parking Safety

With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Parking safety** from the Settings menu in the infotainment system to select the following:

- If Forward/Side safety is selected, Parking Collision-Avoidance Assist warns you and assists braking when a collision with a pedestrian or object is imminent from the front or side.
- If Backward safety is selected, Parking Collision-Avoidance Assist warns you and assists braking when a collision with a pedestrian or object is imminent from behind.

i Information

Forward/Side safety can be selected only when Backward safety is selected. When the vehicle is restarted and Backward safety is selected, Forward/Side safety maintains the previous setting.

Parking Collision-Avoidance Assist operation

Turning Parking Collision Avoidance Assist On/Off



Press and hold the Parking Safety (P***) button more than 2 seconds, to turn the Parking Collision-Avoidance Assist on or off.

Operating conditions

If Parking Collision-Avoidance Assist detects a collision risk with a pedestrian or object, Parking Collision-Avoidance Assist warns you with an audible warning and warning message on the instrument cluster. When Surround View Monitor is operating, a warning may appear on the infotainment system screen.

If Parking Collision-Avoidance Assist detects an imminent collision with a pedestrian or object behind your vehicle, Parking Collision-Avoidance Assist may assist braking.

If **Backward safety** is selected from the settings menu, Parking Collision-Avoidance Assist is in ready status when all of the following conditions are met:

Rear safety

- · The boot and door are closed.
- The EPB (Electronic Parking Brake) is released.
- The gear is shifted to R (Reverse).
- Vehicle speed is below 10 km/h (for detecting pedestrians).
- Vehicle speed is below 4 km/h (for detecting objects).
- Parking Collision-Avoidance Assist components such as the rear view camera and the rear ultrasonic sensors are in normal conditions.

Front/Side safety

- · The boot and door are closed.
- The Electronic Parking Brake (EPB) is released.
- The gear is shifted to R (Reverse) or D (Drive).
- Vehicle speed is below 4 km/h (for detecting pedestrians and objects).
- Parking Collision-Avoidance Assist components such as the wide view cameras and the ultrasonic sensors are in normal conditions.

When Parking Collision-Avoidance Assist activates, a line appears near the vehicle image in the instrument cluster.

- Rear Safety: Appears behind the vehicle image.
- Front/Side Safety: Appears in front or side of the vehicle image.



i Information

Parking Collision-Avoidance Assist operates only once after shifting the gear to R (Reverse) or D (Drive). To reactivate Parking Collision-Avoidance Assist, shift the gear from another gear to R (Reverse) or D (Drive).

Off conditions

Rear safety

If Parking Collision-Avoidance Assist detects an imminent collision with a pedestrian or object behind your vehicle, Parking Collision-Avoidance Assist may assist braking. Immediately press the brake pedal and check vehicle surroundings because the brake assist ends within 5 minutes.

Braking control ends when:

- You shift the gear to P (Park) or D (Drive).
- You press the brake pedal with sufficient force.

When Parking Collision-Avoidance Assist is activated whilst reversing, braking control is released after 5 minutes and the EPB (Electronic Parking Brake) is applied.

Front/Side safety

If Parking Collision-Avoidance Assist detects an imminent collision with a pedestrian or object behind your vehicle, Parking Collision-Avoidance Assist may assist braking. Immediately press the brake pedal and check vehicle surroundings because the brake assist ends within 2 seconds when in D (Drive) or 5 minutes when in R (Reverse).

Braking control ends when:

- You shift the gear to P (Park) or R (Reverse).
- You press the brake pedal with sufficient force.

Parking Collision-Avoidance Assist malfunction and limitations

Parking Collision-Avoidance Assist malfunction



When Parking Collision-Avoidance Assist or other related functions do not work properly, the "Check driver assistance system." warning message may appear on the instrument cluster, and Parking Collision-Avoidance Assist turns off automatically. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Parking Collision-Avoidance Assist disabled



The "Driver assistance system limited. Camera obscured." or "Driver assistance system limited. Ultrasonic sensor blocked." warning message may appear on the instrument cluster if:

- The wide view camera(s) or ultrasonic sensor(s) are covered or blocked with foreign material, such as snow or rain, etc.
- There is inclement weather, such as heavy snow, heavy rain, etc.

Parking Collision-Avoidance Assist may turn off or may not operate properly. Check the wide view camera(s) and ultrasonic sensor(s) are clean.

i Information



When the Parking Collision-Avoidance Assist Warning is operating, if the function is not working normally or the ultrasonic sensor is blocked, the \(\Delta\) warning light may illuminate in the direction of the corresponding sensor.

Limitations of Parking Collision-Avoidance Assist

Parking Collision-Avoidance Assist may not assist braking or warn you even if there are pedestrians or objects if:

- · Problems with vehicle
 - Any non-factory equipment or accessory is installed on your vehicle.
 - Your vehicle has been damaged due to an accident or other causes.
 - Bumper height or ultrasonic sensor installation locations have been modified.
 - Wide view camera(s) or ultrasonic sensor(s) are damaged.
 - Wide view camera(s) or the ultrasonic sensor(s) is covered or blocked with snow, water, or dirt, etc.
 - Wide view camera(s) is obscured by a light source or by inclement weather, such as heavy rain, thick fog, snow, etc.

- · Problems with the surroundings
 - The surroundings are very bright or dark.
 - The weather is very hot or cold.
 - The wind is either greater than 20 km/h or blowing perpendicular to the rear bumper.
 - Objects generating excessive noise, such as vehicle horns, loud motorcycle vehicles or truck air brakes, are near your vehicle.
 - An ultrasonic sensor with similar frequency is near your vehicle.
 - The road is slippery or inclined.
- · Problems with pedestrian or object
 - The pedestrian is in a state that is difficult detect
 - There is elevation difference between your vehicle and the pedestrian.
 - The pedestrian blends into the background when seen from the front view camera.
 - The pedestrian is near the front or rear edge of the vehicle.
 - The pedestrian is not standing upright.
 - The pedestrian is very short or tall.
 - The pedestrian is wearing clothing that does not reflect ultrasonic waves well.
 - Size, thickness, height, or shape of the object does not reflect ultrasonic waves well (e.g., pole, bush, kerbs, carts, edge of a wall, etc.).
 - The pedestrian or object is moving.
 - The pedestrian or object is very close to your vehicle.
 - There is a wall is behind the pedestrian or object.
 - The object is not located at the front or rear centre of your vehicle.

- The object is not parallel to the front or rear bumper.
- The sensors cannot detect pedestrians or objects.
- · Problems with driving condition
 - You drive the vehicle immediately after shifting to R (Reverse) or D (Drive).
 - You accelerate your vehicle or drive in circles.
 - You drive your vehicle immediately after starting the vehicle.

WARNING

Parking Collision-Avoidance Assist may not operate in all situations and cannot avoid all collisions.

To prevent serious injury or death:

- Always pay attention to road and traffic conditions whilst driving. Brake as needed to avoid collisions. Do not solely rely on Parking Collision-Avoidance Assist.
- Always look around your vehicle to make sure there are no pedestrians or objects before driving.
- The performance of Parking Collision-Avoidance Assist may differ under certain conditions. If your vehicle speed is greater than 4 km/h, Parking Collision-Avoidance Assist provides collision avoidance assist only when pedestrians are detected.
- Some objects may not be detected by the ultrasonic sensors due to the object's distance, size, or material.

A CAUTION

- Noise may be heard when sudden braking occurs to avoid a collision.
- When another system's warning message appears or audible warning is heard, Parking Collision-Avoidance Assist may not warn you.
- You may not hear the audible warning of Parking Collision-Avoidance Assist if the surrounding environment is too noisy.
- Parking Collision-Avoidance Assist may not work properly if the bumper has been damaged, replaced, or repaired.
- Parking Collision-Avoidance Assist may not operate normally if there is interference from strong electromagnetic waves.
- The brake control may not operate properly depending on the status of ESC (Electronic Stability Control).

There is only a warning when:

- The ESC (Electronic Stability Control) warning light is on.
- ESC (Electronic Stability Control) is controlling the brake force to the wheels.
- Check the brake fluid and brake pad condition periodically. Depending on the condition, brake operation performance may reduce.

i Information

Parking Collision-Avoidance Assist can detect a pedestrian or an object when:

- A pedestrian is standing near the vehicle.
- A large obstacle, such as a vehicle, is parked in the near your vehicle.

Remote Smart Parking Assist 2 (RSPA 2)

tif equipped

Remote Smart Parking Assist uses vehicle sensors to help you park and exit parking spaces remotely from outside the vehicle by controlling the steering wheel, vehicle speed, and gearshifts.

opeca, and gears mito.		
Function	Description	
	Remotely moving forward or rearward	
Remote Operation	0000	
	Perpendicular reverse parking	
	Diagonal reverse parking	
Smart Parking or Remote Parking		
	Parallel reverse parking	

Function	Description		
	Parallel forward exit		
Smart Exit			

- Remote Parking and Remote Operation function may be operated from outside the vehicle using the smart key.
- Smart Parking and Remote Parking function may be operated from inside the vehicle.
- Smart Parking and Remote Parking function helps you with perpendicular reverse parking, diagonal reverse parking, and parallel reverse parking.
- Smart Exit function helps you with parallel forward exit.
- When Remote Smart Parking Assist operates, Parking Distance Warning and Surround View Monitor also operates. For more information, refer to the "Parking Distance Warning (PDW)" and "Surround View Monitor (SVM)" sections in this chapter.
- Remote Smart Parking Assist helps parking by detecting the parking lines with the wide view camera.

Remote Smart Parking Assist settings

A CAUTION

When a trailer is connected to your vehicle, Remote Smart Parking Assist automatically turns off. In this case, Remote Smart Parking Assist is not functional. Always have your eyes on the road. (if equipped with genuine Genesis parts)

Warning methods



With the vehicle on, select **Setup** > **Vehicle** > **Driver assistance** > **Warning methods** from the Settings menu in the infotainment system to select the following:

 Warning volume: The warning volume can be adjusted. If you set the warning volume to '0', the warning volume does not turn off but sounds as '1'.

i Information

- If you change the warning methods, the warning methods of other Driver Assistance systems may change.
- When the vehicle is restarted, the warning methods maintains their previous setting.
- The setting menu may not be available for your vehicle depending on the vehicle features and specifications.

Remote Smart Parking Assist operation

Remote Smart Parking Assist button



Location	Name	Symbol	Description
Inside vehicle	Parking/ View button	ŗ	 Press and hold the Parking/View button to turn on Remote Smart Parking Assist. Also, Forward/Reverse Parking Distance warning automatically turns on. However, functions may differ depending on the situations. Refer to each function's description for more details in the following pages. Press and hold the Parking/View button whilst Smart Parking or Smart Exit function is on to operate the function.
	Remote Start button	HOLD	 Press the Remote Start button after the door is locked with the vehicle off to start the vehicle remotely. Press the Remote Start button whilst Remote Parking or Remote Operation function is operating to end function operation.
Smart key	Forward button	⊕† P	When using Remote Parking function, regardless of which direction the button is pressed, parking is supported whilst the button is pressed.
	Rearward button	₽	When using the Remote Operation function, the vehicle moves in the direction of the button whilst the button is pressed.

Remote Operation

Operating order

Getting ready to remotely move forward and rearward

There are two ways to operate the Remote Operation function.


Method (1): Using the function with vehicle off

1. Within a certain range from the vehicle press the door lock (⊕) button on the smart key and lock all doors.



2. Press and hold the Remote Start (button within 4 seconds until the vehicle starts.

For more information on remotely starting the vehicle, refer to the "Remote start" section in chapter 6.



Method (2): Using the function with vehicle on.

- Park the vehicle in front of the space where you want to use the Remote Operation function, and shift the gear to P (Park) (1).
- 2. Press and hold the Parking/View (戶) button (2) to turn on Smart Parking Assist.
 - The "Under Remote Control" message appears on the infotainment system screen.
- 3. Get out of the vehicle with the smart key and close all doors and boot.

i Information

- Agree must be selected on the infotainment system and the infotainment system has to operate properly to use the Remote Operation function.
- Method (2) can be used after the vehicle has been driven above 5 km/h.
- If the function is turned on again after perpendicular parking is completed by Remote Smart Parking Assist, Remote Operation function can be used with Method (2).
- Check that all smart keys are outside the vehicle when using Remote Operation function. If a smart key is inside the vehicle, the Remote Operation function does not work.

2. Remotely moving forward and rearward



[A] Forward [B] Rearward

- Press and hold the Forward (🗓) or Rearward (🖟) button on the smart key.
 - Remote Smart Parking Assist automatically controls the steering wheel, vehicle speed, and gearshift.
 Your vehicle moves in the direction of the button pressed.
 - If you do not hold down the Forward ((B)) or Rearward (B) button, your vehicle stops and function control pauses. The function starts operating again when the button is pressed and held again.
- When your vehicle reaches the target location, release the smart key Forward (⊕) or Rearward (⊕) button.
- Get in your vehicle with the smart key or press the Remote Start () button on the smart key from outside the vehicle.
 - A message appears on the infotainment system screen informing you that remotely moving your vehicle forward or rearward has been completed. The gear is shifted to P (Park) and the EPB is applied.
 - The vehicle remains on if you are in the vehicle. The vehicle turns off if you press the Remote Start (♠) button.

i Information

- Check that all smart keys are outside your vehicle before using the Remote Operation function.
- Remote Operation function operates only when the smart key is within 4 m from your vehicle. If there is no vehicle movement even when the Forward or Rearward button is pressed on the smart key, check the distance from the vehicle and press the button again.
- The detection range of the smart key may differ depending on radio waves in the area such as transmission towers or broadcast stations.
- When remotely moving forward using Method (1), it is intended to be a departure scenario, and your vehicle moves 4 m to check for pedestrians, animals, or objects around your vehicle. Your vehicle makes small steering changes when driving forward.
- When remotely moving forward using Method (2), it is recognised as a parking situation, and immediately controls the steering wheel depending on the condition ahead to assist with entering the parking space and aligning your vehicle. The function performance may be reduced depending on the pedestrians, animals, and objects near your vehicle or other factors.
- When moving remotely rearward, both Method (1) and (2) align the steering wheel and then only move your vehicle in a straight path.

WARNING

- When using Remote Operation function, make sure all passengers have exited your vehicle and are standing in a safe location away from your vehicle.
- If your vehicle's battery is discharged or Remote Smart Parking Assist malfunctions when parked in a narrow parking space, the Remote Operation function does not operate. Always park your vehicle in a space wide enough for you to get in or out of your vehicle.
- Depending on the parking space or the movement of another vehicle after you have parked, you may not be able to exit from the space using the Remote Operation function.
- Before leaving your vehicle, close the windows. Make sure the vehicle is off before locking the doors.

Remote Operation function operation status

Operation status	Smart key LED
Under control	Green LED continuously blinks
Pause	Red LED continuously blinks
Off	Red LED illuminates for 4 seconds and then turns off
Complete	Green LED illuminates for 4 seconds and then turns off

i Information

If the smart key is not within the operating range from the vehicle (about 4 m), the smart key LED does not illuminate or blink. Use the smart key within the operating range.

How to turn off Remote Operation function whilst operating

- Press the Parking/View (CD) button whilst the infotainment system guides you using method 2.
- Shift the gear except to P (Park) whilst the infotainment system guides you using method 2.
- Press the Parking Safety (P™≜) button or select Cancel on the infotainment system.
- Press the Remote Start (D) button on the smart key whilst the vehicle is being controlled by Remote Operation function. Remote Operation function and the vehicle turn off.
- Get into your vehicle with the smart key. Remote Operation function turns off and the vehicle remains on

The function pauses in the following conditions when:

- There is a pedestrian, animal, or object detected in the direction your vehicle is moving.
- The door or boot is open.
- The Forward (🖹) or Rearward (🖺) button is not continuously pressed.
- Multiple buttons are pressed simultaneously on a smart key.
- The smart key is not operated within 4 m from your vehicle.
- A button on another smart key is pressed in addition to the operating smart key.

- Parking Collision-Avoidance Assist or Rear Cross-Traffic Collision-Avoidance Assist operates when your vehicle is backing whilst remotely controlled.
- Your vehicle moves about 7 m whilst the smart key button is pressed with Remote Operation function (maximum travel distance per button press).

The function cancels in the following conditions when:

- · The steering wheel is turned.
- The gear is shifted whilst your vehicle is moving.
- EPB (Electronic Parking Brake) is operating whilst the vehicle is moving.
- The bonnet is opened.
- The brake pedal or accelerator pedal is pressed when all the doors are closed.
- The smart key is outside your vehicle when the brake pedal is pressed and the driver's door is open.
- · Rapid acceleration occurs.
- · Vehicle skid occurs.
- An obstacle prevents the wheel from moving.
- About 3 minutes and 50 seconds have passed since Remote Operation function was initiated.
- The slope of the road exceeds the operational range.
- The function is paused for more than 1 minute.
- The total travel distance of your vehicle has exceeded about 14 m after Remote Operation function is operated.
- The steering wheel, gearshift, braking, and drive controls are not working properly.
- There is a problem with the smart key or the smart key battery is low.

- ABS, TCS or ESC system operates due to slippery road conditions.
- Theft Alarm System sounds.
- When Remote Operation function is cancelled, your vehicle automatically stops, shifts the gear to P (Park), and applies EPB (Electronic Parking Brake).
- The charging door is open.

Smart Parking, Remote Parking

Operating order

Parking function operates in the following order:

- 1. Getting ready for parking
- 2. Searching for parking space
- 3. Select parking type and operating mode
- 4. Smart Parking
- 5. Remote Parking
 - Parking function includes Smart Parking and Remote Parking.

1. Getting ready for parking



- With the vehicle on, press the brake pedal and shift the gear to D (Drive) or N (Neutral).
- Press and hold the Parking/View (도) button to turn on Remote Smart Parking Assist.

i Information

- Agree must be selected on the infotainment system screen and the infotainment system has to operate properly to use Parking function.
- If you drive above 5 km/h with the vehicle on, you may use the Parking function with the gear shifted to N (Neutral).

2. Searching for parking space




- Slowly drive forward maintaining the distance of about 100 cm from the parked vehicles.
 - When searching for a parking space is complete, a message appears informing you that searching for a parking space is complete.
 - Select Parking Type appears on the infotainment system screen and the selected parking space appears on Top View screen of Surround View Monitor.

i Information

- Remote Smart Parking Assist searches for parking lines or parking spaces that are next to parked vehicles, or parking spaces with parked vehicles in front or rear.
- Whilst searching for a parking space, when the vehicle speed is above 20 km/h, a message appears on the infotainment system screen informing you to slow down. When vehicle speed is above 30 km/h, Parking function turns off.
- Searching for a parking space is completed when there is enough space to move the vehicle in addition to the parking space.
- Even if you are informed that searching for a parking space is complete, Remote Smart Parking Assist may search for a parking space again depending on surroundings.

i Information



- If the distance is below 0.5 m or over 1.5 m, Remote Smart Parking Assist may not search for a parking space.
- If you do not maintain a certain distance from the parked vehicles, the performance to search for a parking space may reduce.
- Due to abnormal performance of the ultrasonic sensor or the influence of the surroundings, Parking function may not be able to search for a parking space even if there is a parking space, or may search for a space that is not suitable for parking.
- If the parking space is on a incline or if your vehicle is not straight when searching for a parking space, the parking type displayed may be different from the actual parking type which should be selected. If this occurs, do not select the parking type, and search for another parking space.

3. Select parking type and operating mode



(1) Parking type - Perpendicular reverse (Left/Right), Parallel reverse (Left/Right) Diagonal reverse (Left/Right)

With the vehicle stopped by pressing the brake pedal, select parking type.

i Information

- If you continue to drive without stopping after the parking type selection screen appears, Remote Smart Parking Assist returns to the previous stage and searches for a parking space.
- If the Parking function is cancelled unintentionally by pressing the Parking/View (上) button before the parking type is selected, you can return to the parking type selection stage by pressing and holding the button again whilst the vehicle is stopped.

A CAUTION

Before selecting the Parking type, you should check whether the parking space is suitable.

If the searched parking space is narrow or unsuitable for parking, do not select the Parking type and move the vehicle to search for another parking space.




(2) Operating mode - Remote Parking, Smart Parking

After selecting a parking type, the infotainment system screen guides you with Remote Parking function and Smart Parking function. Follow the instructions to operate Remote Smart Parking Assist.

i Information

- Operating instructions are displayed on the screen for each desired function you select.
- Do not take your foot off the brake pedal during the Parking function guide. When the vehicle moves, Remote Smart Parking Assist turns off.
- If Remote Smart Parking Assist cannot activate Remote Parking function, only the Smart Parking guide is displayed on the infotainment system screen.

4. Smart Parking





- Press the Parking/View (ED) button
 when the vehicle is stopped by pressing
 the brake pedal. When the brake pedal
 is released, Remote Smart Parking
 Assist automatically controls the
 steering wheel, vehicle speed, and
 gearshift.
 - Whilst Smart Parking function is operating, if you do not hold down the Parking/View button, the vehicle stops and function control pauses. The function starts operating again when the Parking/View button is pressed and held again.
 - When the vehicle reaches the target parking position, a message appears on the infotainment system screen informing you that parking of your vehicle has been completed.

i Information

- Smart Parking function does not operate if a door is open or the seat belt is not fastened.
- The parking location indicator is displayed on the Surround View Monitor screen and is displayed until the vehicle enters the parking space for the first time by the Smart Parking function.
- Vehicle speed can be adjusted by pressing the brake pedal whilst Smart Parking function is operating. The vehicle does not accelerate even when the accelerator pedal is pressed.
- Depending on parking environments, if the vehicle is stopped by a stopper, parking may be completed.
- If you need to change the vehicle's position or location, manually complete parking your vehicle.

5. Remote Parking



- Shift the gear to P (Park), get out of your vehicle with the smart key and close all doors.
- Press and hold the Forward (🖹) or Rearward (🖺) button on the smart key.
 - Remote Smart Parking Assist automatically controls the steering wheel, vehicle speed, and gearshift. Your vehicle moves in the direction of the button pressed.
 - If you do not hold down the Forward ((3)) or Rearward (3) button, your vehicle stops and function control pauses. The function starts operating again when the button is pressed and held again.
- When your vehicle reaches the target location, release the smart key Forward (♣) or Rearward (♣) button.
 - A message appears informing you that parking your vehicle is complete on the infotainment system screen.
 The gear is shifted to P (Park) and the EPB is applied.

i Information

- Check that all smart keys are outside your vehicle before using the Remote Parking function.
- Remote Parking function only operates when the smart key is within 4 m from your vehicle. If there is no vehicle movement even when the Remote Forward or Rearward button is pressed on the smart key, check the distance to the vehicle and press the button again.
- The detection range of the smart key may differ depending on radio waves in the area such as transmission towers or broadcast stations.
- The parking location indicator is displayed on the Surround View Monitor screen and is displayed until the vehicle enters the parking space for the first time by the Remote Parking function.
- Depending on parking environments, if the vehicle is stopped by a stopper, parking may be completed.
- If you need to change the vehicle's position or location, manually complete parking your vehicle.

WARNING

- When using Remote Smart Parking function, make sure all passengers have exited your vehicle and are standing in a safe location away from your vehicle.
- Before leaving your vehicle, close the windows. Make sure the vehicle is off before locking the doors.

Parking function operation status

• Smart Parking function

Operation status	Turn signal	
Under control	The turn signal of the parking direction blinks until the first reverse is complete.	

· Remote Parking function

Operation status	Smart key LED	Turn signal
Under control	Green LED continuously blinks	The turn signal of the parking direction blinks until the first reverse is complete.
Pause	Red LED continuously blinks	-
Off	Red LED illuminates for 4 seconds and then turns off	-
Complete	Green LED illuminates for 4 seconds and then turns off	-

i Information

If the smart key is not within the operating range from the vehicle (about 4 m), the smart key LED does not illuminate or blink. Use the smart key within the operating range.

How to turn off Parking function whilst operating

- Press the Parking/View (知) button in the following stage:
 - Searching for parking space
 - Select parking type
- Shift the gear to R (Reverse) in the following stage:
 - Searching for parking space
 - Select parking type
 - Select operating mode
- Press the Parking Safety (P^m<u>A</u>) button or select Cancel on the infotainment system screen to turn off Parking function.
- Whilst Smart Parking function is operating:
 - If the vehicle is stopped by pressing the brake pedal, and the gear is shifted, Parking function turns off. At this time, EPB (Electronic Parking Brake) is not applied.
- Whilst Remote Parking function is operating:
 - Press the Remote Start (♠) button on the smart key. Parking function turns off.
 - Get into the vehicle with the smart key. Parking function turns off. At this time, the vehicle remains on.

The function pauses in the following conditions when:

- Smart Parking
 - There is a pedestrian, animal, or object in the direction your vehicle is moving.
 - The door or boot is open.
 - The driver's seat belt is not fastened.
 - Parking Collision-Avoidance Assist or Rear-Cross Traffic Collision-Avoidance Assist operates when your vehicle is reversing whilst remotely controlled.
 - The Parking/View (戶) button is not continuously pressed.
 - The vehicle is stopped by pressing the brake pedal.
- Remote Parking
 - There is a pedestrian, animal, or object in the direction your vehicle is moving.
 - The door or boot is open.
 - The Forward (1) or Rearward (1) button is not continuously pressed.
 - Multiple buttons are pressed simultaneously on a smart key.
 - The smart key is not operated within 4 m from your vehicle.
 - A button on another smart key is pressed in addition to the operating smart key.
 - Parking Collision-Avoidance Assist or Rear-Cross Traffic Collision-Avoidance Assist operates when your vehicle is backing whilst remotely controlled.

When Parking function is paused, the vehicle will automatically stop. If the condition that made the function pause disappears, the function may operate again.

The function cancels in the following conditions when:

- · Smart Parking
 - The steering wheel is turned.
 - The gear is shifted whilst your vehicle is moving.
 - EPB (Electronic Parking Brake) is operating whilst your vehicle is moving.
 - The bonnet is open.
 - The driver's door is open with the seat belt unfastened.
 - Rapid acceleration occurs.
 - Vehicle skid occurs.
 - An obstacle prevents the wheel from moving.
 - There are pedestrians, animals, or objects at the front and rear of the vehicle at the same time.
 - About 3 minutes and 50 seconds have passed since Smart Parking function was initiated.
 - The slope of the road exceeds the operational range.
 - The function is paused for more than 1 minute.
 - The steering wheel, gearshift, braking, and drive controls are not working properly.
 - ABS, TCS, or ESC system operates due to slippery road conditions.
 - The charging door is open.

When Smart Parking function is cancelled, your vehicle automatically stops, shifts the gear to P (Park), and applies EPB (Electronic Parking Brake).

- · Remote Parking
 - The steering wheel is turned.
 - The gear is shifted.
 - EPB (Electronic Parking Brake) is operating whilst your vehicle is moving.
 - The bonnet is open.

- The brake pedal or accelerator pedal is pressed when all the doors are closed.
- The smart key is outside the vehicle when the brake pedal is pressed whilst the driver's door is open.
- Rapid acceleration occurs.
- Vehicle skid occurs.
- An obstacle prevents the wheel from moving.
- There are pedestrians, animals, or objects at the front and rear of the vehicle at the same time.
- About 3 minutes and 50 seconds have passed since Remote Parking function was initiated.
- The slope of the road exceeds the operational range.
- The function is paused for more than 1 minute
- The steering wheel, gearshift, braking, and drive controls are not working properly.
- There is a problem with the smart key or the smart key battery is low.
- ABS, TCS, or ESC system operates due to slippery road conditions.
- Theft Alarm System sounds.
- The charging door is open.

When Remote Parking function is cancelled, your vehicle automatically stops, shifts the gear to P (Park), and applies EPB (Electronic Parking Brake).

Smart Exit

Operating order

Smart Exit function operates in the following order:

- 1. Getting ready for exit
- 2. Checking space
- 3. Select exit direction
- 4. Smart Exit

1. Getting ready for exit

- With the vehicle on, press the brake pedal and shift the gear to P (Park) or N (Neutral).
- 2. Press and hold the Parking/View (도) button to turn on Remote Smart Parking Assist.



i Information

- Agree must be selected on the infotainment system screen and the infotainment system has to operate properly to use Smart Exit function.
- Drive below 5 km/h with the vehicle on and shift the gear to N (Neutral), Smart Exit function can be used.
- If the function is turned on again after parallel parking is completed by Remote Smart Parking Assist, Smart Exit function can be used.

2. Checking space



- When the vehicle is stopped by pressing the brake pedal, the vehicle sensors detect the distance from nearby objects and check for space to exit.
 - When checking for space is complete, a message appears informing you that searching for a parking space is complete.

▲ WARNING

- Whilst checking for space, if there is a collision risk with pedestrian, animal, or object in the direction of vehicle exit, for your safety, Smart Exit function can be turned off.
- Even if the parking space check is completed, objects in the blind spot area cannot be detected by the sensors. The driver must directly check the blind spot area and continue using the function.

i Information

Due to abnormal performance of the ultrasonic sensor or the influence of the surroundings, Smart Exit function may not search for a exit space even if there is a exit space, or may search for a space that is not suitable for exiting.

3. Select exit direction



- With the vehicle stopped by pressing the brake pedal, the infotainment system screen displays the possible directions for parallel exit.
- 2. Touch the infotainment system screen or use the central controller to select the desired exit direction.

A CAUTION

- Before selecting the Exit Direction, the driver should check whether the space for exit is suitable.
- If the searched exit space by Remote Smart Parking Assist is narrow or unsuitable (surrounding vehicles are parked vertically, etc.), do not use the Smart Exit function.

4. Smart Exit



- 1. Press the Parking/View (도) button when the vehicle is stopped by pressing the brake pedal. When the brake pedal is released, Remote Smart Parking Assist automatically controls the steering wheel, vehicle speed, and gearshift.
 - Whilst Smart Exit function is operating, if you do not hold down the Parking/View button, the vehicle stops and function control pauses. The function starts operating again when the Parking/View button is pressed and held again.
 - When the vehicle reaches the target exit location, a message appears on the infotainment system screen informing you that parking of your vehicle has been completed.

i Information

- Smart Exit function does not operate if a door is open or the seat belt is not fastened.
- Vehicle speed can be adjusted by pressing the brake pedal whilst Smart Exit function is operating. The vehicle does not accelerate even when the accelerator pedal is pressed.
- If exit is completed whilst pressing the brake pedal, Smart Exit function is completed with the gear in D (Drive).
- If exit is completed whilst pressing the accelerator pedal, you must take your foot off the accelerator pedal once for the accelerator pedal to operate.
- If there is no vehicle operation such as pressing the brake pedal or accelerator pedal within 4 seconds after exit is complete, the vehicle automatically shifts to P (Park) and applies EPB (Electronic Parking Brake).
- After Exit function is complete, always check the surroundings before driving.

Smart Exit operation status

Operation status	Turn signal
Under control	The turn signal of the exit direction blinks until the exit is complete or Smart Exit is cancelled.

How to turn off Smart function whilst operating

- Press the Parking/View (知) button in the following stage:
 - Checking space
 - Select exit direction
- Shift the gear to R (Reverse) in the following stage:
 - Checking space
 - Select exit direction
- Press the Parking Safety (P^m<u>A</u>) button or select Cancel on the infotainment system screen to turn off Exit function.
- Whilst Smart Exit function is operating, if the vehicle is stopped by pressing the brake pedal, and the gear is shifted, Exiting function turns off. At this time, EPB (Electronic Parking Brake) is not applied.

The function pauses in the following conditions when:

- There is a pedestrian, animal, or object in the direction your vehicle is moving.
- · A door or boot is open.
- The driver's seat belt is not fastened.
- Parking Collision-Avoidance Assist or Rear-Cross Traffic Collision-Avoidance Assist operates when your vehicle is backing whilst remotely controlled.
- The Parking/View (도) button is not continuously pressed.
- The vehicle is stopped by pressing the brake pedal.

When Exit function is paused, the vehicle will stop. If the condition that made the function pause disappears, the function may operate again.

The function cancels in the following conditions when:

- Smart Exit
 - The steering wheel is turned.
 - The gear is shifted whilst the vehicle is moving.
 - EPB (Electronic Parking Brake) is operating whilst your vehicle is moving.
 - The bonnet is open.
 - The driver's door is open with the seat belt unfastened.
 - Rapid acceleration occurs.
 - Vehicle skid occurs.
 - An obstacle prevents the wheel from moving.
 - There are pedestrians, animals or objects at the front and rear of the vehicle at the same time.
 - About 3 minutes and 50 seconds have passed since Smart Exit function was initiated.
 - The slope of the road exceeds the operational range.

- The function was paused for more than 1 minute.
- The steering wheel, gearshift, braking, and drive controls are not working properly.
- ABS, TCS, or ESC system operates due to slippery road conditions.
- The charging door is open.

When Smart Exit function is cancelled, your vehicle automatically stops, shifts the gear to P (Park), and applies EPB (Electronic Parking Brake).

Remote Smart Parking Assist malfunction and limitations

Remote Smart Parking Assist malfunction

Remote Smart Parking Assist check



When Remote Smart Parking Assist is not working properly, the "Check Parking Assist" warning message may appear on the infotainment system screen. If the message appears, stop using Remote Smart Parking Assist, and we recommend that your vehicle be inspected by an authorised Genesis repairer.

Remote Smart Parking Assist cancelled



When Remote Parking Assist is operating, the function can be cancelled, and the "Parking Assist Cancelled" warning message may appear on the infotainment system screen. Other messages may appear depending on the given situation. Follow the instructions provided whilst parking your vehicle with Remote Parking Assist. Always look around and pay attention when using Remote Smart Parking Assist.

Remote Smart Parking Assist conditions not met



The "Parking Assist conditions not met" warning message may appear on the infotainment system screen if:

- Parking/View (戶) button has been pressed and held whilst ready to operate. After a whilst, press and hold the Parking/View (戶) button again to see if Remote Smart Parking Assist operates.
- The smart key's battery is low. Check the battery and replace it if needed.

Detecting sensors

Refer to the "Driver Assistance System sensors" section in this chapter for the location and the general precautions of the wide-front/side/rear view cameras and front/side/rear ultrasonic sensors.

A WARNING

Do not manually adjust the outside rear-view mirrors or use the Remote Smart Parking Assist after a hard impact on the outside rear-view mirrors.

Limitations of Remote Smart Parking Assist

In the following circumstances, the use of Remote Smart Parking Assist may be limited, there may be a risk of collision, or Remote Smart Parking Assist may turn off. You may have to park your vehicle or to drive away from the parked location without using this function.

- An object is attached to the steering wheel.
- Your vehicle has snow chains, spare tyre, or different size wheels installed.
- Tyre pressure is lower or higher than the standard tyre pressure.
- Your vehicle is loaded with luggage longer or wider than your vehicle or a trailer or towbar mounted carrier is connected to your vehicle.
- There is an issue with the wheel alignment.
- Your vehicle is leaning severely to one side.
- Your vehicle is equipped with a trailer towbar.
- The licence plate is installed in a location different from the intended location.
- There is a person, animal, or object above or below the ultrasonic sensor when Remote Smart Parking Assist is activated.

- The parking space is narrow, curved or angled.
- There is an obstacle such as person, animal, or object (trash can, bicycle, motorcycle, shopping cart, narrow pillar, etc.) detected near the parking space.
- There is a circular pillar or narrow pillar, or a pillar surrounded by objects such as fire extinguisher detected near the parking space.
- The road surface is bumpy (kerbstone, speed bump, etc.) or slippery.
- The parking space is near a vehicle with higher ground clearance or a larger vehicle such as truck.
- · The parking space is inclined.
- · There is a heavy wind.
- Remote Smart Parking Assist is operating on uneven roads, gravel roads, bushes, etc.
- The weather is very hot or cold.
- The ultrasonic sensor is covered or blocked with snow, water, or dirt.
- A wireless transmission device operates near the ultrasonic sensors.
- An ultrasonic sensor with a similar frequency is near your vehicle.
- A sensor has been damaged or scratched by a sharp object.
- When the ultrasonic sensor cannot detect the following objects:
 - Slim objects such as ropes, chains, or small poles.
 - Narrow objects such as corners of a square column
 - Objects less than 100 cm in height and narrower than 14 cm in diameter.
 - Objects that tend to absorb sensor frequency such as clothes, spongy material, or snow.
 - Pedestrians, animals, or objects that are very close to the ultrasonic sensors.

- The cameras may not properly recognise or may not recognise the parking line and objects when:
 - There are small objects (kerb, etc.), sharp objects, or thin objects (rope, etc.) around.
 - People, animals or objects are too close or too far from the vehicle.
 - Objects are on a higher position, such as pickup trucks.
 - The camera is covered or blocked by dirt or moisture.
 - The camera is exposed to bright light.
 - The surroundings are too dark.
 - Light is reflected from a surface.

Remote Smart Parking Assist may not operate normally under the following circumstances:

· Parking on inclines



Park or exit your vehicle manually on inclines.

· Parking in snow




Snow may interfere with sensor operation, or Remote Smart Parking Assist may cancel if the road is slippery where you are parking.

· Parking on uneven road



Remote Smart Parking Assist may cancel when the vehicle slips, or the vehicle cannot move due to road conditions such as pebbles or fragmented stones.

Parking behind a truck



Do not use Remote Smart Parking Assist around vehicles with higher ground clearance, such as a bus, truck, etc. It may lead to an accident.

Parking near a pillar



Remote Smart Parking Assist performance may be reduced or collision with an obstacle may occur when there is a narrow object, circular pillar, square pillar, or a pillar surrounded by objects such as a fire extinguisher, etc., near the parking space. Park or exit your vehicle manually.

· Parking next to a misaligned vehicle



If Remote Smart Parking Assist is used, when parking next to a misaligned vehicle, your vehicle may cross the parking marking on the opposite side of the parked vehicle.

• Parking in angled spaces



Remote Operation may not operate properly in a diagonal parking space.

 Leaving a parking space near a wall or parking in a narrow space



- Remote Smart Parking Assist may not operate normally when leaving a parking space that is narrow and near a wall. Always check for pedestrians, animals, objects whilst leaving.
- Remote Smart Parking Assist does not search for parking spaces at areas with narrow parking spaces that are narrower than the minimum space required for parking.
- · Parking in abnormal spaces



Remote Smart Parking Assist does not work normally when the parking lines are not parallel. Do not park even though the parking space is recognised by the sensor.

· Parking on inclined parking space



Remote Smart Parking Assist does not work normally on a inclined or curved road surface. Do not park even though the parking space is recognised by the sensor.

▲ WARNING

The driver is responsible for parking and exiting safely when using Remote Smart Parking Assist. Make sure there are no pedestrians, animals, or objects around the vehicle when using Remote Smart Parking Assist.

To prevent serious injury or death:

- When using Remote Smart Parking Assist, stay out of the path of your vehicle.
- A collision may occur if a pedestrian, animal, or object are in the blind spot area of the sensors or are very close to the sensors.
- A collision may occur if a pedestrian, animal, or object suddenly enters the path of your vehicle whilst Remote Smart Parking Assist is operating.
- Do not use Remote Smart Parking Assist under the influence of alcohol.
- Do not let children or other people use the smart key.
- Do not use Remote Smart Parking Assist continuously for a long time. It may adversely affect Remote Smart Parking Assist performance.

- Remote Smart Parking Assist may not operate normally if your vehicle needs wheel alignment adjustment such as when your vehicle tilts to one side. We recommend that your vehicle be inspected by an authorised Genesis repairer.
- Remote Smart Parking Assist may suddenly brake to help avoid a collision.
- Only use Remote Smart Parking Assist in parking spaces large enough for your vehicle.

i Information

- The vehicle may move with the stop lights on when the brakes are applied by Remote Smart Parking Assist.
- The Remote Smart Parking Assist's performance may temporarily reduce or may turn off when the vehicle is turned on after being parked in cold weather for a long time.
- If the 3rd stage warning (continuous beep) of Forward/Rearward Parking Distance Warning sounds whilst Remote Smart Parking Assist is operating, it means the obstacle detected is close to your vehicle and Remote Smart Parking Assist temporarily stops operating.

Declaration of conformity

Front radar

The radio frequency components (Front Radar) complies:



Front corner radar/Rear corner radar

+if equipped

The radio frequency components (Front corner radar/Rear corner radar) complies:



8. Emergency situations

Hazard warning flasher	8-2
In case of an emergency whilst driving	8-2
If the vehicle stalls whilst driving	
If the vehicle stalls at a crossroads or crossing	
If you have a flat tyre whilst driving	
If the vehicle does not start	8-3
Jump starting (12 V Battery)	8-4
Tyre Pressure Monitoring System (TPMS)	8-7
Check tyre pressure	
Tyre pressure monitoring system	
Low tyre pressure position and tyre pressure telltale	8-9
TPMS (Tyre Pressure Monitoring System) malfunction indicator	8-10
Changing a tyre with TPMS	8-11
If you have a flat tyre (with tyre mobility kit)	8-12
Introduction	8-12
Notes on the safe use of the Tyre Mobility Kit	8-13
Components of the Tyre Mobility Kit	8-14
Using the Tyre Mobility Kit When a tyre is flat	
How to adjust tyre pressure	8-18
Towing	
Towing service	8-19
Removable towing book	8-20

Hazard warning flasher



The hazard warning flasher warns other drivers to exercise extreme caution when approaching, overtaking, or passing your vehicle.

It should be used whenever making emergency repairs or when stopped near the edge of a roadway.

To turn on or off the hazard warning flasher, press the hazard warning flasher button with the Start/Stop button in any position. The hazard warning flasher button is located in the centre fascia panel. All turn signal lights will flash simultaneously.

- The hazard warning flasher operates regardless of whether your vehicle is DRIVE READY (READYINDICATOR ON) or not.
- The turn signals do not work when the hazard flasher is on.

In case of an emergency whilst driving

If the vehicle stalls whilst driving

- Reduce the vehicle speed gradually, keeping a straight line. Move cautiously off the road to a safe place.
- · Turn on your hazard warning flasher.
- Try to start the vehicle again. If your vehicle does not start, we recommend that you contact an authorised Genesis repairer or seek other qualified assistance.

If the vehicle stalls at a crossroads or crossing

If the vehicle stalls at a crossroads or intersection, if safe to do so, shift the gear to N (Neutral) and then push the vehicle to a safe location.

If you have a flat tyre whilst driving

If a tyre goes flat whilst you are driving:

- Take your foot off the accelerator pedal and let the vehicle slow down whilst driving straight ahead. Do not apply the brakes immediately or attempt to pull off the road because this may cause loss of vehicle control resulting in a collision. When the vehicle has slowed to such a speed that it is safe to do so, brake carefully and pull off the road. Drive off the road as far as possible and park on a firm, level ground. If you are on a divided highway, do not park in the median area between the two traffic lanes.
- When the vehicle is stopped, press the hazard warning flasher button, shift the gear to P (Park), apply the recuperative brake, and press the Start/Stop button to the OFF position.
- Have all passengers get out of the vehicle. Make sure they all get out on the side of the vehicle that is away from traffic.
- When you have a flat tyre, refer to the "If you have a flat tyre (with tyre mobility kit)" section in this chapter.

If the vehicle does not start

Confirm the EV battery is not low on the charge gauge.

- Be sure the gear is in P (Park). The vehicle starts only when the gear is in P (Park).
- Check the 12 V battery connections to be sure they are clean and tight.
- Turn on the interior light. If the light dims or goes out when you operate the starter, the 12 V battery is drained.

Do not push or pull the vehicle to start it.

This could cause damage to your vehicle.

Jump starting (12 V Battery)

Jump starting can be dangerous if done incorrectly. Follow the jump starting procedure in this section to avoid serious injury or damage to your vehicle. If in doubt about how to properly jump start your vehicle, have a service technician or towing service do it for you.

WARNING

To prevent serious injury or death to you or bystanders, always follow these precautions when working near or handling the battery:

Always read and follow instructions carefully when handling a battery.



Wear eye protection designed to protect the eyes from acid splashes.



Keep all flames, sparks, or smoking materials away from the battery.



Hydrogen gas is always present in battery cells. It is highly combustible, and may explode if ignited.



Keep batteries out of reach of children.



Batteries contain sulphuric acid which that is highly corrosive. Do not allow acid to contact your eyes, skin, or clothing.

If acid gets into your eyes, flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If acid gets on your skin, thoroughly wash the area. If you feel pain or a burning sensation, get medical attention immediately.



- When lifting a plastic-cased battery, excessive pressure on the case may cause battery acid to leak. Lift with a battery carrier or with your hands on opposite corners.
- Do not attempt to jump start your vehicle if your battery is frozen.
- Never attempt to recharge the battery when the vehicle's battery cables are connected to the battery.
- The electrical ignition system works with high voltage.

Never touch these components with the READY indicator ON or when the Start/Stop button is in the DRIVE READY position.

- Do not allow the positive (+) and negative (-) jumper cables to touch. It may cause sparks.
- The battery may rupture or explode when you jump start with a low or frozen battery.
- Do not directly connect the negative (-) to the jump cable. Connect the negative (-) to the one of the metallic parts located far from the jump cable in the vehicle.
 - The direct negative (-) connection to the jump cable may cause an explosion.
- Be sure to use only 12 V battery to jump start. Using batteries with other voltages to jump start can damage the battery or even provoke an explosion.

A WARNING

- Keep sparks away from the battery as the explosive gas is generated by the sparks whilst the battery is running.
- When connecting the supplementary battery and the discharged battery with a jump cable because the jump start does not operate with jump start terminal in the motor compartment, do not directly connect the negative (-) to the jump cable.
 - Connect the negative (-) to one of the metallic parts located far from the jump cable in the vehicle. The direct negative (-) connection to the jump cable may cause an explosion.
- The battery contains dilute sulphuric acid, which is highly corrosive, so be careful not to let the battery liquid get on your body, clothes, or car body. If dilute sulphuric acid gets on your body or eyes, immediately rinse the area with clean water for about 15 minutes and then consult a doctor.

i Information

Your vehicle has a battery in the luggage compartment, but when you jump start your vehicle, use the jumper terminal in the motor compartment.

If jump start does not operate with the jump start terminal in the motor compartment, use the battery terminal in the boot.

Jump starting procedure


i Information

Your vehicle has a battery in the luggage compartment, but when you jump start your vehicle, use the jumper terminal in the motor compartment.

- Position the vehicles close enough that the jumper cables can reach. Do not allow the vehicles to touch.
- Avoid fans or any moving parts in the motor compartment at all times, even when the vehicles are turned off.
- 3. Turn off all electrical devices such as radios, lights, air conditioning, etc. Put the vehicles in P (Park) and apply the parking brake. Turn both vehicles OFF.
- 4. Open the bonnet.
- 5. Open the service cover.
- 6. Remove the motor compartment fuse box cover.

A CAUTION

Before jump starting, make sure to correctly identify the positive (+) and negative (-) terminals to avoid reverse polarity connections.



- Connect the jumper cables in the exact sequence shown in the image. First connect one jumper cable to the positive (+) jumper terminal of your vehicle (1).
- Connect the other end of the jumper cable to the red, positive (+) battery/jumper terminal of the assisting vehicle (2).
- Connect the second jumper cable to the black, negative (-) battery/jumper terminal of the assisting vehicle (3).
- 10. Connect the other end of the second jumper cable to the chassis ground of your vehicle (4).

Do not allow the jumper cables to contact anything except the correct battery or jumper terminals or the correct ground. Do not lean over the battery when making connections.

▲ WARNING

Do not connect the jumper cable to the negative (-) jumper terminal of the discharged battery. A spark could cause the battery to explode and lead to a personal injury or vehicle damage.

- 11.Start the assisting vehicle and let it idle for a few minutes. Then start your vehicle.
- 12.Keep your vehicle operating for at least 30 minutes at idle or driving to assure make sure your battery receives enough charge to be able to start on its own after the vehicle is shut off. A completely discharged battery may require as long as 60 minutes runtime to fully recharge it. If the vehicle is run for less, the vehicle may not restart.

If your vehicle does not start after a few attempts, it probably requires service. We recommend that your vehicle be inspected by an authorised Genesis repairer.

Disconnect the jumper cables in the exact reverse order you connected them:

- 1. Disconnect the jumper cable from the chassis ground of your vehicle (4).
- Disconnect the other end of the jumper cable from the black, negative (-) battery/jumper terminal of the assisting vehicle (3).
- 3. Disconnect the second jumper cable from the red, positive (+) battery/jumper terminal of the assisting vehicle (2).
- 4. Disconnect the other end of the jumper cable from the red, positive (+) jumper terminal of your vehicle (1).

⚠ WARNING

Whilst jump starting your vehicle, avoid the positive (+) and negative (-) cables coming into contact. A spark could cause personal injury.

NOTICE

To prevent damage to your vehicle:

- Only use a 12 V power supply (battery or jumper system) to jump start your vehicle.
- Do not attempt to jump start your vehicle by push-starting.
- Always be sure that the battery cover and cable are tightened after finishing jump start your vehicle. Otherwise is may cause damage to the relevant parts, noise trouble, or entrance of foreign substances.

i Information



An inappropriately disposed battery may be harmful to the environment and human health. Always dispose used batteries in accordance with local law(s) or regulations.

Tyre Pressure Monitoring System (TPMS)



- [A] Low Tyre Pressure Position Telltale and Tyre Pressure Telltale (Shown on the instrument cluster display)
- [B] Low Tyre Pressure Telltale/TPMS Malfunction Indicator

Check tyre pressure



- You can check the tyre pressure in the Normal view on the instrument cluster.
 Refer to the "View modes" section in chapter 4.
- Tyre pressure is displayed after a few minutes of driving.
- If tyre pressure is not displayed when the vehicle is stopped, "Drive to display" message appears.
- The displayed tyre pressure values may differ from those measured with a tyre pressure gauge.

- You can change the tyre pressure unit from the Settings menu in the infotainment system. Select:
 - Setup > General > Units > Tyre air pressure > psi/kPa/bar

i Information

The infotainment system may change after software updates. For more information, refer to the manual provided in the infotainment system and the quick reference guide.

Tyre pressure monitoring system

WARNING

Over-inflation or under-inflation can reduce tyre life, adversely affect vehicle handling, and lead to sudden tyre failure that may cause loss of vehicle control resulting in an accident.

Each tyre, including the spare (if provided), should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tyre inflation pressure label. (If your vehicle has tyres of a different size than the size indicated on the vehicle placard or tyre inflation pressure label, you should determine the proper tyre inflation pressure for those tyres.)

As an added safety feature, your vehicle has been equipped with a Tyre pressure monitoring system (TPMS) that illuminates a low tyre pressure telltale when one or more of your tyres is significantly under-inflated. Accordingly, when the low tyre pressure telltale illuminates, you should stop and check your tyres as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tyre causes the tyre to overheat and can lead to tyre failure.

Under-inflation also reduces energy efficiency and tyre tread life, and may affect the vehicle's handling and stopping ability.

Please note that the TPMS is not a substitute for proper tyre maintenance, and it is the driver's responsibility to maintain correct tyre pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tyre pressure telltale.

Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tyre pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists.

When the malfunction indicator is illuminated, the system may not be able to detect or signal low tyre pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tyres or wheels on the vehicle that prevent the TPMS from functioning properly.

Always check the TPMS malfunction telltale after replacing one or more tyres or wheels on your vehicle to ensure that the replacement or alternate tyres and wheels allow the TPMS to continue to function properly.

NOTICE

If any of the below happens, we recommend that you have the system inspected by an authorised Genesis repairer.

- The Low Tyre Pressure Telltale/TPMS
 Malfunction Indicator does not
 illuminate for 3 seconds when the
 Start/Stop button is pressed to the
 POWER ON position or when the
 vehicle is running.
- The TPMS Malfunction Indicator remains illuminated after blinking for about 1 minute.
- 3. The Low Tyre Pressure Position Telltale remains illuminated.

Low tyre pressure position and tyre pressure telltale

Low tyre pressure warning light



Low tyre pressure position telltale



When the tyre pressure monitoring system warning indicators are illuminated and a warning message displayed on the instrument cluster display, one or more of your tyres is significantly under-inflated. The Low Tyre Pressure Position Telltale will indicate which tyre is significantly underinflated by illuminating the corresponding parking lamp.

If either telltale illuminates, immediately reduce your speed, avoid hard cornering and anticipate increased stopping distances. You should stop and check your tyres as soon as possible. Inflate the tyres to the proper pressure as indicated on the vehicle's placard or tyre inflation pressure label located on the driver's side centre pillar outer panel.

The Low Tyre Pressure Telltale will remain on and the TPMS Malfunction Indicator may blink for one minute and then remain illuminated (when the vehicle is driven about 10 minutes at speed above 25 km/h) until you have the low pressure tyre repaired and replaced on the vehicle.

WARNING

In winter or cold weather, the Low Tyre Pressure Telltale may be illuminated if the tyre pressure was adjusted to the recommended tyre inflation pressure in warm weather. It does not mean your TPMS is malfunctioning because the decreased temperature leads to a proportional lowering of tyre pressure.

When you drive your vehicle from a warm area to a cold area or from a cold area to a warm area, or the outside temperature is greatly higher or lower, you should check the tyre inflation pressure and adjust the tyres to the recommended tyre inflation pressure.

WARNING

Low pressure damage

Significantly low tyre pressure makes the vehicle unstable and can contribute to loss of vehicle control and increased braking distances.

Continued driving on low pressure tyres can cause the tyres to overheat and fail.

TPMS (Tyre Pressure Monitoring System) malfunction indicator



The TPMS Malfunction Indicator will illuminate after it blinks for about one minute when there is a problem with the tyre Pressure Monitoring System.

We recommend that the system be checked by an authorised Genesis repairer as soon as possible.

NOTICE

If there is a malfunction with the TPMS, the Low Tyre Pressure Position Telltale will not be displayed even though the vehicle has an under-inflated tyre.

NOTICE

The TPMS Malfunction Indicator may illuminate after blinking for one minute if the vehicle is near electric power supply cables or radio transmitters such as police stations, government and public offices, broadcasting stations, military installations, airports, transmitting towers, etc.

Additionally, the TPMS Malfunction Indicator may illuminate if snow chains are used or electronic devices such as computers, chargers, remote starters, navigation, etc. This may interfere with normal operation of the TPMS.

Changing a tyre with TPMS

If you have a flat tyre, the Low Tyre Pressure and Position telltales will come on. We recommend that the flat tyre be repaired by an authorised Genesis repairer as soon as possible.

NOTICE

Do not use a puncture-repair kit not approved by Genesis vehicle. tyre sealant not approved by Genesis vehicle or the equivalent specified for your vehicle may damage the tyre pressure sensor.

Once the original wheel equipped with a tyre pressure monitoring sensor is reinflated to the recommended pressure and reinstalled on the vehicle, the Low Tyre Pressure Telltale and TPMS Malfunction Indicator will go off within a few minutes of driving.

If the indicators do not extinguish after a few minutes we recommend that you consult an authorised Genesis repairer.

Each wheel is equipped with a tyre pressure sensor mounted inside the tyre behind the valve stem. You must use TPMS specific wheels. It is recommended that you always have your tyres serviced by an authorised Genesis repairer.

You may not be able to identify a tyre with low pressure by simply looking at it. Always use a good quality tyre pressure gauge to measure. Please note that a tyre that is hot (from being driven) will have a higher pressure measurement than a tyre that is cold.

A cold tyre means the vehicle has been sitting for 3 hours and driven for less than 1.6 km in that 3 hour period.

Allow the tyre to cool before measuring the inflation pressure. Always be sure the tyre is cold before inflating to the recommended pressure.


WARNING

- The TPMS cannot alert you to severe and sudden tyre damage caused by external factors such as nails or road debris
- If you feel any vehicle instability, immediately take your foot off the accelerator, apply the brakes gradually with light force, and slowly move to a safe position off the road.

WARNING

Tampering with, modifying, or disabling the Tyre Pressure Monitoring System (TPMS) components may interfere with the system's ability to warn the driver of low tyre pressure conditions and/or TPMS malfunctions and may void the warranty.

If you have a flat tyre (with tyre mobility kit)



For safe operation, carefully read and follow the instructions in this manual before use.

- (1) Compressor
- (2) Sealant bottle

The Tyre Mobility Kit is a temporary fix to the tyre we recommend the tyre be inspected by an authorised Genesis repairer or the equivalent approved for your vehicle as soon as possible.

A CAUTION

When two or more tyres are flat, do not use the Tyre Mobility Kit because the sealant provided with the Tyre Mobility Kit must be used for only one flat tyre.

A WARNING

Do not use the Tyre Mobility Kit to repair punctures in the tyre walls. This can result in an accident due to tyre failure.

M WARNING

Have your tyre repaired as soon as possible. The tyre may lose air pressure at any time after inflating with the Tyre Mobility Kit.

Introduction

With the Tyre Mobility Kit you stay mobile even after experiencing a tyre puncture.

The compressor and sealing compound system effectively and comfortably seals most punctures in a passenger car tyre caused by nails or similar objects and reinflates the tyre.

After you ensure that the tyre is properly sealed you can drive cautiously on the tyre distance up to 200 km at a max. speed of 80 km/h in order to reach a service station or tyre dealer for a tyre replacement.

It is possible that some tyres, especially with larger punctures or damage to the sidewall, cannot be sealed completely.

Air pressure loss in the tyre may adversely affect tyre performance.

For this reason, you should avoid abrupt steering or other driving manoeuvres, especially if the vehicle is heavily loaded.

The Tyre Mobility Kit is not designed or intended as a permanent tyre repair method and is to be used for one tyre only.

This instruction shows you step by step how to temporarily seal the puncture simply and reliably.

Read the section "Notes on the safe use of the Tyre Mobility Kit".

MARNING

Do not use the Tyre Mobility Kit if a tyre is severely damaged by driving, run flat or with insufficient air pressure.

Only punctured areas located within the tread region of the tyre can be sealed using the Tyre Mobility Kit.

Notes on the safe use of the Tyre Mobility Kit

- Park your car at the side of the road so that you can work with the Tyre Mobility Kit away from moving traffic.
- To be sure your vehicle will not move, even when you're on fairly level ground, always set your parking brake.
- Only use the Tyre Mobility Kit for sealing/inflation passenger car tyres.
 Only punctured areas located within the tread region of the tyre can be sealed using the tyre mobility kit.
- Do not use on motorcycles, bicycles or any other type of tyres.
- When the tyre and wheel are damaged, do not use Tyre Mobility Kit for your safety.
- Use of the Tyre Mobility Kit may not be effective for tyre damage larger than about 4 mm
- If the tyre cannot be made roadworthy with the Tyre Mobility Kit, we recommend that you contact an authorised Genesis repairer.
- Do not use the Tyre Mobility Kit if a tyre is severely damaged by driving, run flat or with insufficient air pressure.
- Do not remove any foreign objects such as nails or screws that have penetrated the tyre.
- Provided the car is outdoors, leave the vehicle in DRIVE READY (READY indicator ON).
 - Otherwise operating the compressor may eventually drain the car battery.
- Never leave the Tyre Mobility Kit unsupervised whilst it is being used.
- Do not leave the compressor running for more than 10 min. at a time or it may overheat.

- Do not use the Tyre Mobility Kit if the ambient temperature is below -30°C.
- In case of skin contact with the sealant, wash the area thoroughly with plenty of water. If the irritation persists, seek medical attention.
- In case of eye contact with the sealant, flush your eyes for at least 15 minutes. If the irritation persists, seek medical attention.
- In case of swallowing the sealant, rinse the mouth and drink plenty of water. However, never give anything to an unconscious person and seek medical attention immediately.
- Long time exposure to the sealant may cause damage to bodily tissue such as kidney, etc.

Components of the Tyre Mobility Kit



- (1) Speed restriction label
- (2) Sealant bottle and label with speed restriction
- (3) Filling hose
- (4) Holder for the sealant bottle
- (5) Connectors and cable for power outlet direct connection
- (6) ON/OFF switch
- (7) Compressor
- (8) Pressure gauge for displaying the tyre inflation pressure
- (9) Button for reducing the tyre inflation pressure

Connectors, cable and connection hose are stored in the compressor housing. Strictly follow the specified sequence, otherwise the sealant may escape under high pressure.

A WARNING

Expired sealant

Do not use the Tyre sealant after the sealant has expired (for example, past the expiration date on the sealant container). This can increase the risk of tyre failure.

A WARNING

Sealant

- · Keep out of reach of children.
- · Avoid contact with eyes.
- · Do not swallow.

Using the Tyre Mobility Kit When a tyre is flat

A CAUTION



Detach the speed restriction label from the sealant bottle, and place it in a highly visible place inside the vehicle such as on the steering wheel to remind the driver not to drive too fast.

A CAUTION

If only the tyre pressure needs to be adjusted, refer to "How to Adjust Tyre Pressure" in this chapter.

Before using the Tyre Mobility Kit, be fully aware of the explanation on the sealant.

- 1. Shake the sealant bottle (2).
- Connect the filling hose (3) to the sealant bottle (2) in the direction of [A] and connect the sealant bottle to the holder for the sealant bottle (4) in the direction of [B].



- 3. Ensure that the compressor is switched OFF.
- 4. Unscrew the valve cap from the valve of the defective wheel and screw the filling hose (3) of the sealant bottle onto the valve.



NOTICE

Securely install the sealant filling hose onto the valve. If not, sealant may flow rearward, possibly clogging the filling hose.

5. Plug the compressor power cord (5) into the vehicle power outlet.



NOTICE

Only use the front passenger side power outlet when connecting the power cord.

6. With the vehicle in DRIVE READY

(READY indicator ON), switch on the compressor and let it run for about 5-7 minutes to fill the sealant up to proper pressure. (refer to the Tyre and Wheels, chapter 2).

The inflation pressure of the tyre after filling is unimportant and will be checked/corrected later.

Be careful not to overinflate the tyre and stay away from the tyre when filling it.

A CAUTION

Do not attempt to drive your vehicle if the tyre pressure is below 200 kPa (29 psi). This could result in an accident due to sudden tyre failure.

- 7. Switch off the compressor.
- Detach the hoses from the sealant bottle connector and from the tyre valve.

Return the Tyre Mobility Kit to its storage location in the vehicle.

 Immediately drive about 7-10 km (about 10 minutes) to evenly distribute the sealant in the tyre.

Do not exceed a speed of 80 km/h. If possible, do not fall below a speed of 20 km/h.



Whilst driving, if you experience any unusual vibration, ride disturbance or noise, reduce your speed and drive with caution until you can safely pull off of the side of the road.

Call for road side service or towing.

- 10.After driving about 7-10 km (about 10 minutes), stop at a safe location.
- 11.Connect the filling hose (3) of the compressor directly to the tyre valve.



12. Plug the compressor power cord (5) into the vehicle power outlet.

13. Adjust the tyre inflation pressure to the recommended tyre inflation.

With the vehicle in DRIVE READY (READY indicator ON) proceed as follows:

To increase the inflation pressure:

Switch on the compressor. To check the current inflation pressure setting, briefly switch off the compressor.

To reduce the inflation pressure:
Press the button (9) on the compressor.

NOTICE

Do not let the compressor run for more than 10 minutes, otherwise the device will overheat and may be damaged.

i Information

The pressure reading on the gauge may be higher than the actual reading when the compressor is running. To get an accurate tyre pressure, the compressor needs to be turned off.

A CAUTION

If the inflation pressure is not maintained, drive the vehicle a second time, refer to step 9.

Then repeat steps 10 to 13.

Use of the Tyre Mobility Kit may be ineffective for tyre damage larger than about 4 mm.

We recommend that you contact an authorised Genesis repairer if the tyre cannot be made roadworthy with the Tyre Mobility Kit.

WARNING

The tire inflation pressure must be inflated to the proper pressure (Refer to the "Tyres and wheels" section in chapter 2). If it is not, do not continue driving. Call for road side service or towing.

A CAUTION

Tyre pressure sensor (if equipped with TPMS)

The sealant on the tyre pressure sensor and wheel should be removed when you replace the tyre with a new one and inspect the tyre pressure sensors. We recommend that you get this done by an authorised Genesis repairer.

i Information

When reinstalling the repaired or replaced tyre and wheel on the vehicle, tighten the wheel bolt to 14~16 kgf·m (101~116 lbf·ft).

How to adjust tyre pressure

- 1. Park your vehicle in a safe location.
- 2. Connect the filling hose (3) of the compressor directly to the tyre valve.



- 3. Plug the compressor power cord (5) into the vehicle power outlet.
- 4. Adjust the tyre inflation pressure to the recommended tyre inflation.

With the vehicle in DRIVE READY (READY indicator ON), proceed as follows.

To increase the inflation pressure: Switch on the compressor. To check the current inflation pressure setting, briefly switch off the compressor.

To reduce the inflation pressure: Press the button (9) on the compressor.

NOTICE

Do not let the compressor run for more than 10 minutes, otherwise the device will overheat and may be damaged.

i Information

- The pressure reading on the gauge may be higher than the actual reading when the compressor is running. To get an accurate tyre reading, the compressor needs to be turned off.
- When reinstalling the repaired or replaced tyre and wheel on the vehicle, tighten the wheel bolt to 14~16 kgf·m (101~116 lbf·ft).

A CAUTION

Do not use the sealant when only the tyre pressure needs to be adjusted.

A WARNING


The tyre inflation pressure must be at least 220 kPa (32 psi). If it is not, do not continue driving.

Call for road side service or towing.


Towing

Towing service

Flatbed Towing



Wheel lift Towing



[A] Dollies

If towing is necessary, contact an authorised Genesis repairer or a commercial tow-truck service.

AWD vehicles must be towed with a wheel lift and dollies or flatbed with all the wheels off the ground.

Precautions when moving a short distance before towing a vehicle

Move short distances within 10 m at a speed of 5 km/h or less only when loading on a tow truck or if the vehicle needs to be repositioned.

At this time, the gear must be in the N (Neutral) position and the parking brake must be released. If it is impossible to operate the reduction gear and parking brake, move the vehicle by using dollies, tyre skate, etc with all wheels lifted.

NOTICE

To prevent damage when towing:

- Do not lift using the trailer towbar or body and chassis parts.
- Do not tow vehicles with sling-type equipment. Only use wheel lift or flatbed equipment.



NOTICE


Always shift the gear to N (Neutral) to prevent damage to the reduction gear before towing.

Removable towing hook

We recommend that your vehicle be towed by an authorised Genesis repairer or a commercial tow-truck service.

Only use the towing hook to move short distances (within 10 m at a speed of 5 km/h or less) or to lift the vehicle before towing.

1. Open the boot, and remove the towing hook from the tool case.



Rear


- (1) Install
- (2) Remove
- 2. Remove the hole cover by pressing the cover on the bumper.
- Install the towing hook by turning it clockwise into the hole until it is fully secured.
- 4. Remove the towing hook and install the cover after use.

9. Maintenance

Motor compartment overview	9-3
Maintenance services	9-4
Owner's responsibility	9-4
Owner maintenance precautions	9-4
Owner maintenance	9-5
Owner maintenance schedule	9-5
Scheduled maintenance services	9-7
Normal maintenance schedule	9-8
Maintenance under severe usage conditions	9-10
Explanation of scheduled maintenance items	9-11
Cooling system	9-11
Coolant	
Reduction gear fluid	
Brake hoses and lines	
Brake fluid	
Brake discs, pads and calipers	
Drive shafts and boots	
Steering gear box, linkage & boots/lower arm ball joint	
Air conditioning refrigerant	
Coolant	
Checking the coolant level	
Changing coolant	
Brake fluid	
Checking the brake fluid level	
Reduction gear fluid	
Washer fluid	9-16
Checking the washer fluid level	
Cabin air filter	9-16
Filter inspection	9-16
Filter replacement	
Wiper blades	9-18
Blade inspection	
Blade replacement	
Battery (12 V)	9-19

	For best battery service	
	Battery replacement	
	Battery capacity label	
	Battery recharging	9-21
	Reset items	9-22
	Tyres and wheels	9-23
	Tyre care	9-23
	Recommended cold tyre inflation pressures	9-23
	Check tyre inflation pressure	
	Tyre rotation	
	Wheel alignment and tyre balance	
	Tyre replacement	9-26
	Wheel replacement	9-26
	Tyre traction	9-26
	Tyre maintenance	9-26
	Tyre sidewall labelling	9-27
	Low aspect ratio tyres	
	Summer tyres	9-29
	Fuses	9-30
	Instrument panel fuse replacement	9-31
	Motor compartment panel fuse replacement	
	Fuse/relay panel description	
	Light bulbs	9-50
	Headlamp, parking lamp, turn signal lamp, Daytime Running Lamp (DRL)	
	replacement	9-51
	Side repeater lamp replacement	9-52
	Puddle lamp replacement	
	Rear combination lamp replacement	9-52
ı	Reverse guide lamp replacement	9-52
ı	High mounted stop lamp replacement	9-53
	Licence plate lamp replacement	
	Interior light replacement	
	Appearance care	9-55
	Exterior care	
	Interior care	

Motor compartment overview



The actual motor compartment in the vehicle may differ from the illustration.

- (1) Windscreen washer fluid reservoir
- (2) Brake fluid reservoir
- (3) Cabin air filter
- (4) Jump-start negative (chassis) terminal
- (5) Fuse box
- (6) Low conductivity coolant reservoir
- (7) Coolant reservoir
- (8) Emergency cable

Maintenance services

Exercise the utmost care to prevent damage to your vehicle and injury to yourself whenever performing any maintenance or inspection procedures.

We recommend you have your vehicle maintained and repaired by an authorised Genesis repairer. An authorised Genesis repairer meets Genesis vehicle's high service quality standards and receives technical support from Genesis vehicle to provide you with a high level of service satisfaction.

Owner's responsibility

Maintenance service and record retention are the owner's responsibility.

Retain documents that show proper maintenance has been performed on your vehicle in accordance with the scheduled maintenance service charts on the following pages. You need this information to establish your compliance with the servicing and maintenance requirements of your vehicle warranties.

Detailed warranty information is provided in your Service Passport.

Repairs and adjustments required as a result of improper maintenance or a lack of required maintenance are not covered.

Owner maintenance precautions

Inadequate, incomplete, or insufficient servicing may result in operational problems with your vehicle that could cause vehicle damage or a collision that results in serious injury or death.

Your vehicle must not be modified in any way. Such modifications may adversely affect the performance, safety, or durability of your vehicle and may, in addition, violate conditions of the limited warranties covering the vehicle.

NOTICE

Improper owner maintenance during the warranty period may affect the warranty coverage. For more information, read the separate Service Passport provided with the vehicle.

Owner maintenance

A WARNING

Performing maintenance on the vehicle can be dangerous. If you lack sufficient knowledge, experience, or proper tools and equipment to do the work, we recommend to have it done by an authorised Genesis repairer. Before performing maintenance:

- Park your vehicle on level ground. Shift the vehicle to P (Park), apply the parking brake, and press the Start/Stop button to the OFF position.
- Block the tyres (front and back) to prevent the vehicle from moving.
 Remove loose clothing or jewellery that can become entangled in moving parts.
- Keep flames, sparks, or smoking materials away from the battery and parts.

A WARNING

Make sure to turn the Start/Stop button to the 'OFF' position to shut down the vehicle before performing maintenance work on the vehicle.

The following lists are vehicle checks and inspections that should be performed by the owner or an authorised Genesis repairer at the frequencies indicated to help ensure safe and dependable operation of your vehicle.

Any adverse conditions should be brought to the attention of your authorised Genesis repairer as soon as possible.

These Owner Maintenance vehicle checks are generally not covered by warranties and you may be charged for labour, parts, and lubricants used.

The electric control system in the vehicle may cause malfunction or other negative impact on an artificial heart or artificial internal organs. Be sure to inquire the impact of the electric control system on any artificial organs from the medical product corporation.

Owner maintenance schedule

When you stop for charging:

- Check the coolant level in the coolant reservoir.
- Check the windscreen washer fluid level.
- · Check for low or under-inflated tyres.

Whilst operating your vehicle:

- Check for vibrations in the steering wheel. Notice if there is any increased steering effort or looseness in the steering wheel, or change in its straight-ahead position.
- Notice if your vehicle constantly turns slightly or "pulls" to one side when travelling on smooth, level road.
- When stopping, listen and check for unusual sounds, pulling to one side, increased brake pedal travel, or "hard-to-push" brake pedal.
- If any slipping or changes in the operation of your gear shift occurs, check the shift gear fluid level.
- · Check the shift gear P (Park) function.
- · Check the parking brake.
- Check for fluid leaks under your vehicle (water dripping from the air conditioning system during or after use is normal).

At least monthly:

- Check the coolant level in the coolant reservoir.
- Check the operation of all exterior lights, including the headlamps, stoplights, turn signals, and hazard warning flashers.
- Check the inflation pressures of all tyres including the spare for tyres that are worn, show uneven wear, or are damaged.
- · Check for loose wheel nuts.

WARNING



Be careful when checking your coolant level if the motor compartment is hot. This may result in coolant being blown out of the opening and cause serious burns and other injuries.

At least twice a year:

- Check the radiator, heating, and air conditioning hoses for leaks or damage.
- Check the windscreen washer spray and wiper operation. Clean the wiper blades with a clean cloth dampened with washer fluid.
- Check the headlamps alignment.
- Check the seat belts for wear and function.

At least once a year:

- · Clean the body and door drain holes.
- Lubricate the door hinges and bonnet hinges.
- Lubricate the door, bonnet locks, and latches.
- · Lubricate door rubber weather strips.
- · Check the air conditioning system.
- Inspect and lubricate the shift gear linkage and controls.
- · Clean the battery (12 V) and terminals.
- · Check the brake fluid level.

Scheduled maintenance services

If any of the following conditions apply, follow the Maintenance Under Severe Usage Conditions.

- Repeatedly driving short distances of less than 8 km in normal temperatures or less than 16 km in freezing temperatures
- Driving on rough, dusty, muddy, unpaved, graveled, or salt-spread roads
- · Driving in areas using salt or other corrosive materials or in very cold weather
- Driving in heavy dust conditions
- Driving in heavy traffic areas with the ambient temperature higher than 32 °C whilst consuming more than 50 % of electric energy.
- Driving on uphill, downhill, or mountain roads repeatedly
- · Using for towing or camping, and driving with loading on the roof.
- Driving as a patrol car, taxi, or other commercial use or vehicle towing
- Frequently driving under high speed or rapid acceleration/deceleration
- · Frequently driving in stop-and-go conditions

If your vehicle is operated under the above conditions, you should inspect, replace or refill more frequently than the following Normal Maintenance Schedule. After the periods or distance shown in the chart, continue to follow the prescribed maintenance intervals.

Normal maintenance schedule

The following maintenance services must be performed to ensure good vehicle performance.

Keep receipts for all vehicle services to protect your warranty. Where both kilometres and time are shown, the frequency of service is determined by whichever occurs first.

I: Inspect and if necessary, adjust, correct, clean, or replace.

R: Replace or change.

	of months or driving distance, whichever comes first								
Maintenance intervals	Months	24	48	72	96	120	144	168	192
	km×1,000	30	60	90	120	150	180	210	240
Maintena	nce item								
Cooling system		I	I	I	I	I	I	I	I
Coolant*1	Standard	At first, replace at 195,000 km or 120 months after that, replace every 30,000 km or 24 months							
Low Replace every 60,000 km or 36		or 36 m	nonths*2						
Reduction gear	fluid		I		I		I		I
12 V auxiliary battery condition		Inspect 15,000 km or 12 months							
All electrical system		I	I	I	I	I	I	I	1
Brake lines, hos connections	es and	I	I	I	I	I	I	I	I
Brake pedal		I	I	I	I	I	I	I	I
Parking brake		I	I	I	I	I	I	I	I
Brake fluid		R	R	R	R	R	R	R	R
Brake discs and pads		I	I	I	I	I	I	I	I
Steering gear rack, linkage and boots		I	I	I	I	I	I	I	I
Driveshaft and boots		I	I	I	I	I	I	ı	I
Rotate tyres (includes tread wear inspection and tyre pressure check)		Rotate every 15,000 km or 12 months							
Front suspension	n ball joints	I	I	I	I	I	I	I	I

	Number o	of months or driving distance, whichever comes first							
Maintenance intervals	Months	24	48	72	96	120	144	168	192
	km×1,000	30	60	90	120	150	180	210	240
Maintena	nce item								
Bolt and nuts or body	n chassis and	I	I	I	I	I	I	I	I
Air conditioner	refrigerant	I	I	I	I	I	I	I	I
Air conditioner	compressor	I	I	I	I	I	I	I	I
Cabin air filter		R	R	R	R	R	R	R	R

^{*1:} When replacing or adding coolant, we recommend that you visit an authorised Genesis repairer.

^{*2 :} For your convenience, this can be replaced prior to its interval when you do maintenance of other items.

Maintenance under severe usage conditions

The following items must be serviced more frequently on the vehicles mainly used under severe and low mileage driving conditions. Refer to the chart below for the appropriate maintenance intervals.

I: Inspect and if necessary, adjust, correct, clean, or replace

R: Replace

Maintenance item	Maintenance operation	Maintenance Intervals	Driving condition
Cabin air filter	R	Replace more frequently depending on the condition	B, D, F
Disc brakes, pads and calipers	I	Inspect more frequently depending on the condition	B, C, D, E, F, G, H, I, J
Driveshaft and boots	I	Inspect more frequently depending on the condition	B, C, D, E, F, G, H, I
Front suspension ball joints	I	Inspect more frequently depending on the condition	B, C, D, E, F
Reduction gear fluid	R	Replace every 120,000 km	B, D, G, H
Steering gear rack, linkage and boots	I	Inspect more frequently depending on the condition	C, D, E, F, G

Severe driving conditions

- A. Repeatedly driving short distances of less than 8 km in normal temperatures or less than 16 km in freezing temperatures
- B. Driving on rough, dusty, muddy, unpaved, graveled, or salt-spread roads
- C. Driving in areas using salt or other corrosive materials or in very cold weather
- D. Driving in heavy dust conditions
- E. Driving in heavy traffic areas with the ambient temperature higher than 32 $^{\circ}$ C whilst consuming more than 50 $^{\circ}$ 0 of electric energy.
- F. Driving on uphill, downhill, or mountain roads repeatedly
- G. Using for towing or camping, and driving with loading on the roof
- H. Driving as a patrol car, taxi, or other commercial use or vehicle towing
- I. Frequently driving under high speed or rapid acceleration/deceleration.
- J. Frequently driving in stop-and-go conditions

Explanation of scheduled maintenance items

Cooling system

Check the cooling system components, such as radiator, coolant reservoir, hoses, and connections for leakage and damage. Replace any damaged parts.

Coolant

The coolant should be changed at the intervals specified in the maintenance schedule.

Reduction gear fluid

The reduction gear fluid should be inspected according to the intervals specified in the maintenance schedule.

Brake hoses and lines

Visually check for proper installation, chafing, cracks, deterioration, and any leakage. Replace any deteriorated or damaged parts immediately.

Brake fluid

Check the brake fluid level in the brake fluid reservoir. The level should be between the MIN and the MAX marks on the side of the reservoir. Use only hydraulic brake fluid conforming to DOT 4 specification.

Brake discs, pads and calipers

Check the pads, the disc, and the rotor for any excessive wear-out. Inspect calipers for any fluid leakage.

Drive shafts and boots

Check the drive shafts, boots and clamps for cracks, deterioration, or damage. Replace any damaged parts and, if necessary, repack the grease.

Suspension mounting bolts

Check the suspension connections for looseness or damage. Retighten to the specified torque.

Steering gear box, linkage & boots/lower arm ball joint


With the vehicle stopped and the vehicle off, check for excessive free-play in the steering wheel. Check the linkage for bends or damage. Check the dust boots and ball joints for deterioration, cracks, or damage. Replace any damaged parts.

Air conditioning refrigerant

Check the air conditioning lines and connections for leakage and damage.

Coolant

Checking the coolant level



[A] Low conductivity coolant [B] Standard coolant

Check the condition and connections of all cooling system hoses and heater hoses. Replace any swollen or deteriorated hoses.

The coolant level should be filled between the MAX (Maximum) and the MIN (Minimum) marks on the side of the coolant reservoir when the motor compartment is cool.

If the coolant is low, we recommend that you have the vehicle inspected by an authorised Genesis repairer.

▲ WARNING





The electric motor for the cooling fan may continue to operate or start up when the vehicle is not running and can cause serious injury.

Keep hands, clothing and tools away from the rotating fan blades of the cooling fan. The electric motor for the cooling fan is controlled by vehicle coolant temperature, refrigerant pressure and vehicle speed. As the vehicle coolant temperature decreases, the electric motor will automatically shut off. This is a normal condition.

A WARNING



Check the coolant level when the motor compartment is cooled. Coolant level is influenced by temperature, and if the coolant reservoir cap is removed when coolant temperature is high, hot coolant and steam may blow out under pressure causing serious injury.

A WARNING

Make sure the coolant cap is properly closed after refilling coolant. Otherwise, the motor may be overheated whilst driving.

1. Check if the coolant cap label is straight in front.

Motor compartment front view



Make sure that the tiny protrusions inside the coolant cap are securely interlocked.

Recommended coolant

- When adding coolant, use only deionized water, distilled water, or soft water for your vehicle and never mix hard water in the coolant filled at the factory.
- An incorrect coolant mixture may result in severe malfunction or motor damage.
- Do not use alcohol or methanol coolant or mix them with the specified coolant.
- Do not use a solution that contains more than 60 % antifreeze or less than 35 % antifreeze, which could reduce the effectiveness of the solution.

For mixing percentage, refer to the following table:

Ambient temperature	Mixture percentage (volume)			
temperature	Antifreeze	Water		
-15 °C (5 °F)	35	65		
-25 °C (-13 °F)	40	60		
-35 °C (-31 °F)	50	50		
-45 °C (-49 °F)	60	40		

i Information

If in doubt about the mix ratio, a 50 % water and 50 % antifreeze mix is the easiest to mix together because it is the same quantity for each.

Changing coolant

We recommend that the coolant be changed by an authorised Genesis repairer according to the Maintenance Schedule at the beginning of this chapter.

A WARNING

Do not use coolant or antifreeze in the washer fluid reservoir.

Coolant can severely obscure visibility when sprayed on the windscreen and may cause loss of vehicle control resulting in an accident.

Coolant may also cause damage to paint and body trim.

NOTICE

To prevent damage to motor parts, put a thick towel around the coolant cap before refilling the coolant to prevent the coolant from overflowing into motor parts.

Brake fluid

Checking the brake fluid level



Check the fluid level in the reservoir periodically. The fluid level must be between the **MAX** (Maximum) and **MIN** (Minimum) marks on the side of the reservoir.

Before removing the reservoir cap and adding brake fluid, clean the area around the reservoir cap thoroughly to prevent brake fluid contamination.

If the level is low, add the specified brake fluid to the **MAX** level. If the fluid level is excessively low or frequent additions are required, we recommend that the brake system be inspected by an authorised Genesis repairer.

A WARNING

If brake fluid gets in your eyes, flush your eyes with clean water for at least 15 minutes and get immediate medical attention.

NOTICE

- Do not allow brake fluid to contact the vehicle's body paint, because paint damage may occur.
- Never use brake fluid that has been exposed to open air for an extended time and dispose of it properly.
- Do not use a wrong type of brake fluid.
 A few drops of mineral based oil in your brake system may damage the brake system parts.

i Information

Use only the brake fluid specified in the "Recommended lubricants and capacities" section in chapter 2.

Reduction gear fluid

There is no reduction gear fluid level gauge in the vehicle. Check the reduction gear fluid every 60,000 km regularly. If the vehicle is driven under severe condition, check the maintenance under severe usage condition and we recommend that you consult an authorised Genesis repairer.

Washer fluid

Checking the washer fluid level



Check the fluid level in the washer fluid reservoir and add fluid if necessary. Plain water can be used if washer fluid is not available. However, use washer fluid with antifreeze in cold climates to prevent freezing.

WARNING

To prevent serious injury or death:

- Do not use coolant or antifreeze in the washer fluid reservoir. Coolant can severely limit your visibility when sprayed on the windscreen and may cause loss of vehicle control resulting in a collision.
- Do not allow sparks or flame to contact the washer fluid or the washer fluid reservoir. Washer fluid may contain alcohol and can be flammable.
- Do not drink washer fluid and avoid contact with skin.
- Keep washer fluid away from children and animals.

Cabin air filter

Filter inspection

The cabin air filter must be replaced according to the Maintenance Schedule. If the vehicle operates in severely air-polluted cities or on dusty rough roads for a long time, have it inspected more frequently and replaced immediately. Replace the cabin air filter by following the procedure below and be careful to avoid damaging other components.

Filter replacement

1. Open the glove box and remove the support rod (1).



2. Remove the stoppers on both sides to allow the glove box to hang open.



3. Press and hold the lock on the left side of the cover.

4. Pull out the cover.




- 5. Replace the cabin air filter.
- 6. Reassemble in the reverse order of disassembly.

Motor compartment


- 1. Open the bonnet.
- 2. Use a + screwdriver to remove the screws mounted on the air filter cover.

When removing the cover, make sure the [C] part remains still.




- [A] Screw removal [B] Screw mounting
- 3. Press and hold the lock on the left side of the cover.

4. Pull out the cover.



- 5. Replace the cabin air filter.
- 6. Reassemble in the reverse order of disassembly.



- [A] Glove box[B] Motor compartment

Install a new cabin air filter with the arrow symbol in the correct direction to improve effectiveness.

- · Glove box: Install with the arrow symbol facing downward (\downarrow).
- · Motor compartment: Install with the arrow symbol facing up (↑).

Wiper blades

Blade inspection

Contamination of either the windscreen or the wiper blades with foreign substances may reduce the effectiveness of the windscreen wipers.

Common sources of contamination are insects, tree sap, and hot wax treatments used by some commercial car washes. If the blades are not wiping properly, clean both the window and the blades with glass cleaner or mild detergent, and rinse thoroughly with clean water.

NOTICE

To prevent damage to the wiper blades, arms, or other components, do not:

- Use petrol, kerosene, paint thinner, or other solvents on or near them.
- · Attempt to move the wipers manually.

Blade replacement

When the wipers no longer clean adequately, the blades may be worn or cracked. Replace the wipers with new ones.

NOTICE

To prevent damage:

- · Never use non-specified wiper blades.
- Lift the wiper arms when in the top wiping position.
- Always return the wiper arms to the windscreen before driving.


Front windscreen wiper blade

This vehicle has a "hidden" wiper design that cannot be lifted when in their bottom resting position.


 Within 20 seconds of turning off the vehicle, push and hold the wiper lever down to the MIST position for about 2 seconds until the wipers move to the top wipe position.



- 2. Lift the wipers off the windscreen.
- 3. Disassemble the washer fluid hose by pulling downward whilst bending down the end of blade.



4. Disassemble it by pulling upward whilst pressing the groove (1) located on the side of the wiper blade.



- 5. Install the new wiper blade assembly in the reverse order of removal.
- 6. Gently put down the wiper back onto the windscreen.
- 7. Turn the wipers to any ON position to return the wiper arms to the bottom resting position.

Battery (12 V)

▲ WARNING

To prevent serious injury or death to you or bystanders when working near or handling the battery:

Always read and follow instructions carefully when handling a battery.



Wear eye protection designed to protect the eyes from acid splashes.



Keep all flames, sparks, or smoking materials away from the battery.



Hydrogen gas is always present in battery cells. It is highly combustible, and may explode if ignited.



Keep batteries out of reach of children.



Batteries contain sulphuric acid that is highly corrosive. Do not allow acid to contact your eyes, skin or clothing.

If acid gets into your eyes, flush your eyes with clean water for at least 15 minutes and get immediate medical attention. If acid gets on your skin, thoroughly wash the area. If you feel pain or a burning sensation, get medical attention immediately.



- Lift a battery with a battery carrier or with your hands on opposite corners. When lifting a plastic-cased battery, excessive pressure on the case may cause battery acid to leak.
- Do not attempt to jump start your vehicle if your battery is frozen.
- Never attempt to recharge the battery when the vehicle's battery cables are connected to the battery.
- The electrical ignition system works with high voltage. NEVER touch these components with the READY indicator ON or when the Start/Stop button is in the DRIVE READY position.

NOTICE

To prevent battery damage:

- Always fully charge the battery and store indoors when you do not plan to use the vehicle for a long time if the outside temperature is low enough to cause the battery to freeze.
- Always fully charge the battery to prevent battery case damage in low temperature areas.
- Prevent liquid from wetting the battery terminals.
- · Do not tilt the battery.
- Never connect unauthorised devices to the battery.

For best battery service



- Keep the battery securely mounted.
- Keep the battery top clean and dry.
- Keep the terminals and connections clean, tight, and coated with petroleum jelly or terminal grease.
- Rinse any spilled electrolyte from the battery immediately with a solution of water and baking soda.
- If the vehicle is not going to be used for an extended period of time, disconnect the battery cables.
- Inspect the battery frequently and keep the battery clean at all times. Leaving the battery contaminated will shorten battery life.

 Before recharging the battery or performing any inspections, turn off the vehicle and turn off all electrical equipment.

i Information

Open the battery cover to check the batteries.

Battery replacement

12 V battery



When replacing the battery, disconnect the negative (-) cable (1) and remove the positive (+) battery fuse box (2).

i Information

To check the batteries, open the cover. The clips must be removed first to open the cover.

Battery capacity label



- 1. The Genesis vehicle model name of battery
- 2. The nominal capacity (in Ampere hours)
- 3. The nominal reserve capacity (in min.)
- 4. The normal voltage
- 5. The cold-test current in amperes by SAF / FN

Battery recharging

By battery charger

Should your vehicle's battery become discharged either run the motor for at least 60 minutes driving. Alternatively you may connect a fully automatic regulated charger to the motor compartment front jumper posts or at the battery in the boot.

▲ WARNING

To prevent the risk of serious injury or death from explosions or acid burns:

- Before performing maintenance or recharging the battery, turn off all accessories and stop the vehicle.
- Keep all flames, sparks, or smoking materials away from the battery.
- Always work outdoors or in an area with plenty of ventilation.
- Wear eye protection when checking the battery during charging. Do not contact the battery. This may result in serious injury.
- Remove the battery from the vehicle and place it in a well ventilated area.

- Watch the battery during charging, and stop or reduce the charging rate if the battery cells begin boiling violently.
- Remove the negative battery cable first and install it last when the battery is disconnected. Disconnect the battery charger in the following order:
 - 1. Turn off the battery charger main switch.
 - 2. Unhook the negative clamp from the negative battery terminal.
 - 3. Unhook the positive clamp from the positive battery terminal.

NOTICE

AGM battery

Absorbent Glass Mat (AGM) batteries are maintenance-free and should be serviced by an authorised Genesis repairer. Only charge using fully automatic battery chargers that are specifically for AGM batteries.

A CAUTION

Do not open or remove the cap on top of the battery. This may cause leaks of internal electrolyte that could result in serious injury.

By jump starting

After a jump start from a good battery, drive the vehicle for 20-30 minutes before it is shutoff. The vehicle may not restart if you shut it off before the battery had a chance to adequately recharge.

Refer to the "Jump starting (12 V Battery)" section in chapter 8 for more information on jump starting procedures.

i Information



An inappropriately disposed battery may be harmful to the environment and human health. Always dispose used batteries in accordance with local law(s) or regulations.

Reset items

The following items may need to be reset after the battery has been discharged or disconnected:

- Current trip/After charging/Since last reset(items in Utility view) (refer to chapter 4)
- Integrated memory system (refer to chapter 5)
- Power windows (refer to chapter 5)
- Power boot (refer to chapter 5)
- Automatic climate control system (refer to chapter 5)
- Rear side window sunshades (refer to chapter 5)
- Clock (refer to the Infotainment system manual)
- Infotainment system (refer to the Infotainment system manual)

Tyres and wheels

A WARNING

Tyre failure may cause loss of vehicle control and result in a collision. To reduce risk of serious injury or death:

- Inspect your tyres monthly for proper inflation as well as wear and damage.
- The recommended cold tyre pressure for your vehicle can be found in this manual and on the tyre label located on the driver's side centre pillar. Always use a tyre pressure gauge to measure tyre pressure. tyres with too much or too little pressure wear unevenly causing poor handling.
- Check the pressure of the spare every time you check the pressure of the other tyres on your vehicle.
- Replace tyres that are worn, show uneven wear, or are damaged. Worn tyres may cause loss of braking effectiveness, steering control, or traction.
- Always replace tyres with the same size, type, construction, and tread pattern as each tyre that was originally supplied with this vehicle. Using tyres and wheels other than the recommended sizes may cause unusual handling characteristics, poor vehicle control, or negatively affect your vehicle's Anti-Lock Brake System (ABS).

Tyre care

For proper maintenance, safety, and maximum electric energy economy, always maintain the recommended tyre inflation pressures and stay within the load limits and weight distribution recommended for your vehicle.



All specifications (sizes and pressures) can be found on a label attached to the driver's side centre pillar.

Recommended cold tyre inflation pressures

Check all tyre pressures (including the spare) when the tyres are cold. "Cold tyres" mean the vehicle has not been driven for at least three hours or driven less than 1.6 km.

Warm tyres normally exceed the recommended cold tyre pressures by 28 to 41 kPa (4 to 6 psi). Do not release air from warm tyres to adjust the pressure. The tyres are under-inflated. For the recommended inflation pressure, refer to the "Tyres and wheels" section in chapter 2.

▲ WARNING

- Recommended pressures must be maintained for the best ride, vehicle handling, and minimum tyre wear.
- Over-inflation or under-inflation can reduce tyre life, adversely affect vehicle handling, and lead to sudden tyre failure that may result in loss of vehicle control resulting in a collision.
- Severe under-inflation may lead to severe heat build-up, causing blowouts, tread separation, and other tyre failures that result in the loss of vehicle control resulting in a collision. This risk is much higher on hot days and when driving for long periods at high speeds.
- Under-inflation may cause excessive wear, poor handling, and reduced electric energy economy. Wheel deformation is also possible. Keep your tyre pressures at the proper levels. If a tyre frequently needs refilling, we recommend that it be inspected by an authorised Genesis repairer.
- Over-inflation produces a harsh ride, excessive wear at the centre of the tyre tread, and a greater possibility of damage from road hazards.

Check tyre inflation pressure

Check your tyres at least once a month or more.

How to check

Use a good quality tyre pressure gauge to check the tyre pressure. You cannot tell if your tyres are properly inflated simply by looking at them. Radial tyres may look properly inflated when they are under-inflated.

Remove the valve cap from the tyre valve stem. Press the tyre gauge firmly onto the valve to get a pressure measurement. If the cold tyre inflation pressure matches the recommended pressure on the tyre and loading information label, no further adjustment is necessary. If the pressure is low, add air until it reaches the recommended pressure. Make sure to put the valve caps back on the valve stems. Without the valve cap, dirt or moisture could get into the valve core and cause air leakage. If a valve cap is missing, install a new one as soon as possible.


If you overfill the tyre, release air by pushing on the metal stem in the centre of the tyre valve. Recheck the tyre pressure with the tyre gauge. Be sure to put the valve caps back on the valve stems. Without the valve cap, dirt or moisture may get into the valve core and cause air leakage. If a valve cap is missing, install a new one as soon as possible.

Tyre rotation

To equalize tread wear, Genesis vehicle recommends that the tyres be rotated every 10,000 km or sooner if irregular wear develops.

During rotation, check the tyres for correct balance.

When rotating tyres, check for uneven wear and damage. Abnormal wear is usually caused by incorrect tyre pressure, improper wheel alignment, out-of-balance wheels, severe braking, or severe cornering. Look for bumps or bulges in the tread or side of the tyre. Replace the tyre if you find any of these conditions. Replace the tyre if fabric or cord is visible. After rotation, be sure to bring the front and rear tyre pressures to specification and check wheel bolt torque (proper torque is 14-16 kgf·m [101-116 lbf·ft]).



Disc brake pads should be inspected for wear whenever tyres are rotated.

i Information

When installing an unsymmetrical tyre, install the side marked "outside" facing out.

WARNING

- Do not use the compact spare tyre for tyre rotation.
- Do not mix bias ply and radial ply tyres under any circumstances. This may cause unusual handling characteristics that may cause loss of vehicle control and result in a collision.

Wheel alignment and tyre balance

The wheels on your vehicle were aligned and balanced carefully at the factory and you may not need to have your wheels aligned again. If you notice unusual tyre wear or your vehicle pulling to one side, the alignment may need to be adjusted.

If you notice your vehicle vibrating when driving on a smooth road, your wheels may need to be rebalanced.

NOTICE

Only use approved wheel weights or your vehicle's aluminium wheels may be damaged.

Tyre replacement



[A] Tread wear Indicator

If the tyre is worn evenly, a tread wear indicator appears as a solid band across the tread. This shows there is less than 1.6 mm of tread left on the tyre. Replace the tyre when this happens.

Do not wait for the band to appear across the entire tread before replacing the tyre.

A WARNING

To reduce the risk of serious injury or death:

- Replace tyres that are worn, show uneven wear, or are damaged. Worn tyres may cause loss of braking effectiveness, steering control, and traction.
- Always replace tyres with the same size as of tyre that was originally supplied with this vehicle. Using tyres and wheels other than the recommended sizes may cause unusual handling characteristics, poor vehicle control, or negatively affect your vehicle's Anti-Lock Brake System (ABS).
- When replacing tyres (or wheels), it is recommended to replace the two front or two rear tyres (or wheels) as a pair.
 Replacing just one tyre may seriously affect your vehicle's handling.

- Tyres degrade over time, even when they are not being used. Regardless of the remaining tread, Genesis vehicle recommends that tyres be replaced after six (6) years.
- Driving in hot climates or excessive loading may accelerate the tyre aging process.

Wheel replacement

When replacing the metal wheels for any reason, make sure the new wheels are equivalent to the original factory units in diameter, rim width, and offset.

Tyre traction

Tyre traction can be reduced if you drive on worn tyres or the tyres that are improperly inflated, or on slippery road surfaces. Replace the tyres when tread wear indicators appear. To reduce the possibility of losing control, slow down whenever there is rain, snow, or ice on the road.

Tyre maintenance

In addition to proper inflation, correct wheel alignment helps decrease tyre wear. If you find a tyre is worn unevenly, have your dealer check the wheel alignment.

When you have new tyres installed, make sure they are balanced. This may increase ride comfort and tyre life. Additionally, a tyre must always be rebalanced if it is removed from the wheel.

Tyre sidewall labelling

This information identifies and describes the fundamental characteristics of the tyre and also provides the tyre identification number (TIN) for safety standard certification. The TIN can be used to identify the tyre in case of a recall.



1. Manufacturer or brand name Manufacturer or brand name is shown.

2. Tyre size designation

A tyre's sidewall is marked with a tyre size designation. You need this information when selecting replacement tyres for your vehicle. The following explains what the letters and numbers in the tyre size designation mean.

Example tyre size designation:

(These numbers are provided as an example only. Your tyre size designator may vary depending on your vehicle.)

245/45R19 101H

245 - Tyre width in millimeters.

45 - Aspect ratio. The tyre's section height as a percentage of its width.

R - Tyre construction code (Radial).

19 - Rim diameter in inches.

101 - Load Index, a numerical code associated with the maximum load the tyre can carry.

H - Speed Rating Symbol. See the speed rating chart in this section for additional information.

Wheel size designation

Wheels are also marked with important information that you need if you ever have to replace one.

Example wheel size designation:

8.5J X 20

8.5 - Rim width in inches.

J - Rim contour designation.

20 - Rim diameter in inches.

Tyre speed ratings

The chart below lists many different speed ratings currently being used for passenger vehicle tyres. The speed rating is part of the tyre size designation on the sidewall of the tyre. This symbol corresponds to that tyre's designed maximum safe operating speed.

Speed rating symbol	Maximum speed	
S	180 km/h	
Т	190 km/h	
Н	210 km/h	
V	240 km/h	
W	270 km/h	
Y	300 km/h	

3. Checking tyre life (TIN: Tyre Identification Number)

Any tyres that are over six years old, based on the manufacturing date, (including the spare tyre) should be replaced by new ones. You can find the manufacturing date on the tyre sidewall (possibly on the inside of the wheel), displaying the DOT Code. The DOT Code is a series of characters on a tyre consisting of numbers and English letters. The manufacturing date is designated by the last four digits (characters) of the DOT code.

DOT: XXXX XXXX OOOO

The front part of the DOT shows a plant code number, tyre size, and tread pattern and the last four numbers indicate week and year manufactured.

For example:

DOT XXXX XXXX 1524 represents that the tyre was produced in the 15th week of 2024.

4. Genesis exclusive tyre

Genesis vehicle recommends that tyres designed specifically for Genesis vehicles be used. You may find the marking "GOE" (Genesis Original Equipment) embossed on the tyre sidewall.

5. Tyre ply composition and material

The number of layers or plies of rubber-coated fabric in the tyre. tyre manufacturers also must indicate the materials in the tyre, which include steel, nylon, polyester, and others. The letter "R" means radial ply construction; the letter "D" means diagonal or bias ply construction. The letter "B" means belted-bias ply construction.

6. Maximum permissible inflation pressure

This number is the greatest amount of air pressure that should be put in the tyre. Do not exceed the maximum permissible inflation pressure. Refer to the tyre and Loading Information label for recommended inflation pressure.

7. Maximum load rating

This number indicates the maximum load in kilograms and pounds that can be carried by the tyre. When replacing the tyres on the vehicle, always use a tyre that has the same load rating as the factory installed tyre.

8. Uniform tyre quality grading

Quality grades can be found where applicable on the tyre sidewall between tread shoulder and maximum section width.

For example: TREADWEAR 200 TRACTION AA TEMPERATURE A

Tread wear

The tread wear grade is a comparative rating based on the wear rate of the tyre when tested under controlled conditions on a specified government test course. For example, a tyre graded 150 would wear one-and-a-half times (1½) as well on the government course as a tyre graded 100.

The relative performance of tyres depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices, and differences in road characteristics and climate.

These grades are molded on the sidewalls of passenger vehicle tyres. The tyres available as standard or optional equipment on your vehicle may vary depending on the grade.

Traction - AA, A, B & C

The traction grades, from highest to lowest, are AA, A, B, and C. Those grades represent the tyre's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tyre marked C may have poor traction performance.

A WARNING

The traction grade assigned to this tyre is based on straight ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

Temperature - A, B & C

The temperature grades are A (the highest), B, and C representing the tyre's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel.

Sustained high temperature may cause the material of the tyre to degenerate and reduce tyre life, and excessive temperature may lead to sudden tyre failure. Grades B and A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

▲ WARNING

The temperature grade for this tyre is established for a tyre that is properly inflated and not overloaded. Excessive speed, under-inflation, over-inflation, or excessive loading, either separately or in combination, may cause heat build-up and possible sudden tyre failure.

Low aspect ratio tyres

tif equipped

The aspect ratio is lower than 50 on low aspect ratio tyres.

Because low aspect ratio tyres are optimised for handling and braking, their sidewall is a little stiffer than a standard tyre. Also, low aspect ratio tyres tend to be wider and consequently have increased contact with the road surface. In some instances, low aspect ratio tyres may generate more road noise compared with standard tyres.

A CAUTION

Low aspect wheels and tyres are easily damaged. To reduce the risk of damage:

- When driving on rough roads, passing over a pothole, speed bump, manhole, or kerb stone, drive the vehicle slowly not to damage the tyres and wheels.
 Damage is not covered by your vehicle warranty.
- Inspect the tyre condition and pressure every 3,000 km.
- It is difficult to visually inspect for tyre damage with your eyes. If any damage is found, we recommend that you contact an authorised Genesis repairer.

Summer tyres

Genesis vehicle specifies summer tyres on some models to provide superior performance on dry roads. Summer tyre performance is substantially reduced in snow and ice. Summer tyres do not have the tyre traction rating M+S (Mud and Snow) on the tyre side wall. If you plan to operate your vehicle in snowy or icy conditions, Genesis vehicle recommends the use of snow tyres or all season tyres on all four wheels.

Fuses

Blade type






Cartridge type





Multi type



Midi type



A vehicle's electrical system is protected from electrical overload damage by fuses.

This vehicle has 4 fuse panels, one located in the driver's side panel bolster and the others in the motor compartment and luggage compartment.

If any of your vehicle's lights, accessories, or controls do not work, check the appropriate circuit fuse. If a fuse has blown, the element inside the fuse is melted or broken.

If the electrical system does not work, first check the driver's side fuse panel. Before replacing a blown fuse, turn off the vehicle and all switches, and then disconnect the negative battery cable. Always replace a blown fuse with one of the same rating.

If the replacement fuse blows, this indicates an electrical problem. Avoid using the system involved and we recommend that you contact an authorised Genesis repairer.

A WARNING

Never replace a fuse with anything but another fuse of the same rating.

- A higher capacity fuse may cause damage and possibly cause a fire.
- Do not install a wire or aluminium foil instead of the proper fuse - even as a temporary repair. It may cause extensive wiring damage and possibly a fire.

NOTICE

Do not use a screwdriver or any other metal object to remove fuses because it may cause a short circuit and damage the system.

Instrument panel fuse replacement





luggage compartment



- 1. Turn off the vehicle.
- 2. Turn off all other switches.
- 3. Open the fuse panel cover.
- Refer to the label on the inside of the fuse panel cover to locate the suspected fuse location.
- Pull the suspected fuse straight out. Use the removal tool provided in the motor compartment fuse panel cover.



- 6. Check the removed fuse and replace it if it is blown. Spare fuses are provided in the instrument panel fuse panels (or in the motor compartment fuse panel).
- 7. Push in a new fuse of the same rating, and make sure it fits tightly in the clips. If it is not tight, we recommend that you contact an authorised Genesis repairer.


In an emergency, if you do not have a spare fuse, use a fuse of the same rating from a circuit you may not need for operating the vehicle.

If the headlamps or other electrical components do not work and the fuses are undamaged, check the fuse panel in the motor compartment.

Motor compartment panel fuse replacement

Blade fuse/Cartridge fuse

Blade type fuse



Cartridge type fuse



- 1. Turn off the vehicle.
- 2. Turn off all other switches.
- 3. Remove the fuse panel cover by pressing the tap and pulling up.
- Refer to the label on the inside of the fuse panel cover to locate the suspected fuse location.
- Pull the suspected fuse straight out. Use the removal tool provided in the motor compartment fuse panel.
- 6. Check the removed fuse and replace it if it is blown. To remove or insert the fuse, use the removal tool in the motor compartment fuse panel.
- 7. Push in a new fuse of the same rating, and make sure it fits tightly in the clips. If it is not tight, we recommend that you contact an authorised Genesis repairer.

NOTICE

Always securely install the fuse panel cover. Water may contact the fuse and cause an electrical failure.

Multi fuse/Midi fuse

Multi type



Midi type



If the multi fuse or midi fuse is blown, we recommend that you contact an authorised Genesis repairer.

Fuse/relay panel description


Instrument panel fuse panel



Inside the fuse panel cover, you can find the panel label describing fuse names and ratings.

i Information

Not all fuse panel descriptions in this manual may be applicable to your vehicle. When you inspect the fuse panel on your vehicle, refer to the fuse panel label.



Instrument panel fuse panel

Fuse Name	Symbol	Fuse Rating	Circuit Protected
CURTAIN		10 A	BDC
A/C	A/C	7.5 A	Rear Junction Block (Blower #2 Relay), Front/Rear A/C Controller, A/C Control Module
BRAKE SWITCH	BRAKE SWITCH	7.5 A	Stop Light Switch, BDC

Fuse Name	Symbol	Fuse Rating	Circuit Protected
MEMORY1	1 MEMORY	10 A	CDCU, ADAS Unit (Parking), Front/Rear Smart Phone Wireless Charger, Rear Corner Radar LH/RH, Driver/Passenger Door Mood Lamp Unit, Rear Door Mood Lamp Unit LH/RH, Front A/C Control Module, CCIC Keyboard, A/C Control Module, Mood Lamp Module, Rear Door Curtain Unit, Console Mood Lamp LH/RH, Crash Pad Mood Lamp LH/RH
A/BAG IND	IND C	7.5 A	NOT USED
PRESAFETY SEAT BELT	PRESAFETY SEAT BELT	10 A	Pre-Active Seat Belt Unit
MODULE 8	8 MODULE	10 A	Data Link Connector, Rain Sensor, ICC Unit, Multifunction Switch, A/C Control Module, Steering Tilt & Telescopic Unit
E-SHIFTER 2	2 E-SHIFTER	10 A	Electronic Shift Dial, SCU
CCU	CCU	10 A	CCU
MEMORY 2	2 MEMORY	7.5 A	Rear A/C Controller, Head-Up Display, BDC, Security Indicator
BDC 1	¹ BDC	7.5 A	BDC
MODULE 2	2 MODULE	10 A	CCU, Stop Light Switch
POWER HANDLE	POWER HANDLE	15 A	Steering Tilt & Telescopic Unit
MULTI MEDIA	MULTI MEDIA	25 A	CCIC Head Unit

Fuse Name	Symbol	Fuse Rating	Circuit Protected
MODULE 4	4 MODULE	10 A	AMP, CCRC RH, Inverter (Rear), Driver/Passenger Power Seat Module, Rear Seat Console Switch, Rear Seat LH/RH Module, Front/Rear Smart Phone Wireless Charger, UVC Lamp Unit, Data Link Connector, Electro Chromic Mirror, Armrest Heater Unit, CCIC Keyboard, ICC Unit, CCIC Head Unit, DCU
CLUSTER	CLUSTER	7.5 A	Front Monitor, Head-Up Display
MASSAGE SEAT (RR)	MASSAGE SEAT (RR)	15 A	Rear Seat LH/RH Lumbar Support Unit
SBCM (DRV)	SBCM (DRV)	20 A	Driver SBCM
MODULE 7	7 MODULE	7.5 A	Head Lamp LH/RH
POWER TRUNK	€	10 A	Boot Latch Motor
AMP 2	² AMP	15 A	CCRC RH
MODULE 5	5 MODULE	10 A	Driver Door Module, Multifunction Switch
E-SHIFTER 1	1 E-SHIFTER	7.5 A	Electronic Shift Dial, SCU
MODULE 1	1 MODULE	10 A	Front Monitor, CCU, CCIC Head Unit, Front Console Keyboard, DCU, BDC, Armrest Lamp, Electronic Shift Dial, CCRC RH, AMP, ADAS Unit (Parking), Rear Seat Console USB Charger, Rear Seat Console Switch
POWER SEAT (PASS 1)	1 PASS	30 A	Passenger Power Seat Module
S/HEATER (DRV)	DRV	25 A	Driver Power Seat Module

Fuse Name	Symbol	Fuse Rating	Circuit Protected
WIPER	\Box	10 A	Multifunction Switch
AIR BAG 2	² O ,;	10 A	SRS Control Module
BDC 2	² BDC	10 A	BDC, Driver/Passenger Door Outside Handle, Rear Door Outside Handle LH/RH
AIR BAG 1	10%	10 A	SRS Control Module
POWER SEAT (PASS 2)	2PASS	25 A	Passenger Power Seat Module
S/HEATER (PASS)	PASS	20 A	Passenger Power Seat Module
MODULE 6	6 MODULE	7.5 A	BDC
WIRELESS DCU	wireless DCU	10 A	DCU
POWER SEAT (RR RH 2)	2 RR RH	25 A	Rear Seat RH Module
SBCM (PASS)	SBCM (PASS)	20 A	Passenger SBCM
HEATED ARMREST	ARMREST HTD	15 A	Armrest Heater Unit
MODULE 3	3 MODULE	10 A	Crash Pad Switch, ADAS Unit (Driving), Steering Tilt & Telescopic Unit, Front Console Switch, LKAS Unit, ECS Unit, ADAS Unit (Parking), Rear Corner Radar LH/RH, RWS Module, CDCU
POWER SEAT (DRV 1)	1 DRV	30 A	Driver Power Seat Module

Fuse Name	Symbol	Fuse Rating	Circuit Protected
P/WINDOW LH	LH	30 A	Front Power Window Module LH, Rear Power Window Module LH
MODULE 9	9 MODULE	10 A	VESS Unit, Driver/Passenger Power Outside Mirror, Driver Door Module, PTL Unit, Driver/Passenger Power Seat Module, Driver/Passenger Lumbar Support Unit, Driver/Passenger Power Seat Switch, Rear Seat LH/RH Power Switch, Rear Seat LH/RH Lumbar Support Unit, Rear Seat LH/RH Module, Rear Seat LH/RH Heater Unit, P/R Junction Block (RLY. 1/5)
POWER SEAT (RR RH 1)	1 RR RH	25 A	Rear Seat RH Module
POWER SEAT	←	10 A	Driver/Passenger Lumbar Support Unit
POWER SEAT (RR LH 2)	2RR LH	25 A	Rear Seat LH Module
POWER SEAT (DRV 2)	2 _{DRV}	25 A	Driver Power Seat Module


Motor compartment fuse panel



Inside the fuse panel cover, you can find the panel label describing fuse names and ratings.

i Information

Not all fuse panel descriptions in this manual may be applicable to your vehicle. When you inspect the fuse panel on your vehicle, refer to the fuse panel label.



9-39

Motor compartment fuse panel

Туре	Fuse Name	Symbol	Fuse Rating	Circuit Protected
	LDC	LDC	225 A	ICCU
MINE	B+9	9 = +	150 A	P/R Junction Block (Fuse: F7/F8/F9/F10/F11/S1/S2/S3), PCB Block (Fuse: S1/S2/S3/S4)
	MDPS 1	1	125 A	MDPS Unit
	COOLING FAN	*	100 A	Cooling Fan Motor
	REAR HEATED	<u> </u>	80 A	RLY.5
	IEB 1	1 IEB	60 A	IEB Unit
	IEB 2	² IEB	60 A	IEB Unit
MULTI	BLOWER	SS	50 A	RLY.1
WOET	IEB 3	3 IEB	50 A	IEB Unit
	E-SHIFTER	E-SHIFTER	40 A	SCU
	EOP 2	² EOP	40 A	Traction Motor Oil Pump (Rear)
	VCU 1	1 VCU	30 A	VCU
	WIPER	∇	30 A	Wiper Motor

Туре	Fuse Name	Symbol	Fuse Rating	Circuit Protected
	B+2	2 - +	40 A	P/R Junction Block (Fuse: F12/F13/F15), PDC (IPS11, IPS12)
SB	HEAD LAMP LH	LH HEAD LAMP	40 A	Headlight LH
05	EOP1	1 EOP	40 A	Traction Motor Oil Pump (Front)
	HEAD LAMP RH	RH HEAD LAMP	40 A	Headlight RH
	OBC	ОВС	10 A	VCMS, ICCU
	HORN	Þ	15 A	PCB Block (Horn Relay)
	INVERTER 1	I INVERTER	10 A	Inverter (Front)
	BMS	BMS	15 A	вми
MICRO	EWP1	1 EWP	20 A	Electronic Water Pump (BSA)
·····erte	B/ALARM	1	15 A	PCB Block (B/Horn Relay)
	EWP 2	² EWP	20 A	Electronic Water Pump (Radiator)
	IG 3 (8)	8 IG3	20 A	RLY.4
	VCU 2	² VCU	20 A	VCU
	CHARGER HTD 1	¹ CHARGER HTD	10 A	Charged Door Module LH

Туре	Fuse Name	Symbol	Fuse Rating	Circuit Protected
	CHARGER 1	1 CHARGER	10 A	Charged Door Module LH
	POWER OUTLET	POWER OUTLET	20 A	Armrest Power Outlet
	ACTIVE HOOD 2	23/	10 A	Active Bonnet Control Unit
	CHARGER 2	2 CHARGER	10 A	NOT USED
	CHARGER HTD 2	² CHARGER HTD	10 A	NOT USED

Fuse Name	Symbol	Fuse Rating	Circuit Protected
IEB 4	4 IEB	10 A	IEB Unit
IG 3 (6)	⁶ IG3	10 A	Front/Rear A/C Controller, A/C PTC Heater, Front Monitor, DCU, CCRC RH, A/C Control Module, Incar Temperature Sensor, Incar PM Sensor, CCIC Head Unit, Coolant Valve, Electronic A/C Compressor
EWP 3	³ EWP	15 A	Electronic Water Pump (BSA/Radiator/PEM), Coolant 3way Valve (BSA)
IG 3 (4)	4 IG3	10 A	VCU
VCU 4	⁴ VCU	10 A	VCU
MODULE 1	1 MODULE	10 A	Front Radar, Front Corner Radar LH/RH, Inverter (Front)
MDPS 2	² ⊕	10 A	MDPS Unit
ACTIVE HOOD 1	126	10 A	Active Bonnet Control Unit
IG 3 (3)	³ IG3	10 A	Traction Motor Oil Pump (Front/Rear), ICCU, BMU, Inverter (Rear)
IG 3 (7)	7 IG3	10 A	VCMS, CCU, IPS Control Module
IG 3 (2)	² IG3	10 A	SCU, Cooling Fan Motor, Inverter (Front)
WASHER	\Diamond	15 A	Washer Relay
IG 1	IG1	30 A	IG1 Relay

Fuse Name	Symbol	Fuse Rating	Circuit Protected
IG 3 (1)	1 IG3	30 A	IG3 relay
IG 2	IG2	30 A	IG2 Relay
ACC	ACC	30 A	ACC Relay


Boot fuse panel (Rear sub junction block)



Inside the fuse panel cover, you can find the panel label describing fuse names and ratings.

i Information

Not all fuse panel descriptions in this manual may be applicable to your vehicle. When you inspect the fuse panel on your vehicle, refer to the fuse panel label.



9-45

Boot fuse panel (Rear sub junction block)

Fuse Name	Symbol	Fuse Rating	Circuit Protected
B+4	4 = +	50 A	PDC (Long Term Load Latch Relay , IPS13, Fuse: F4/F5/F12/F13/F21/F28/F37/F47/F55)
B+5	5 - +	50 A	PDC (Fuse: F29/F36/F46/F48/F49/F53/F56)
B+1	1 = +	50 A	PDC (IPS4, IPS5, IPS6, IPS7)
B+3	3 = +	50 A	PDC (Fuse: F1/F9/F10/F17/F18/F25/F26/F33/F34/F43/F44/F51/ F52/F58/F59)
P/DOOR (PASS)	P/DOOR (RASS)	15 A	Passenger Door Latch
CHARGER	CHARGER	15 A	Charging Connector Lock/Unlock Relay
PDS (RR LH)	RR LH	25 A	Rear Power Door Closing Actuator LH
P/WINDOW RH	RH	30 A	Rear Power Window Module RH Driver Power Window Module
PDS (RR RH)	RR RH	25 A	Rear Power Door Closing Actuator RH
AMP	AMP	25 A	AMP
RR DR CURTAIN	RR DR CURTAIN	15 A	Rear Door Curtain Unit
SBCM (RR LH)	SBCM (RR LH)	20 A	Rear SBCM LH
SBCM (RR RH)	SBCM (RR RH)	20 A	Rear SBCM RH

Fuse Name	Symbol	Fuse Rating	Circuit Protected
PRESAFETY SEAT BELT 1	1 PRESAFETY SEAT BELT	30 A	Pre-Active Seat Belt Unit
BLOWER 2	² &	20 A	Blower #2 Relay
ECS	ECS	15 A	ECS Unit
PRESAFETY SEAT BELT 2	2 PRESAFETY SEAT BELT	30 A	Pre-Active Seat Belt Unit
POWER SEAT (RR LH 1)	1 RR LH	30 A	Rear Seat LH Module
P/DOOR (DRV)	P/DOOR (DRV)	15 A	Driver Door Latch
INVERTER 2	2 INVERTER	10 A	Inverter (Rear)
SEAT HEATER (RR LH)	RR LH	30 A	Rear Seat LH Module, Rear Seat LH Heater Unit
POWER TRUNK	€\$1	30 A	PTL Unit
SEAT HEATER (RR RH)	RR RH	30 A	Rear Seat RH Module, Rear Seat RH Heater Unit

Boot fuse panel (Battery junction block)



Inside the fuse panel cover, you can find the panel label describing fuse names and ratings.

i Information

Not all fuse panel descriptions in this manual may be applicable to your vehicle. When you inspect the fuse panel on your vehicle, refer to the fuse panel label.



Boot fuse panel (Battery junction block)

Fuse Name	Symbol	Fuse Rating	Circuit Protected
RWS	후륜조향시스템 RWS	100 A	RWS Module
B+8	8 = +	100 A	Rear Junction Block (Fuse: S1/S2/F1/F5/F8/F11/F14/F17/F20)
B+7	7 📑	100 A	Rear Junction Block (Fuse: S4/F16/F22/F24/F25/F26)
B+6	6 -+	100 A	Rear Junction Block (Fuse: S3/F3/F6/F9/F12/F15/F18/F21/F23)
AMS	발전제어 AMS	10 A	12 V Battery Sensor
AUX BATT	보조 배터리 AUX BATT	50 A	NOT USED

Light bulbs

We recommend that you contact an authorised Genesis repairer to replace most vehicle light bulbs. It is difficult to replace vehicle light bulbs because other parts of the vehicle must be removed before you can get to the bulb. This is especially true for removing the headlamp assembly to get to the bulb(s). Removing/installing the headlamp assembly can result in damage to the vehicle.

WARNING

- Prior to replacing a light, press the brake pedal, shift to P (Park), apply the parking brake, press the Start/Stop button to the OFF position, and take the key with you when leaving the vehicle to avoid sudden movement of the vehicle and to prevent possible electric shock.
- Be aware the bulbs may be hot and may burn your fingers.

NOTICE

- Be sure to replace any burned-out bulb with one of the same wattage to prevent damage to the fuse or electrical wiring system.
- To prevent damage, do not clean the headlamp lens with chemical solvents or strong detergents.

i Information

Headlamp desiccant (if equipped)
This vehicle is equipped with desiccant to reduce fogging inside the headlamp due to moisture. The desiccant is consumable and its performance may change based on the used period or environment. If fogging inside the headlamp due to moisture continues for a long time, we recommend that you contact an

i Information

authorised Genesis repairer.

The headlamp and tail lamp lenses could appear to have condensation inside if the vehicle is washed after driving or if the vehicle is driven in wet weather. This condition is caused by a higher temperature inside the light and a cooler outside temperature. Moisture that condenses in the lamp evaporates after driving with the lamp on. If the moisture does not evaporate, we recommend that you contact an authorised Genesis repairer.

i Information

- A normally functioning lamp may flicker momentarily to stabilize the vehicle's electrical control system. If the lamp goes out, or continues to flicker, we recommend that you contact an authorised Genesis repairer.
- The parking lamp may not turn on when the parking lamp switch is turned on, but the parking lamp and headlamp switch may turn on when the headlamp switch is turned on. This may be caused by network failure or vehicle electrical control system malfunction. If this occurs, we recommend that you contact an authorised Genesis repairer.

i Information

Adjust the headlamps aim after an accident or the headlamp is replaced.

Headlamp, parking lamp, turn signal lamp, Daytime Running Lamp (DRL) replacement



- (1) Headlamp (Low)
- (2) Headlamp (High)
- (3) Headlamp (Low beam assist)
- (4) Daytime running lamp
- (5) Parking lamp
- (6) Turn signal lamp
- (7) Headlamp (Low beam assist)

If the LED lamp does not operate, we recommend that you contact an authorised Genesis repairer.

The LED lamps cannot be replaced as a single bulb. A skilled technician should check or repair the LED lamp, otherwise you may damage related parts of the vehicle.

Side repeater lamp replacement



If the LED lamp (1) does not operate, we recommend that you contact an authorised Genesis repairer.

The LED lamps cannot be replaced as a single bulb. A skilled technician should check or repair the LED lamp, otherwise you may damage related parts of the vehicle.

Puddle lamp replacement



If the LED lamp (1) does not operate, we recommend that you contact an authorised Genesis repairer.

The LED lamps cannot be replaced as a single bulb because it is an integrated unit. A skilled technician should check or repair the LED lamp, otherwise you may damage related parts of the vehicle.

Rear combination lamp replacement



- (1) Tail lamp/Stop lamp
- (2) Stop lamp
- (3) Turn signal lamp

If the LED lamp does not operate, we recommend that you contact an authorised Genesis repairer.

The LED lamps cannot be replaced as a single bulb because it is an integrated unit. A skilled technician should check or repair the LED lamp, otherwise you may damage related parts of the vehicle.

Reverse guide lamp replacement



If the LED lamp (1) does not operate, we recommend that you contact an authorised Genesis repairer.

The LED lamps cannot be replaced as a single bulb because it is an integrated unit. A skilled technician should check or repair the LED lamp, otherwise you may damage related parts of the vehicle.

High mounted stop lamp replacement



If the LED lamp (1) does not operate, we recommend that you contact an authorised Genesis repairer.

The LED lamps cannot be replaced as a single bulb because it is an integrated unit. A skilled technician should check or repair the LED lamp, otherwise you may damage related parts of the vehicle.

Licence plate lamp replacement



If the LED lamp (1) does not operate, we recommend that you contact an authorised Genesis repairer.

The LED lamps cannot be replaced as a single bulb because it is an integrated unit. A skilled technician should check or repair the LED lamp, otherwise you may damage related parts of the vehicle.

Interior light replacement

Front lamps



Rear lamps



Vanity mirror lamp



Glove box lamp



Inner door handle lamp (1) / Foot lamp (2) / Door courtesy lamp (Bulb type) (3)




Mood lamp



Boot lamp



Boot emergency lamp



If the LED lamp does not operate, we recommend that you contact an authorised Genesis repairer.

The LED lamps cannot be replaced as a single unit because it is an integrated unit. A skilled technician should check or repair the LED lamp, otherwise you may damage related parts of the vehicle.

Appearance care

Exterior care

NOTICE

If you park your vehicle near a stainless steel sign or glass facade building, the vehicle's exterior plastic parts such as a bumper, spoiler, garnish, lamp or outside rear-view mirrors might be damaged due to sunlight reflecting from the sign or building. To prevent damage of the exterior plastic parts, you should avoid parking in areas where light may be reflected or use a car cover. (The exterior plastic parts applied to your vehicle may vary.)

Exterior general caution

It is very important to follow the label directions when using any chemical cleaner or polish. Read all warning and caution statements that appear on the label.

Finish maintenance

Washing

To help protect your vehicle's finish from rust and deterioration, wash it thoroughly and frequently at least once a month with lukewarm or cold water.

If you use your vehicle for off-road driving, you should wash it after each off-road trip. Pay special attention to the removal of any accumulation of salt, dirt, mud, and other foreign materials. Make sure the drain holes in the lower edges of the doors and rocker panels are kept clear and clean.

Insects, tar, tree sap, bird droppings, industrial pollution, and similar deposits may damage your vehicle's finish if not removed immediately.

Even prompt washing with plain water may not completely remove all these deposits. Use a mild soap, safe for use on painted surfaces.

After washing, rinse the vehicle thoroughly with lukewarm or cold water. Do not allow soap to dry on the finish.

NOTICE

High pressure water may damage front and rear cameras, sensors, vehicle trim, and boots (rubber or plastic covers) or connectors.

A WARNING

After washing the vehicle, dry the brakes by applying them lightly whilst maintaining a slow forward speed.

NOTICE

- Do not use strong soap, chemical detergents, or hot water, and do not wash the vehicle in direct sunlight or when the body of the vehicle is warm.
- To prevent damage to the plastic parts, do not clean with chemical solvents or strong detergents.

NOTICE



- Water washing in the motor compartment including high pressure water washing may cause the failure of electrical circuits located in the motor compartment.
- Never allow water or other liquids to come in contact with electrical/electronic components inside the vehicle as water or other liquids may flow into the motor compartment through the front boot and damage electrical/electronic components.

i Information

Matte paint finish vehicle (if equipped)
To prevent damage the matte finish:

- Do not go through an automatic car wash with rotating brushes.
- Avoid using a steam cleaner. High temperature steam may leave stains that are difficult to remove.
- Use a soft cloth (e.g. microfiber towel or sponge) when washing your vehicle and dry with a microfiber towel. When you hand wash your vehicle, do not use a cleaner that finishes with wax. If the vehicle surface is too dirty (sand, dirt, dust, contaminant, etc.), clean the surface with water before washing the vehicle.

Waxing

A good coat of wax helps protect your paint from contaminants.

Wax the vehicle when water no longer beads on the paint.

Always wash and dry the vehicle before waxing. Use a good quality liquid or paste wax, and follow the manufacturer's instructions. Wax all metal trim to protect it and to maintain its luster.

Removing oil, tar, and similar materials with a spot remover usually strips the wax from the finish. Be sure to re-wax these areas even if the rest of the vehicle does not yet need waxing.

NOTICE

- Do not wipe dust or dirt off the body with a dry cloth to prevent scratching the finish.
- Do not use steel wool, abrasive cleaners, or strong detergents containing highly alkaline or caustic agents on chrome-plated or anodized aluminium parts to prevent discolouration or paint deterioration.

NOTICE

Matte paint finish vehicle (if equipped)

Do not use any polish protector such as detergent, abrasive, or polish. If wax is applied, remove the wax immediately using a silicone remover. If any tar or tar contaminant is on the surface, use a tar remover to clean. Be careful not to apply too much pressure on the painted area.

Finish damage repair

Deep scratches or stone chips on the painted surface must be repaired promptly. Exposed metal quickly rusts and may develop into a major repair expense.

i Information

If your vehicle is damaged and requires any metal repair or replacement, make sure the body shop applies anti-corrosion materials to the parts repaired or replaced.

NOTICE

Matte paint finish vehicle (if equipped)

It is impossible to only repaint the damaged area. The whole part must be repainted as necessary. If the vehicle is damaged and painting is required, we recommend that you contact an authorised Genesis repairer.

Bright-metal maintenance

- To remove road tar and insects, use a tar remover, not a scraper or other sharp object.
- To protect the surfaces of bright-metal parts from corrosion, apply a coating of wax or chrome preservative, and rub to a high luster.
- During winter weather or in coastal areas, cover the bright metal parts with a heavier coating of wax or preservative. If necessary, coat the parts with non-corrosive petroleum jelly or other protective compound.

Underbody maintenance

Corrosive materials used for ice and snow removal and dust control may collect on the underbody. If these materials are not removed, accelerated rusting may occur on underbody parts such as the frame and floor pan, even though they have been treated with rust protection.

Thoroughly flush the vehicle underbody and wheel openings with lukewarm or cold water once a month, after off-road driving and at the end of each winter. Pay special attention to these areas because it is difficult to see all the mud and dirt. It will do more harm than good to wet down the road grime without removing it. The lower edges of doors, rocker panels, and frame members have drain holes that must not be allowed to clog with dirt. Trapped water in these areas may cause rusting.

Aluminium wheel maintenance

The aluminium wheels are coated with a clear protective finish.

- Do not use abrasive cleaner, polishing compound, solvent, or wire brushes on aluminium wheels.
- Use only a mild soap or neutral detergent, and rinse thoroughly with water. Also, clean the wheels after driving on salted roads.
- Do not wash the wheels with high-speed car wash brushes.
- Do not use any cleaners containing acid or alkaline detergents.

Corrosion protection

Protecting your vehicle from corrosion

By using the most advanced design and construction practices to combat corrosion, Genesis vehicle produces vehicles of the highest quality. However, this is only part of the job. To achieve the long-term corrosion resistance your vehicle can deliver, the owner's cooperation and assistance are also required.

Common causes of corrosion

The most common causes of corrosion on your vehicle are:

- Road salt, dirt, and moisture that is allowed to accumulate underneath the vehicle.
- Removal of paint or protective coatings by stones, gravel, abrasion, minor scrapes, and dents that leave unprotected metal exposed to corrosion.

High-corrosion areas

If you live in an area where your vehicle is regularly exposed to corrosive materials, corrosion protection is particularly important. Some of the common causes of accelerated corrosion are road salts, dust control chemicals, ocean air, and industrial pollution.

Moisture breeds corrosion

Moisture creates the conditions in which corrosion is most likely to occur. For example, corrosion is accelerated by high humidity, particularly when temperatures are just above freezing. In such conditions, the corrosive material is kept in contact with the vehicle surfaces by moisture that is slow to evaporate.

Mud is particularly corrosive because it is slow to dry and holds moisture in contact with the vehicle. Although the mud appears to be dry, it can still retain moisture and promote corrosion.

High temperatures may also accelerate corrosion of parts that are not properly ventilated so the moisture can be dispersed. For all these reasons, it is particularly important to keep your vehicle clean and free of mud or accumulations of other materials. This applies not only to the visible surfaces but particularly to the underside of the vehicle.

To help prevent corrosion

Keep your vehicle clean

The best way to prevent corrosion is to keep your vehicle clean and free of corrosive materials. Attention to the underside of the vehicle is particularly important.

If you live in a high-corrosion area
where road salts are used, near the
ocean, areas with industrial pollution,
acid rain, and the like, take extra care to
prevent corrosion. In winter, hose off
the underside of your vehicle at least
once a month and be sure to clean the
underside thoroughly when winter is
over.

- When cleaning underneath the vehicle, pay particular attention to the components under the fenders and other areas that are hidden from view. Do a thorough job; just dampening the accumulated mud rather than washing it away may accelerate corrosion rather than prevent it. Water under high pressure and steam are particularly effective in removing accumulated mud and corrosive materials.
- When cleaning lower door panels, rocker panels, and frame members, make sure that drain holes are kept open so that moisture can escape and not be trapped inside to accelerate corrosion.

Keep your garage dry

Do not park your vehicle in a damp, poorly ventilated garage. This creates a favorable environment for corrosion. This is particularly true if you wash your vehicle in the garage or drive it into the garage when it is still wet or covered with snow, ice, or mud. Even a heated garage may contribute to corrosion unless it is well ventilated so moisture is dispersed.

Keep paint and trim in good condition

Scratches or chips in the finish must be covered with "touch-up" paint as soon as possible to reduce the possibility of corrosion. If bare metal is showing through, the attention of a qualified body and paint shop is recommended.

Bird droppings are highly corrosive and may damage painted surfaces in just a few hours. Always remove bird droppings as soon as possible.

Interior care

Interior general precautions

Prevent caustic solutions such as perfume and cosmetic oil, from contacting the interior parts because they may cause damage or discolouration. If they do contact the interior parts, wipe them off immediately. See the instructions for the proper way to clean vehicle interior surfaces.

NOTICE

- Never allow water or other liquids to come in contact with electrical/electronic components inside the vehicle as this may damage them.
- When cleaning leather products (steering wheel, seats etc.), use neutral detergents or low alcohol content solutions. If you use high alcohol content solutions or acid/alkaline detergents, the colour of the leather may fade or the surface may get stripped off.

Cleaning the upholstery and interior trim

Vehicle interior surfaces

tif equipped

Remove dust and loose dirt from interior surfaces with a whisk broom or a vacuum cleaner. If necessary, clean interior surfaces with a mixture of warm water and mild non-detergent cleaner (test all cleaners on a concealed area before use).

Fabric

+if equipped

Remove dust and loose dirt from fabric with a whisk broom or vacuum cleaner. Clean with a mild soap solution recommended for upholstery or carpets. Remove fresh spots immediately with a fabric spot cleaner. If you do not pay attention to fresh spots immediately, the fabric may be stained and its colour may be affected. Also, its fire-resistant properties may be reduced if the material is not properly maintained.

NOTICE

Using anything but recommended cleaners and procedures may affect the fabric's appearance and fire-resistant properties.

Leather

tif equipped

- · Features of seat leather
 - Leather is made from the outer skin of an animal, which goes through a special process to be available for use. Because it is a natural product, each part differs in thickness or density.

Wrinkles may appear as a natural result of stretching and shrinking depending on the temperature and humidity.

- The seat is made of stretchable fabric to improve comfort.
- The parts contacting the body are curved and the side supporting area is high that provides driving comfort and stability.
- Wrinkles may appear naturally from usage. It is not a fault of the products.

NOTICE

- Wrinkles or abrasions that appear naturally from usage are not covered by warranty.
- Belts with metallic accessories, zippers, or keys inside the back pocket may damage the seat fabric.
- Be sure not to wet the seat. It may change the nature of natural leather.
- Jeans or clothes that could bleed may contaminate the surface of the seat covering fabric.

- · Caring for the leather seats
 - Vacuum the seat periodically to remove dust and sand on the seat. It prevents abrasion or damage of the leather and maintain its quality.
 - Wipe the natural leather seat cover often with dry or soft cloth.
 - Use of proper leather protector may prevent abrasion of the cover and helps maintain the colour. Be sure to read the instructions and consult a specialist when using leather coating or protective agent.
 - Light coloured (beige, cream beige) leather may be easily contaminated and the stains may be noticeable.
 - Avoid wiping with a wet cloth. It may cause the surface to crack.
- · Cleaning the leather seats
 - Remove all spills instantly.
 - For cosmetic products (sunscreen, foundation, etc.)

Apply cleansing cream on a cloth and wipe the contaminated spot. Wipe off the cream with a damp cloth and then wipe with a dry cloth.

For beverages (coffee, soft drink, etc.)

Apply a small amount of neutral detergent and wipe until it does not smear.

- For oil

Remove oil instantly with an absorbable cloth and wipe with stain remover used only for natural leather.

For chewing gum
 Harden the gum with ice and remove it gradually.

Handling prime napa leather (if equipped)

Try to avoid excessive sunlight and heat exposure. Excessive sunlight and heat exposure naturally fades and dries out napa leather, causing wrinkles and discolouration. If the napa leather is wet with liquid, immediately clean it with lint-free cloth to minimise damage. Do not scratch the napa leather surface with a sharp object. If your napa leather seat is bright coloured, it may be contaminated or stained from dyed materials such as jeans.

Interior wooden trim

- Use a wooden furniture protector (e.g. wax, coating compound) to clean the interior wooden trim.
- Sharp objects (e.g. driver, knife), adhesive materials, or tapes may damage the interior wooden trim.
- Any strong impacts may damage the interior wooden trim.
- If the coating finish over the interior wooden trim is removed, moisture may damage or change wood traits.
- If the interior wooden trim is damaged, you may get a splinter from the wood surface. We recommend that the damaged interior wooden trim be replaced by an authorised Genesis repairer.
- Forged wood is an eco-friendly wooden trim made from recycled wood chips.
 Due to these material characteristics, the grain direction is not constant and small dots or natural cracks may occur.
 These are natural appearance characteristics of real wood from the manufacturing method and are not appearance defects.

Cleaning the seat belt webbing

Clean the belt webbing with any mild soap solution recommended for cleaning upholstery or carpet. Follow the instructions provided with the soap.

⚠ WARNING

Do not bleach or re-dye the webbing because this may weaken the seat belt.

Cleaning the interior window glass

If the interior glass surfaces need to be cleaned, use a glass cleaner. Follow the directions on the glass cleaner container.

NOTICE

Do not scrape or scratch the inside of the rear window. This may result in damage to the rear window defroster grid.

Index

A	
About "Getting started with your electric vehicle"	1-6
Accessing your vehicle	
Immobiliser system	
Smart key	5-6
Active bonnet lift system	3-61
System activation	
System limitation	3-62
System malfunction	3-63
Active sound design	6-46
Advanced Rear Occupant Alert (ROA)	5-25
Advanced Rear Occupant Alert precautions	5-26
Declaration of Conformity	5-26
System operation	5-25
System setting	5-25
Air conditioner compressor label	2-14
Air conditioning system	2-12
All Wheel Drive (AWD)	6-37
Emergency precautions	6-39
Appearance care	9-55
Exterior care	9-55
Interior care	9-59
Australian Design Rules	1-3
Automatic climate control system	5-73
Automatic heating and air conditioning	
Manual heating and air conditioning	5-76
System maintenance	5-86
System operation	5-85
Aux. Battery Saver+	1-46
_	
В	
Battery (12 V)	9-19
Battery capacity label	9-21
Battery recharging	9-21
Battery replacement	9-21
For best battery service	9-20
Reset items	9-22
Before driving	6-3
Before entering the vehicle	
Before starting	
Before Using Driver Assistance System	
Driver Assistance System sensors	
Blind-Spot Collision-Avoidance Assist (BCA)	
Blind-Spot Collision-Avoidance Assist malfunction and limitations	
Blind-Spot Collision-Avoidance Assist operation	
Blind-Spot Collision-Avoidance Assist settings	
Blind-Spot View Monitor (BVM)	7-69
Blind-Spot View Monitor malfunction	7-70

Blind-Spot View Monitor operation7-70

Blind-Spot View Monitor settings	7-70
Bonnet	
Closing the bonnet	5-41
Opening the bonnet	5-41
Brake fluid	9-14
Checking the brake fluid level	9-14
Braking system	
Anti-lock Brake System (ABS)	6-29
Auto Hold	6-27
Brake Assistant System (BAS)	6-36
Brake Disc Cleaning	
Disc brakes wear indicator	
Electronic Parking Brake (EPB)	
Electronic Stability Control (ESC)	
Emergency Stop Signal (ESS)	
Good braking practices	
High performance brakes	
Hill-Start Assist Control (HAC)	
Multi-Collision Brake (MCB)	
Power-assist brakes	
Vehicle Stability Management (VSM)	
Bulb wattage	
Sub natage	
C	
Out to the first	0.40
Cabin air filter	
Filter inspection	
Filter replacement	
Centre console overview	
Charging your electric vehicle	
Checking basic information on charging your electric vehicle	
Safety precautions for charging your electric vehicle	
Stopping charging immediately	
Using a DC charger	
Using a portable charger (ICCB)	
Using an AC charger	
Child Restraint System (CRS)	
Installing a Child Restraint System	
Our recommendation: Children always in the rear	
Selecting a Child Restraint System	
Climate control additional features	
Air conditioning auto-drying	
Auto defogging system	
Auto dehumidify	
Automatic controls linked to climate control settings (for driver's seat)	
Rear climate auto Off	
Recirculating air when entering a tunnel	
Recirculating air when washer fluid is used	
Convenience features	
Coolant	9-12
Changing coolant	0-14

Checking the coolant level9-12
Countermeasures for accidents or fire1-57
If the electric vehicle catches fire1-57
If the electric vehicle is submerged1-57
If the electric vehicle needs towing1-58
Other precautions for electric vehicle accidents1-58
D
Declaration of conformity7-158
Front corner radar/Rear corner radar7-158
Front radar
Dimensions
Door locks
Automatic door lock and unlock features5-21
Electronic child safety lock
Operating door locks from inside the vehicle5-16
Operating door locks from outside the vehicle5-15
Rear seat easy door close5-19
Drive mode integrated control system 6-42
Drive mode
Driver assistance system
Driver Attention Warning (DAW)7-61
Driver Attention Warning malfunction and limitations
Driver Attention Warning operation7-61
Driver Attention Warning settings
Driving your electric vehicle1-47
Checking electric vehicle driving information1-48
Starting and stopping the vehicle1-47
Driving your vehicle
29 /
E
Electric charging door5-51
Opening the electric charging door5-51
Electric vehicle specifications
Electronic control suspension6-40
System malfunction6-40
Electronically controlled suspension with road preview6-41
Limitations of the system6-42
System malfunction6-41
Emergency situations8-1
Explanation of scheduled maintenance items9-11
Air conditioning refrigerant9-11
Brake discs, pads, calipers, and rotors9-11
Brake fluid9-11
Brake hoses and lines9-11
Coolant
Cooling system9-11
Drive shafts and boots9-11
Reduction gear fluid9-11

Steering gear box, linkage & boots/lower arm ball joint	Q ₋ 11
Suspension mounting bolts	0-11 0-11
Exterior lights	
Battery saver function	
Headlamps delay function	
Headlamps levelling device	
Headlamps moisture removal function	
High beam operation	
Lighting control	
Reversing guide lamp	
Turn signals and lane change signals	
Exterior overview (Front view)	
Exterior overview (Rear view)	
Exterior overview (Rear view)	2-3
F	
Fire any sint and and and and any and any	F 10
Fingerprint authentication system	
Fingerprint authentication system operation	
Fingerprint authentication system settings	
Limitations of the system	
When purchasing a used vehicle	
Foreword: Electric vehicle system overview	
Forward Attention Warning (FAW)	
Forward Attention Warning malfunction and limitations	
Forward Attention Warning operation	
Forward Attention Warning settings	
Forward Collision-Avoidance Assist (FCA)	
Forward Collision-Avoidance Assist malfunction and limitations	
Forward Collision-Avoidance Assist operation	
Forward Collision-Avoidance Assist settings	
Forward/Side/Reverse Parking Collision-Avoidance Assist (PCA)	
Parking Collision-Avoidance Assist malfunction and limitations	
Parking Collision-Avoidance Assist operation	
Parking Collision-Avoidance Assist settings	
Fuses	9-30
Fuse/relay panel description	9-33
Instrument panel fuse replacement	9-31
Motor compartment panel fuse replacement	9-32
Н	
•	
Hazard warning flasher	
Head-Up Display (HUD)	
Head-up display information	
Head-up display settings	
Precautions whilst using the head-up display	
High Beam Assist (HBA)	
High Beam Assist malfunction and limitations	
High Beam Assist operation	
High Beam Assist setting	
Highway Driving Assist (HDA)	7.04

Highway Driving Assist malfunction and limitations	7-102
Highway Driving Assist operation	
Highway Driving Assist settings	
Highway Lane Change Assist	
Hyundai Motor Company	1-3
I	
If the vehicle does not start	0.2
If you have a flat tyre (with tyre mobility kit)	
Components of the Tyre Mobility Kit	
How to adjust tyre pressure	
Introduction	
Notes on the safe use of the Tyre Mobility Kit	
Using the Tyre Mobility Kit When a tyre is flat	
Important safety precautions	
Airbag hazards	
Always wear your seat belt	
Control your speed	
Driver distraction	
Keep your vehicle in safe condition	
Never drink or take drugs and drive	
Restrain all children	
In case of an emergency whilst driving	
If the vehicle stalls at a crossroads or crossing	
If the vehicle stalls whilst driving	
If you have a flat tyre whilst driving	
Infotainment system	
Antenna	
BANG & OLUFSEN sound system	
Bluetooth® Wireless Technology	
Infotainment system	
Steering wheel remote controls	
USB Port	
Voice recognition	
Instrument cluster	
Gauges and meters	,
Instrument cluster control	4-3
Instrument cluster display messages	4-20
Warning and indicator lights	
Instrument cluster display	
Instrument cluster display control	4-24
View modes	
Integrated memory system	5-27
Recalling memory positions	5-27
Resetting the system	
Seat easy access	5-28
Storing memory positions	5-27
Intelligent Front-lighting System (IFS)	5-60
System malfunction and limitations	5-61
	F 00

System settings	5-60
Intelligent Speed Limit Assist (ISLA)	
Intelligent Speed Limit Assist malfunction and limitations	7-58
Intelligent Speed Limit Assist operation	7-57
Intelligent Speed Limit Assist settings	7-56
Interior features	5-95
Armrest warmer (front)	5-96
Clock	5-102
Coat hook	5-102
Cup holder	5-95
Floor mat anchors	5-103
Luggage net holder	5-105
Power outlet	5-99
Rear mirror	
Rear side window sunshades	5-103
Sunvisor	5-98
USB charger	5-99
UV-C sterilizer system	5-96
Wireless smartphone charging system	5-100
Interior lamps	5-67
Boot emergency lamp	5-70
Door handle lamp/Foot lamp/Door courtesy lamp	5-69
Front lamps	5-67
Glove box lamp	5-68
Interior lamp AUTO cut	5-67
Interior lights always on	5-69
Luggage compartment lamp	5-70
Mood lamp	5-69
Puddle light	5-70
Rear interior lamp	5-68
Rear mirror lamp	5-68
Vanity mirror lamp	5-68
Interior overview	2-4
Introduction	1-3
J	
Jump starting (12 V Battery)	8-4
L	
Lane Following Assist (LFA)	7.00
Lane Following Assist Malfunction and limitations	
Lane Following Assist manufaction and infinations	
Lane Following Assist operation Lane Following Assist settings	
Lane Keeping Assist (LKA)	
Lane Keeping Assist (LKA) Lane Keeping Assist malfunction and limitations	
Lane Keeping Assist manunction and limitations Lane Keeping Assist operation	
Lane Keeping Assist operation	
Light bulbs	
Headlamp, parking lamp, turn signal lamp, Daytime Running Lamp (DRI) re	

High mounted stop lamp replacement 9-53 Interior light replacement 9-53 Licence plate lamp replacement 9-53 Puddle lamp replacement 9-52 Rear combination lamp replacement 9-52 Reverse guide lamp replacement 9-52 Side repeater lamp replacement 9-52
M
Maintenance 9-1 Maintenance services 9-4 Owner maintenance precautions 9-4 Owner's responsibility 9-4 Manual Speed Limit Assist (MSLA) 7-53 Manual Speed Limit Assist operation 7-53 Mirrors 5-34 Inside rear-view mirror 5-34 Outside rear-view mirrors 5-34 Reverse parking aid 5-36 Motor compartment overview 2-8, 9-3 Motor number 2-14
N
Navigation-based Smart Cruise Control (NSCC) 7-85 Limitations of Navigation-based Smart Cruise Control 7-88 Navigation-based Smart Cruise Control operation 7-86 Navigation-based Smart Cruise Control settings 7-86 Non-Powered Boot 5-42 Closing the boot 5-42 Emergency boot safety release 5-43 Opening the boot 5-42
0
Open Source Software Notice2-15OTA software update5-54Approving software update5-54Downloading software5-54Preparing software update5-54Updating software5-55Owner maintenance9-5Owner maintenance schedule9-5
P
Parking Distance Warning (PDW) 7-121 Parking Distance Warning malfunction and limitations 7-125 Parking Distance Warning operation 7-122 Parking Distance Warning settings 7-121 Power boot 5-44 Emergency boot safety release 5-48

Operating the power boot	
Power boot operating conditions	
Resetting the power boot	
Setting the power boot	5-47
R	
Rear Cross-Traffic Collision-Avoidance Assist (RCCA)	7-113
Rear Cross-Traffic Collision-Avoidance Assist malfunction and limitations	
Rear Cross-Traffic Collision-Avoidance Assist operation	
Rear Cross-Traffic Collision-Avoidance Assist settings	
Rear Occupant Alert (ROA)	
System operation	
System setting	
Rear View Monitor (RVM)	7-104
Rear View Monitor malfunction and limitations	
Rear View Monitor operation	
Rear View Monitor settings	
Recommended lubricants and capacities	
Recuperative braking system	
One Pedal Driving	
Recuperative braking system limitations	
Using i-PEDAL	
Using recuperative braking system	
Reduction gear	
Good driving practices	
Instrument cluster display messages	
Refrigerant label	
Remote Smart Parking Assist 2 (RSPA 2)	
Remote Smart Parking Assist malfunction and limitations	
Remote Smart Parking Assist manufaction and inmediations	
Remote Smart Parking Assist settings	
Remote start	
Road active noise control	
System malfunction	
\$	
Safe Exit Assist (SEA)	
Safe Exit Assist malfunction and limitations	
Safe Exit Assist operation	
Safe Exit Assist settings	
Safety messages	
Safety system	
Scheduled maintenance services	
Maintenance under severe usage conditions	
Seat belts	
Additional seat belt safety precautions	
Care of seat belts	
	33

Pre-Active Seat Belt (PSB)	3-36
Seat belt restraint system	
Seat belt safety precautions	
Seat belt warning light	
Seats	
Air ventilation seats	
Front seats	
Headrest	
Rear seats	
Safety precautions	
Seat warmers	
Smart boot	
Deactivating smart boot	
Detecting area	
Using smart boot	
Smart Cruise Control (SCC)	
Smart Cruise Control malfunction and limitations	
Smart Cruise Control manufaction and infinitations	
Smart Cruise Control operation	
Smart recuperation system	
Front sensors (Front radar)	
Pausing smart recuperation system	
Smart recuperation level settings	
Smart recuperation system on/off	
Smart recuperation system operating condition	
Smart recuperation system precautions	
System malfunction due to sensor problems	6 20
Special driving conditions	
Driving at night	
Driving in flooded areas	
Driving in the rain	
Hazardous driving conditions	
-	
Highway driving Rocking the vehicle	
9	
Smooth cornering	
Start/Stop button	
Start/Stop button positions	
Turning off the vehicle	
Steering wheel	
Haptic warning / Steering wheel wibration warning	5-33
•	
Horn	
Motor Driven Power Steering (MDPS)	
Rear Wheel Steering (RWS)	
Steering wheel grip sensor	
Tilt / Telescopic steering	5-31
Steering wheel controls overview	
Storage compartment	
Centre console storage	5-93

Glove box	5-94
Rear console storage	5-94
Sunglasses holder	
Supplemental restraint system - airbags	
Additional safety precautions	
Airbag warning labels	
Do not install a Child Restraint System on the front passenger seat	3-56
How does the airbags system operate?	3-53
SRS care	
SRS components	
SRS warning light	
What to expect after an airbag inflates	
Where are the airbags?	
Why didn't my airbag go off in a collision?	
Surround View Monitor (SVM)	
Surround View Monitor malfunction and limitations	
Surround View Monitor operation	
Surround View Monitor settings	7-107
Т	
Theft alarm system	5-23
Towing	
Removable towing hook	
Towing service	
Trailer towing	
Tyre Pressure Monitoring System (TPMS)	
Changing a tyre with TPMS	
Check tyre pressure	
Check tyle pressure	0-/
Low tyre pressure position and tyre pressure telltale	
Low tyre pressure position and tyre pressure telltale	8-9
, ,	8-9 8-10
Low tyre pressure position and tyre pressure telltale	8-9 8-10 8-8
Low tyre pressure position and tyre pressure telltale	8-9 8-10 8-8 2-13
Low tyre pressure position and tyre pressure telltale	8-9 8-10 8-8 2-13 2-11, 9-23
Low tyre pressure position and tyre pressure telltale	8-9 8-10 8-8 2-13 2-11, 9-23 9-24
Low tyre pressure position and tyre pressure telltale	8-98-82-132-11, 9-239-249-29
Low tyre pressure position and tyre pressure telltale	8-98-82-132-11, 9-239-249-29
Low tyre pressure position and tyre pressure telltale	8-98-82-132-11, 9-239-249-299-299-29
Low tyre pressure position and tyre pressure telltale	8-98-82-132-11, 9-239-249-299-299-299-23
Low tyre pressure position and tyre pressure telltale	
Low tyre pressure position and tyre pressure telltale	
Low tyre pressure position and tyre pressure telltale	
Low tyre pressure position and tyre pressure telltale TPMS (Tyre Pressure Monitoring System) malfunction indicator Tyre pressure monitoring system Tyre specification and pressure label Tyres and wheels Check tyre inflation pressure Low aspect ratio tyres Recommended cold tyre inflation pressures Summer tyres Tyre care Tyre maintenance Tyre replacement Tyre rotation Tyre sidewall labelling Tyre traction	
Low tyre pressure position and tyre pressure telltale TPMS (Tyre Pressure Monitoring System) malfunction indicator Tyre pressure monitoring system Tyre specification and pressure label Tyres and wheels Check tyre inflation pressure Low aspect ratio tyres Recommended cold tyre inflation pressures Summer tyres Tyre care Tyre maintenance Tyre rotation Tyre rotation Tyre sidewall labelling Tyre traction Wheel alignment and tyre balance	
Low tyre pressure position and tyre pressure telltale TPMS (Tyre Pressure Monitoring System) malfunction indicator Tyre pressure monitoring system Tyre specification and pressure label Tyres and wheels Check tyre inflation pressure Low aspect ratio tyres Recommended cold tyre inflation pressures Summer tyres Tyre care Tyre maintenance Tyre replacement Tyre rotation Tyre sidewall labelling Tyre traction	
Low tyre pressure position and tyre pressure telltale TPMS (Tyre Pressure Monitoring System) malfunction indicator Tyre pressure monitoring system Tyre specification and pressure label Tyres and wheels Check tyre inflation pressure Low aspect ratio tyres Recommended cold tyre inflation pressures Summer tyres Tyre care Tyre maintenance Tyre rotation Tyre rotation Tyre sidewall labelling Tyre traction Wheel alignment and tyre balance	
Low tyre pressure position and tyre pressure telltale TPMS (Tyre Pressure Monitoring System) malfunction indicator Tyre pressure monitoring system Tyre specification and pressure label Tyres and wheels Check tyre inflation pressure Low aspect ratio tyres Recommended cold tyre inflation pressures Summer tyres Tyre care Tyre maintenance Tyre replacement Tyre rotation Tyre sidewall labelling Tyre traction Wheel alignment and tyre balance Wheel replacement	

Other precautions for electric vehicle management	
Precautions when using the high voltage battery	
Using Electric Vehicle functions	1-30
Checking energy information	
Checking the Electric Vehicle screen configuration	
Setting a battery discharging limit when using Vehicle to Load (V2L)	1-37
Setting electric vehicle specialised functions	1-38
Setting the next departure time	1-33
Setting the options for the AC charger	
Setting the target battery charge level	1-36
Using V2L function	1-42
Safety precautions when using the V2L function	1-42
Solving V2L problems	1-45
Using electricity outside the vehicle	
,	
V	
Vehicle certification label	2_13
Vehicle Identification Number (VIN)	
Vehicle information	
Vehicle modifications	
Vehicle settings (infotainment system)	
Setting your vehicle	
Vehicle weight	
Overloading	
Vehicle weight and luggage volume	
venicle weight and luggage volume	2-12
W	
VV	
	9-16
Washer fluid	
Washer fluid	9-16
Washer fluid	9-16 5-66
Washer fluid Checking the washer fluid level Welcome system Dynamic welcome light	9-16 5-66 5-66
Washer fluid	9-16 5-66 5-66
Washer fluid	9-16 5-66 5-66 5-66
Washer fluid Checking the washer fluid level Welcome system Dynamic welcome light Interior lamp Puddle lamp and door handle lamp Windows	
Washer fluid Checking the washer fluid level Welcome system Dynamic welcome light Interior lamp Puddle lamp and door handle lamp Windows Power windows	9-16 5-66 5-66 5-66 5-38
Washer fluid Checking the washer fluid level Welcome system Dynamic welcome light Interior lamp Puddle lamp and door handle lamp Windows Power windows Remote window opening/closing feature (Remote Window Control)	
Washer fluid Checking the washer fluid level Welcome system Dynamic welcome light Interior lamp Puddle lamp and door handle lamp Windows Power windows Remote window opening/closing feature (Remote Window Control) Windscreen defrosting and defogging	
Washer fluid Checking the washer fluid level Welcome system Dynamic welcome light Interior lamp Puddle lamp and door handle lamp Windows Power windows Remote window opening/closing feature (Remote Window Control) Windscreen defrosting and defogging Rear window defroster	
Washer fluid Checking the washer fluid level Welcome system Dynamic welcome light Interior lamp Puddle lamp and door handle lamp Windows Power windows Remote window opening/closing feature (Remote Window Control) Windscreen defrosting and defogging Rear window defroster To defog inside windscreen	
Washer fluid Checking the washer fluid level Welcome system Dynamic welcome light Interior lamp Puddle lamp and door handle lamp Windows Power windows Remote window opening/closing feature (Remote Window Control) Windscreen defrosting and defogging Rear window defroster To defog inside windscreen To defrost outside windscreen	
Washer fluid	
Washer fluid Checking the washer fluid level Welcome system Dynamic welcome light Interior lamp Puddle lamp and door handle lamp Windows Power windows Remote window opening/closing feature (Remote Window Control) Windscreen defrosting and defogging Rear window defroster To defog inside windscreen To defrost outside windscreen Winter driving Snow or icy conditions	
Washer fluid Checking the washer fluid level Welcome system Dynamic welcome light Interior lamp Puddle lamp and door handle lamp Windows Power windows Remote window opening/closing feature (Remote Window Control) Windscreen defrosting and defogging Rear window defroster To defog inside windscreen To defrost outside windscreen Winter driving Snow or icy conditions Winter precautions	
Washer fluid	
Washer fluid	
Washer fluid Checking the washer fluid level Welcome system Dynamic welcome light Interior lamp Puddle lamp and door handle lamp Windows Power windows Remote window opening/closing feature (Remote Window Control) Windscreen defrosting and defogging Rear window defroster To defog inside windscreen To defost outside windscreen Winter driving Snow or icy conditions Winter precautions Wiper blades Blade inspection Blade replacement	
Washer fluid	